



Cisco D9854 Advanced Program  
Receiver Software Version 3.96  
Installation and Configuration Guide

**Please Read This Entire Guide**

**Veillez lire entièrement ce guide**

**Bitte das gesamte Handbuch durchlesen**

**Sírvase leer completamente la presente guía**

**Si prega di leggere completamente questa guida**

**Important**

Please read this entire guide before you install or operate this product. Give particular attention to all safety statements.

**Important**

Veillez lire entièrement ce guide avant d'installer ou d'utiliser ce produit. Prêtez une attention particulière à toutes les règles de sécurité.

**Zu beachten**

Bitte lesen Sie vor Aufstellen oder Inbetriebnahme des Gerätes dieses Handbuch in seiner Gesamtheit durch. Achten Sie dabei besonders auf die Sicherheitshinweise.

**Importante**

Sírvase leer la presente guía antes de instalar o emplear este producto. Preste especial atención a todos los avisos de seguridad.

**Importante**

Prima di installare o usare questo prodotto si prega di leggere completamente questa guida, facendo particolare attenzione a tutte le dichiarazioni di sicurezza.

# Notices

## Trademark Acknowledgments

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks).

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

The DVB logo is a registered trademark of the DVB Project.

Other third party trademarks mentioned are the property of their respective owners.

The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

## Publication Disclaimer

Cisco Systems, Inc. assumes no responsibility for errors or omissions that may appear in this publication. We reserve the right to change this publication at any time without notice. This document is not to be construed as conferring by implication, estoppel, or otherwise any license or right under any copyright or patent, whether or not the use of any information in this document employs an invention claimed in any existing or later issued patent.

## Copyright

© 2008-2012 Cisco and/or its affiliates. All rights reserved. Printed in the United States of America.

Information in this publication is subject to change without notice. No part of this publication may be reproduced or transmitted in any form, by photocopy, microfilm, xerography, or any other means, or incorporated into any information retrieval system, electronic or mechanical, for any purpose, without the express permission of Cisco Systems, Inc.



## **AVC/MPEG-4/H.264 Products**

With respect to each AVC/MPEG-4/H.264 product, Cisco is obligated to provide the following notice:

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com).

Accordingly, please be advised that service providers, content providers and broadcasters are required to obtain a separate use license from MPEG LA prior to any use of AVC/MPEG-4/H.264 encoders and/or decoders.

## Safety Precautions

|  |   |  |
|--|---|--|
| This symbol alerts you to the presence of uninsulated dangerous voltage inside the product enclosure that poses a risk of electric shock.  |  <div style="border: 1px solid black; padding: 5px; margin: 5px auto; width: 80%; text-align: center;"> <b>CAUTION</b><br/>                     RISK OF ELECTRIC SHOCK<br/>                     DO NOT OPEN                 </div>  | This symbol alerts you to important operating and maintenance (servicing) instructions included with this product. |
| <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p style="text-align: center;"><b>CAUTION</b></p> <p style="text-align: center; font-size: 9px;">TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVERS FROM THIS UNIT. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL. SEE ADDITIONAL SAFETY INSTRUCTIONS BELOW.</p> </div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p style="text-align: center;"><b>WARNING</b></p> <p style="text-align: center; font-size: 9px;">TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.</p> </div> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;"><b>CAUTION</b></p> <p style="text-align: center; font-size: 9px;">THIS EQUIPMENT MAY HAVE UP TO TWO POWER SUPPLY CORDS. TO REDUCE THE RISK OF ELECTRIC SHOCK, TWO POWER SUPPLY CORDS MAY HAVE TO BE DISCONNECTED BEFORE SERVICING.</p> </div> |   |  |

- 1 Read Instructions – All the safety and operating instructions should be read before the product is operated.
- 2 Retain Instructions – The safety and operating instructions should be retained for future reference.
- 3 Heed Warnings – All warnings on the product and in the operating instructions should be adhered to.
- 4 Follow Instructions – All operating and use instructions should be followed.
- 5 Cleaning – Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Exception: A product that is meant for uninterrupted service and that, for some specific reason, such as the possibility of the loss of an authorization code for a CATV converter, is not intended to be unplugged by the user for cleaning or any other purpose, may exclude the reference to unplugging the product in the cleaning description above.

- 6 Attachments – Do not use attachments not recommended by the product manufacturer as they may cause hazards.
- 7 Water and Moisture – Do not use this product near water – for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.

Accessories – Do not place this product on an unstable cart, stand, tripod, bracket, or table.

The product may fall, causing serious injury to a child or adult, and serious damage to the product.

## Safety Precautions

Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.


- 8 A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.

### PORTABLE CART WARNING



- 9 Ventilation – Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
- 10 Power Sources – This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.
- 11 Grounding or Polarization – This product may be equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug. Alternate Warnings – This product is equipped with a three-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding-type plug.
- 12 Power-Cord Protection – Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

- 13 Protective Attachment Plug - The product is equipped with an attachment plug having overload protection. This is a safety feature. See Instruction Manual for replacement or resetting of protective device. If replacement of the plug is required, be sure the service technician has used a replacement plug specified by the manufacturer that has the same overload protection as the original plug.
- 14 Outdoor Antenna Grounding - If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.



TO CATV SYSTEM INSTALLER  
This reminder is provided to call the CATV system installer's attention to Article 820-40 of the National Electrical Code (NEC) that provides guidelines for proper grounding, and in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of entry as practical.

- 15 Lightning - For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
- 16 Power Lines - An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
- 17 Overloading - Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
- 18 Object and Liquid Entry - Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

## Safety Precautions

- 19 Servicing – Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
- 20 Damage Requiring Service – Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
  - a When the power-supply cord or plug is damaged,
  - b If liquid has been spilled, or objects have fallen into the product,
  - c If the product has been exposed to rain or water,
  - d If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation,
  - e If the product has been dropped or damaged in any way, and
  - f When the product exhibits a distinct change in performance – this indicates a need for service.
- 21 Replacement Parts – When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
- 22 Safety Check – Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
- 23 Wall or Ceiling Mounting – The product should be mounted to a wall or ceiling only as recommended by the manufacturer.
- 24 Heat – The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

Protect yourself from electric shock and your system from damage!

- This product complies with international safety and design standards. Observe all safety procedures that appear throughout this guide, and the safety symbols that are affixed to this product.
- If circumstances impair the safe operation of this product, stop operation and secure this product against further operation.


Avoid personal injury and product damage! Do not proceed beyond any symbol until you fully understand the indicated conditions!




**You will find this symbol on the product and/or in the literature that accompanies this product.**

**It indicates important operating or maintenance instructions.**




 You may find this symbol on the product and/or in the literature that accompanies this product.

It indicates a live terminal; the symbol pointing to the terminal device.

 You may find this symbol on the product and/or in the literature that accompanies this product.

It indicates a protective earth terminal.

 You may find this symbol on the product and/or in the literature that accompanies this product.

It indicates excessive or dangerous heat.

### Power

- Important! This is a Class I product. You must earth this product. This equipment may have up to two power supply cords. To reduce the risk of electric shock, two power supply cords may have to be disconnected before servicing.
- This product plugs into a socket-outlet. The socket-outlet must be near this product, and must be easily accessible.
- Connect this product only to the power source that is indicated on the rear panel of this product.
- If this product does not have a mains power switch, the power cord serves this purpose

### Enclosure

- Do not allow moisture to enter this product.
- Do not open the enclosure of this product unless otherwise specified.
- Do not push objects through openings in the enclosure of this product.

### Cables

- Always disconnect all power cables before servicing this product.
- Always pull on the plug or the connector to disconnect a cable. Never pull on the cable itself.
- Do not walk on or place stress on cables or plugs.

### Factory service

- Refer service only to service personnel who are authorized by the factory.

## Règles de sécurité


Protégez-vous des risques d'électrocution et protégez votre système contre les endommagements éventuels.


Ce produit respecte les standards internationaux de sécurité et de conception. Veuillez observer toutes les procédures de sécurité qui apparaissent dans ce guide, ainsi que les symboles de sécurité qui figurent sur le produit.


Si, du fait des circonstances, ce produit cesse de fonctionner normalement, cessez de l'utiliser et empêchez-en l'utilisation future.

Évitez le risque de blessures et de dommages aux produits! Ne procédez à aucune tâche tant que vous n'aurez pas entièrement assimilé les conditions indiquées par un symbole!

 Ce symbole figure dans la documentation accompagnant ce produit. Il indique d'importantes instructions de fonctionnement ou d'entretien.

 Ce symbole peut être attaché à ce produit. Il indique une borne sous tension; la direction indique la borne.

 Ce symbole peut être attaché à ce produit. Il indique une borne de terre de protection.

 Ce symbole peut être attaché à ce produit. Il indique une température excessive ou dangereuse.

### Alimentation

- Important! Ce produit fait partie de la classe I. Vous devez le mettre à la terre.
- Ce produit se branche dans une prise murale. Cette dernière doit être placée à proximité du produit et doit être facilement accessible.
- Ne branchez ce produit qu'à la source d'alimentation indiquée sur son panneau arrière.
- Si ce produit n'a pas d'interrupteur d'alimentation générale, le cordon d'alimentation remplit ce rôle.

### Enceinte

- Ne laissez pas l'humidité pénétrer dans ce produit.
- N'ouvrez pas l'enceinte de ce produit, sauf instructions contraires.
- Ne forcez pas d'objets dans les ouvertures du boîtier.

### Câbles

- Débranchez toujours tous les cordons d'alimentation avant de réparer ce produit.
- Tirez toujours sur la prise ou le connecteur pour débrancher un câble. Ne tirez jamais directement sur le câble.

- Ne marchez pas sur les câbles ou les prises et n'y exercez aucune pression.

#### Réparations effectuées à l'usine





- Ne confiez les travaux de réparations qu'au personnel autorisé par l'usine.

## Sicherheitsvorkehrungen

Schützen Sie sich gegen elektrischen Schlag, und Ihr Gerät gegen Beschädigung!

- Dieses Gerät entspricht internationalen Sicherheits- und Ausführungsnormen. Beachten Sie alle in diesem Handbuch enthaltenen Sicherheitshinweise sowie die am Gerät angebrachten Warnzeichen.
- Sollten örtliche Umstände den sicheren Betrieb dieses Gerätes beeinträchtigen, schalten Sie es ab und sichern es gegen weitere Benutzung.

Vermeiden Sie Verletzungen sowie Beschädigung des Gerätes! Wenn Sie zu einem der folgenden Warnzeichen gelangen, nicht weiterarbeiten, bis Sie seine Bedeutung voll verstanden haben!

-  **Dieses Symbol erscheint auf dem Gerät und/oder in der ihm beiliegenden Literatur. Es bedeutet wichtige, zu beachtende Betriebs- oder Wartungsanweisungen.**
-  **Wenn dieses Zeichen am Gerät angebracht ist, warnt es vor einer spannungsführenden Stelle.**
-  **Dieses Symbol kennzeichnet auf dem Gerät die Anschlußstelle der Sicherheitserde.**
-  **Wenn dieses Zeichen am Gerät angebracht ist, warnt es vor heißen Stellen, die zu Verbrennungen führen können.**

#### Netzspannung

- Wichtig! Dieses Gerät ist ein Produkt der Schutzklasse I. Es muß geerdet werden.
- Das Gerät ist an einer Steckdose anzuschließen. Diese muß sich leicht zugänglich in unmittelbarer Nähe des Gerätes befinden.
- Die Netzversorgung muß den auf der Rückwand des Gerätes angegebenen Werten entsprechen.
- Falls sich kein Hauptschalter am Gerät befindet, dient das Netzkabel diesem Zweck.

#### Gehäuse

- Das Innere des Gerätes ist vor Feuchtigkeit zu schützen.
- Das Gehäuse ist nicht zu öffnen.
- Niemals einen Gegenstand durch die Gehäuseöffnungen einführen!

## Safety Precautions

### Kabel

- Vor jeglicher Wartung des Gerätes sind alle Kabel zu entfernen.
- Hierzu grundsätzlich am Stecker oder Verbindungsstück und niemals am Kabel selber ziehen.
- Nicht auf die Kabel oder Stecker treten oder diese einer Zugbelastung aussetzen.

### Hersteller-Wartung

- Wartungsarbeiten sind nur durch vom Hersteller autorisierte Techniker vorzunehmen.





## Precauciones de seguridad

¡Protéjase contra la electrocución y proteja su sistema contra los daños!

Este producto cumple con los criterios internacionales de seguridad y diseño. Observe todas los procedimientos de seguridad que aparecen en esta guía, y los símbolos de seguridad adheridos a este producto.

Si las circunstancias impiden la operación segura de este producto, suspenda la operación y asegure este producto para que no siga funcionando.

¡Evite lastimarse y evite dañar el producto! No avance más allá de cualquier símbolo hasta comprender completamente las condiciones indicadas!

-  **Encontrará este símbolo en el impreso que acompaña a este producto. Este símbolo indica instrucciones importantes de funcionamiento o mantenimiento.**
-  **Es posible que este símbolo esté pegado al producto. Este símbolo indica un terminal vivo, la flecha apunta hacia el aparato terminal.**
-  **Podría encontrar este símbolo pegado al producto. Este símbolo indica un terminal de protección de tierra.**
-  **Podría encontrar este símbolo pegado al producto. Este símbolo indica calor excesivo o peligroso.**

### Alimentación

- Importante! Este es un producto de Clase I. Tiene que estar conectado a tierra.
- Este producto se conecta a un enchufe. El enchufe necesita estar cerca del producto y ser fácilmente accesible.
- Conecte este producto únicamente a la fuente de suministro eléctrico indicada en el panel posterior del producto.
- Si el producto no tiene interruptor para la línea principal, utilice el cordón toma de corriente para este propósito.

### Cubierta

- No permita que la humedad penetre en este producto.
- No abra la cubierta del producto a menos que se indique lo contrario.
- No introduzca objetos a través de las aberturas de la cubierta del producto.

### Cables

- Siempre desconectar todos los cables eléctricos antes de revisar o reparar el producto.
- Tire siempre del enchufe o del conector para desconectar un cable. Nunca tire del cable mismo.
- No camine ni aplique presión sobre los cables o enchufes..

### Revisión y reparación de fábrica





- Solo personal aprobado por la fábrica puede darle servicio al producto.

## Precauzioni di sicurezza

Protegetevi da scosse elettriche e proteggete il vostro sistema da possibili danni!

- Questo prodotto soddisfa le norme internazionali per la sicurezza ed il design. Seguite tutte le procedure di sicurezza contenute in questa guida e i simboli di sicurezza applicati al prodotto.
- Se circostanze avverse compromettono la sicurezza d'uso di questo prodotto, interrompetene l'uso e assicuratevi che il prodotto non venga più utilizzato.

Evitare infortuni alla persona e danni al prodotto! Non procedere oltre a qualunque simbolo fino a quando non si siano comprese pienamente le condizioni indicate!

-  **Questo simbolo, che appare nella letteratura di accompagnamento del prodotto, indica importanti istruzioni d'uso e di manutenzione.**
-  **Sul prodotto potete vedere questo simbolo che indica un dispositivo terminale sotto tensione; la freccia punta verso il dispositivo.**
-  **Potrete trovare il presente simbolo applicato a questo prodotto. Questo simbolo indica un terminale protettivo di messa a terra.**
-  **Potrete trovare il presente simbolo attaccato a questo prodotto. Questo simbolo indica un calore eccessivo o pericoloso.**

### Alimentazione

- Importante! Questo prodotto è di Classe I. Va messo a terra.
- Questo prodotto si inserisce in una presa di corrente. La presa di corrente deve essere in prossimità del prodotto, e deve essere facilmente accessibile.

## **Safety Precautions**

- Collegare questo prodotto solamente alla fonte di alimentazione indicata sul pannello posteriore di questo prodotto.
- Se questo prodotto non è dotato di un interruttore principale, il cavo di alimentazione funge a questo scopo.

## **Chiusura**

- Proteggete da umidità questo prodotto.
- Non aprire la chiusura di questo prodotto a meno che non sia specificato diversamente. Non inserire oggetti attraverso le fessure della chiusura.

## **Cavi**

- Staccare sempre tutti i cavi di alimentazione prima di svolgere l'assistenza tecnica al prodotto.
- Per scollegare un cavo tirate la spina o il connettore, non tirare mai il cavo stesso.
- Non calpestare o sottoporre a sollecitazioni i cavi o le prese.

## **Riparazioni di fabbrica**

- Per le riparazioni contattate solamente personale tecnico autoizzato dalla fabbrica.

# Contents

|                           |          |
|---------------------------|----------|
| <b>Safety Precautions</b> | <b>v</b> |
|---------------------------|----------|

|                          |              |
|--------------------------|--------------|
| <b>About This Manual</b> | <b>xxiii</b> |
|--------------------------|--------------|

|                         |       |
|-------------------------|-------|
| Objective.....          | xxiii |
| Audience .....          | xxiii |
| Required Knowledge..... | xxiii |

|   |          |
|---|----------|
| <b>Chapter 1 Quick Setup - Read Me First!</b> | <b>1</b> |
|---|----------|

|   |    |
|---|----|
| Connecting the Receiver to Other Equipment.....                                 | 2  |
| Maintenance of EMC Compliance.....  | 3  |
| Setting up for Network Connection.....  | 4  |
| Quick Setup Instructions for RF Acquisition.....                                | 5  |
| Assigning a Program Channel to a PE (Program Entry).....                        | 7  |
| ASI Out.....  | 8  |
| Setting up the HD-SDI Outputs (SDI Model, with SD/HD-SDI and AES outputs) ..... | 9  |
| Setting up the MOIP Outputs (Base Model) .....                                  | 10 |
| Setting the DPM Mode.....   | 11 |

|                               |           |
|-------------------------------|-----------|
| <b>Chapter 2 Introduction</b> | <b>13</b> |
|-------------------------------|-----------|

|                                       |    |
|---------------------------------------|----|
| D9854 Advanced Program Receiver ..... | 14 |
| Key Features .....                    | 14 |
| Optional Features.....                | 15 |
| SFN Model Receivers .....             | 16 |
| Software Update .....                 | 16 |
| DVB-ASI Transport Stream Outputs..... | 17 |
| MPEGoIP Output.....                   | 17 |
| MPE Output.....                       | 17 |
| HD-SDI Outputs .....                  | 18 |

|                               |           |
|-------------------------------|-----------|
| <b>Chapter 3 Installation</b> | <b>19</b> |
|-------------------------------|-----------|

|  |    |
|--|----|
| Rack Installation.....                       | 20 |
| Power Connection.....                        | 20 |
| Mechanical Loading .....                     | 20 |
| Elevated Operating Ambient Temperature ..... | 20 |
| Equipotential Bonding .....                  | 21 |
| Installing the D9854 Receiver.....           | 22 |
| Rack Mounted .....                           | 22 |

|   |    |
|---|----|
| Cooling.....  | 22 |
| Grounding.....  | 22 |
| Mounting the D9854 Receiver to a Rack.....                  | 22 |
| Connecting AC Power to the D9854 Receiver .....             | 23 |
| D9854 Receiver Rear Connector Panel.....                    | 24 |
| Connecting the Input/Output Signals.....                    | 26 |
| Connecting the RF Inputs .....                              | 26 |
| Connecting the ASI Input .....                              | 26 |
| Connecting the Video Outputs .....                          | 26 |
| Connecting the Audio Outputs.....                           | 27 |
| Connecting the Ethernet Management Interface.....           | 28 |
| Connecting the IP TS Output .....                           | 28 |
| Connecting the ASI Output.....                              | 28 |
| External Alarm System Connector .....                       | 29 |
| Connecting the RS-232 Data Interface.....                   | 29 |
| Cue Tone/Cue Trigger Interface .....                        | 30 |
| Configuring Open-collector Outputs.....                     | 31 |
| Setting Admin User Privileges via a Telnet Connection ..... | 32 |
| Administrator User Privileges .....                         | 32 |
| Starting a Telnet Session .....                             | 32 |
| Adding a New User.....                                      | 32 |
| Deleting a User .....                                       | 33 |
| Changing a Username.....                                    | 33 |
| Changing a Password (allowed by all Users) .....            | 33 |
| Printing the List of Users .....                            | 34 |
| Resetting the Login Credentials.....                        | 34 |
| Common Interface Modules.....                               | 35 |

## **Chapter 4 Front Panel Operation 37**

|   |    |
|---|----|
| About the Front Panel .....                     | 38 |
| LCD .....                                       | 38 |
| Keypad .....                                    | 38 |
| CI Slots.....                                   | 38 |
| Front Panel LEDs .....                          | 39 |
| Navigation/Selection Keypad .....               | 40 |
| Locking/Unlocking the Front Panel .....         | 42 |
| Startup Screen.....                             | 43 |
| Main Structure.....                             | 43 |
| Channel Authorization Status.....               | 43 |
| LCD Panel .....                                 | 43 |
| LCD Symbol.....                                 | 44 |
| Assigning Program to the Program Entry.....     | 45 |
| Deleting a Program from the Program Entry ..... | 46 |
| Main Menu.....                                  | 47 |
| Main Selection .....                            | 47 |



|   |     |
|---|-----|
| Status Menu .....                       | 48  |
| Structure .....                         | 48  |
| Status Menu: General .....              | 49  |
| Status Menu: Services .....             | 50  |
| Status Menu: TS Input .....             | 52  |
| Status Menu: TS Output .....            | 55  |
| Program Status .....                    | 55  |
| Setup Menu .....                        | 57  |
| Structure .....                         | 57  |
| Setup Menu: Admin .....                 | 58  |
| Setup Menu: TS Input .....              | 62  |
| Setup Menu: IP .....                    | 69  |
| Setup Menu: Services .....              | 75  |
| Setup Menu: Common Interface (CI) ..... | 88  |
| Setup Menu: Outputs .....               | 92  |
| Setup Menu: CA .....                    | 111 |
| Setup Menu: Alarm/Warning .....         | 113 |
| Setup Menu: Noise Cutoffs .....         | 115 |
| About Menu .....                        | 118 |
| General .....                           | 118 |
| Licenses .....                          | 119 |
| Versions Menu .....                     | 120 |
| Diagnostics Menu .....                  | 123 |
| Alarms/Warnings .....                   | 123 |
| Logs .....                              | 123 |
| PSI - Frequency Plan .....              | 124 |
| PSI - Channels .....                    | 124 |
| PSI - Tables .....                      | 125 |
| Power On .....                          | 125 |
| Health Monitor .....                    | 126 |

## **Chapter 5 Web GUI Setup and Monitoring 127**

|   |     |
|---|-----|
| Logging On to the Web Interface .....                   | 128 |
| D9854 Summary Overview .....                            | 129 |
| D9854 Menus .....                                       | 131 |
| D9854 Web GUI Environment .....                         | 133 |
| Window Buttons .....                                    | 133 |
| Setting up Input Information .....                      | 134 |
| Setting up the RF Input .....                           | 134 |
| Setting up the ASI Input .....                          | 138 |
| Setting up SI Receive Parameters .....                  | 140 |
| Setting up Muting Threshold Controls .....              | 142 |
| Viewing the Input Status .....                          | 144 |
| Setting up the Channel Selections .....                 | 145 |
| Viewing the Channel Status .....                        | 146 |
| Configuring the Common Interface (CI) Information ..... | 148 |

|   |     |
|---|-----|
| Viewing the Common Interface (CI) Status .....                | 151 |
| Viewing the CA Status .....                                   | 152 |
| Setting up the BISS Mode .....                                | 153 |
| Viewing the PSI Tables.....                                   | 154 |
| Viewing PSI Frequency Table Information.....                  | 155 |
| Viewing the PSI Channels .....                                | 156 |
| Viewing the PID Input Status .....                            | 157 |
| Setting up Audio and Video Information .....                  | 158 |
| Setting up the Video Parameters .....                         | 158 |
| Setting up Captions .....                                     | 160 |
| Setting up Subtitles.....                                     | 161 |
| Setting up the VBI.....                                       | 163 |
| Setting up Audio Parameters.....                              | 164 |
| Setting up Cueing Parameters .....                            | 167 |
| Setting up Cue Tone Test.....                                 | 169 |
| Setting up Cue Tones .....                                    | 170 |
| Setting up SDI.....   | 171 |
| Setting up Services to be Decoded by the D9854 Receiver ..... | 172 |
| Configuring Transport Stream Information.....                 | 173 |
| Configuring the ASI Output.....                               | 173 |
| Configuring the DPM ASI Details.....                          | 175 |
| Configuring the MPEGoIP Output.....                           | 181 |
| Configuring the DPM MPEGoIP Output Details.....               | 184 |
| Configuring System Settings.....                              | 191 |
| Viewing the System Identification .....                       | 191 |
| Viewing Hardware Features and Base License Information.....   | 192 |
| Setting up IP Information .....                               | 193 |
| Setting up IP Routing Information.....                        | 195 |
| Setting up SNMP Information and Trap Destinations .....       | 196 |
| Configuring Time/Clock Settings.....                          | 198 |
| Viewing the Alarm/Warning Status.....                         | 199 |
| Setting up Alarms and Warnings .....                          | 200 |
| Viewing Alarm/Warning History.....                            | 203 |
| Viewing Version Information .....                             | 204 |
| Setting up Import/Export Information .....                    | 206 |
| Viewing the Backup/Restore Status .....                       | 208 |
| Managing D9854 Web GUI Accounts .....                         | 209 |
| Configuring Lock Level Settings .....                         | 213 |
| Configuring Front Panel Settings .....                        | 215 |
| Viewing Support Information.....                              | 216 |
| Viewing Contact Information .....                             | 216 |
| Viewing Diagnostic Logs.....                                  | 217 |
| Viewing the Usage Counters.....                               | 218 |
| Viewing Operating Board Temperatures .....                    | 220 |
| Viewing Alarm/Warning History.....                            | 221 |
| Loading a Software Version .....                              | 222 |

## **Chapter 6 Service and Maintenance 225**

|                                     |     |
|-------------------------------------|-----|
| Front Panel LEDs .....              | 226 |
| D9854 Receiver Alarm Messages ..... | 227 |
| Alarms .....                        | 227 |
| Warnings .....                      | 257 |

## **Chapter 7 Customer Information 269**

## **Appendix A Technical Specifications 271**

|   |     |
|---|-----|
| L-Band Input and Processing .....             | 272 |
| General .....                                 | 272 |
| LNB LO Stability .....                        | 272 |
| LNB Power and Control .....                   | 273 |
| DVB-S/DVB-S2 .....                            | 273 |
| Video Inputs/Outputs and Processing .....     | 276 |
| General .....                                 | 276 |
| Video Outputs .....                           | 276 |
| Embedded Data in SDI .....                    | 279 |
| Audio Outputs .....                           | 280 |
| Conditional Access .....                      | 280 |
| Transport Stream Outputs .....                | 282 |
| ASI Output .....                              | 282 |
| MPEGoIP Output (optional) .....               | 282 |
| MPE Output .....                              | 283 |
| Control, Management and Data Interfaces ..... | 284 |
| Ethernet Management Interface .....           | 284 |
| Ethernet Data Interface .....                 | 284 |
| RS-232 Data Interface .....                   | 284 |
| Alarm Interface .....                         | 284 |
| Contact Closure Interface .....               | 285 |
| Power and General Specifications .....        | 286 |
| General .....                                 | 286 |
| Power .....                                   | 286 |
| Mechanical .....                              | 287 |
| Environment .....                             | 287 |

## **Appendix B Default Settings 289**

|                                |     |
|--------------------------------|-----|
| Factory Default Settings ..... | 290 |
| Administration .....           | 290 |
| RF Input .....                 | 290 |
| Tune Mode .....                | 291 |
| IP .....                       | 291 |
| Video .....                    | 292 |

|   |     |
|---|-----|
| Audio .....   | 292 |
| Subtitles .....                                       | 292 |
| CI .....  | 293 |
| Cueing .....  | 293 |
| TS Out - ASI .....                                    | 294 |
| TS Out - MOIP1 .....                                  | 294 |
| DPM - ASI .....                                       | 295 |
| Noise Cutoff .....                                    | 296 |
| Import/Export (Web GUI only) .....                    | 296 |
| DPM Default Settings for Different Output Modes ..... | 297 |

## Appendix C Lock Levels 301

|                                  |     |
|----------------------------------|-----|
| D9854 Receiver Lock Levels ..... | 302 |
| Video .....                      | 302 |
| Aspect Ratio .....               | 302 |
| Closed Caption .....             | 303 |
| Subtitles .....                  | 303 |
| Download .....                   | 303 |
| Runnable Application .....       | 303 |
| Runnable FPGA .....              | 304 |
| Audio .....                      | 304 |
| PV Muting Thresholds .....       | 304 |
| LDPC Muting Thresholds .....     | 304 |
| Muting Thresholds .....          | 305 |
| Fixed PID .....                  | 305 |
| IP .....                         | 305 |
| SNMP Comm .....                  | 305 |
| Trap Destination .....           | 306 |
| Active Settings .....            | 306 |
| Active Tuning .....              | 306 |
| Active Inputs .....              | 307 |
| BISS .....                       | 308 |
| Program Entry .....              | 308 |
| Program Status .....             | 308 |
| Decode Enable .....              | 308 |
| Power On .....                   | 309 |
| User Setting .....               | 309 |
| Admin .....                      | 309 |
| DPM Transmit .....               | 310 |
| DPM Global Configuration .....   | 310 |
| DPM PE Maps .....                | 311 |
| DPM PID Map .....                | 311 |
| IP Configuration .....           | 312 |
| Alarm Setting .....              | 312 |
| Warning Setting .....            | 313 |
| Fault Status .....               | 313 |

|                     |     |
|---------------------|-----|
| Fault History ..... | 313 |
| Log History .....   | 314 |

## **Appendix D Compliance** **315**

|   |     |
|---|-----|
| Applicable Standards and Notices .....                      | 316 |
| Safety .....  | 316 |
| EMC .....   | 316 |
| Electromagnetic Compatibility Regulatory Requirements ..... | 316 |
| FCC Notices .....   | 317 |
| Industry Canada Notice .....                                | 317 |
| Unauthorized Modifications .....                            | 317 |
| Declaration of Conformity .....                             | 318 |

## **Index** **319**



# About This Manual

## Objective

This manual describes how to install, use and maintain the Cisco® D9854 Advanced Program Receiver.

**Note:** The manual describes all available options for the D9854 receiver. Your D9854 receiver may only have some of the features described in this manual.

## Audience

The audience of this manual includes users (operators) and service personnel who are responsible for the installation, configuration, operation, monitoring and service of the D9854 receiver.

## Required Knowledge

To use this documentation, the user should have a basic knowledge of the technology used in relation to this product. Service personnel should have additional skills and be familiar with cabling, electronic circuitry, and wiring practices.

This manual is intended for operators who are responsible for the configuration, remote operation and maintenance of the D9854 receiver.





# 1

---

## Quick Setup - Read Me First!

### Overview


This chapter provides a quick setup for your D9854 receiver. If you are unsure about which receiver settings to use, contact your local service provider for assistance.

### In This Chapter


- Connecting the Receiver to Other Equipment..... 2
- Setting up for Network Connection..... 4
- Quick Setup Instructions for RF Acquisition..... 5
- Assigning a Program Channel to a PE (Program Entry)..... 7
- ASI Out..... 8
- Setting up the HD-SDI Outputs (SDI Model, with SD/HD-SDI and AES outputs)..... 9
- Setting up the MOIP Outputs (Base Model) ..... 10
- Setting the DPM Mode..... 11

## Connecting the Receiver to Other Equipment

The following displays the rear panel of the D9854 Base Model:



The following displays the rear panel of the D9854 SDI Model, with SD/HD-SDI and AES outputs:



- 1 Connect the L-Band signal to RF1. 13V or 18V LNB power is only available on the RF1 port. The factory default setting for LNB power is OFF.
- 2 Connect the ASI OUT port to an ASI device for digital tier applications.
- 3 Connect the Composite Video Output to a video monitor.
- 4 Connect the terminal block balanced audio outputs labeled AUDIO 1 and AUDIO 2 to monitoring equipment.
- 5 Apply power by connecting the receiver to a power outlet. The message "Application Starting" will appear on the front panel. The boot process approximately 1 minute for the unit to initialize. When ready, the front panel display shows the startup screen.
- 6 The Ethernet Management port does not currently provide SNMP or management control. It is used for software application downloads only.
- 7 Connect the HD-SDI outputs (M1 and M2) to HD compatible signal processing equipment or HD signal monitoring equipment, if applicable.

## Maintenance of EMC Compliance

The power cord (consisting of appliance coupler, flexible cord, and plug) supplied with this product meets the requirements for use in the country for which this product was purchased. In general, the power cord must be approved by an acceptable, accredited agency responsible for evaluation in the country where the product will be used.

Double-shielded (braid/foil or braid/braid) cables should be used for all ASI I/O and RF inputs. Single-shield cables are acceptable for all other inputs and outputs. For terminal block (Alarms) I/O, no shielding is required.

## Setting up for Network Connection

- 1 Press **MENU** to display the Main menu.
- 2 Press **▶** to go to the Setup menu. Press **SELECT**. Press **▶** twice to select the IP menu. Press **SELECT** twice to go to the IP menu.
- 3 Use the **▲▼** arrow keys to navigate up and down the IP menu, and the **◀▶** arrow keys to move across the IP menu to set the IP Address, Mask and Gateway parameters. Use the number keys to directly enter numbers in the fields. For more information on keypad operation, see Keypad Convention.
- 4 Press **SELECT** each time to save the changes. Press **MENU** four times to return to the startup screen.

## Quick Setup Instructions for RF Acquisition

- 1 Press **MENU** to display the Main menu.
- 2 Press **▶** to go to the Setup menu. Press **SELECT**. Press **▶** to move to the TS Input menu. Press **SELECT**.
- 3 To setup the ASI input port, go to step 4. To setup the RF1 input port, go to step 5.
- 4 Press **SELECT** three times. Press **▼** to set the ASI port to Act (Activate). Press **SELECT**. Go to step 11.
- 5 Press **SELECT**. Press **▶** to go to RF1. Press **SELECT** twice. Use **▼** to set the RF1 port parameter to Act (Activate). Press **SELECT**.
- 6 Press **▼** to move to the LO1, LO2, Crossover menu. Verify these parameters for your application. If no change is needed, go to Step 7. If required, you may modify these settings. Use **▶** to move to the parameter that you want to modify. Press **SELECT**. Use the numerical keypad to enter new frequencies. Press **SELECT**.
- 7 Press **▼** five times to move to the Modulation and Rolloff menu. Press **SELECT**. Use **▲▼** to choose DVB-S or DVB-S2. Press **SELECT**. If DVB-S2 is used, press **▶** to choose Rolloff. Press **SELECT**. Use **▲▼** to choose the value. Press **SELECT**.
- 8 Press **▲** to move to the Freq., Sym Rate, and FEC menu. Press **SELECT**. Enter the RF frequency. Press **SELECT**. Press **▶** to move to the Sym. Rate menu. Press **SELECT**. Enter the symbol rate. Press **SELECT**. If DVB-S2 is used, proceed to step 9. If DVB-S is used, press **▶** to set up the FEC. Press **SELECT**. Use **▲▼** to select AUTO. Press **SELECT**.
- 9 Press **▼** twice to move to the Net ID menu. Press **▶** to choose Net ID. Press **SELECT**. Enter the value. Press **SELECT**.
- 10 Press **▼**. Press **SELECT**. Use **▲▼** to change the LNB power, if needed. Only the RF1 port is capable of providing 13V or 18V. Press **SELECT**.
- 11 Press **MENU** three times. Press **▶** to move to Save & Exit. Press **SELECT**. Save & Exit will return you to the Main: Setup menu; Abandon & Exit will go back to the last menu accessed with the original parameters; Cancel will go back to the last menu accessed with changes saved.
- 12 The receiver will search for the signal and display "Acquisition Successful". It will find the first available channel on the network. Press **MENU** twice to return to the start-up menu.

## Chapter 1 Quick Setup - Read Me First!

- 13 If the front LED is solid green, the unit is authorized. Proceed with Assigning a Program Channel to a PE (Program Entry). If the front LED is flashing green, the unit is unauthorized. Please contact your service provider and provide the Tracking ID number for authorization. The Tracking ID can be found on the **ABOUT** menu. To locate the Tracking ID, press **MENU**, press **▶** twice, and then press **SELECT** twice. Make a note of the Tracking ID number. Press **MENU** three times to return to the startup screen.

## Assigning a Program Channel to a PE (Program Entry)



- 1 At the start-up screen, PE1 is initially displayed.
- 2 Press **ADV** and use the ▲▼ keys to scroll through the available program entries.
- 3 Press **ADV** again to select the channel number.
- 4 Use the ▲▼ keys to scroll through the available program channels or directly enter the channel number using the 0 to 9 keys; press **SELECT** to save the channel selection.

**Important:** In addition to ASI out availability on both models, your D9854 will be configured for either HD-SDI or MOIP output. Please follow the procedure for your model to configure the outputs.


## ASI Out

- 1 Press **MENU** to move to the MAIN MENU.
- 2 Press **▶** to move to the Setup menu. Press **SELECT**.
- 3 Press **▼** to move to the Outputs menu. Press **SELECT**.
- 4 Press **▶** to move to the TS Out menu. Press **SELECT**.
- 5 Press **SELECT** to access the ASI menu. Press **▼**. Press **SELECT**. Use **▲▼** to select the output mode. The factory default is "No Output". It is recommended to set the Output Mode to MAP Svc Chans Only. Refer to *Factory Default Settings* (on page 290) for Different Output Modes, for information on the default settings in order to choose the desired Output Mode. Press **SELECT**. Press **▶** to select "YES" if requested to "RESYNC ALL?". Press **SELECT**. Press **▶** to move to Descrambling Mode Menu. Press **SELECT**. Use **▲▼** to select the scrambling mode. Press **SELECT**.
- 6 Press **APPLY**. Press **SELECT**.
- 7 Press **MENU** 5 times to return to the startup menu.



## Setting up the HD-SDI Outputs (SDI Model, with SD/HD-SDI and AES outputs)


The following displays the rear panel of the D9854 SDI Model, with SD/HD-SDI and AES outputs:



- 1 Press **MENU**.
- 2 Press **▶** to move to the Setup menu. Press **SELECT**.
- 3 Press **▶** three times to move to the Services menu. Press **SELECT**.
- 4 Press **SELECT** to enter the Video menu.
- 5 Press **SELECT** to enter the PV Format menu, then use **▲▼** to navigate and configure the output. Press **SELECT** to save the changes.
- 6 Press down arrow to move to the SD Format menu. Press **SELECT** to enter the menu and use **▲▼** to navigate and configure the output. Press **SELECT** to save the changes.
- 7 Press **MENU** two times. Press **▶** to move to the Outputs Menu. Press **SELECT**. Press **▶** two times to enter the M1/M2 Menu. Press **SELECT**. Press **SELECT** and use **▲▼** to enter ASI or SDI output on port 1. Press **SELECT** to save changes. Press **▶** to move to M2. Press **SELECT** and use **▲▼** to enter ASI or SDI output on port 2. Press **MENU** repeatedly to return to the startup screen.

## Setting up the MOIP Outputs (Base Model)

The following displays the rear panel of the D9854 Base Model:



- 1 Press **MENU** to move to the Main Menu.
- 2 Press **▶** to move to the Setup menu. Press **SELECT**.
- 3 Press **▼** to move to the Outputs menu. Press **SELECT**.
- 4 Press **▶** to move to the TS Out menu. Press **SELECT**.
- 5 Press **▶** to move to the MOIP menu. Press **SELECT**. Press **▶**. Press **SELECT** for Rate Control. Use **▲▼** to select "USER". Selecting "Auto" for Rate Control results in the device setting the output rate to be the same as the input rate. Press **SELECT**. Press **▶** to move to the User Rate menu. Press **SELECT** and use the keypad to enter the desired bit rate. Press **SELECT** to save changes.
- 6 Press **▼** to move to the Output Mode. Press **SELECT**. Use **▲▼** to choose the output mode for your application. Press **SELECT**. Press **▶** to move to Descrambling Mode menu. Press **SELECT**. Use **▲▼** to select the scrambling mode. Press **SELECT**.
- 7 Press **▼**. Press **▶** to move to Insert Null Packet. Press **SELECT**. Use **▲▼** to change the selection to "No". Press **SELECT**.
- 8 Press **▼** two times. Press **SELECT**. Use **▲▼** to change the selection to UDP or RTP. Press **SELECT**.
- 9 Press **▼**. Press **SELECT**. Enter the Destination Address using the keypad. Press **SELECT**. Press **▶** to move to the UDP Port. Press **SELECT** and enter the Port number using the keypad. Press **SELECT** to save the change. Press **▶** to move to the source port. Press **SELECT** and enter the Port number using the keypad. Press **SELECT** to save the change. The default is zero, which allows the system to assign a port.
- 10 Press **▼**. Press **▶** two times to move to PCR@IP Start menu. Press **SELECT**. Press **▼** to set value to "No". Press **SELECT** to save the value.
- 11 Press **▼** two times. Press **▶** to move to PCR Addition. Press **▼** to select "No".
- 12 Press **MENU** to exit the menu level and save the changes.

## Setting the DPM Mode

A program can be set to one of three Digital Program Mapping (DPM) modes, either Drop, Pass or Map respectively. For more information, see *TS Out - DPM* (on page 101).

| LCD Setting | Description   |
|-------------|---|
| Drop        | Removes the service and its associated PMT reference from the transport output.   |
| Pass        | Permits the source content and PMT reference to appear in the transport output with the same references unless the source material is mapped on another PE. |
| Map         | Provides the flexibility to define all the outgoing PID numbers for a PE, including those not currently on transmission.                                    |

- 1 Press **MENU** to display the Main Menu.
- 2 Press **▶** to move to the Setup menu. Press **SELECT**.
- 3 Press **▶** five times to move to the Outputs menu. Press **SELECT**.
- 4 Press **▶** to move to the TS Out menu. Press **SELECT**.
- 5 Press **▶** twice to move to the DPM menu. Press **SELECT**.
- 6 Press **SELECT** to access the Global menu.
- 7 Press **SELECT** to choose ASI for Resync All. Press **▶** and then press **SELECT** to continue.
- 8 Press **MENU**. Press **▶** to move to the ASI menu. Press **SELECT**. Verify the PE1 "InCh" and "OutCh" programs.
- 9 Press **▶** three times to choose Act. Press **SELECT**. Use **▲▼** to select the DPM action for the PID associated with the PE. Press **SELECT**. Press **APPLY**. Press **SELECT** to save the changes.
- 10 Press **MENU** six times to return to the start-up screen.



# 2

---

## Introduction

### Overview

This chapter is a general introduction to the D9854 Advanced Program Receiver. It describes the most common applications and interfaces of the receiver.

### In This Chapter

- D9854 Advanced Program Receiver ..... 14
- DVB-ASI Transport Stream Outputs ..... 17

## D9854 Advanced Program Receiver

The D9854 Advanced Program Receiver is designed for satellite content distribution applications requiring DVB-S and DVB-S2 reception capabilities with advanced digital outputs for digital tier program distribution. A built-in decoder will be capable of decoding a MPEG-2 or MPEG-4 High Definition (HD) program for analog monitoring or high-quality HD-SDI output version will be available for re-encode applications.

The ASI transport output or the optional MPEGoIP output will provide a number of output modes including the capability of carrying a decrypted program for digital tier distribution. This helps ensure that compressed video programs are efficiently distributed to households equipped with digital set-top boxes. Digital Program Insertion (DPI) information will also be available along with the video and audio PIDs (Packet Identifiers) for external ad insertion in compressed digital format.

### Key Features

The D9854 receiver provides the following key features:

- Four L-band inputs
- DVB-S QPSK demodulation
- DVB-S2 QPSK/8PSK demodulation
- PowerVu® conditional access with DES or DVB descrambling
- Supports Basic Interoperable Scrambling System (BISS) conditional access
- DVB-CI support for CAM-based conditional access
- 4:2:0 HD MPEG-4 AVC and MPEG-2 1080i and 720p decoding
- 4:2:0 SD MPEG-4 AVC and MPEG-2 decoding
- Aspect ratio conversion (4:3, 16:9, 14:9) with Active Format Descriptor (AFD) control for SD programs
- AFD support for down-conversion of HD programs with aspect ratio conversion
- Closed Captioning support for EIA-608 and EIA-708
- MPEG and Dolby® Digital audio decoding
- DVB or Imtext subtitles
- Four audio outputs providing either two stereo pairs or four mono channels of balanced, audio, each with the ability to use part of their output for applications such as SAP, cue tones, etc.
- Utility data up to 38.4 kbps via RS-232

- Uplink addressable decoder output control (VBI, audio routing, DPI, and ASI output)
- Fingerprint trigger
- Field upgradeable software and security
- SNMP for setup, control, and monitoring
- Front panel LCD for control and monitoring each with the ability to use part of their output for applications such as SAP, cue tones, etc.
- DVB-VBI and SCTE-127 support
- DTMF cue tone and cue trigger outputs for ad-insertion
- Digital Program Mapping providing uplink control for service replacements in blackout areas
- Field upgradeable software and security
- Front panel LCD and keypad for monitoring and control
- Web browser interface for easy setup, control, and monitoring. The supported web browsers are: Internet Explorer 7.0, Internet Explorer 8.0, Firefox 3.5, and Firefox 3.6.
- DVB-VBI and SCTE-127 support
- CAM Interface software
- DTMF cue tone and cue trigger outputs for ad insertion
- Digital Program Mapping providing uplink control for service replacements in blackout areas
- Multiprotocol Encapsulation (MPE) output
- HD to SD down conversion in uncompressed domain
- Live Event Control Support

## Optional Features

The following features are available options:

- MPEGoIP output only available on the Digital Transport Model
- User-switchable redundant ASI outputs or SDI or HD-SDI outputs
- SD or HD-SDI video output with embedded audio
- AES-3id digital audio output

## SFN Model Receivers

The Single Frequency Network (SFN) receivers do not include some of the key features normally equipped on D9854 receivers, such as Digital Program Mapping (DPM), MPEGoIP output, and transport stream null packet stuffing. These features are disabled on this receiver model. SFN model receivers can be identified by the part number “401943801060305” on the label on the top cover of the unit.

## Software Update

All software in the D9854 receiver is stored in non-volatile memory that can be electrically programmed. New software releases for the D9854 receiver can be downloaded via the Ethernet 10/100/1000 BaseT Management interface.




# DVB-ASI Transport Stream Outputs

The D9854 receiver has one DVB-ASI output. This output can be used as an input for a DVB-T transmitter or other types of DVB-ASI reception equipment.

## MPEGoIP Output

The optional MPEGoIP output provides a number of output modes including the capability of carrying a decrypted program for digital tier distribution. This helps ensure that compressed video programs are efficiently distributed to households equipped with digital set-top boxes. Digital Program Insertion (DPI) information will also be available along with the video and audio PIDs (Packet Identifiers) for external ad-insertion in compressed digital format.


The diagram below shows an example of the D9854 receiver used in an MPEGoIP application.



## MPE Output

The Multiprotocol Encapsulation (MPE) output provides a means to carry packet oriented IP protocols on top of a transport stream. The MPE output receives IP packets from the transport stream and the IP data can be sent through an Ethernet switch to an IP router or directly to a receiving device.


The diagram below shows an example of the D9854 receiver used in an MPE application.



## HD-SDI Outputs

The D9854 Advanced Program Receiver is designed for satellite content distribution applications requiring DVB-S and DVB-S2 reception capabilities with advanced digital outputs for digital tier program distribution. A built-in decoder is capable of decoding an MPEG-2 or MPEG-4 High Definition (HD) program for analog monitoring. A high-quality HD-SDI output version is available for re-encoding applications.

The diagram below shows an example of the D9854 receiver used in HD-SDI monitoring applications.



# 3

## Installation

### Introduction

This chapter contains the information for technicians installing the Cisco D9854 Advanced Program Receiver.

### Qualified Personnel

Only appropriately qualified and trained service personnel should attempt to install, operate, or maintain the D9854 receiver.



**WARNING:**

**Allow only authorized and qualified service personnel to install, operate, maintain, and service this product. Otherwise, personal injury or equipment damage may occur.**

### In This Chapter

|   |    |
|---|----|
| ■ Rack Installation.....                                      | 20 |
| ■ Installing the D9854 Receiver .....                         | 22 |
| ■ D9854 Receiver Rear Connector Panel.....                    | 24 |
| ■ Connecting the Input/Output Signals.....                    | 26 |
| ■ Setting Admin User Privileges via a Telnet Connection ..... | 32 |
| ■ Common Interface Modules.....                               | 35 |

## Rack Installation

### Power Connection

To operate the receiver, you must connect it to an AC power source. For information about connecting the chassis to AC power, see *Appendix B - Technical Specifications* (on page 271).

As Cisco units are designed for continuous operation, some products do not have a power switch. In this case the mains cord and/or DC power supply cable serve(s) as the mains disconnect device.



**WARNING:**

Make sure that at least one end of the power cable(s) remains easily accessible for unplugging, if you need to switch off the unit. For example: Ensure that the socket outlet is installed near the product.



**WARNING:**

To avoid electrical shock, connect the three-prong plug on this product to an earth-grounded three-pin socket outlet only.

### Mechanical Loading

Make sure that the rack is placed on a stable surface. If the rack has stabilizing devices, install these stabilizing devices before mounting any equipment in the rack.



**WARNING:**

Avoid personal injury and damage to this equipment. Mounting this equipment in the rack should be such that a hazardous condition is not caused due to uneven mechanical loading.

### Elevated Operating Ambient Temperature



Only install this equipment in a humidity- and temperature-controlled environment that meets the requirements given in this equipment's technical specifications.



**CAUTION:**

If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient temperature. Therefore, install this equipment in an environment compatible with the manufacturer's maximum rated ambient temperature.

## Equipotential Bonding

If this equipment is equipped with an external chassis terminal marked with the IEC 60417-5020 chassis icon () or 5017 () , the installer should refer to CENELEC standard EN 50083-1 or IEC standard IEC 60728-11 for correct equipotential bonding connection instructions.

## Installing the D9854 Receiver

### Rack Mounted

The D9854 receiver is a 1U unit with connector access at the rear panel. The receiver is intended for mounting in a standard 19" rack with minimum 1U spacing between units to allow adequate ventilation/air flow.

The D9854 receiver is vented from front to back. Multiple units can be stacked in a rack, provided that adequate cooling is available.

### Cooling

The D9854 receiver is cooled by the use of internal fans. The air intake is from the front and the air outlet is on the rear.

**Note:** Adequate cooling must be provided equaling 107 W (maximum) at 25°C per unit to avoid overheating.



**CAUTION:**

The inlet air temperature must not exceed 50°C/122°F at any time.

### Grounding

You must ensure that the unit is properly connected to ground in order to meet safety and EMC requirements. Before any other connection is made, the unit must be connected to a protected ground terminal as described below:

- Via the three wire power cord of the AC power supply. This connection is mandatory.
- In addition, via the protective ground terminal on the rear panel of the unit. This connection provides additional protection of the equipment.

### Mounting the D9854 Receiver to a Rack

- 1 Mount L-brackets in the rack to support each D9854 receiver to be installed.
- 2 Place the receiver in its position in the rack.
- 3 Mount the receiver securely to the rack by securing the mounting flanges to the rack using the four screws provided.
- 4 Make sure the air outlet holes on the back of the receiver are not obstructed to allow air flow from the front to the back of the chassis.

## Connecting AC Power to the D9854 Receiver


- 1 Connect the power cord (supplied with the D9854 receiver) between the rear panel power receptacle and a 100 to 120/200 to 240 V AC power outlet.
- 2 Make sure that the power cable is connected to protective ground. See *Grounding* (on page 22) for more information.

The D9854 receiver is equipped with one power supply located in the rear of the chassis. Note the location of the power supply in the event of alarms/warnings resulting in replacement of a power supply. Alarm messages appear in the Message Log.


## D9854 Receiver Rear Connector Panel

The following diagrams show the rear connector panel of the two D9854 receiver models available.

The following displays the base model:



The following displays the SDI model, with SD/HD-SDI and AES outputs:



The following table describes the function and type of the various connectors.

| Connector  | Description  | Type  |
|------------|--|-------|
| RF Inputs  | Each input accepts an LNB signal input. RF1 provides LNB power for use when no external LNB power source is available. RF2 to RF4 require an external LNB power source.  | F     |
| ASI Input  | Asynchronous Serial Interface Input.   | BNC   |
| ASI Output | One Asynchronous Serial Interface Output.  | BNC   |
| TS Output  | This is for the MPEGoIP and MPE outputs. The MPEGoIP output of the transport stream is encapsulated in the IP packets to a groomer for distribution. The MPE output receives IP packets from the transport stream. | RJ-45 |



### D9854 Receiver Rear Connector Panel

| Connector                          | Description   | Type                             |
|------------------------------------|---|----------------------------------|
| Management                         | For code downloading/application upgrading for the D9854 receiver.  | RJ-45                            |
| HD-SDI Outputs                     | M1 and M2 provide HD serial digital video with embedded audio output for HD applications according to SMPTE-292M.   | BNC                              |
| RS-232 Data                        | RS-232 data output: 7 bits, even parity, 1 stop bit, up to 38.4 kb/s. These outputs are user-configurable via the Setup menu on the front panel.                      | 9-pin sub-D female               |
| Cue Tone/Cue Trigger Relay Outputs | Program relay provides programmed responses for alarms, cue trigger states for ad-insertion equipment, or a cue tone output for connection to ad-insertion equipment. | 15-pin sub-D female              |
| Composite Video Outputs            | CVBS 1 and CVBS 2 provide two identical SD composite video outputs for monitoring applications.   | BNC                              |
| Component Video Outputs            | SD to HD upconverted component video output for HD monitoring applications.   | BNC                              |
| AES-3id Audio Outputs              | AES-3id outputs. One output for each stereo channel.  | BNC                              |
| Balanced Audio Outputs             | Audio 1 and Audio 2 provide two stereo pairs or four mono channels.   | Terminal Blocks                  |
| Ground                             | Screw   | Grounding point for the receiver |
| Power                              | AC power  | IEC 60320 Sheet 14               |

## Connecting the Input/Output Signals

### Connecting the RF Inputs

Connect up to four LNB RF cables to the RF connectors labeled RF1 through RF4 on the rear of the unit.

Use 75-ohm (braid/foil or braid/braid), low insertion loss coaxial cable.

Each input accepts an LNB signal input. RF2 to RF4 require an external LNB power source.


### Connecting the ASI Input

If desired, connect to the ASI IN port to an asynchronous serial interface for uplink monitoring.

### Connecting the Video Outputs

The video output connectors are of the BNC type.

The following table shows the video connector:

| Connector   | Interface type | Connector type |
|---|----------------|----------------|
|  | SNPTE-292M     | BNC female     |

#### Connecting the Component Video Output

Connect a video monitor to the connectors labeled Pr, Pb, and Y.

#### Connecting the Composite Video Output

Connect a video monitor to the CVSB 1 and CVSB 2 connectors. The two outputs are identical. Use a 75-ohm double-braided coax cable.

#### Connecting the HD-SDI Outputs

Connect HD rebroadcast equipment to the connectors labeled M1 and M2, and/or if required, connect them to a video monitor.


There are two connectors to provide active loop-through possibility.

## Connecting the Audio Outputs

### Connectors for the Digital Audio Output

The configuration of the D9854 receiver outputs two stereo channels. The D9854 receiver also supports encoding of audio embedded in the HD-SDI video signal.

The following drawing shows the audio connector.

| Connector   | Interface type | Connector type |
|---|----------------|----------------|
|  | AES-292M       | BNC female     |

**Note:** The digital audio output is always 75-ohm single-ended.


### Connecting the Digital Audio Outputs

Connect digital audio output broadcast equipment to the AES-3id connectors. The two stereo channels are useful for Dolby Digital 5.1 passthrough applications. Use a high-quality, double-shielded RJ6 coaxial cable.

**Hint:** For digital audio connections, use a balanced cable designed for 110-ohm AES-EBU digital audio.

### Connecting the Balanced Audio Output

- 1 Connect the AUDIO 1 and AUDIO 2 balanced audio outputs to monitoring equipment. Use a multi-conductor, pluggable cable from the receiver's AUDIO 1 and AUDIO 2 (Left and Right) terminals to your equipment, as shown in the following illustration.

| Connector   | Connector type |
|---|----------------|
| <p><b>Terminal screws</b></p>  | Terminal Block |

- 2 Feed the stripped ends of the positive, negative and ground wires into the appropriate terminals as labeled, and then screw the terminal screws (located on the top of the terminal block) finger tight to each wire.

## Connecting the Ethernet Management Interface

The RJ-45 interface for 100/1000BASE-T Ethernet is currently intended for upgrading/downloading the software application. You must set up the IP address, the default gateway and the subnet mask to match the network connection. This is done through the front panel menu. For further information, see *Setting up for Network Connection* (on page 4).

**Note:** Proper cables are required for reliable Ethernet operation; to run up to a maximum segment length of 100 m and up to 100BASE-T, the cable has to comply with the EIA/TIA Category 5 (or higher) wire specifications, and for 1000BASE-T, Category 6 is required. For EMC protection, shielded cables must be used.

- 1 Connect an RJ-45 cable between the Ethernet connector on the D9854 receiver and the Ethernet port of your PC.
- 2 Set up the IP address on the D9854 receiver (via the front panel display). For information on setting up the IP address via the front panel, see *Setting up for Network Connection* (on page 4).

## Connecting the IP TS Output

The RJ-45 interface IP TS OUT is 10/100/1000BASE-T Ethernet. It is intended for both MPEGoIP and MPE outputs. The MPEGoIP output of the transport stream is encapsulated in the IP packets to a groomer (for example, Cisco D9900 Digital Content Manager) for distribution. The MPE output receives IP packets from the transport stream.

**Note:** For reliable Ethernet operation; to run over a maximum segment length of 100 m and up to 100BASE-T, the cable has to comply with the EIA/TIA Category 5 (or higher) wire specifications, and for 1000BASE-T, Category 6 is required.

Connect a crossed RJ-45 cable between the Ethernet connector (DATA port only) on the D9854 receiver and the Ethernet port of the equipment after the D9854 receiver. The equipment after the D9854 receiver could be an IP router or a switch.

## Connecting the ASI Output

Connect the output signal from the D9854 receiver ASI OUT connector.

Use a Belden “Brilliance” cable with foil/braid construction. The shield must provide 99% or better shielding effectiveness.

The equipment after the D9854 receiver could be a Cisco D9887 HDTV Receiver.

## External Alarm System Connector

The D9854 receiver and Alarm relay functionality. See *Connecting the Cue Tone/Cue Trigger Interface* (see "Cue Tone/Cue Trigger Interface" on page 30) for more information on Cue Tone and Cue Trigger equipment connections. These outputs are user-configurable via the Setup Menu on the front panel.


The Alarm output connector is a 15-pin sub-D female connector. The following diagram shows the connector and the pin allocation table for the Alarm output pins.

The connector pin states depend on the selected Relay Mode. The Relay Mode is set on the front panel via the Main: Setup: Outputs menu.

### Changing the Relay Mode for Alarm Monitoring

The Alarm relay is a program relay that can be configured to provide programmed responses for alarms, warnings, cue trigger states for ad-insertion equipment, or a cue tone output for connection to ad-insertion equipment. As a default, the Alarm Relay is configured for Alarm mode.

- 1 On the front panel menu, go the Main: Setup: Outputs, and select **Cueing**.
- 2 Use the down arrow key to scroll through the menu to Relay Mode.
- 3 Change the state to **Alarm** and press the **Select** key to save the new setting. As a result, the rear panel connector pin states will change to that shown in the table below for Alarm mode.

| Connector   | Normally closed pin | Common pin | Normally open pin | Relay Mode      |
|---|---------------------|------------|-------------------|-----------------|
|  | 11                  | 10         | 15                | Trigger         |
|   | 15                  | 10         | 11                | Alarm (default) |

**Note:** A Normally closed state implies the state when power is applied to the relay in a normal operating state, without a trigger or alarm condition present.


## Connecting the RS-232 Data Interface

The DCE DB-9 female connector is intended for low-speed data: 7 bits, even parity, 1 stop bit, up to 38.4 kb/s (default). These outputs are user-configurable via the Setup Menu on the front panel.

The interconnect cable from the D9854 receiver to a PC should be straight through (for example, no handshaking), shielded and equipped with a DB-9 male connector at one end to mate with the rear panel RS-232 Data interface, and a female DB-9 connector to connect to the PC.

**RS-232 Data Connector Pin Allocation**


The table shows the RS-232 Data connector and the pin allocation:

| Connector   | Normally closed pin | Common pin    |
|---|---------------------|---------------|
|  | 1                   | Not connected |
|   | 2                   | TxD           |
|   | 3                   | RxD           |
|   | 4                   | Not connected |
|   | 5                   | Ground        |
|   | 6                   | Not connected |
|   | 7                   | Not connected |
|   | 8                   | Not connected |
|   | 9                   | Not connected |

**Cue Tone/Cue Trigger Interface**

The D9854 receiver is equipped with a connector labeled Cue Tone/Relay for alarm relay outputs for remote alarm signaling. This connector provides Cue Tone, Cue Trigger and Alarm relay functionality. These outputs are user-configurable via the Setup Menu on the front panel.

The connector is a 15-pin sub-D female connector. The following diagram shows the connector and the pin allocation table for Cue Tone, Cue Trigger and Alarm relay connections.

| Connector   | Pin | Pin allocation |
|---|-----|----------------|
|  | 1   | Cue Trig 1     |
|   | 2   | Cue Trig 2     |
|   | 3   | Cue Trig 3     |
|   | 4   | Cue Trig 4     |
|   | 5   | Cue Trig 5     |
|   | 6   | Cue Trig 6     |
|   | 7   | Cue Trig 7     |
|   | 8   | Cue Trig 8     |
|   | 9   | Not connected  |
|   | 10  | Alarm - Ground |

## Connecting the Input/Output Signals

| Connector | Pin | Pin allocation          |
|-----------|-----|-------------------------|
|           | 11  | Alarm - Normally open   |
|           | 12  | Chassis ground          |
|           | 13  | Cue Tone -              |
|           | 14  | Cue Tone +              |
|           | 15  | Alarm - Normally closed |

### Connecting the Cue Tone Interface

Connect the Cue Tone pins, 13 and 14 to a device to facilitate ad-insertion using DTMF Analog Cue Tones.

### Connecting the Cue Trigger Interface

Connect the Cue Trigger pins (1 to 8) to up to 8 serial control devices or a device to control ad-insertion. These outputs are user-configurable on the front panel menu.

## Configuring Open-collector Outputs

The D9854 supports decoding of SCTE-35 messages with DTMF descriptor. The D9854 outputs tones or sets the open collector contacts according to the content of the DTMF descriptor in the Cisco D9054 HDTV Encoder and the Cisco D9036 Modular Encoding Platform. For information on the open-collector output settings, see the *Cisco D9054 HDTV Encoder Installation and Operation Guide, part number 4043745* and *Cisco D9036 Modular Encoding Platform Installation and Configuration Guide, part number 4043885*.

## Setting Admin User Privileges via a Telnet Connection

### Administrator User Privileges

Up to 10 usernames/passwords can be defined for login use via a telnet session or Web GUI (for example, http) session on the D9854 receiver.

When a user tries to login via a telnet or http connection, the user is required to provide a username and a password. The user is granted access only if this username/password pair exists in the authentication table.

The factory preset "Admin" account has Admin privileges and is allowed to add new users, delete users, change usernames, and modify its own passwords. Users with non-Admin privileges (for example, User and Guest) are only allowed to modify their own passwords.

### Starting a Telnet Session

To start a communication session with the receiver, use a utility such as Tera Term Pro or PuTTY.

Proceed as follows to log into a new connection using Tera Term:

- 1 In the New Connection window, enter the IP address in the **Host** field.
- 2 Select **Telnet** and enter 23 in the **TCP port #** field.
- 3 Click **OK**.
- 4 At the Login prompt, type the default username, `admin` and press **Enter**.
- 5 At the Password prompt, type the default password, `localadmin` and press **Enter**.
- 6 At the D9854 prompt, type `lr` and press **Enter**.

### Adding a New User

- 1 At the D9854 prompt, type `pwd add_user` and press **Enter**.
- 2 At the NEW USERNAME prompt, type a new username and press **Enter**.
- 3 At the NEW PASSWORD prompt, type a new password and press **Enter**.  
**Note:** The new password must follow the rules configured in the Password Complexity parameter. For more information, see *To Configure the User Login Passwords* (see "To Change the User Login Passwords" on page 209) for the web GUI or *Setup Menu: IP* (on page 69) for the Front Panel.
- 4 At the CONFIRM NEW PASSWORD prompt, type the new password again and press **Enter**.

**Note:** The New Password and Confirm New Password should be identical.



- At the NEW USER PRIVILEGES prompt, enter the type of account you want to assign the user. The following table illustrates the different login types:

| Account Type | Enter | Access   |
|--------------|-------|--|
| Guest        | 3     | View settings only.                                |
| User         | 2     | View and edit settings.                            |
| Admin        | 1     | View, edit settings, and add/delete user accounts. |

- At the ADMINISTRATOR PASSWORD prompt, type the administrator's password and press **Enter**.

## Deleting a User

- At the D9854 prompt, type `pwd del_user` and press **Enter**.
- At the USERNAME prompt, type the username you want to remove and press **Enter**.
- At the ADMINISTRATOR PASSWORD prompt, type in the administrator's password and press **Enter**.

## Changing a Username

Proceed as follows to modify a username:

- At the D9854 prompt, type `pwd username_change` and press **Enter**.
- At the CURRENT USERNAME prompt, type the username you want to edit and press **Enter**.
- At the NEW USERNAME prompt, type the new username and press **Enter**.  
**Note:** Ensure that the new username does not match any of the usernames already defined in the authentication table.
- At the ADMINISTRATOR PASSWORD prompt, type the administrator's password and press **Enter**.

## Changing a Password (allowed by all Users)

Passwords can be changed by all users.

- At the D9854 prompt, type `pwd password_change` and press **Enter**.
- At the CURRENT PASSWORD prompt, type the current login password you want to change and press **Enter**.
- At the NEW PASSWORD prompt, type a new login password and press **Enter**.
- At the CONFIRM NEW PASSWORD prompt, type the new login password again to confirm and press **Enter**.

**Note:** The new password and the confirm new password should be identical. Each user, including the admin user, can modify only his own password.

## Printing the List of Users

At the D9854 prompt, type `pwd list_users` and press **Enter**.

**Note:** Only usernames will be printed. Passwords will not be visible.

## Resetting the Login Credentials

At any time, the user authentication table can be reset from the front panel. This option is under the Setup: IP: IP menu. Scroll down to Reset Credentials and press **SELECT**. Press **▶** and then press **SELECT** to confirm the operation. A new login username and randomly generated password will be displayed on the front panel display for approximately 30 seconds. The new account will have Admin privileges. It is recommended that this account be replaced by a login username and password chosen by the administrator. To change the username and password, you must be an Admin user. Refer to *To Configure the User Login Passwords* (see "*To Change the User Login Passwords*" on page 209).

**Note:** After this recovery procedure, all existing user accounts will be lost.

## Common Interface Modules

Only CAMs purchased from Cisco are currently supported. The following lists the supported CAMs:

| Common Interface Modules   | Part Number |
|--|-------------|
| Aston Professional CAM, for descrambling CONAX<br>(maximum 12 services)  | 4016669     |
| Aston Consumer CAM for descrambling CONAX<br>(maximum 2 services)  | 4016670     |
| CAM for descrambling CryptoWorks V9523361<br>Aston Professional CAM for descrambling Irdeto<br>(maximum 12 services) | 4016671     |
| Aston Consumer CAM for descrambling Irdeto<br>(maximum 2 services)   | 4016672     |
| Aston Professional CAM for descrambling<br>MediaGuard<br>(maximum 12 services)                                       | V9528197    |
| Aston Consumer CAM for descrambling<br>MediaGuard<br>(Maximum 2 services)  | V9528198    |
| Aston Professional CAM for descrambling Viaccess<br>(maximum 12 services)  | V9528199    |
| Aston Consumer CAM for descrambling Viaccess<br>(maximum 2 services)   | V9528240    |
| CAM for descrambling Roscrypt<br>(maximum 50 services)   | NA          |
| SMiT Professional Irdeto CAM<br>(maximum 8 services)   | 4037372     |
| SMiT Consumer Irdeto CAM   | 4037371     |

**Note:** Roscrypt CAMs are not available from Cisco, and must be purchased from a recognized vendor.



# 4

---

## Front Panel Operation

### Overview


This chapter describes how to set up the D9854 Advanced Program Receiver using the front panel keys and display. This information is primarily applicable for standalone operation.

### In This Chapter

|   |     |
|---|-----|
| ■ About the Front Panel .....             | 38  |
| ■ Locking/Unlocking the Front Panel ..... | 42  |
| ■ Startup Screen.....                     | 43  |
| ■ Main Menu.....                          | 47  |
| ■ Status Menu .....                       | 48  |
| ■ Setup Menu.....                         | 57  |
| ■ About Menu.....                         | 118 |
| ■ Versions Menu .....                     | 120 |
| ■ Diagnostics Menu .....                  | 123 |

## About the Front Panel

The D9854 receiver is operated using controls and indicators on the front panel. These include the numeric keypad, the Navigation/Selection keypad, the LCD, the Alarm and Signal indicators. These are shown in the following illustration.



### LCD

The LCD provides information on the selections available at any menu level, current settings for parameters, and certain status and alarm indications. This is a 2x40, backlit LCD display. The top line may be status data or identifier information. It can also display optional functions available for tuning operations. The bottom line will show selections or parameter values available using the navigation/selection keypad. The items are selected by pressing the **SELECT** (center key) or the ▼ (down arrow) key on the navigation/selection keypad.

### Keypad

The numeric keypad is used to enter alphanumeric values. The **MENU** key sets the software to the initial menu and returns to the previous menu. The **MENU** key can also be used to cancel a numeric entry at any point during the entry sequence, and the ◀ (left arrow) key allows backspacing through the entry.

### CI Slots

The CI slots allow the use of CAM (Conditional Access Module) Smart Card to decrypt purchased programming. For setup information, see *Setup Menu: Common Interface (CI)* (on page 88). For a list of supported CAMs, refer to *Common Interface Modules* (on page 35).

## Front Panel LEDs

The functions of the LEDs are described in the table below.

| LED    | Signal State/Color | Explanation  |
|--------|--------------------|--|
| ALARM  | Red                | Solid for five seconds indicates a Warning.  |
|        | Red                | Flashing indicates an Alarm.   |
| SIGNAL | Green              | Solid indicates all of the following conditions: <ul style="list-style-type: none"> <li>■ all RF inputs are enabled, all inputs are locked to a signal, and are not muted.</li> <li>■ all routed ASI outputs are operating without an error.</li> </ul>  |
|        | Green              | Flashing indicates one of the following conditions: <ul style="list-style-type: none"> <li>■ difficulty with an input, route or output.</li> <li>■ one or more RF inputs, or the ASI input are not synchronized.</li> <li>■ one or more ASI outputs are routed, but muted by a fault condition.</li> <li>■ no RF signal is present or detected, or it is muted.</li> <li>■ receiver is not authorized to receive the program.</li> </ul> |
|        | Off                | Off indicates all of the following conditions: <ul style="list-style-type: none"> <li>■ no RF input signal is available, enabled or detected, or the input is muted.</li> <li>■ no ASI input is present</li> <li>■ no valid inputs are available.</li> </ul>   |

## Navigation/Selection Keypad






Throughout this manual, there are references to parts of a keypad on the front of the receiver.

The navigation keys (**LEFT**, **RIGHT**, **UP**, and **DOWN**) and the **SELECT** key are the primary controllers. Each navigation key performs various functions, depending on the current state of the menu system (i.e., sometimes the left navigation key backspaces over an entry and sometimes moves the cursor to a different menu item). Once the cursor is over the desired function, pressing the **SELECT** (center key) key selects the current item. Pressing the **SELECT** key stores any entered values.

The following is the Navigation/Selection keypad, which changes its function, depending on the current state of the menu.




The following table shows which parts of this integral interface are being referenced by which term.

| Button          | Function  |  |
|-----------------|---|--|
| LEFT Arrow key  | When moving through menus, highlights the menu item to the left. When entering data, moves the cursor to the left. In some menus, backspaces over the data entry. |   |
| RIGHT Arrow key | When moving through menus, highlights the menu item to the right. When entering data, moves the cursor to the right.  |   |
| UP Arrow key    | Highlights the menu item above.   |  |
| DOWN Arrow key  | Highlights the menu item below.   |  |
| SELECT key      | Runs the highlighted command or opens the highlighted menu.   |  |



| Button             | Function   |
|--------------------|--|
| INFO key           | <p>Press the key on the lower left of the numeric keypad for context-sensitive help messages, when available.</p> <p>When entering characters in numeric or alphanumeric fields, this key can be used to toggle between upper and lower case.</p>  |
| MENU key           | <p>Press the key on the lower right of the numeric keypad. Starts the on-screen display. Also functions as the Escape key so you can back out of menus and data entry fields.</p>  |
| Alphanumeric Entry | <p>Pressing the numeric keys 2-9 once will enter the respective digit into a data entry field. Pressing these buttons again will enter the first of the letters displayed beside the number. Repeatedly pressing the button will toggle through all of the key's possible choices. When entering text, the 1 button can be used to insert spaces (press twice).</p> <p>To delete a character, press 0 twice.</p> |
| ADV                | Toggles between Program Entry and Channel number.  |
| MAP                | Edit, insert, and delete Digital Program Mapping (DPM) Modes on Program Entries or on PIDS within Program Entries.   |
| NAV                | For future use.  |



## Locking/Unlocking the Front Panel

Depending on the customer's default settings, the receiver is shipped with a locked or unlocked front panel. You can lock or unlock the front panel using the front panel keypad.

- 1 From the Startup screen, press **SELECT** and then **INFO**. This will unlock the front panel keypad and allow you to make changes to all the operating parameters; however, if the keypad remains untouched for the duration of the set timeout period (default is 60 seconds), the keypad will change back to the Lock state unless you change the keypad state on the Admin Menu. Likewise you can toggle the keypad lock state back using **SELECT** and **INFO** at any time provided the KB Lock state on the Admin Menu is Enabled. For more information on front panel keypad buttons, see Keypad Convention.

**Note:** If the lock level is 3 or 4, you must enter a password to unlock the front panel. For more information on lock level password, see *Setup Menu: Admin* (on page 58).

- 2 To disable Lock completely, navigate to **Setup, Admin, KB Lock** in the LCD display and press the **SELECT** key.
- 3 Change the **KB Lock** state from **Enabled** to **Disabled**.
- 4 The front panel will now be unlocked allowing you to change any of the operating parameters.

To lock the front panel, perform the same procedure, except use **▲▼** to change the state. In this case you will not be prompted to confirm the operation.

## Startup Screen

### Main Structure

On power-up and initialization, the startup screen is displayed similar to that shown below. The screen also indicates the signal status.

|  |                                     |
|--|-------------------------------------|
| PE1 ◆12345 Channel Name<br>RF1 Freq:12.658 Lvl:-50 Marg:11.6 | PE: 1<br>Auth:Y                     |
| Startup Screen   | Channel Authorization Status Screen |

### Channel Authorization Status

From the startup screen, press the right or left arrow keys on the front panel keypad to move to the PE entry authorization status screen. This screen indicates whether the selected channel is authorized.

| Auth Status | Description                              |
|-------------|--|
| Y           | Indicates the channel is authorized.     |
| N           | Indicates the channel is not authorized. |

### LCD Panel

The LCD panel displays basic signal and program information in the LCD display, as described in the following illustration:


|                                    |   |
|------------------------------------|---|
| PE1◆12345 Channel Name             | ⏏ |
| RF1 Freq:12.658 Lvl:<-70 Marg 17.2 |   |

| LCD Setting | Description  |
|-------------|--|
| PE          | <p>Program Entry (PE). The receiver supports up to 16 program entries.</p> <p><b>Note:</b> Only PE1 supports PowerVu descrambling. Do not assign PowerVu channels to PE2 to PE16. If any PowerVu channels are assigned to PE2 to PE16, all Service PIDs associated with these channels will be dropped from the transport output.</p> <p>All 16 PEs can use the Conditional Access Modules (CAMs).</p> |
| 12345       | Channel for program monitoring.  |

| LCD Setting  | Description  |
|--------------|--|
| Channel name | Name of the monitored program.   |
| RF           | Active RF input port.<br><b>Note:</b> ASI will be shown if the ASI input port is active.   |
| Freq:        | Downlink frequency of the tuned signal in GHz.   |
| Lvl:         | Signal level in dBm.   |
| Marg:        | Carrier-to-noise (C/N) margin in dB.   |
| DEGD         | The Degraded indicator only appears if there is degraded tuning information in use. This occurs if the SI tables are not consistent on the incoming stream. The receiver will attempt to identify the service list based on the information available. Check the SI acquisition and stream information to ensure that the channels, network, and tuning information are operating as expected. |

## LCD Symbol

Various symbols will periodically appear in the top right-hand corner of the LCD panel, indicating which user actions are currently acceptable. The following displays the location of the symbol:



The following table describes the various symbols:

| LCD Symbol | Description   |
|------------|---|
| ⌚          | The Hourglass indicates that parameters are being saved in the background. You can continue to perform any operation desired.<br><b>Note:</b> If a power-cycle/interruption occurs while the hourglass is displayed, some parameters may not be saved. Refrain from powering off the unit while the hourglass is displayed. |
| ℹ          | The Info symbol indicates that the INFO key is active. In most cases, this will display contextual information on the LCD screen.   |
| Ⓢ          | The Select symbol indicates that the SELECT key is active.  |

| LCD Symbol | Description  |
|------------|--|
| ◀▶         | The Left/Right symbol indicates that the RIGHT/LEFT arrow key is active; e.g., pressing the RIGHT/LEFT arrow key will have an affect, such as moving the cursor to the right/left.   |
| ▲▼         | The up/down symbol indicates that the UP/DOWN arrow key is active.   |
| DL         | The Download In Progress (DL) symbol indicates that the receiver is currently downloading a software update and storing it into memory in the background.<br><b>Note:</b> Service interruption occurs during a reboot, which is always required when the receiver's software is updated.       |
| DT         | The Download Trigger (DT) symbol indicates new software is ready for download, but a download trigger by the receiver is required before it will be downloaded.<br><b>Note:</b> Service interruption occurs during a reboot, which is always required when the receiver's software is updated. |
| D          | The Download symbol indicates that a software download for a version of software already in memory has been detected.  |
| *          | The Session Open symbol indicates that you are changing a group of related items.  |

## Assigning Program to the Program Entry

- 1 Press MENU until you display the startup screen.


PE # Ch #  
 ↓ ↓  
 PE1♦706 Channel Name  
 RF1 Freq:12.658 Lvl:-50 Marg:11.6

The PE (Program Entry) channel is initially displayed.


**Note:** PE1 is the default.

## Chapter 4 Front Panel Operation

- 2 Press the **ADV** key to select PE1.




- 3 Press **▲▼** to scroll through the available program entries.
- 4 Press **ADV** again to select the channel number.



- 5 Directly enter the channel number using the 0 to 9 keys and press **SELECT** to apply the channel number, or press **▲▼** to scroll through the available channels.

### Deleting a Program from the Program Entry


- 1 Press **MENU** until the startup screen appears.



The PE channel is initial displayed.

**Note:** PE1 is the default.

- 2 Press the **ADV** key to select PE1.



- 3 Press the **▲▼** to scroll through the available program entries.
- 4 Press **ADV** again to select the channel number.
- 5 Enter the channel number 0 with the numeric keys and press **SELECT** to apply and delete the program.


## Main Menu

Operation of the D9854 receiver begins at the Main menu. From the startup screen, press the **MENU** key to view the Main menu.



## Main Selection

Select the desired function by moving the cursor left or right by pressing the **LEFT** or **RIGHT** arrow key. Once a selection is made by pressing the **SELECT** key, the LCD presents the second menu level for the selected function. Succeeding levels for each function include all the hierarchical levels for the function in the front panel LCD. For example, the TS Input level is shown as Main: Setup: TS Input, with each succeeding level separated by a colon (:), as shown in the example below. The front panel menus are described on the following pages.




# Status Menu

## Structure

To view the Status menu from the Main menu, press the **SELECT** key. The Status menu indicates the status of the input and output signals, the video and audio services, and allows you to browse and/or configure the alarms and warnings.

The Status menu is split into four parts; General, Services, TS Input and TS Output. Each parameter is described in this section. For instructions on how to select and store settings, see *About the Front Panel* (on page 38).

The Status menu has the following structure:





**Status Menu: General**

| <b>Menu Item</b> | <b>Description</b>  | <b>Parameters</b>   |
|------------------|---|---|
| Input            | Indicates the currently selected input source.                                | RF1 to RF4, or ASI  |
| Status           | Indicates whether the input signal is locked.                                 | Locked - Indicates the receiver is locked to a carrier with no valid content.<br>Lock+Sig - Indicates the receiver is locked to a carrier with valid content.<br>No Lock - Indicates the receiver is not locked to a carrier. |
| Rate (Mbps)      | Indicates the bit rate of the input transport stream, in Mbps.                |   |
| Level (dBm)      | Indicates the strength of the received signal level, in dBm.                  |   |
| PE               | Select the Program Entry to view.   | PE1 to PE32   |
| Mode             | Indicates how the program is scrambled.                                       | Unkn, DES, DVB, BISS1, BISS2, or BISS3  |
| Auth             | Indicates whether the receiver is authorized to receive the program.          | Yes or No   |
| Enc              | Indicates whether the received program is encrypted.                          | Yes or No   |
| Scr              | Indicates whether the received program is scrambled.                          | Yes or No   |
| CA System        | Indicates the type of Conditional Access (CA) system used by the program.     | SA, BISS, or FTA (Free To Air)  |
| Video            | Indicates the video encoding, format, and resolution of the received program. | MPEG1, MPEG2, or H264 format with a resolution of:<br>SD480i/2997, SD480i/3000, SD576i/2500, HD720p/5000, HD720p/5994, HD720p/6000, HD1080i/2500, HD1080i/2997, or HD1080i/3000<br><br>Unknown or Unsupported                 |
| Rate (Mbps)      | Indicates the bit rate of the received video stream, in Mbps.                 |   |
| Alarms           | Displays the number of active alarms.   |   |
| Warnings         | Indicates the number of active warnings.                                      |   |

## Chapter 4 Front Panel Operation

| Menu Item                  | Description   | Parameters  |
|----------------------------|---|---|
| Browse                     | Select to view the current active alarms and warnings, including additional details.  |   |
| Clear All                  | Select to clear all the active alarms and warnings. You will be prompted to verify whether you want to clear all the alarms and warnings.                                     | Abort, Continue. Select Abort to cancel the operation or Continue to clear all the warnings and alarms. |
| Current Date and Time      | Displays the current SNTP date and time, if available. Otherwise, the current TDT date and time is displayed.<br><b>Note:</b> This is displayed as local time.                |   |
| Current TDT Date and Time  | Displays the current TDT (Time and Date Table) date and time received from the DVB stream.<br><b>Note:</b> This is displayed as local time.                                   |   |
| Current SNTP Date and Time | Displays the current SNTP (Simple Networking Time Protocol) date and time if IRD receives a valid reply from the NTP server.<br><b>Note:</b> This is displayed as local time. |   |

## Status Menu: Services

### Video

| Menu Item    | Description   | Parameters  |
|--------------|---|---|
| Video        | Indicates the video encoding, format, and resolution of the received program.                                     | MPEG1, MPEG2, or H264 format with a resolution of: SD480i/2997, SD480i/3000, SD576i/2500, HD720p/5000, HD720p/5994, HD720p/6000, HD1080i/2500, HD1080i/2997, or HD1080i/3000<br>Unknown, or Unsupported |
| Rate (Mbps)  | Indicates the bit rate of the received video stream, in Mbps.   |   |
| 3:2 Pulldown | Indicates whether the 3:2 pulldown is detected, was recently detected, or not detected in the input video stream. | Yes, No or Recent   |

## Status Menu

| Menu Item | Description  | Parameters   |
|-----------|--|--|
| FPS       | Indicates the frame rate of the input video stream.      | Typically 25.0, 29.97, 30.0, 50.0, 59.94, 60.0, unknown or unsupported |
| Stream AR | Indicates the aspect ratio of the incoming video stream. | 4:3, 14:9 or 16:9  |
| Act Conv  | Displays the actual applied aspect ratio conversion.     | None, 4:3 L/B, 4:3 P/B, 14:9, 14:9, 4:3 F/H or 16:9 F/W                |

## Audio

| Menu Item     | Description   | Parameters  |
|---------------|---|---|
| AUD           | Indicates the current audio decoder status.   | AUD1 for audio channel Aud1.<br>AUD2 for audio channel Aud2.<br>AUD1 to AUD4 for two stereo audio channels.         |
| Format        | Indicates the format of the audio input stream.   | None, Sine, Pink, Beep, MPEG1L1, MPEG1L2, MPEG2L1, MPEG2L2, AC3, LOAS AAC, ADTS AAC, LOAS HEAAC, ADTS HEAAC, or DDP |
| BR (Kbps)     | Indicates the bit rate of the audio input stream, in kbps.  |   |
| Buffer        | Indicates the buffer level of the input audio stream, in bytes.   |   |
| SFR (KHz)     | Indicates the sample rate of the input audio stream, in kHz.  | 32.0, 44.1, or 48.0 kHz   |
| DDP IND       | Indicates the presence of Dolby Digital Plus frames within a Dolby Digital Plus audio stream.   | OFF or ON   |
| DUAL-MONO IND | Indicates the presence of dual mono audio outputs in the audio stream. If the dual mono indicator is set to ON, the left and right outputs will correspond to mono channel 1 and mono channel 2 respectively. | OFF or ON   |

## Status Menu: TS Input

### Input

| Menu Item       | Description   | Parameters  |
|-----------------|---|---|
| Input           | Indicates the active input port receiving the signal.   | RF1, RF2, RF3, RF4, or ASI  |
| Status          | Indicates the current signal lock status for the input.   | Locked - Indicates the receiver is locked to a carrier with no valid content.<br>Lock+Sig - Indicates the receiver is locked to a carrier with valid content.<br>No Lock - Indicates the receiver is not locked to a carrier. |
| Rate (Mbps)     | Indicates the bit rate of the received input signal.  | in Mbps   |
| Level (dBm)     | Indicates the signal level of the received signal.  | in dBm  |
| SymRate         | Indicates the Symbol Rate of the received signal.   | in Msymbols/second  |
| FEC             | Indicates the FEC (Forward Error Correction) rate of the received signal.   | N/A, 1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 7/8, 8/9 or 9/10   |
| Modulation      | Indicates the modulation type for the received signal.  | N/A, QPSK, 8PSK, DVB-S, DVB-S2 or 16QAM   |
| Pol             | Indicates the signal polarization setting. This setting is only applicable when LNB Power is set to H-NIT or V-NIT. The selected setting must match the polarization of the transmitted signal. | Horiz (Horizontal), Vert (Vertical) or Auto   |
| IQ Tuner        | Indicates the IQ (Input Signal Inversion) for the received signal.  | Inv or NonInv   |
| IQ Status       | Indicates the input signal spectrum inversion setting (IQ), which allows the operator to track and select inverted and non-inverted digital signals.  | Auto, Opposite, or Normal   |
| Dnlk Freq (GHz) | Indicates the current downlink frequency.   | in GHz  |
| L-Band          | Indicates the current L-Band frequency.   | in MHz  |

## Status Menu

| Menu Item       | Description   | Parameters   |
|-----------------|---|--|
| Pilot Present   | Indicates whether a Pilot is present for the received signal. The Pilot is set on the modulator for input signal synchronization purposes.                      | Yes, No, or N/A  |
| C/N (dB)        | Indicates the current Carrier-to-Noise ratio.   | in dB  |
| C/N Margin (dB) | Indicates the current Carrier-to-Noise Margin for the received signal. The Carrier-to-Noise margin is the actual distance that C/N is from the noise threshold. | Values can be displayed in the range of -32.0 to +30.0 dB. |
| PER             | Indicates the current PER (Packet Error Rate) of the received signal (DVB-S2).  |  |
| PVBER           | Indicates the PV (Post-Viterbi) BER for the received signal (DVB-S).  |  |
| LDPCBER         | Indicates the LDPC (Low Density Parity Check) error rate for the received signal (DVB-S2).  |  |
| AFC (MHz)       | Indicates the current Automatic Frequency Control count.  | in MHz   |
| UEC             | Indicates the current Uncorrected Error Count for the received signal.  |  |
| CEC             | Indicates the current Corrected Error Count for the received signal (DVB-S).  |  |
| Clear Counts    | Select this option to clear the error counters.   |  |
| ASI Link        | Indicates whether there is a transport stream link error.   | Error, Ok, or N/A  |
| Transport       | Indicates the current transport synchronization status.   | Error, Ok, or N/A  |
| Packet Size     | Indicates the packet size (in bytes) for the ASI input.   | 188, 204, or N/A   |
| Net Name        | Indicates the name assigned to the network.   | Up to 12 alphanumeric characters.                          |

## Chapter 4 Front Panel Operation

| Menu Item | Description   | Parameters   |
|-----------|---|--|
| NetID     | Indicates the Network ID of the uplink signal the receiver is to receive when using the selected preset. The receiver's Network ID must match the Network ID associated with the transmitted signal that identifies the NIT to be used.<br><b>Note:</b> Each network must be assigned a unique ID (number). | 1 to 65535   |
| TxID      | Indicates the Transport ID.   | 1 to 65535   |
| LNB Stat  | Indicates the current Low Noise Block (LNB) connection status.  | No Load, Over Loaded, Over Temperature, Short Circuit, Disabled, Normal or N/A |
| Polar     | Indicates the polarity of the LNB Power supply.   | Off, 13V, or 18V   |
| LO Select | Indicates whether a 22 kHz tone is available on input port RF1. This is applicable for dual-band applications.  | On or Off  |

### Program PIDs

| Menu Item | Description  | Parameters   |
|-----------|--|--|
| PE        | Select the Program Entry to view.                                      | PE1 to PE32  |
| Stream    | Indicates the name assigned to the Program Entry.                      | Up to 4 alphanumeric characters  |
| Detail    | Indicates any detail associated with the program PID (e.g., MPG2 PID). | MPG1 VID, MPG2 VID, 422 VID, H264 VID, HD VID, MPG4 VID, MPG AUD, MPG2 AUD, DVB AC3, DVB DDP, AAC AUD, HEAAC, AUD, MPG4 AUD, DBE AUD, DTS AUD, DVB TXT, DVB VBI, DVB SUBT, DVB ASYN, DVB SYNS, DVB SYND, DVB MPE, DVB DCAR, DVB OCAR, SA VBI, ATSC AC3, ATSC DDP, SA UTLD, SCTE DPI, SA HSD, SA CDDL, SA WBD, SA SUBT, ECM, EMM, PCR, or UNKNOWN |
| PID       | Indicates the program PID number.                                      | 1 to 8191  |
| Present   | Indicates whether the PID is present in the incoming stream.           | Yes or No  |

## Status Menu: TS Output

### Output Status

| Menu Item   | Description  | Parameters     |
|-------------|--|----------------|
| Output      | Indicates the output type.                                     | ASI or MPEGoIP |
| Rate (Mbps) | Indicates the current output bit rate.                         | 0 to 213 Mbps  |
| Free (Mbps) | Indicates the available bandwidth, in Mbps (without stuffing). |                |

## Program Status

| Menu Item | Description   | Parameters  |
|-----------|---|---|
| PE        | Select the Program Entry number to view.  | PE1 to PE32   |
| SR Status | This displays the status of an alternate authorized program/service from the same transport stream when the receiver is not authorized to view the primary program. This is an uplink initiated function that maps the alternate service to the original (primary) service PIDs, replacing the original service with the alternate service at the digital transport output. No local intervention is required by the receiver operator for provision of this service replacement feature. | <p>Not Started - Indicates that an event has not started.</p> <p>Primary - Indicates that a service replacement event is active, but the primary program is being displayed.</p> <p>Alternate - Indicates that a service replacement event is active, and that the receiver has tuned to and is displaying the alternate program/event as it is not authorized to view the scheduled event.</p> |

## Chapter 4 Front Panel Operation

| Menu Item      | Description  | Parameters  |
|----------------|--|---|
| SR Event Type  | Indicates the type of service replacement event.   | <p>None - Indicates that no service replacement event is scheduled.</p> <p>Scheduled - Indicates that all receivers will tune to the alternate program at the scheduled time. This setting is only applicable to current PE1 (i.e., PowerVu) programs; not PE2 through PE32.</p> <p>CA - Indicates that only receivers unauthorized to view the scheduled program will tune to the alternate program according to the selected authorization tier bits. This setting is only applicable to current PE1 (i.e., PowerVu) programs; not PE2 through PE32.</p> <p>Cue Trigger - Indicates that only receivers authorized by the Cue Trigger mask will tune to the scheduled program/event. Cue triggers can only be initiated /controlled on PE1 (i.e., PowerVu).</p> |
| SR Event Start | Displays the start time of the service replacement event when one is scheduled; otherwise, the default start time is displayed. The default start time is 2007/09/01 00:00:00. |   |
| SR Event End   | Displays the end time of the service replacement event when one is scheduled; otherwise, the default end time is displayed. The default end time is 2007/09/01 00:00:00.       |   |



# Setup Menu

## Structure

To view the Setup menu from the Main menu, press the **RIGHT** arrow key once and the **SELECT** key. The Setup menu is split into nine parts; Administration, TS Input, IP, Services, CI, Outputs, CA, Alarms/Warnings, and Noise Cutoff. For instructions on how to select and store settings, see *About the Front Panel* (on page 38).

The Setup menu allows you to set all the parameters associated with the following:

- Administration - lock level, password, factory reset, keypad lock, download mode and date and time
- TS Input - frequency parameters for acquiring and locking on to an RF signal, or receiving an ASI input
- IP - parameters for setting up the Ethernet ports
- Services - audio video, captions, and VBI
- CI - parameters to decrypt programming available from service provider programmers via CAM Smart Cards
- Outputs - alarm relays, cue tone/cue trigger setup, parameters for setting up the transport stream out, which includes DPM
- CA - conditional access
- Alarms/Warnings - enables alarms/warnings traps and relays
- Noise Cutoff - muting thresholds

The Setup menu has the following structure:




## Setup Menu: Admin

To view the Admin menu from the Main menu, press the **SELECT** key.

For instructions on how to select and store settings, see *About the Front Panel* (on page 38).

The Admin menu has the following structure:



| Menu Item  | Description  | Parameters       |
|------------|--|------------------|
| Lock Level | Sets the front panel interface lock level.<br><br>For information on each of the lock levels, see <i>D9854 Receiver Lock Levels</i> (on page 302). | 0, 1, 2, 3, or 4 |
| Password   | Enter the password to successfully set the current lock level. The default password for all lock levels is 1234.                                   |                  |

| Menu Item                     | Description  | Parameters  |
|-------------------------------|--|---|
| Old Pwd, New Pwd, Confirm Pwd | To change the password, enter the old password (Old Pwd). Next, enter the new password (New Pwd, four digits in the range from 0000 to 9999) and re-enter the new password for confirmation (Confirm Pwd). To change the password, the receiver must be in Lock Level 0. The default password is 1234. |   |
| Factory Reset                 | Select this option to perform a reset of receiver settings back to the factory set (default) values. A warning message prompts you to confirm the operation.   | Reboots Unit - you are prompted to verify the operation.<br>Abort or Continue |
| Clear FWD tables              | Select to clear settings that are only used in older applications. Reverting back to an older application will revert to the default values of the cleared settings. A warning message prompts you to confirm the operation.   | Abort or Continue   |
| Reboot                        | Allows you to reboot the receiver. You will be asked to confirm the operation.   | Select Continue to reboot the receiver or Abort to cancel the operation.      |
| KB Lock                       | Select whether to lock the front panel keypad after a time of disuse.  | Enabled or Disabled   |
| KB Lock Timeout               | If KB Lock is enabled, you can set the keypad lock timeout period, in seconds. The keypad will lock after the set period of disuse. Avoid setting the period to a short duration when the keypad is used often.  | 5 to 1800 seconds. The default is 60 seconds.                                 |
| LCD Contrast                  | Adjusts the contrast of the LCD menu panel.  | 1 (lowest contrast) to 30 (highest contrast)                                  |

## Chapter 4 Front Panel Operation

| Menu Item             | Description  | Parameters   |
|-----------------------|--|--|
| DL Mode               | Set the unforced over-the-air download mode.   | <p>Always - Unforced download will be accepted and saved in memory.</p> <p>Once - An unforced download will be accepted, followed by a reboot of the receiver, and the DL Mode will change to Never.</p> <p>Never - Unforced downloads will not be accepted.</p> <p><b>Note:</b> Forced downloads (initiated by the uplink) are always accepted and always result in a reboot of the receiver. <i>Service interruption will occur!</i></p> |
| Limit Version         | Indicates the oldest version of the application that can be installed on the current unit. Older applications will not be installed. | Read-only alphanumeric value   |
| DL Status, Type, Bank | Indicates the DL Mode status, type and bank (i.e., type of code).  | <p>DL Status - Idle, Running, Timeout. Idle indicates the receiver is waiting for a download. Running indicates the receiver is processing a download. Timeout indicates the receiver didn't complete the download.</p> <p>Type - None, Rear Panel, HTTP or Over Air.</p> <p>Bank - App 5514, App 7109, FPGA 7109, Sat 7109, Screen logo, Menu Logo, Eth Logo, App PPC, PowerPC, DB Update or Exec Bin.</p>                                |
| CDT#                  | Indicates the total number of expected code tables in the current download.  | Read-only numeric value.   |
| Recv                  | Displays the number of code tables received since the last completed or aborted download, or power-cycle.                            | Read-only numeric value.   |


| Menu Item   | Description  | Parameters   |
|-------------|--|--|
| Reject      | Displays the number of code tables rejected. Tables are rejected whenever validation fails due to things like CRC failure or incorrect code or receiver type.  | Read-only numeric value.   |
| Command     | Select a command to issue to the current download.   | Restart, Abort or None. Abort stops a download that is currently being received. Restart restarts a previously aborted download. Note that the download does not resume from where it was aborted, but restarts from the beginning. None means no action is to be performed. |
| Date Format | Select the date format.  | YYYY_MM_DD, DD_MM_YYYY, or MM_DD_YYYY  |
| Time Format | Select the time format.  | 24Hr, 24Hr SuspendZero, 12Hr, 12Hr SuspendZero. The SuspendZero options omit the leading zero.   |
| GMT Off     | Select the local time zone offset relative to the GMT time. The time information in the transmitted stream is broadcast as GMT time and changing this setting will allow the unit to correctly display the local time. | +13:00, +12:00, +11:00, +10:00, +09:30, +09:00, +08:00, +07:00, +06:30, +06:00, +05:45, +05:30, +05:00, +04:30, +04:00, +03:30, +03:00, +02:00, +01:00, GMT, -01:00, -02:00, -03:30, -04:00, -05:00, -06:00, -07:00, -08:00, -09:00, -10:00, -11:00, -12:00                  |

## Setup Menu: TS Input

To view the TS (Transport Stream) Input menu from the Main menu, press the **RIGHT** arrow key once and then the **SELECT** key to reach the Setup menu. Then press the **RIGHT** arrow key once and the **SELECT** key to view the TS Input menu.

For instructions on how to select and store settings, see *About the Front Panel* (on page 38).

The TS Input menu has the following structure:



### ASI Input

| Menu Item  | Description   | Parameters   |
|------------|---|--|
| ASI Active | Select whether to tune to the ASI input.<br><b>Note:</b> Setting a new input to be active will deactivate the currently active input. | Act or No  |
| Tune Mode  | Select the tables required for the service list creation and signal acquisition.  | Basic - Requires NIT to be present.<br>Auto - Uses all the available service list tables and it will acquire if any table is present.<br>Custom - Uses the Custom Tuning parameters, specified by the user.<br>The default is Basic. |

## Setup Menu

| Menu Item | Description  | Parameters   |
|-----------|--|--|
| CA Ctl    | Sets how the conditional access will attempt to descramble the scrambled programs. The behavior of this setting is different between PowerVu streams and those that require a CAM. | <p>For PowerVu streams:</p> <p>Std - In standard mode, if a program is not authorized, even if some services are not scrambled, the whole program will not be authorized.</p> <p>Open - In open mode, if a program is not authorized, any services in the program that are not scrambled will still be available.</p> <p>For Non-PowerVu (CAM) streams:</p> <p>Std - In standard mode, if a program's CA system is not supported by the CAM, the channel is not authorized.</p> <p>Open - In open mode, all the program's CA systems are validated by the CAM. The channel is always authorized.</p> |
| Select    | This sets the parameters the receiver uses for signal switching.   | RF Map or Preset. RF Map uses the orbital positioning settings to find and lock onto a signal, while it can be ignored for Preset.   |

### RF1, RF2, RF3, RF4 (RFx) Input

| Menu Item                       | Description   | Parameters  |
|---------------------------------|---|---|
| RFx Active (RF1, RF2, RF3, RF4) | Select the input to be active.<br><b>Note:</b> Setting a new input to be active will deactivate the currently active input.   | Act or No   |
| Tune Mode                       | Select which tables are required for the service list creation and signal acquisition.<br><b>Note:</b> When editing the tuning, the device is in a transient state while acquiring tuning information and channel lists, etc. The receiver reverts to the previous set of tuning settings/information and channels until these changes are either saved or abandoned. | <p>Basic - Requires NIT to be present.</p> <p>Auto - Uses all the available service list tables and it will acquire if any table is present.</p> <p>Custom - Uses the Custom Tuning parameters, specified by the user.</p> <p>The default is Basic.</p> |

## Chapter 4 Front Panel Operation

| Menu Item | Description  | Parameters   |
|-----------|--|--|
| CA Ctl    | Sets how the conditional access will attempt to descramble the scrambled programs. The behavior of this setting is different between PowerVu streams and those that require a CAM. | <p>For PowerVu streams:</p> <p>Std - In standard mode, if a program is not authorized, even if some services are not scrambled, the whole program will not be authorized.</p> <p>Open - In open mode, if a program is not authorized, any services in the program that are not scrambled will still be available.</p> <p>For Non-PowerVu (CAM) streams:</p> <p>Std - In standard mode, if a program's CA system is not supported by the CAM, the channel is not authorized.</p> <p>Open - In open mode, all the program's CA systems are validated by the CAM. The channel is always authorized.</p> |
| Select    | Sets the method used by the RF tuner to determine which input to use when switching transports.  | <p>UserCfg - User configuration will only use the active RF input.</p> <p>SW Map - Software map uses the orbital position settings from each input and map it to those in the NIT.</p>   |
| LO1 (GHz) | Sets the lower oscillator frequency, in GHz, of the LNB. In a single band oscillator, set its frequency, in GHz.   | 0.0 to 15.0 GHz. Must be lower than the value for LO2.   |
| LO2 (GHz) | Sets the higher oscillator frequency, in GHz, of the LNB. In a single band oscillator, set this value to 0.0.  | 0.0 to 15.0 GHz. Must be higher than the value for LO1.  |



## Setup Menu

| Menu Item                 | Description   | Parameters  |
|---------------------------|---|---|
| Crossover (GHz)           | This is the crossover frequency, which is an internal threshold frequency used for selecting the LO1 or LO2 frequency, depending on the current Downlink frequency settings. This option is only used in dual-band LNB applications.  | 0.0 to 15.0 GHz. In single-band LNB applications, set this value to 0.0.  |
| Satellite                 | This is the name of the satellite currently selected. Choose the satellite you want to use to receive the signal from the list of satellites available. When you select a satellite, the orbital position (OrbPos) is displayed. This is important for automatic switching from one RF input to another in the event of loss of the signal, allowing the receiver to acquire an alternate signal.   | When the satellite is not listed, enter the known orbital position (OrbPos) of the satellite you want to use to receive the signal. |
| OrbPos                    | <p>This is the location in orbit of the satellite currently being used. The satellite position (in degrees) in combination with the direction (either <b>E</b> (East) or <b>W</b> (West)) denotes the satellite position the dish connected to the current RF Input should point. This is used when the satellite is not available in the look-up menu list.</p> <p>For manual configuration, simply enter the location of the satellite using the numerical keypad. The receiver will not recognize the satellite name and identify it as Unknown. This setting is required to resolve any ambiguity between RF inputs during automatic disaster recovery.</p> | Degrees   |
| E/W                       | Denotes the satellite position the dish connected to the current RF Input should point. This is used when the satellite is not available in the look-up menu list.  | E, W or NA  |
| Pol                       | Marks the polarity of the signal connected to this RF input.  | H (horizontal), Vert (vertical), A (Auto). Auto is only applicable when LNB Power is set to H-NIT or V-NIT.                         |
| Validate Orbital Position | This option allows you to configure and validate the RF inputs to match those expected by the network. The receiver will check to see if all the frequencies in the Network Information Table (NIT) can be tuned to.  | Yes or No   |

## Chapter 4 Front Panel Operation

| Menu Item                        | Description  | Parameters   |
|----------------------------------|--|--|
| Orbital Position Validation Date | This displays the last date that the 'Validate Orbital Position' operation was performed.  | N/A  |
| Freq (GHz)                       | This is the current Downlink operating frequency used by the receiver for tuning the received digital signal.  | 0.0 to 15.0 GHz  |
| SymRate                          | This is the symbol rate. The symbol rate must match that of transmitted signal.  | 1.0 to 45.0 Ms/s for DVB-S.<br>1.0 to 30.0 Ms/s for DVB-S2 if Pilot Present is set to Yes.<br>5.0 to 30.0 Ms/s for DVB-S2 if Pilot Present is set to No.   |
| FEC                              | Select the Forward Error Correction inner code rate. The FEC must match the FEC of the transmitted signal.   | 1/2, 2/3, 3/4, 5/6, 7/8, or Auto   |
| L-Band                           | This is the L-Band operating frequency used by the receiver. This value is determined by the values set in the Freq and LO options.  | 950 to 2150 MHz  |
| RF Lock                          | Indicate whether the tuner has locked onto the Radio Frequency signal with the current settings.   | Lock or NoLock   |
| Modulation                       | Sets the modulation type for the received signal.  | DVB-S or DVB-S2  |
| Rolloff                          | Sets the rolloff factor of the incoming signal.  | .20, .25, .35. Use .20 or .35 when DVB-S modulation is used, and either of the three when DVB-S2 is used. Use a small number to reject or filter carriers close to the same frequency.           |
| InputIQ                          | Select the Input signal spectrum inversion setting, which allows the operator to track and select inverted and non-inverted digital signals. This is normally used to automatically reject or filter out unwanted signals. | Auto, Normal, or Opposite.<br>Auto - The signal is tracked and inverted for correct selection, as required.<br>Opposite - The signal is always inverted.<br>Normal - The signal is not inverted. |

## Setup Menu

| Menu Item | Description  | Parameters  |
|-----------|--|---|
| NetID     | Select the Network ID of the uplink signal the receiver is to receive. The receiver's Network ID must match the Network ID associated with the transmitted signal. | 1 to 65535. The default value is 1.   |
| LNB Power | Set the power output of RF1 to the external LNB.   | Off, 13V, 18V, V-NIT, or H-NIT.<br><br>V-NIT and H-NIT will use vertical and horizontal polarity until it is automatically read from the NIT.<br><br><b>Note:</b> Power will not be applied to the LNB when set to Off. |
| 22kHz     | For dual band applications, select whether to transmit the 22 kHz tone Local Oscillator control signal of RF1.   | On, Off, or Auto.<br><br>Auto uses the crossover frequency to determine if the tone is transmitted.   |

## Tune Mode

### Custom

This menu is where you set up your custom properties. Select the channel to set up and then edit it.

| Menu Item          | Description  | Parameters   |
|--------------------|--|--|
| Services List Mode | If using custom tune mode, select which tables are required for tuning.  | Degraded or Rigorous.<br><br>Rigorous - Requires all service list tables to be present to acquire the signal.<br><br>Degraded - Requires any service list table to be present to acquire the signal. |
| BAT                | This is not supported in the current release.  | No   |
| NIT                | If using custom tune mode, select whether to use the Network Information Table (NIT) when creating the service list. | Yes or No  |

## Chapter 4 Front Panel Operation

| Menu Item        | Description  | Parameters   |
|------------------|--|--|
| SDT              | If using custom tune mode, select whether to use the Service Description Table (SDT) when creating the service list.                         | Yes or No  |
| PAT              | If using custom tune mode, select whether to use the Program Association Table when creating the service list.                               | Yes or No  |
| Frequency Tuning | If using custom tune mode, select whether to use the NIT to tune to other transports, or to force the tuning to user configuration settings. | NIT or User Cfg.<br>NIT - The receiver can change tuning parameters to use all transports available in the NIT.<br>User Cfg - The receiver is forced to use the user selected tuning parameters. |

### Status

| Menu Item         | Description   | Parameters           |
|-------------------|---|----------------------|
| Service List Mode | Indicates if all the expected service list tables are present (Rigorous) or only some of the service list tables are present (Degraded) | Degraded or Rigorous |
| BAT               | This is not supported in the current release.   | No                   |
| NIT               | Indicates whether the Network Information Table (NIT) is being used to create the service list.   | Yes or No            |
| SDT               | Indicates whether the Service Description Table (SDT) is being used to create the service list.   | Yes or No            |
| PAT               | Indicates whether the Program Association Table (PAT) is being used to create the service list.   | Yes or No            |
| Frequency Tuning  | Indicates whether tuning is using the NIT to tune to other transports, or whether tuning is forced to use the user selected parameters. | NIT or User Cfg      |

## Re-Acquire

| Menu Item  | Description  | Parameters  |
|------------|--|---|
| Re-Acquire | Re-acquires the signal using the tuning parameters from user settings. | Abort or Continue. Select Abort to cancel the operation or choose Continue to complete the operation. |


## Setup Menu: IP

To view the IP menu from the Main menu, press the **RIGHT** arrow key once and then the **SELECT** key to reach the Setup menu. Then, press the **RIGHT** arrow key twice and the **SELECT** key to view the IP menu.

The IP menu allows you to set the parameters for communicating with other equipment via the Ethernet Data and Management ports for MPEGoIP and MPE applications and upgrading application software.

For instructions on how to select and store settings, see *About the Front Panel* (on page 38).

The IP menu has the following structure:



IP

| Menu Item   | Description  | Parameters   |      |             |   |           |    |             |    |               |
|-------------|--|--|------|-------------|---|-----------|----|-------------|----|---------------|
| Port ID     | Select the Ethernet interface to configure.  | 1, 2, or 3. Interface 1 is the control and management interface and interface 2 and interface 3 are data interfaces.<br><br>The default is 1.  |      |             |   |           |    |             |    |               |
| Description | Sets the description or name for the Ethernet interface.   | Up to 20 alphanumeric characters in length.  |      |             |   |           |    |             |    |               |
| V4/V6       | Select the IP protocol.  | Only IPv4 is currently supported.  |      |             |   |           |    |             |    |               |
| IP Address  | Sets the IPv4 IP address for the interface.  | 12 digits in length (###.###.###.###)  |      |             |   |           |    |             |    |               |
| Mask        | Sets the number of CIDR (Classless Inter-Domain Routing) bits in the network mask.   | 8 to 30  |      |             |   |           |    |             |    |               |
| Gateway     | Sets the Network Gateway Address on the Network, used to expose the receiver to a WAN.   | The IP Address/Mask and Gateway Address should be changed together, i.e., as a group. The following table shows the most commonly used Subnet mask values to enter for a chosen IP address mask, which will depend on the size of your network. <table border="1" data-bbox="1063 1039 1526 1264"> <thead> <tr> <th>Mask</th> <th>Subnet Mask</th> </tr> </thead> <tbody> <tr> <td>8</td> <td>255.0.0.0</td> </tr> <tr> <td>16</td> <td>255.255.0.0</td> </tr> <tr> <td>24</td> <td>255.255.255.0</td> </tr> </tbody> </table> | Mask | Subnet Mask | 8 | 255.0.0.0 | 16 | 255.255.0.0 | 24 | 255.255.255.0 |
| Mask        | Subnet Mask  |  |      |             |   |           |    |             |    |               |
| 8           | 255.0.0.0  |  |      |             |   |           |    |             |    |               |
| 16          | 255.255.0.0  |  |      |             |   |           |    |             |    |               |
| 24          | 255.255.255.0  |  |      |             |   |           |    |             |    |               |
| Phy Mode    | Set the speed and duplex type of the interface. Select Auto for PHY to negotiate speed and duplex with other devices on the network, or select 10 HD (half-duplex), 10 FD (full-duplex), 100 HD, 100 FD, or 1000 FD to lock into a fixed mode. | Auto (default), 1000FD (full duplex), 100HD (half duplex), 10FD, or 10HD   |      |             |   |           |    |             |    |               |
| MAC Address | Displays the MAC address of the interface. It is set at the factory and is a read-only value.  | N/A  |      |             |   |           |    |             |    |               |

| Menu Item                   | Description   | Parameters  |
|-----------------------------|---|---|
| Multicast Forwarding        | <p>Sets whether all the MPE data is forwarded to the network. It can forward up to 5 MPE PIDs.</p> <p><b>Note:</b> This can only be configured on Port 2. Port 1 is fixed to Forward None.</p> <p><b>Note:</b> The receiver supports up to a maximum of 10 Mbps throughput when forwarding 1500 byte packets.</p>   | Forward None or Forward All   |
| SNMP Read Community String  | <p>Sets the password to read data from a device and to display diagnostics traps/alarms.</p> <p>This is used when communicating with a device within an SNMP environment.</p>   | <p>Up to 31 alphanumeric characters in length. This string is case-sensitive.</p> <p>The default community string is: public.</p> |
| SNMP Write Community String | <p>Sets the password to write data to a device.</p> <p>This is used when communicating with a device within an SNMP environment.</p>  | <p>Up to 31 alphanumeric characters in length. This string is case-sensitive.</p> <p>The default community string is: public.</p> |
| Reset Credentials           | <p>If for some reason, you cannot access the decoder (due to a forgotten password, corrupted data, etc.), the recovery procedure for the decoder is as follows:</p> <p>Using the keypad, choose this field on the front panel menu. A default login username and randomly generated password will be displayed on the front panel display for approximately 30 seconds. The new account will have Admin privileges. It is recommended that this account be replaced by a login username/password chosen by the administrator. To change the username and password, you must be an Admin user. Refer to <i>Setting Admin User Privileges via a Telnet Connection</i> (on page 32).</p> <p><b>Note:</b> After this recovery procedure, all existing user accounts will be lost.</p> |   |

## Chapter 4 Front Panel Operation

| Menu Item           | Description   | Parameters   |
|---------------------|---|--|
| Password Complexity | Sets the password complexity for all users. The complexity level changes will only affect the new user accounts and password changes. It will not affect existing accounts. | No Checking, Minimal Checking, or Full Complexity Checking<br>For more information, see the Password Complexity table below. |
| SNTP Server         | Sets the NTP server address. If the NTP server address is not set (0.0.0.0), the IRD will not attempt to connect to the server.   | 12 digits in length (###.###.###.###)  |
| SNTP Enable         | Periodically request NTP timestamps from the NTP server and to synchronize its system (i.e., non-DVB related) time with the NTP server.                                     | Yes or No  |

### Password Complexity

| Password Complexity      | Description  |
|--------------------------|--|
| No Checking              | There are no restrictions on passwords.<br><b>Note:</b> A minimum of one character is required.  |
| Minimal Checking         | The passwords must comply with the following requirements: <ul style="list-style-type: none"> <li>■ It cannot contain username or reversed username.</li> <li>■ It cannot contain any of the following strings: cisco, sciatl, ocsic, Itaics, atlsci, icslta, or any string achieved by full or partial capitalization of letters.</li> <li>■ No letter is repeated more than three times in a row.</li> <li>■ Must contain a minimum of four characters.</li> </ul>   |
| Full Complexity Checking | The passwords must comply with the following requirements: <ul style="list-style-type: none"> <li>■ It cannot contain username or reversed username.</li> <li>■ It cannot contain any of the following strings: cisco, sciatl, ocsic, Itaics, atlsci, icslta, or any string achieved by full or partial capitalization of letters.</li> <li>■ No letter is repeated more than three times in a row.</li> <li>■ Must contain a minimum of eight characters.</li> <li>■ Must contain a minimum of three of the following types of characters: capital letters, small letters, digits, and special characters.</li> </ul> |



**Trap Destinations**

| Menu Item             | Description  | Parameters  |
|-----------------------|--|---|
| Trap IP Address       | Sets the destination IP address for SNMP trap messages for system events (for example, fault messages).  | Up to 12 digits in length, e.g., 155.128.100.200                      |
| Ins, Del              | You can choose to Insert or Delete entries. Up to 25 entries can be assigned to the Trap IP Address and Community String fields. To add a new entry, press <b>Ins</b> and enter the new entry in the IP Address or Community String field. To delete an existing entry, scroll to the IP address or community string you want to delete and press <b>Del</b> . |   |
| Trap Community String | Sets the Community string for the Trap IP Address.   | Public or custom string. Up to 35 characters. The default is: public. |

**Protocols**

The **Protocols** menu allows you to control remote access protocols (Telnet, SSH, HTTP, DTX, and SNMP) to the IRD.

| Menu Item | Description   | Port Number    | Parameters                  |
|-----------|---|----------------|-----------------------------|
| Telnet    | Controls Telnet access to the IRD. Select <b>Enable</b> to allow Telnet connections. Select <b>Disable</b> to disable the listener for the Telnet port. | TCP port #23   | Enable (default) or Disable |
| SSH       | Controls SSH access to the IRD. Select <b>Enable</b> to allow secure shell connections. Select <b>Disable</b> to disable the listener for the SSH port. | TCP port #22   | Enable (default) or Disable |
| HTTP      | Controls HTTP access to the IRD. Select <b>Enable</b> to allow web connections. Select <b>Disable</b> to disable the listener for the HTTP port.        | TCP port #80   | Disable or Enable (default) |
| DTX       | Controls DTX access to the IRD. Select <b>Enable</b> to allow DTX connections. Select <b>Disable</b> to disable the listener for the DTX port.          | UDP port #8401 | Enable (default) or Disable |

| Menu Item | Description   | Port Number   | Parameters                  |
|-----------|---|---------------|-----------------------------|
| SNMP      | Controls SNMP access to the IRD. Select <b>Enable</b> to allow SNMP connections. Select <b>Disable</b> to disable the listener for the SNMP port. | UDP port #161 | Enable (default) or Disable |

By enabling or disabling the protocols, dynamic hardware and software firewalls are created for the D9854 receiver.

### Accessing TCP and UDP Services

The following describes the commands used to access port information for all the supported protocols. The examples of TCP-based services are: Telnet, SSH, and HTTP. The examples of UDP-based services are: SNTP and SNMP.

Proceed as follows to obtain TCP or UDP information:

- 1 Start a new communication session with the receiver using a utility, such as Tera Term Pro or PuTTY. For more information on starting a new connection, see *Starting a Telnet Session* (on page 32).
- 2 In the D9854 command prompt, type `ipal tcp_list` for a list of TCP connections or `ipal udp_list` for a list of UDP connections and press **Enter**. The following is an example of the results:

```

192.131.244.112:23 - Tera Term VT
File Edit Setup Control Window Resize Help

D9854>
D9854>ipal tcp_list
Idx  family Recv-Q  Send-Q  LocalAddress  ForeignAddress  Refs  State/Backlog  RTO
2    IPV4  0/32768  0/32768  0.0.0.0:22   0.0.0.0:0       5    LISTEN/0       0
3    IPV4  0/32768  0/32768  0.0.0.0:23   0.0.0.0:0       4    LISTEN/0       0
5    IPV4  0/32768  0/32768  0.0.0.0:80   0.0.0.0:0       2    LISTEN/0       0
13   IPV4  0/33580  0/33580  192.131.244.112:22  192.131.244.200:57181 6    ESTABLISHED    1000
12   IPV4  1/33580  452/33580  192.131.244.112:23  192.131.244.200:57178 7    ESTABLISHED    1000
14   IPV4  0/33580  0/33580  192.131.244.112:23  192.131.244.200:57189 7    ESTABLISHED    1000
9    IPV4  0/33580  0/33580  192.131.244.112:80  192.131.244.200:57173 7    ESTABLISHED    1000
10   IPV4  0/33580  0/33580  192.131.244.112:80  192.131.244.200:57174 6    ESTABLISHED    1000
15   IPV4  0/33580  0/33580  192.131.244.112:80  192.131.244.200:57191 6    ESTABLISHED    1000

D9854>
D9854>ipal udp_list
Index family RecvQ  SendQ  LocalAddress  Refs
0    IPV4  0/32768  0/32768  0.0.0.0:54668  2
1    IPV4  0/32768  0/32768  192.131.244.112:123  2
4    IPV4  0/32768  0/32768  192.131.244.112:161  2
8    IPV4  0/32768  0/32768  192.131.244.112:8401  2

D9854>[]
    
```

- 3 All other connections that are not specifically requested by remote access protocol selection or triggered by user actions, such as an FTP transfer, do not have active listeners and the corresponding TCP/UDP ports are closed. To strengthen security, the hardware firewall drops all incoming packets for the closed ports.


**Note:** The hardware firewall may impose different rules for the Management and Data ports. For example, remote access protocols, such as SSH or HTTP, are only enabled on the Management port.

# Setup Menu: Services

To view the Services menu from the Main menu, press the **RIGHT** arrow key once and then the **SELECT** key to reach the Setup menu. Then press the **RIGHT** arrow key three times and the **SELECT** key to view the Services menu.

The Services menu allows you to set up all the operating parameters associated with audio, video and captions services.

Each parameter is described below. The menu has the following structure:



## Video

| Menu Item | Description  | Parameters                     |
|-----------|--|--------------------------------|
| PV Format | Sets the primary video output format for local decoding. | Auto, SD, HD 720p, or HD 1080i |

## Chapter 4 Front Panel Operation

| Menu Item          | Description   | Parameters   |
|--------------------|---|--|
| PV Output          | Indicates the actual output video format. This value is read-only.  | SD, HD 720p, or HD 1080i   |
| Stream             | Indicates the video format of the input video stream. This value is read-only.  |  |
| SD Format          | Selects the standard definition output format to use on the primary video if the PV Output is set to SD.  | Auto, NTSC, PAL-N (AR), PAL-M or PAL-B/G/I/D. Use NTSC for 525-line systems and PAL-B/G/I/D for 625-line systems.                            |
| SD Output          | Indicates the actual standard definition format of the primary video output if the PV Output is set to SD.  | NTSC, PAL-N (AR), PAL-M or PAL-B/G/I/D   |
| Bitrate            | Indicates the bit rate of the input video stream, in Mbps.  | 1.0 to 15.0 Mbps   |
| Tri-Synch          | Select whether to use component Tri-Synchronization.  | Enabled or Disabled  |
| Alarm Video Cutoff | Sets whether the video output is cut off if any enabled alarm is active on the receiver. When video is cut off, there will be no horizontal or vertical synchronization on the output. This is useful for downstream redundancy switching by detecting a loss of video signal.<br><br><b>Note:</b> This same function also exists under Setup: Alarm/Warning. | Enable or Disable.<br>The default is Disable.  |
| OSD Messages       | Sets whether alarms and warnings are to be displayed on the on-screen display (e.g., TV monitor).   | Enable or Disable  |
| TV A/R             | Select the standard definition aspect ratio of your TV monitor.   | 4:3 or 16:9  |
| Convert            | Select the conversion method that the receiver will perform on the incoming signal for the picture to be displayed correctly on your TV based on the TV A/R setting.  | None, Auto, Auto AFD, 16:9 L/B, 4:3 P/B, 14:9, 4:3 CCO, 16:9 SCALE. The default is Auto. For more information, see Aspect Ratio Conversions. |
| Stream             | Indicates the aspect ratio of the incoming video stream. This is read-only.   | 4:3 or 16:9  |





## Setup Menu

| Menu Item  | Description   | Parameters  |
|------------|---|---|
| Act Conv   | <p>The actual aspect ratio conversion the receiver will perform based on what you have selected. This is read-only.</p> <p>Refer to the Aspect Ratio Conversions table below for the conversions performed by the receiver based on your selection, and the effect on the picture displayed by the receiver in each case (without Auto AFD)</p> | None, 16:9 L/B, 4:3 P/B, 14:9, 4:3 CCO, 16:9 SCALE  |
| WSS Mode   | Select the Wide Screen Signaling output mode. It is used to select how the receiver affects PAL WSS when it is present in the VBI line 23.  | <p>Auto:Create - Creates WSS to output the correct aspect ratio when performing aspect ratio conversion.</p> <p>Auto:Modify - If WSS is present in the input stream, it is modified to output the correct aspect ratio when performing aspect ratio conversion. If WSS is not present in the input, no WSS will be present in the output.</p> <p>Suppress - Removes WSS output.</p> <p>Passthrough - Passes WSS unmodified as received by the receiver.</p> <p>The default is Auto.</p> |
| WSS Status | This indicates the current output value of PAL WSS in VBI line 23.  | <p>4:3 F/F, 16:9 L/B CEN, 16:9 L/B TOP, &gt;16:9 L/B, 14:9 L/B CEN, 14:9 L/B TOP, 14:9 F/F CEN, 16:9 F/F, or UNDEFINED</p> <p><b>Note:</b> F/F is full format, and L/B is letter box.</p>   |







### Aspect Ratio Conversions

The following table displays the conversions performed by the receiver based on the Act Conv selection:


## Chapter 4 Front Panel Operation

| Stream | TV A/R | Conversion | Act Conv | Description  | Image  |
|--------|--------|------------|----------|--|--|
| 4:3    | 4:3    | None       | None     | Normal Picture   | <br>4:3           |
| 4:3    | 4:3    | Auto       | None     | No conversion  |  |
| 4:3    | 4:3    | 16:9 L/B   | None     | Conversion is not possible. Normal picture.                |  |
| 4:3    | 4:3    | 4:3 CCO    | None     | Conversion is not possible. Normal picture.                |  |
| 4:3    | 4:3    | 4:3 P/B    | None     | Conversion is not possible. Normal picture.                |  |
| 4:3    | 4:3    | 14:9       | None     | Conversion is not possible. Normal picture.                |  |
| 4:3    | 4:3    | 16:9 SCALE | None     | Conversion is not possible. Normal picture.                |  |
| 4:3    | 16:9   | None       | None     | Picture is short & fat.                                    | <br>4:3 Stretch |
| 4:3    | 16:9   | Auto       | 4:3 P/B  | Uses 4:3 P/B.  | <br>4:3 PB      |
| 4:3    | 16:9   | 16:9 L/B   | None     | Conversion is not possible. Picture appears short and fat. |  |
| 4:3    | 16:9   | 4:3 CCO    | None     | Conversion is not possible. Picture appears short and fat. |  |
| 4:3    | 16:9   | 4:3 P/B    | 4:3 P/B  | 4:3 picture is centered in a pillar-style box.             | <br>4:3 PB      |

Setup Menu

|      |      |            |            |   |  |
|------|------|------------|------------|---|--|
| 4:3  | 16:9 | 14:9       | 14:9       | Compromises some up-sampling. Some black bars and cropping are visible.                         | <br>14:9              |
| 4:3  | 16:9 | 16:9 SCALE | 16:9 SCALE | Vertically up-samples the centre of the 4:3 picture and crops the top and bottom of the screen. | <br>16:9 FH           |
| 16:9 | 16:9 | None       | None       | Normal  | <br>16:9              |
| 16:9 | 16:9 | Auto       | None       | No conversion. Normal picture.  |  |
| 16:9 | 16:9 | 16:9 L/B   | None       | Conversion is not possible. Normal picture.   |  |
| 16:9 | 16:9 | 4:3 CCO    | None       | Conversion is not possible. Normal picture.   |  |
| 16:9 | 16:9 | 4:3 P/B    | None       | Conversion is not possible. Normal picture.   |  |
| 16:9 | 16:9 | 14:9       | None       | Conversion is not possible. Normal picture.   |  |
| 16:9 | 16:9 | 16:9 SCALE | None       | Conversion is not possible. Normal picture.   |  |
| 16:9 | 4:3  | None       | None       | Picture appears tall and thin.  | <br>16:9 Compressed |
| 16:9 | 4:3  | 16:9 L/B   | 16:9 L/B   | Vertically down-samples the picture and applies black bars at the top & bottom of the screen.   | <br>4:3 LB          |
| 16:9 | 4:3  | 4:3 CCO    | 4:3 CCO    | Horizontally up-samples the centre portion of the picture to fill the 720.                      | <br>4:3 Crop        |

## Chapter 4 Front Panel Operation

|      |     |            |      |  |   |
|------|-----|------------|------|--|---|
| 16:9 | 4:3 | 4:3 P/B    | None | Conversion is not possible. Picture appears tall and thin.                   |   |
| 16:9 | 4:3 | 14:9       | 14:9 | Compromises some up-sampling. Some black bars and some cropping are visible. |  |
| 16:9 | 4:3 | 16:9 SCALE | None | Conversion is not possible. Picture appears tall and thin.                   |   |

**Note:** Active Format Descriptor (AFD) - normally it is necessary to set both the TV Aspect Ratio and Conversion to correctly display the video program on the TV system. The Auto AFD option enables the receiver output to automatically match the display format of the video program to the TV system based on specific (uplink) program information carried in the transport stream. In this case, the receiver performs the conversion based on the TV Aspect Ratio setting combined with the program-specific uplink information to provide the “best fit” for display of the program material on the TV. This feature is primarily used in 16:9 and 14:9 (wide screen) applications.

### Audio

| Menu Item       | Description   | Parameters  |
|-----------------|---|---|
| Aud#            | Sets which balanced audio output on the rear panel to configure.                      | 1 or 2  |
| Stereo/Mono     | Sets the output mixing.   | <p>Stereo - Left and Right are passed directly through to Left and Right</p> <p>R-MONO - Right is passed to both the Left and Right</p> <p>L-MONO - Left is passed to both the Left and Right</p> <p>Mixed - Left is passed to both the Left and Right, and Right is passed to both the Left and Right.</p> |
| AC3 Compression | Sets the AC3 compression mode to use if the output is compressed Dolby Digital audio. | <p>Line Mode, Custom 1, Custom 0 or RF Mode.</p> <p>RF Mode is recommended for analog cable modulators.</p>   |
| Left (dB)       | Sets the volume adjustment for the Left audio channel, in dB.                         | <p>-6.0 to +6.0</p> <p>Any value can be entered with the numeric keypad (in the appropriate range), but the UP and DOWN arrows will increase or decrease in 0.5 dB steps.</p>   |



## Setup Menu

| Menu Item        | Description  | Parameters  |
|------------------|--|---|
| Right (dB)       | Sets the volume adjustment for the Right audio channel, in dB.   | -6.0 to +6.0<br><br>Any value can be entered with the numeric keypad (in the appropriate range), but the UP and DOWN arrows will increase or decrease in 0.5 dB steps.  |
| DDP              | <p>Sets the Dolby Digital Plus output mode. If Trans is selected, it will transcode to Dolby Digital (AC-3) audio output. If Passthrough is selected and the bitrate is less than 1536 kbps (48 Khz), passthrough is performed and Dolby Digital Plus compressed out is received. If Passthrough is selected and the bitrate is more than 1536 Kbps, transcoding will be performed. This setting affects only the AES-3id and SDI outputs.</p> <p><b>Note:</b> Dolby Digital Plus is only available on Audio 1. Ensure that the Aud# is set to Aud1.</p> <p><b>Note:</b> Ensure that the Digital Out Pref is set to Compressed for digital passthrough. Otherwise, only decoded PCM will be available. This parameter has no effect if the audio source is not Dolby Digital Plus.</p> | Trans (Transcoded) or Pass (Passthrough)  |
| PMT Source       | Selects the PMT source for the audio channel.  | None, AUDI to AUD64   |
| Digital Out Pref | Sets the output preference for the SDI output or AES-3id output.   | <p>PCM Samples - If the audio source is MPEG Layer II format, the output will be routed to the SDI output as PCM.</p> <p>Compressed - If the audio source is AES compressed, the output will be routed to the AES-3id output, compressed.</p> |

## Chapter 4 Front Panel Operation

### Digital Out Preference

When Dig Out Pref is set to PCM Samples, the output is PCM regardless of whether it's MPEG, Dolby Digital (AC-3) or AAC audio. Additionally, when the output is Compressed, MPEG-1 L1 and L2 will be output PCM, even though Dolby Digital (AC-3) and AAC is compressed (and transcoded).

|  | Digital Output Preference |  |  |
|--|---------------------------|--|--|
| Output Input   | PCM Samples               | Compressed                             |  |
|  |                           | DDP Mode                               |  |
|  |                           | Transcode<br>(Converter)               | Passthrough  |
| MPEG LA (MPEG-1 and MPEG-2)                          | PCM                       | PCM                                    | PCM  |
| Dolby Digital (AC-3)                                 | PCM                       | Dolby Digital (AC-3)                   | Dolby Digital (AC-3)                               |
| Dolby Digital Plus (E-AC-3)<br>(Bit rate < 1.5 Mbps) | PCM                       | Dolby Digital (AC-3)                   | Dolby Digital Plus (E-AC-3) (no over-clocking, x1) |
| Dolby Digital Plus (E-AC-3)<br>(Bit rate > 1.5 Mps)  | PCM                       | Dolby Digital (AC-3)                   | Dolby Digital (AC-3)                               |
| MPEG-2 AAC, MPEG-4<br>(AAC and HE-AAC)               | PCM                       | MPEG-2 AAC,<br>MPEG-4 (AAC and HE-AAC) | MPEG-2, MPEG-4<br>(AAC and HE-AAC)                 |

### Captions

| Menu Item      | Description   | Parameters  |
|----------------|---|---|
| Preferred Mode | Selects the type of closed captioning to use if there are multiple available in the stream. | Auto, SA Custom, EIA 708, Type 3, Type 4 SA, DVS 053 Type 4 ATSC, Reserved or DVS 157. The default is Auto.<br><br><b>Note:</b> SA Custom is not supported when telecine video coding is enabled. |
| Actual Output  | Indicates the actual closed caption mode in the output. This is read-only.                  | Auto, SA Custom, EIA 708, Type 3, Type 4 SA, Type 4 ATSC, Reserved, or DVS 157  |

## VBI

| Menu Item                      | Description   | Parameters   |
|--------------------------------|---|--|
| WSS Mode                       | Selects the Wide Screen Signaling output mode. It is used to select how the receiver affects PAL WSS when it is present in the VBI line 23. | <p>Auto:Create - Creates WSS to output the correct aspect ratio, when performing aspect ratio conversion.</p> <p>Auto:Modify - If WSS is present in the input stream, it is modified to output the correct aspect ratio when performing aspect ratio conversion. If WSS is not present in the input, no WSS will be present in the output.</p> <p>Suppress - Removes WSS output.</p> <p>Passthrough - Passes WSS unmodified as received by the receiver.</p> <p>The default is Auto.</p> |
| WSS Stat                       | This indicates the current output value of PAL WSS in VBI line 23.  | <p>4:3 F/F, 16:9 L/B CEN, 16:9 L/B TOP, &gt;16:9 L/B, 14:9 L/B CEN, 14:9 L/B TOP, 14:9 F/F CEN, 16:9 F/F, or UNDEFINED</p> <p><b>Note:</b> F/F is full format, and L/B is letter box.</p>  |
| VITS PAL Line 17, 18, 330, 331 | Select whether to enable or disable Vertical Interval Test Signal on PAL Lines 17, 18, 330, or 331.   | Enable or Disable  |

## SDI

| Menu Item | Description  | Parameters          |
|-----------|--|---------------------|
| VII       | This selects whether to enable or disable the SDI VII (video index)/AFD output in SDI. | Enabled or Disabled |
| VBI       | This selects whether to enable or disable the VBI output in SDI.                       | Enabled or Disabled |
| DPI       | This selects whether to enable or disable the DPI output in SDI.                       | Enabled or Disabled |

## Chapter 4 Front Panel Operation

| Menu Item | Description  | Parameters          |
|-----------|--|---------------------|
| EIA-708   | This selects whether to enable or disable the EIA-708 output in SDI. | Enabled or Disabled |

### Audio Slot

| Menu Item                  | Description   | Parameters  |
|----------------------------|---|---|
| Group, Slot <-<br>Audio Ch | This selects the audio channel grouping, and audio channels from the available audio group. | Group: This the channel group - 1 to 4.<br>Slot: This is the HANC position - 1 to 4.<br>Audio: This is the audio source - 1, 2.<br>Ch: This is the source audio channel - 1, 2. |

### Subtitles

This menu allows you to configure the type of subtitling (for example, DVB or Imtext) displayed by the receiver, and how the receiver displays subtitling on the TV.

| Menu Item          | Description  | Parameters  |
|--------------------|--|---|
| Op Mode            | Sets the subtitle mode.                            | Off - No subtitles are displayed.<br>On - Displays DVB or Imtext subtitles, if available.<br>DVB - Displays only DVB titles, if available. Otherwise, no subtitles are displayed.<br>Imtext - Displays only Imtext subtitles, if available. Otherwise, no subtitles are displayed.                      |
| Select Language By | Select the input source for the subtitle language. | Language List - Allows you to select a language from the available list.<br>Language Entry - Allows you to enter a language code.<br>PMT Order - Allows you to select a PMT order.<br>The default setting is Language List. Language Entry and PMT Order are more applicable for advanced applications. |

| Menu Item        | Description  | Parameters   |
|------------------|--|--|
| Language List    | If Language List was selected in the Select Language By menu, select the MPEG language to display.   | ara (Arabic), btk (Batak (Indonesia)), ben (Bengali), bul (Bulgarian), chi (Chinese), cze (Czech), dan (Danish), dut (Dutch), eng (English), fin (Finnish), fre (French), ger (German), gre (Greek), heb (Hebrew), hin (Hindi), hun (Hungarian), ice (Icelandic), ind (Indonesian), ita (Italian), jpn (Japanese), kor (Korean), may (Malay), mul (Multiple Languages), nor (Norwegian), per (Persian), pol (Polish), por (Portuguese), rum (Romanian), rus (Russian), san (Sanskrit), scc (Serbian), sin (Sinhalese), slo (Slovak), som (Somali), spa (Spanish), swe (Swedish), tai (Tai Other), tam (Tamil), tha (Thai), tur (Turkish), ukr (Ukrainian), or vie (Vietnamese) |
| PMT Order        | If PMT Order was selected in the Select Language By menu, select the subtitle PID entry to display. This information is available from your uplink service provider.     | First to Eighth  |
| Entry            | If Language Entry was selected in the Select Language By menu, select the subtitle PID entry to display. The information is available from your uplink service provider. | Enter the three-character code provided by your uplink service provider under Entry using the numeric keypad (e.g., eng for English).<br><br>For a list of language codes, see Language Codes - Sorted by Alpha 3-Letter Code (ISO 639-2)  |
| Imitext Position | Sets the position of the on-screen subtitle text.  | Standard or Extended   |
| ForeGnd          | Sets the text color for Imitext subtitles.   | Auto, Yellow, or White.<br><br>Auto displays text in the color transmitted by the subtitling equipment. Yellow and White override the color set by the uplink, and display text in the selected color.   |

## Chapter 4 Front Panel Operation

| Menu Item | Description                                     | Parameters   |
|-----------|---|--|
| BackGnd   | Sets the text background for Imitext subtitles. | <p>Auto - Uses the uplink subtitling equipment setting.</p> <p>Shadow - Applies an outline to the right side of each text character. No background box is applied to subtitles, i.e., text is visible directly on top of video.</p> <p>Opaque - Applies a black box to each text character.</p> <p>Semi - Applies a semi-transparent box to subtitle text.</p> <p>None - No shadow or outline is applied to subtitle text.</p> |

### Decode

| Menu Item | Description   | Parameters   |
|-----------|---|--|
| Decoder   | Select the local decode service to configure.                             | Video, Audio1 to Audio4, VBI (Vertical Blanking Interval) DATA (low speed data), MPE1 to MPE5 (Multiprotocol Encapsulation), STT (Subtitles), or DPI (Digital Program Insertion) |
| Enabled   | Select whether the local decoding of this service is enabled or disabled. | Yes or No  |



## Setup Menu: Common Interface (CI)


To view the CI menus from the Main menu, press the RIGHT arrow key once and then the SELECT key to reach the Setup menu. Then press the RIGHT arrow key four times and the SELECT key to view the CI menu.

The Common Interface (CI) slots are located under the door on the front panel. They allow use of a CAM (Conditional Access Module) Smart Card to decrypt purchased programming.

You must be authorized to view the programming available via the Smart Card from your service provider.

CAMs must be purchased from Cisco. For a list of the supported CAMs, see Common Interface Modules.

For instructions on how to select and store settings, see About the Front Panel. The CI menu has the following structure:





## CI

| Menu Item | Description   | Parameters  |
|-----------|---|---|
| PE        | Select the Program Entry (PE) to configure the decryption settings.   | PE1 to PE32   |
| Decrypt   | Determines whether to decrypt the channel or to specify the specific components to decrypt.   | <p>ON (default) - Decrypts the entire program entry.</p> <p>OFF - Disables decryption for the current program entry.</p> <p>Comp - Allows specific components to be decrypted, as specified in the component list.</p> <p><b>Note:</b> If the CI Slot is set to Auto for PE1, then Decrypt can only be set to ON.</p> |
| CI Slot   | Select the CAM slot to use for decryption.  | <p>TOP, BOTTOM, AUTO</p> <p>AUTO - PE1 only. The software automatically assigns the slot capable of decrypting the stream. If CI Slot is set to AUTO, Decrypt must be set to ON.</p> <p>TOP - The top CAM slot is used for decryption.</p> <p>BOTTOM - The bottom CAM slot is used for decryption.</p>                |
| COMP only | <p>If any program entries have selected Comp for the Decrypt parameter, you can customize the PID or stream type to decrypt the program.</p> <p>To Add a Record, press the ADV button, select Insert and define the appropriate parameters.</p> <p>To delete an existing record, select Delete and confirm your deletion.</p> <p>There are three different methods in setting a customized record:</p> <p>PID - Set <b>Mode</b> to PID and enter <b>PID</b> number.</p> <p>Stream Type - Set <b>Mode</b> to STREAM, select a <b>Stream</b> type (audio, video, subtitle, ttx, or user) and enter Inst (instance) of the stream type. There is an additional configuration if you select user as the Stream type (see below).</p> <p>Stream Type: User - Set <b>Mode</b> to STREAM, <b>Stream</b> type to USER, manually enter the stream code in <b>Type</b>, and then the <b>Inst</b> (instance) of the stream type.</p> |   |

## Chapter 4 Front Panel Operation

| Menu Item  | Description  | Parameters   |
|------------|--|--|
| Idx        | Select the component record to edit.   | 1-64 (up to 32 records for each CAM)   |
| PE         | Set the Program Entry the component is located.  | 1 to 32  |
| Mode       | Select whether to choose the component by PID or by stream type.   | PID or STREAM  |
| PID        | If decrypting by PID, set the PID number.  | 0 to 8192  |
| Stream     | If decrypting by stream type and set the stream type.  | AUD (audio), VID (video), SUBT (subtitles), TTX (teletext), USER<br><b>Note:</b> Select USER to manually enter a stream type in the <b>Type</b> parameter. |
| Type       | If decrypting by stream type and the stream category is USER, set the stream type value.   | 0 to 255   |
| Inst       | If decrypting by stream type, set the instance of the current stream type.   | 1 to 64  |
| Query      | Set to Enable to query the CAM prior to decryption to ensure that the program can be decrypted.  | Enabled or Disabled (default)  |
| Auto Reset | Set to Enable to automatically reset the card.   | Enable or Disabled (default)   |
| List Mgmt  | Select whether the Common Interface List Management should add or delete individual programs or update all the programs when the list changes.   | AddDel or Update All<br><b>Note:</b> Updating all the programs will cause a temporary loss of service for all the programs when another is being modified. |
| TS_ON_ID   | Set to Enable if you want to restrict the incoming transport stream.<br><br>If the incoming stream does not match the transport stream and original network ID specified (TS_ID and ON_ID), the program will not be decrypted. | Enable or Disable (default)  |
| TS_ID      | Specify the Transport ID.  | 0 to 65535   |

| Menu Item  | Description  | Parameters               |
|------------|--|--------------------------|
| ON_ID      | Specify the Transport Original Network ID.   | 0 to 65535               |
| TS Routing | Select EntireTS to use the CAM to decrypt the entire transport stream, or select ServicesOnly to use the CAM to decrypt only the PIDs being used by the active services. | EntireTS or ServicesOnly |

### Top/Bottom Slot

| Menu Item                  | Description  | Parameters              |
|----------------------------|--|-------------------------|
| CAM Status Overview        | View the status of the CAM that is located in the top or bottom slot.                                | Top slot or Bottom slot |
| Status                     | Displays the status of the CAM.  | Ready or Not Ready      |
| System Name                | Indicates the system name of the CAM.  |                         |
| Application Manufacture ID | Displays the factory loaded application number of the CAM.   |                         |
| Manufacture Code           | Indicates the manufacture's code.  |                         |
| Supported CA System IDs    | Displays the CA system identification name of the CAM. Some CAMs may support multiple CA system IDs. |                         |
| Serial Number              | Indicates the unique serial number of the CAM.   |                         |
| Hardware Version           | Displays the hardware version number of the CAM.   |                         |
| Application Version        | Displays the software version number of the CAM.   |                         |
| Company Name               | Displays the company name of the CAM.  |                         |
| Product Name               | Displays the product name of the CAM.  |                         |


## Setup Menu: Outputs

To view the Outputs menus from the Main menu, press the RIGHT arrow key once and then the SELECT key to reach the Setup menu. Then press the RIGHT arrow key five times and the SELECT key to view the Outputs menu.

The Outputs menu allows you to set up the rear panel control relays for alarms, cue tones and cue triggers, and the transport stream outputs, and Digital Program Mapping (DPM).

For instructions on how to select and store settings, see About the Front Panel.

The Outputs menu has the following structure:



**Cueing**

| <b>Menu Item</b> | <b>Description</b>   | <b>Parameters</b>  |
|------------------|--|--|
| Cueing Mode      | Select whether cueing output should be DTMF tones or trigger pins.   | Trigger or Tone<br><br>Tone - Cue tones are standard Dual-Tone Multi-Frequency (DTMF) tones. The tones are generated at the Cue Tone/Relay output on the rear panel of the receiver.<br><br>Trigger - Cue trigger refers to open-collector pins which can be toggled at the Cue Tone/Relay output on the rear panel of the receiver. |
| Trigger Polarity | If the Cueing Mode was set to Trigger, select the pin polarity.  | High or Low<br><br>High - Pins act as open or floating collectors on an active cueing signal and as ground on an inactive signal.<br><br>Low - Pins act as ground on an active cueing signal and as open or floating collectors on an inactive signal.   |
| Repeat           | If the Cueing Mode was set to Tone, set the number of consecutive tone sequences to be generated. Values greater than 1 are provided when a scenario demands repetition to ensure that the ad insertion equipment receives the signal. | 1, 2, or 3. The default is 3.  |
| Tone (ms)        | If the Cueing Mode was set to Tone, set the duration of each tone, in milliseconds.  | 0 to 80. The default is 40.  |
| Silence (ms)     | If the Cueing Mode was set to Tone, set the duration, in milliseconds, of each silence between tones.  | 0 to 80. The default is 40.  |
| Seq#             | Select the tone sequence to configure.   | 1 to 16  |
| State            | Select whether the current tone sequence is enabled or disabled.   | Enabled or Disabled. When disabled, no cue tone is output.   |

Chapter 4 Front Panel Operation

| Menu Item       | Description   | Parameters   |            |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
|-----------------|---|--|------------|-----------|---------------|--|------|------|-------|----------------|------|-------|-------------|------|-------|----------|-------|------|---------|--------------------------|-------|------|----------|------|-------|
| Tones           | Sets the three digit tone sequence.   | 000 to 999   |            |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
| Mode            | Sets the tone sequence mode.  | * - Start tone only<br># - End tone only<br>*/# - Start and end tones. The end tone is signaled after waiting the time specified in Delay(sec).  |            |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
| Delay(sec)      | If the Mode was set to */# (Start/Stop), set the delay, in seconds, between the start and stop sequences.   | 1 to 255. The default is 30.   |            |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
| Relay Mode      | The relay can be programmed to respond to an alarm or warning state, or the state of one of the eight cue trigger pins. The response is generated at the Cue Tone/Relay output on the rear panel of the receiver. | Alarm or Trigger<br>The following table displays the possible field settings and their relationship to the receiver output: <table border="1" data-bbox="992 871 1437 1432"> <thead> <tr> <th rowspan="2">Relay Mode</th> <th rowspan="2">Condition</th> <th colspan="2">Relay Contact</th> </tr> <tr> <th>NC-C</th> <th>C-No</th> </tr> </thead> <tbody> <tr> <td rowspan="3">Alarm</td> <td>Unit Power Off</td> <td>Open</td> <td>Close</td> </tr> <tr> <td>Alarm State</td> <td>Open</td> <td>Close</td> </tr> <tr> <td>No Alarm</td> <td>Close</td> <td>Open</td> </tr> <tr> <td rowspan="2">Trigger</td> <td>Active (selected in PNC)</td> <td>Close</td> <td>Open</td> </tr> <tr> <td>Inactive</td> <td>Open</td> <td>Close</td> </tr> </tbody> </table> | Relay Mode | Condition | Relay Contact |  | NC-C | C-No | Alarm | Unit Power Off | Open | Close | Alarm State | Open | Close | No Alarm | Close | Open | Trigger | Active (selected in PNC) | Close | Open | Inactive | Open | Close |
| Relay Mode      | Condition   | Relay Contact  |            |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
|                 |   | NC-C   | C-No       |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
| Alarm           | Unit Power Off  | Open   | Close      |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
|                 | Alarm State   | Open   | Close      |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
|                 | No Alarm  | Close  | Open       |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
| Trigger         | Active (selected in PNC)  | Close  | Open       |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
|                 | Inactive  | Open   | Close      |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
| Cue Trigger Bit | If the Relay Mode was set to Trigger, select the cue trigger bit/pin that will activate the relay.  | 1 to 8   |            |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
| Cue Tone Test   | Sets the three digit cueing tone test sequence.   | 000 to 999   |            |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
| Mode            | Sets the test sequence mode.  | * - Start tone<br># - End tone   |            |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |
| Run Test        | Select and press continue to run the cue tone test according to the Cue Tone Test and Mode.   |  |            |           |               |  |      |      |       |                |      |       |             |      |       |          |       |      |         |                          |       |      |          |      |       |

**M1/M2**

| <b>Menu Item</b> | <b>Description</b>  | <b>Parameters</b> |
|------------------|---|-------------------|
| M1 Port Type     | This option allows the operator to set the output format for the M1 port. | ASI or SDI        |
| M2 Port Type     | This option allows the operator to set the output format for the M2 port. | ASI or SDI        |

**TS Out - ASI**

| <b>Menu Item</b> | <b>Description</b>   | <b>Parameters</b>   |
|------------------|--|---------------------|
| Name             | Displays the name assigned to the transport output for ease of reference. This is read-only. | 20-character string |

| Menu Item       | Description  | Parameters   |
|-----------------|--|--|
| Rate Control    | Select the output rate control.  | <p>Auto - The output rate follows that set by the uplink. The output rate will be the same as the input rate (including all null packets). This means the output bit rate is determined automatically based on the input source symbol rate and FEC value.</p> <p>User - The output rate is specified by User Rate(Mbps). It is determined by the user setting regardless of the input source.</p> <p>SFN Units Only:</p> <p>Auto - Sets the output rate at 32 Mbps for DVB-T transports without null packet stuffing. If the incoming rate is lower than 32 Mbps, the receiver will burst up to 32 Mbps, but will average to the incoming bit rate.</p> <p>User - The output rate is specified as the Output Rate parameter with null packet stuffing disabled. The output rate must be set high enough to pass the entire transport or the output will be corrupted. If the incoming rate is lower than the set output rate, the receiver will burst up to the output rate, but will average to the incoming bit rate.</p> |
| User Rate(Mbps) | <p>If the Rate Control was set to User, set the maximum output bit rate. If null packets are inserted, this will be the output rate.</p> <p>This setting is used when the signal source is RF or ASI and allows you to set the output bit rate to a value expected by equipment connected to the ASI output.</p> | <p>0 to 213 Mbps</p> <p><b>Note:</b> Output data may be lost if this bit rate is set to a value less than the actual signal bit rate.</p>  |



| Menu Item          | Description  | Parameters  |
|--------------------|--|---|
| Output Mode        | <p>Select the DPM output mode for the current output.</p> <p>With the exception of No Output, selecting a mode will configure the DPM settings to achieve the specified behavior. In this way, they act as DPM presets.</p> <p>Any changes then made to the DPM settings will switch the mode to Full DPM Control.</p> <p>It is highly recommended to use either one of these basic modes, or, for advanced setup, enter the DPM mapping before setting the Output Mode.</p> | <p>No Output - No ASI output will be generated and the ASI port will be disabled.</p> <p>Passthrough - The output will be identical to the input. All PEs will be set to Pass and other DPM settings will also be set.</p> <p>Service Chans Only - This is similar to Passthrough, except that only channels applied to program entries are available on the output.</p> <p>MAP Passthrough - The output will be identical to the input, except that channels and PIDs will be mapped using the DPM settings. When selecting MAP Passthrough, the option to re-sync will be provided. If you select Yes, it will set the DPM mapping to match the current input. If you select No, it will use the existing DPM maps.</p> <p>MAP Svc Chans Only - This is similar to MAP Passthrough, except that only channels applied to program entries are available on the output.</p> <p>Full DPM Control - The output will be generated according to the DPM settings. This is a manual control setting.</p> |
| Descramble Mode    | <p>Select whether the output will be descrambled if the input is scrambled.</p>  | <p>Scrambled - The output channel will remain scrambled even if the PE is authorized and can descramble the channel.</p> <p>Descrambled - Descrambles the output channel, and passes in-the-clear channels.</p> <p>The default is Descrambled.</p>  |
| Insert Null Packet | <p>Select whether to insert null packets into the output to maintain output at a constant bit rate.</p>  | <p>Yes or No</p>  |

**MOIP1**

| Menu Item        | Description  | Parameters  |
|------------------|--|---|
| Name             | This is the name assigned to the transport output for ease of reference.   | 20-character string   |
| Rate Control     | This is the DPM output rate control.   | <p>Auto - The output rate follows that set by the uplink. The output rate will be the same as the input rate (including all null packets). This means the output bit rate is determined automatically based on the input source symbol rate and FEC value. This setting is used when the signal source is RF.</p> <p>User - The output rate is specified as the Output Rate parameter. It is determined by the user setting regardless of the input source. Null packets are always inserted.</p> |
| User Rate (Mbps) | <p>This parameter controls the output rate when <b>Rate Control</b> is set to User.</p> <p><b>Note:</b> Output data will be partially or completely lost if the user-selected bit rate is set to a value that is less than the actual signal bit rate.</p> | 0 to 206 Mbps   |

| Menu Item          | Description   | Parameters   |
|--------------------|---|--|
| Output Mode        | This selects the DPM output mode.   | <p>No Output - No MPEGoIP output will be generated.</p> <p>Passthrough - The output will be identical to the input. The output channel will not be modified.</p> <p>PE/PID remapping options, PSI regeneration and User Rate are not supported in this mode.</p> <p>Service Chans Only - Only service channels will be output.</p> <p>MAP Passthrough - The output will be identical to the input, except that it will be generated using the DPM and PID mapping settings.</p> <p>MAP Svc Chans Only - Only service channels will be output according to the DPM and PID mapping settings.</p> <p>Full DPM Control - The output will be generated according to the DPM setting.</p> |
| Descramble Mode    | This parameter selects whether the receiver should scramble the output even if it is authorized to receive the channel.   | <p>The default mode is Descrambled.</p> <p>Scrambled - Scrambles the output channel even if the PE is authorized and can descramble the channel.</p> <p>Descrambled - Descrambles the output channel, and passes in-the-clear channels.</p>  |
| Insert Null Packet | <p>This parameter selects whether to insert null packets in the output stream.</p> <p>Null packets are always inserted if the <b>Rate Control</b> is set to User.</p> | Yes or No  |
| Enb                | Selects whether to enable or disable the MPEGoIP output.  | Yes or No  |
| Instance Name      | This is the DPM output instance name.   | Up to 31 characters  |
| MOIP               | Selects the transport protocol to be used for the output stream.  | RTP or UDP   |

## Chapter 4 Front Panel Operation

| Menu Item                      | Description   | Parameters   |
|--------------------------------|---|--|
| Send SAP                       | This selects whether to send Session Announcement Protocol messages.  | Yes or No  |
| SAP ID                         | This is the SAP identifier (ID)/string.   | Up to 49 characters  |
| DestAddr                       | Enter the unicast (valid host IP only) or multicast destination IP address.   | 224.0.0.0 to 239.255.255.255   |
| UDPPort                        | This selects the destination port number.   | 1 to 65535<br><b>Note:</b> If you selected RTP for MOIP, you must select an even destination port number.  |
| SrcPort                        | This selects the source UDP port number.  | 0 to 65535   |
| TS/IP                          | This selects the maximum number of transport packets per IP packet.   | 1 to 7   |
| Min IP/s                       | This selects the minimum number of IP packets per second.   | 0, 2 to 1000   |
| PCR@IP Start                   | This selects whether to always transmit a new IP packet when a new Program Clock Reference (PCR) arrives.   | Yes or No  |
| SAP                            | This selects whether to use the configured SAP string as the channel name.  | Yes or No  |
| MGMT Port Mode, DATA Port Mode | This selects the Management and Data MPEGoIP modes.<br><b>Note:</b> If No Output was selected for MOIP1 Output Mode, updates to the port modes will have no affect. | No Output - Disables the MPEGoIP interface.<br>Always Output - Always outputs data on the port.<br><b>Note:</b> You cannot select Always Output for both ports simultaneously. |
| SAP Multicast Address          | This is the SAP destination IP address.   | 0 to 255 for each of the four fields in the format ###.###.###.###.  |
| PCR Addition                   | This selects whether to add a PCR to the output stream.   | Yes or No  |

**TS Out - DPM**

To view the DPM menu from the TS Out menu, press the RIGHT arrow key. The DPM menu provides access to functionality associated with Global and ASI outputs.


The DPM menu allows you to groom functionality on a program basis where individual service PID modifications are provided on a limited scale.

Use the digital program mapping features to:

- configure the transport output bit rate
- configure the output mode for a program entry
- configure the service and PID output settings in a program entry

**Note:** Any changes made to the ASI DPM values will automatically change the TS Output mode to Full DPM Control.

The DPM menu has the following structure:



## Chapter 4 Front Panel Operation

### DPM - Global

| Menu Item   | Description  | Parameters  |
|-------------|--|---|
| Resync All: | Select to resynchronize all DPM output with the PMT data for all program entries on the selected output.   | ASI   |
| Regenerate  | Selects whether to regenerate the PSI tables in the output.  | Always or As Needed<br>Always - All tables are regenerated.<br>As Needed - Only regenerate the tables if the content has changed. |
| Copy:       | This copies all DPM data from either the ASI output to the MOIP1 output (MPEG over IP) or from the MOIP1 output to the ASI output depending on your selection. | ASI->MOIP1 or MOIP1->ASI  |

### ASI/MOIP1

| Menu Item | Description  | Parameters |
|-----------|--|------------|
| PE        | Select the Program Entry to configure.   | 1 to 32    |
| InCh      | Displays the channel number to which the PE is tuned. This is read-only.                           | 1 to 65535 |
| PMT       | Indicates the input PID value of the Program Map Table for the current channel. This is read-only. | 2 to 8190  |

| Menu Item | Description  | Parameters   |
|-----------|--|--|
| Act       | <p>Selects the action to perform on the current program entry.</p> <p>This setting controls the overall DPM behavior of the PE and will affect how the PID mapping operates.</p> | <p>Pass, Map, or Drop. The default is Pass.</p> <p>Pass - Output channel is the same as the input channel. The OutCh, and PMT settings are ignored. All PID map entries are ignored except for entries that explicitly drop a service.</p> <p>Map - The output channel is mapped to the OutCh and PMT settings. Only services which have entries in the PID map are available on the output. These services will appear in the PMT even if the stream is not present.</p> <p>Drop - The current channel is not sent to the output and its PMT is removed from the output. The OutCh, PMT, and PID map entries are ignored.</p> |
| OutCh     | If mapping the current PE (Act was set to Map), set the output channel number for the current program.   | 1 to 65535   |
| PMT       | If mapping the current PE (Act is set to Map), set the output PID of the PMT.  | 2 to 8190  |
| PID       | Press Select to view and configure the PID map. The PID map is used to map input services to output PIDs. For more information, see PID Map Menu.                                |  |
| Map Mode  | Select the DPM mapping mode for the current output.  | <p>Svc ID - The elementary PIDs are not changed. Channels are remapped by changing their PSI references. When this mode is selected, PID mapping in the PID Map menu is ignored.</p> <p>Svc ID &amp; PID - Channels and the elementary service PIDs can be mapped using the PID Map menu.</p>  |

| Menu Item   | Description  | Parameters   |
|-------------|--|--|
| Duplic Mode | Select how to handle duplicate programs. This setting is only used if the Map Mode menu is set to Svc ID & PID.  | <p>PSI Remap - Every input PID can be mapped to only one output PID. If PID mapping conflicts exist, DPM will use the Precedence Rule to decide which output PID to use. All PMTs using the input PID will be updated to reference the output PID specified by the winner.</p> <p>Pkt Copy - An input PID can be mapped to multiple output PIDs. The PID will be duplicated as many times as needed (up to a certain hardware limitation).</p> <p><b>Note:</b> This may increase the output bandwidth of the stream.</p> <p>Pkt Copy is recommended for most applications.</p> |
| Unref       | Select the action to use for unreferenced content. Unreferenced content is the remainder of the transport stream that is not filtered by the program entries.  | <p>Drop or Pass</p> <p>Drop - All unreferenced content is dropped.</p> <p>Pass - All unreferenced content is passed to the output unchanged.</p>   |
| PSI Options | <p>Select the action to perform on the PSI tables for the output stream.</p> <p><b>Note:</b> The table menus (PAT, CAT, PMT, TSDT, NIT, NITO, SDT, SDTO, BAT, EIT, TDT, RST, TOT, DIT, SIT, ECM, EMM, DRT, CDT) will only appear if you select Ctl by Table.</p> | <p>Pass All - Transmits the incoming PSI Tables as is; does not modify the content and rate. The PSI Rate and table settings are ignored.</p> <p>Drop All - Does not transmit any PSI Tables. The PSI Rate and table settings are ignored.</p> <p>Ctl by Table - Configure the table specific output mode for each table.</p>  |
| PSI Rate    | If the PSI Options was set to Ctrl by Table, select the regeneration rate for those PSI tables being regenerated.  | <p>Auto - Matches the generated PSI tables' output rate to the incoming rate.</p> <p>MPEG Min - Transmits the generated PSI tables on the longest intervals that are allowed by MPEG standard.</p> <p>SA Std - Transmits the generated PSI tables based on PowerVu standard intervals.</p>   |



| Menu Item  | Description  | Parameters   |
|--|--|--|
| Service ID   | Select whether the receiver should always generate PSI tables for the Mapped PE even if the selected input channel is not available, or for only valid service channels/IDs.   | Valid Ch - Only transmits the PSI tables for the mapped program if the program exists on the input stream.<br><br>All Ch - Transmits the PSI tables for the mapped program even if the program does not exist in the input stream.<br><br>All Ch is only valid if the PAT, NIT, SDT and PMT are set to Regenerate. |
| PAT, CAT, PMT, TSDT, NIT, NITO, SDT, SDTO, BAT, EIT, TDT, RST, TOT, DIT, SIT, ECM, EMM, DRT, CDT | Selects the tables which will be passed, dropped, regenerated, or passed with rate control (PwRC) from the output. For more information, see PSI Table Settings.<br><br><b>Note:</b> The table settings are only available if you selected Ctl by Table in the PSI Options menu. |  |
| PE Resync: All, Template, PIDs, Svcs   | Each PE output can be synchronized to its input according to one of four output modes. For information on synchronizing output services, see Synchronizing Output Services.  | Svcs - Map the input to the output based on the services only.<br><br>PIDS - Map the input to the output based on the PIDs only.<br><br>All - Map the input to the output based on the PIDs and services<br><br>Template - Map the input to a fixed template output.   |
| PAT/PMT Offset   | This is a customer-specific mode, only to be used if directed by Cisco. For more information, contact Cisco customer support.  |  |
| NIT Offset   | This is a customer-specific mode, only to be used if directed by Cisco. For more information, contact Cisco customer support.  |  |

PID Map Menu

This menu allows the PID Map to be configured. The PID map is used to map input services to output PIDs.

If the PE action is Pass, or PE action is Map and Map Mode is Svc ID, only entries which drop a service are applied and all other services are passed through. If the PE action is Map and Map Mode is Svc ID & PID, all entries are applied. Any services not mapped by an entry will be dropped.

Press up and down to scroll through the PID map entries. Press **ADV** to insert or delete entries from the PID map. After inserting an entry, specify the service using OutType and In, and set the desired Action. If the action is Map, select the output PID value as well. Then press **APPLY** and save the settings to see the selected input service that will follow that mapping.

| Menu Item | Description   | Parameters  |
|-----------|---|---|
| InTyp     | Displays the input service that will be mapped by the current entry. This value is read-only and for reference purposes.  |   |
| PID       | Displays the input PID that will be mapped by the current entry. This value is read-only and for reference purposes.  | 1 to 8190   |
| Act       | Select the action to perform on the current PID.<br><br>The Drop action is always performed, but the Map option is only applied if the PE action is Map and the Map Mode is Svc ID & PID. | Map - The service selected by the OutType and Instance will be mapped to the specified PID. This is only applied if the PE action is Map and the Map Mode is Svc ID & PID.<br><br>Drop - The service selected by the OutType and Instance will be removed from the PMT and the output stream. |
| OutType   | Select the service to configure. If an input service matches this type and instance specified by In, then the Action will be applied.   | UNKN, ETV, CDT, LSDT, DATA, TTX, MPE, DPI, VBI, SUBT, AUD, VID, PCR or INVL   |
| In        | Select the instance of the service specified by OutType to configure. If an input service matches this type and instance, then the Action will be applied.                                | 1 to 64   |

| Menu Item | Description  | Parameters |
|-----------|--|------------|
| PID       | If mapping this PID (Act is set to Map), select the output PID number. | 1 to 8190  |

## PSI Table Settings

**Note:** The table settings are only available if you selected Ctl by Table in the PSI Options menu.

| Setting | Mode Options            | Description                        | Default |
|---------|-------------------------|------------------------------------|---------|
| PAT     | Pass, Drop, Regen       | Program Association Table          | Pass    |
| CAT     | Pass, Drop, Regen       | Conditional Access Table           | Pass    |
| PMT     | Pass, Drop, Regen       | Program Map Table                  | Pass    |
| TSDT    | Pass, Drop              | Transport Stream Description Table | Pass    |
| NIT     | Pass, Drop, Regen, PwRC | Network Information Table          | Pass    |
| NITO    | Pass, Drop, PwRC        | Network Information Table - Other  | Pass    |
| SDT     | Pass, Drop, Regen, PwRC | Service Description Table          | Pass    |
| SDTO    | Pass, Drop, PwRC        | Service Description Table - Other  | Pass    |
| BAT     | Pass, Drop, PwRC        | Bouquet Association Table          | Pass    |
| EIT     | Pass, Drop              | Event Information Table            | Pass    |
| TDT     | Pass, Drop              | Time and Date Table                | Pass    |
| RST     | Pass, Drop              | Running Status Table               | Pass    |
| TOT     | Pass, Drop              | Time Offset Table                  | Pass    |
| DIT     | Pass, Drop              | Discontinuity Information Table    | Pass    |
| SIT     | Pass, Drop              | Selection Information Table        | Pass    |
| ECM     | Pass, Drop              | Entitlement Control Message        | Pass    |
| EMM     | Pass, Drop              | Entitlement Management Message     | Pass    |

| Setting | Mode Options | Description             | Default |
|---------|--------------|-------------------------|---------|
| DRT     | Pass, Drop   | Disaster Recovery Table | Pass    |
| CDT     | Pass, Drop   | Code Download Table     | Pass    |

**Note:** The CDT is different from the other tables listed because the CDT is referred to within the PMT, rather than outside the PMT. Select Pass to permit the output of CDTs following the configured DPM PID map configuration and all other DPM constraints. If a DPM PID map has not been configured for the CDT PID and the PE Act is set to Map, the CDT will still not output. Select Drop to override the DPM PID map configuration for CDT PIDs and to always drop all CDTs.

#### Setting Up Digital Program Mapping (DPM)

- 1 Verify that you are receiving a valid signal and that you have set up the channels that you want to pass, drop or map.
- 2 Go to the Setup: Outputs, TS Out: DPM: Global menu and select **Resync All** for the selected ASI output. This copies the input services PIDs to the remapped output service PIDs.
- 3 Go to Setup: Outputs: TS Out: DPM: ASI, and select the PE containing the channel you want to configure.
- 4 Set the **Act** for the selected PMT to either **Pass**, **Drop**, or **Map** depending on the action desired.

A program can be set to one of three output modes, either Drop, Pass or Map.

| LCD Setting | Description  |
|-------------|--|
| Drop        | Removes the service and its associated PMT reference from the transport output.  |
| Pass        | Permits the source content and PMT reference to appear in the transport output with the same references.                   |
| Map         | Provides the flexibility to define all the outgoing PID numbers for the PE, including those not currently on transmission. |

- 5 Use the **RIGHT** arrow key to move to the right and select PID to display the detailed menu level.
- 6 Configure the input to output channel mapping. Video and PCR can be output on the same PID or different PIDs. If output on the same PID, they will appear identical to the input.

**Note:** If the parameters cannot be saved, the problem may be that the incorrect Map Mode has been selected. Ensure that Svc ID & PID is selected when remapping PIDs, otherwise a message such as “Bad configuration data” will be displayed and you will need to change the parameters to obtain the correct output.

- 7 Go to Setup: Outputs, TS Out: ASI, and set the **Output Mode** to **Full DPM Control**. Also, if necessary set the Descramble Mode according to whether the program is to be Scrambled or Descrambled for downstream viewing/monitoring.
- 8 On the same menu, set the following parameters:

| Parameter   | Description  |
|-------------|--------------|
| Map Mode    | Svc ID & PID |
| Duplic Mode | Pkt Copy     |
| Unref       | Drop         |
| PSI Options | Ctl By Table |
| PSI Rate    | Any          |
| Svc ID      | Any          |

- 9 Set the table parameters as follows:

| Parameter | Description   |
|-----------|---------------|
| PAT       | Regen         |
| CAT       | Regen         |
| PMT       | Regen         |
| TSDT      | Drop          |
| NIT       | Regen or Drop |
| NITO      | Drop          |
| SDT       | Regen         |
| SDTO      | Drop          |
| BAT       | Drop          |
| EIT       | Drop          |
| TDT       | Pass          |
| RST       | Pass          |
| TOT       | Pass          |
| DIT       | Pass          |
| SIT       | Pass          |
| ECM       | Drop          |
| EMM       | Drop          |
| DRT       | Drop          |
| CDT       | Drop          |

## Chapter 4 Front Panel Operation

- 10 Press **MENU** three times to exit the TS Out menu and save the data. If the changes cannot be saved/made, a message will be displayed indicating "Bad configuration data". The following options are available: Abandon, Exit or Return. Select Return to re-enter the parameter.

**Note:** When remapping an input program channel to an output channel, ensure that the PIDs are mapped to different PIDs to avoid PID collisions.

### Synchronizing Output Services

To synchronize the output to the input Services Only:

This operation synchronizes the inputs to the outputs according to the service assignments only. This is useful when you already have PID assignments set for the services but want to ensure that the services are mapped correctly.

- 1 On the DPM menu, map the output services as desired.
- 2 Select PE Resync: Svcs. The receiver will synchronize the PE output according to the available input services only, and ignore the input to output service PID mapping.

To synchronize the output to the input PIDs only:

This operation synchronizes the inputs to the outputs according to the PID assignments only. This is useful when you have already have the services set up but want to synchronize to the incoming PIDs.

- 1 On the DPM menu, map the output services as desired.
- 2 Select PE Resync: PIDs. The receiver will synchronize the PE output according to the input PIDs only, and ignore the service assignment categories/names.

To synchronize the output to All (Services and PIDs):

This operation synchronizes the inputs to the outputs of the current PMT according to the service assignments and then the PID assignments. This is similar to a sample and hold function.

- 1 On the Detailed Program Mapping Active menu, map the outputs services as desired.
- 2 Select PE Resync: All. The receiver will synchronize the PE output according to the services and then the PIDs assigned to each service.

To synchronize the output to a Template:

Using a template allows you to preset the input to output mapping of a PE according to the preset template. This is helpful in pre-configuring any number of PEs for future use.



## Chapter 4 Front Panel Operation

| Menu Item         | Description  | Parameters   |
|-------------------|--|--|
| ADP Enc Total     | Indicates the total number of encrypted Addressable Data Packets received. Ideally, the ADP Enc Pass and ADP Enc Total numbers should be identical.  |  |
| ADP Non-Enc Pass  | Indicates the number of non-encrypted Addressable Data Packets successfully processed. Ideally, the ADP Non-Enc Pass and ADP Non-Enc Total numbers should be identical.  |  |
| ADP Non-Enc Total | Indicates the total number of non-encrypted Addressable Data Packets received. Ideally, the ADP Non-Enc Pass and ADP Non-Enc Total numbers should be identical.  |  |
| Clear ADP Counts  | Select to clear the Addressable Data Packet counters: ADP Enc Pass, ADP Enc Total, ADP Non- Enc Pass and ADP Non-Enc Total. These values are also reset whenever the receiver is turned on, reset or power-cycled. |  |
| BISS Mode         | Sets the Basic Interoperable Scrambling System (BISS) mode for the receiver. All channels assigned to a PE identified as BISS CA-controlled in the PMT will be decrypted.  | Mode 1 or Mode E   |
| BISS-1 SW         | If BISS Mode is Mode 1, enter the session word.  | 12-character password. Once entered, it cannot be viewed and it is only displayed as asterisks (*).<br>Contact your program provider for the session word. |
| BISS-E ESW        | If BISS Mode is Mode E, enter the encrypted session word.  | 16-character password. Once entered, it cannot be viewed and it is only displayed as asterisks (*).<br>Contact your program provider for the session word. |






## Chapter 4 Front Panel Operation

| Menu Item                 | Description  | Parameters  |
|---------------------------|--|---|
| Alarm Vid Cutoff          | Select whether the video output is cut off if any enabled alarm is active on the receiver. When video is cut off, there will be no horizontal or vertical synchronization on the output. This is useful for downstream redundancy switching by detecting a loss of video signal.<br><b>Note:</b> This function also exists under Setup: Services: Video. | Enable or Disable<br>The default is Disable.  |
| System Alarm/Warning Name | Displays the alarm or warning to configure.  |   |
| Enb                       | Select whether the current alarm is enabled or disabled. If the alarm is disabled, the Rly and Trp settings are ignored  | Yes or No   |
| Rly                       | If the current alarm or warning is enabled (Enb is set to Yes), select whether it will trigger the rear panel relay when the alarm is set or cleared.  | Yes or No<br><b>Note:</b> No is a read only value that indicates the setting is Yes, but is currently being suppressed because the alarm or warning is disabled (Enb is set to No). |
| Trp                       | If the current alarm or warning is enabled (Enb is set to Yes), select whether it will send SNMP trap messages when the alarm is set or cleared.   | Yes or No<br><b>Note:</b> No is a read only value that indicates the setting is Yes, but is currently being suppressed because the alarm or warning is disabled (Enb is set to No). |

## Setup Menu: Noise Cutoffs



To view the Noise Cutoffs menu from the Main menu, press the **RIGHT** arrow key once and then the **SELECT** key to reach the Setup menu. Then press the **RIGHT** arrow key eight times and the **SELECT** key to view the Noise Cutoffs menu.

The Noise Cutoffs menu allows you to set the muting thresholds for both audio and video in the event of a noisy signal. This menu has the following structure:



| Menu Item   | Description   | Parameters   |
|---|---|--|
| Trnsprt(DVBS Marg)<br>Cutoff<br><br>Trnsprt(DVBS2 Marg)<br>Cutoff   | Sets the DVB-S and DVB-S2 Carrier to Noise margins, in dB, below the transport outputs that will be muted.<br><br>The receiver uses these thresholds to determine when to mute the transport in the event of a noisy signal, poor, or loss of signal condition. | -30.0 to 30.0<br><br>This setting must be below the respective Restore value.<br><br>The default is 0.0.<br><br><b>Note:</b> Muting Control must be set to Enable for these settings to be active. |
| Trnsprt(DVBS Marg)<br>Restore<br><br>Trnsprt(DVBS2 Marg)<br>Restore | Sets the DVB-S and DVB-S2 Carrier to Noise margins, in dB, above the transport outputs that will be muted.<br><br>The receiver uses these thresholds to determine when to restore the transport after it has been muted.  | -30.0 to 30.0<br><br>This setting must be above the respective Cutoff value.<br><br>The default is 0.1.<br><br><b>Note:</b> Muting Control must be set to Enable for these settings to be active.  |

Chapter 4 Front Panel Operation

| Menu Item   | Description   | Parameters  |
|---|---|---|
|   | <p>The following displays the Transport Default C/N Margin Relationship</p>   |   |
| <p>Audio(DVBS Marg) Cutoff<br/>Audio(DVBS2 Marg) Cutoff</p>   | <p>Sets the DVB-S and DVB-S2 Carrier to Noise margins, in dB, below the audio outputs that will be muted.</p> <p>The receiver uses these thresholds to determine when to mute the audio in the event of a noisy, poor, or loss of signal condition.</p> | <p>-30.0 to 30.0</p> <p>This setting must be below the respective Restore value.</p> <p>The default is 0.0.</p> <p><b>Note:</b> Muting Control must be set to Enable for these settings to be active.</p> |
| <p>Audio(DVBS Marg) Restore<br/>Audio(DVBS2 Marg) Restore</p> | <p>Sets the DVB-S and DVB-S2 Carrier to Noise margins, in dB, above the audio outputs that will be restored.</p> <p>The receiver uses these thresholds to determine when to restore the audio after it has been muted.</p>                              | <p>-30.0 to 30.0</p> <p>This setting must be below the respective Cutoff value.</p> <p>The default is 0.1.</p> <p><b>Note:</b> Muting Control must be set to Enable for these settings to be active.</p>  |
|   | <p>The following displays the Audio Default C/N Margin Relationship</p>   |   |

## Setup Menu


| Menu Item        | Description   | Parameters                                       |
|------------------|---|--|
| Restore Defaults | Select to restore the default muting thresholds.  |  |
| Muting Control   | Select whether to enable or disable muting cutoffs.<br><br>If disabled, all the other settings are ignored. | Enable or Disable.<br><br>The default is Enable. |

## About Menu

To view the About menu from the Main menu press the **RIGHT** arrow key two times and then the **SELECT** key.

The About menu provides basic hardware information that is useful when requesting customer support from Cisco.

Each parameter is described below. The About menu has the following structure:



### General

| Menu Item   | Description  |
|-------------|--|
| Host Name   | Sets the host name of the current unit. It is a user configurable name that appears on the Web Interface title to identify the receiver. |
| Tracking ID | Displays the unique Tracking ID number that identifies the product version. This is read-only.   |
| Model       | Indicates the model number and name of the receiver. This is read-only.  |
| Master UA   | Indicates the Master User Address (UA), which is required to request program authorization from the uplink. This is read-only.           |
| Ver         | Indicates the version number of the ISE.   |

| Menu Item     | Description  |
|---------------|--|
| Serial Number | Indicates the unique device serial number.   |
| Customer Code | Indicates the unique Customer Code assigned to an organization by Cisco.               |
| Board ID      | Indicates the hardware board design identification.                                    |
| Revision      | Indicates the revision number of the board design.                                     |
| MAC Address   | Indicates the MAC address of the Control Port Ethernet interface.                      |
| FPGA Type     | Indicates the FPGA type and number information.  |
| SDI           | Indicates whether the receiver is equipped with an SDI output.                         |
| MPEGoIP       | Indicates whether the receiver is equipped with an MPEG over IP output.                |
| SFN           | Indicates whether the receiver is configured as a SFN (Single Frequency Network) unit. |

## Licenses


| Menu Item | Description   | Parameters                                      |
|-----------|---|---|
| Feature   | Displays a list of software licenses for the D9854 Advanced Program Receiver. Press up and down to scroll through the list of features.   | HD Decode, H.264 Decode, DVB-S2, or MPEGoIP Out |
| Enb       | Indicates whether the selected software feature is licensed and enabled.<br><br><b>Note:</b> All software licenses are enabled for this release (temporarily). Any of these required licenses will need to be purchased from Cisco in subsequent software releases. | Yes or No                                       |

## Versions Menu

To view the Versions menu from the Main menu press the **RIGHT** arrow key three times and then the **SELECT** key.

The Versions menu provides basic software information that is useful when requesting customer support from Cisco.

The menu has the following structure:



| Menu Item   | Description                                       |
|-------------|---|
| App Current | Indicates the version of the current application. |



| Menu Item                    | Description  |
|------------------------------|--|
| App Safe                     | Indicates the version of the factory loaded safe application.  |
| App Safe Limit               | Indicates the version of the oldest application that can be installed on the current unit. If this value is zero, the oldest application limit is the App Safe version. If this is greater than zero, the shown value or older and the App Safe version is the limit. Older applications will not be installed.  |
| Primary Boot/Secondary Boot  | Indicates the versions of the primary and secondary processors' boot code.   |
| FPPIC                        | Indicates the version of the front panel PIC microcontroller.  |
| FPGA Safe                    | Indicates the version of the factory loaded safe Field Programmable Gate Array (FPGA) code.  |
| FPGA Current                 | Indicates the version of the current Field Programmable Gate Array (FPGA) code.  |
| Ver Register                 | Indicates the version of FPGA code read from the FPGA.   |
| CPLD Primary, CPLD Secondary | Indicates the versions of the current primary and secondary Complex Programmable Logic Device (CPLD).  |
| Application, Select, Erase   | <p>Application - Select between all versions of the application loaded on the current unit.</p> <p>Select - Select and then scroll to Yes to reboot the unit and load the selected application. You will be prompted to continue or abort this operation.</p> <p><b>Note:</b> Selecting an application will cause the unit to reboot and interrupt service.</p> <p>Erase - Select to erase the selected application. You will be prompted continue or abort this operation. You cannot erase the safe application or the current application. While an application is being erased, the busy indicator will appear. You cannot erase another application until it is complete.</p> |

## Chapter 4 Front Panel Operation


| Menu Item                   | Description   |
|-----------------------------|---|
| FPGA Version, Select, Erase | <p>FPGA Version - Select between all versions of the FPGA code loaded on the current unit.</p> <p>Select - Select and then scroll to Yes to reboot the unit and load the selected FPGA code. You will be prompted to continue or abort this operation.</p> <p><b>Note:</b> Selecting an FPGA code will cause the unit to reboot and interrupt service.</p> <p>Erase - Select to erase the selected FPGA code. You will be prompted continue or abort this operation. You cannot erase the safe FPGA code or the current FPGA code. While an FPGA code is being erased, the busy indicator will appear. You cannot erase another FPGA code until it is complete.</p> |

# Diagnostics Menu

To view the Diagnostics menus from the Main menu, press the **RIGHT** arrow key four times and then the **SELECT** key.

For instructions on how to select and store settings, see *About the Front Panel* (on page 38).

The Diagnostics menu has the following structure:



## Alarms/Warnings

| Menu Item     | Description  |
|---------------|--|
| View History  | Select to view the system event messages. Press the <b>UP</b> and <b>DOWN</b> arrow keys to scroll through the list of alarms and warnings. Press the <b>LEFT</b> and <b>RIGHT</b> arrow keys to view the set and reset times. Press the <b>INFO</b> key to view the detailed message. |
| Clear History | Select to clear any existing history information.  |

## Logs

| Menu Item  | Description   |
|------------|---|
| View Logs  | Select to view the system log messages. Press the <b>UP</b> and <b>DOWN</b> arrow keys to scroll through the list of log messages. Press the <b>INFO</b> key and then <b>UP</b> and <b>DOWN</b> arrow keys to view the complete message text. |
| Clear Logs | Select to clear any existing log history information.   |

| Menu Item | Description   |
|-----------|---|
| View DL   | Select to view the system download history messages. Press the <b>UP</b> and <b>DOWN</b> arrow keys to scroll through the list of downloaded messages. Press the <b>INFO</b> key and then <b>UP</b> and <b>DOWN</b> arrow keys to view the complete message text. |

## PSI - Frequency Plan

This is the Frequency Plan sub-menu. You cannot make any changes here, but you can view the available frequency plans stored in the receiver. Press the UP and DOWN arrow keys to scroll through the list of available transports.

| Menu Item  | Description                                    | Parameters   |
|------------|--|--|
| TxID       | Transport ID                                   |  |
| Freq(GHz)  | Downlink Frequency (GHz)                       | 0.0 to 15.0 GHz  |
| FEC        | Forward Error Correction inner code rate       | 1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 7/8, 8/9, or 9/10  |
| Pol        | Polarity of the received signal (H, V, or Off) | Horiz (Horizontal), Vert (Vertical), Circ_l (Left Circular), or Circ_r (Right Circular). |
| ONID       | Original Network ID                            |  |
| SymRate    | Symbol Rate, in Mbps                           |  |
| Modulation | Modulation of the signal                       | QPSK DVB-S, QPSK DVB-S2, 8PSK DVB-S2 or 16QAM DVB-S2                                     |
| OrbPos     | Orbital Position of the satellite (in degrees) | East or West   |

## PSI - Channels

This is the Virtual Channel sub-menu. You cannot make any changes here, but you can view the available channels and their settings. Press the **UP** and **DOWN** arrow keys to scroll through the list of channels.

| Menu Item | Description   |
|-----------|---|
| VC        | Virtual channel number.   |
| TxID      | Identification number of the transport on which the channel is available. For more information on the transport streams, see <i>PSI - Frequency Plan</i> (on page 124). |
| PMT       | PID of the channel's Program Map Table. It is displayed as ---- if unavailable.   |

|              |   |
|--------------|---|
| EMC          | PID of the channel's Entitlement Control Message stream. It is displayed as ---- if unavailable or not scrambled. |
| Program Name | Name of the channel.  |

## PSI - Tables

This is the Tables received sub-menu. You cannot make any changes here, but you can view the PSI tables received and their settings. Press the **UP** and **DOWN** arrow keys to scroll through the list of tables.

| Menu Item | Description                                     | Parameters   |
|-----------|---|--|
| Type      | The MPEG table acronym.                         | PAT, CAT, PMT, TSDT, NIT, NIT Other, SDT, SDT Other, BAT, AEIT P/F, OEIT P/F, TDT, RST, ST, TOT, DIT, SIT, ECM Odd, ECM Even, EMM, MPE, DPI, DRT, CDT, MCT, MIT, MAT, ECT, or Invalid Table ID |
| Tbl-ID    | Unique Table ID.                                |  |
| ID        | MPEG/DVB Table ID.                              |  |
| Ver       | Table Version number.                           |  |
| PID       | Value of the PID on which the table is present. |  |
| Status    | Reception status of the table.                  | None, Partial, Full, Update, Timeout, or Lost  |
| Sections  | Number of sections in the table.                |  |

## Power On

| Menu Item              | Description   |
|------------------------|---|
| Creation Date and Time | Displays the date and time the current unit was manufactured.   |
| Power On Date and Time | Displays the date and time the current unit was last powered up, in relation to the current local time. |
| Total Hrs              | Displays the total number of hours the current unit has been running since being manufactured.          |
| Hrs Since Last Pwroff  | Displays the number of hours the current unit has been running since the last power up.                 |

## Chapter 4 Front Panel Operation

| <b>Menu Item</b>      | <b>Description</b>   |
|-----------------------|--|
| Tot Rst #,            | Displays the total numbers of times the current unit has been reset since it was manufactured.           |
| Clrbl Rst #           | Displays the number of times the unit has been reset since the clearable reset counter was last cleared. |
| Clr Rst #             | Select this option to clear/reset the Clrbl Rst # counter to 0.  |
| Reason For Last Reset | Displays the reason for the last reset.  |

## Health Monitor

| <b>Menu Item</b>             | <b>Description</b>  | <b>Parameters</b> |
|------------------------------|---|-------------------|
| Cur Temp, Max Temp, Avg Temp | Displays the current (Cur Temp), maximum (Max Temp) and the average (Avg Temp) operating temperature. | Degrees Celsius   |

# 5

## Web GUI Setup and Monitoring

### Introduction

This chapter describes how to set up the D9854 Advanced Program Receiver using the web GUI.

### In This Chapter


|  |     |
|--|-----|
| ■ Logging On to the Web Interface.....           | 128 |
| ■ D9854 Summary Overview .....                   | 129 |
| ■ D9854 Menus .....                              | 131 |
| ■ D9854 Web GUI Environment .....                | 133 |
| ■ Setting up Input Information .....             | 134 |
| ■ Setting up Audio and Video Information .....   | 158 |
| ■ Configuring Transport Stream Information ..... | 173 |
| ■ Configuring System Settings.....               | 191 |
| ■ Viewing Support Information.....               | 216 |

## Logging On to the Web Interface

- 1 Open a web browser.

**Note:** The supported web browsers are: Internet Explorer 7.0, Internet Explorer 8.0, Firefox 3.5, and Firefox 3.6.

- 2 Type the IP address of the D9854 Advanced Program Receiver in the Address bar and press **Enter**.



- 3 Type the **Username** and **Password**.

**Note:** The username and password are case-sensitive. The default username is **admin** and the default password is **localadmin**. If you have forgotten your username and password you can reset them from the front panel menu of the D9854 Advanced Program Receiver. For more information, see *Resetting the Login Credentials* (on page 34).

**Important:** The password and user name will be remembered for the whole of the web session. Close the web browser if you want to prevent others from accessing the settings of the D9854 Advanced Program Receiver.

If your session expires, you must refresh the browser and log back in.

- 4 Click **Log in**.

**Note:** If you select **Remember username**, the user name will be remembered the next time you log into the web GUI.



## D9854 Summary Overview

From the user interface of the D9854, click **Summary > Summary Dashboard**. The Summary Dashboard page is displayed.

The screenshot shows the D9854 Summary Dashboard interface. At the top, there is a navigation bar with 'Summary' selected. Below it, a 'Shortcuts - click to open the specific setup pages' bar contains icons for 'Input Setup', 'Program Selection', 'Video Setup', 'Audio Setup', 'Settings File', and 'Service Actions'. The main dashboard area is divided into several modules:

- Decoded Program Status**: A table with columns for Audio, PID, Language, Format, Bit Rate, SFR, and Buffer. It shows two rows of data.
- Audio Status**: A table with columns for Audio, PID, Language, Format, Bit Rate, SFR, and Buffer. It shows two rows of data.
- Current Input Status**: A table with columns for parameter and value. It shows: Downlink Frequency (GHz) 3.449, IQ Opposite, L band Frequency (MHz) 1701.0, Signal Status No Lock, and Symbol Rate (Msym) 28.3465.
- Tuner Performance**: A section with two horizontal bars: C/N Margin (dB) at -2.5 and Signal Level (dBm) at -8.5. It also shows RF Lock (NoLock) and AFC (0.1).

At the bottom left, there is a copyright notice: © 2008-2010 Cisco Systems Inc. All rights reserved.


The Summary Dashboard page displays the main settings of the D9854 Advanced Program Receiver.

The shortcuts above the modules in the Summary Dashboard page are shortcuts to the various setup pages. For example, click **Video Setup** to open the Video Setup page.

You can customize the Summary Dashboard by temporarily minimizing or removing the modules displayed. Each module has a maximize and minimize button, allowing you to view or hide various modules. The default view is displayed when you refresh the Summary Dashboard page.

## Chapter 5 Web GUI Setup and Monitoring

You can also customize the Dashboard by clicking on **Add/Remove Module**. The Dashboard Configuration window is displayed.



The following table describes the all the available modules:

| Module                 | Description  |
|------------------------|--|
| Decoded Program Status | Displays channel and service information.  |
| Audio Status           | Displays the current audio status information, such as the audio format and sampling frequency.                                    |
| Current Input Status   | Displays the current RF Tuning Status information, including the downlink frequency and signal status.                             |
| Tuner Performance      | Displays the satellite dish status, such as the C/N Margin and Signal Level.   |
| Video Status           | Displays the current video information.  |
| Channel Status         | Displays the channel status information, such as the type of CA used and whether the receiver is authorized to receive the signal. |
| PID Information        | Displays the PIDs associated with the channels.  |
| CI Status              | Displays the CAM card information.   |
| Fault Active List      | Displays the currently active alarms and warnings.   |

## D9854 Menus

The D9854 web GUI has menus at the top of the page.



The functions for the menus are as follows:

- **Summary**  
From this menu, you can obtain an overview of the D9854 operation.
- **Input**  
From this menu, you can:
  - set up RF and ASI inputs,
  - configure muting thresholds,
  - view input status,
  - configure channels,
  - configure CI (Common Interface) settings,
  - view PSI, Frequency, and Channel tables.
- **Audio & Video**  
From this menu, you can:
  - configure video settings,
  - set up closed caption and subtitles,
  - configure audio settings,
  - view current audio status,
  - set the cueing parameters.
- **Transport Stream**  
From this menu, you can:
  - configure ASI and MPEGoIP outputs,
  - configure receiver settings.
- **System Settings**  
From this menu, you can:

## Chapter 5 Web GUI Setup and Monitoring

- view alarm and warning status information
- configure ethernet ports,
- set date and time formats,
- configure lock levels.


### ■ Support

From this menu, you can:

- view logs,
- view contact information,
- view and upgrade software version.

# D9854 Web GUI Environment

The following is an example of a D9854 Web GUI page:



## Window Buttons

The GUI of the D9854 has the following general buttons:

| Button         | Description   |
|----------------|---|
| Apply          | Saves and applies the settings to the receiver.   |
| Refresh        | Reads existing data from the D9854. If edits were made in a setup page, then unsaved changes are discarded. |
| Reset Defaults | Discards any changes made and sets data to default values.  |
| Clear Counters | Resets counters on the displayed page.  |

## Setting up Input Information

### Setting up the RF Input

- 1 From the user interface of the D9854, click **Input > Input Setup**. The Input Setup page is displayed.



- 2 In the RF Input Selection section, select **Use RF Input** to activate an RF input. You can select RF 1 to RF 4 below.
- 3 Select UserCfg in the **Input Selection** to lock to the RF input set by the user. Select SW Map to use the orbital position settings to select the RF input. It is recommended that you validate the orbital position for SW Map option.
- 4 Select an RF input to activate (**Use RF 1, Use RF 2, Use RF 3, or Use RF 4**).
- 5 In the **Tuning** section, enter the current operating **Downlink Frequency** used by the receiver for tuning the received digital signal. You can enter a value in the range from 0.0 to 15.0 GHz.
- 6 Type the **Symbol Rate**. The symbol rate must match that of transmitted signal. You can enter a value in the range from 1.0 to 45.0 Ms/s for DVB-S, 1.0 to 30.0 for DVB-S2 if Pilot Present is set to Yes on the Front Panel, or 5.0 to 30.0 for DVB-S2 if Pilot Present is set to No on the Front Panel.
- 7 Select the Forward Error Correction (**FEC**) inner code rate. The FEC rate must match the FEC of the transmitted signal. You can select 1/2, 2/3, 3/4, 5/6, 7/8, or Auto.
- 8 Select the **Modulation** type for the received signal (DVB-S or DVB-S2).

- 9 Select the **Roll Off** factor of the incoming signal (.20, .25, .35). Set the value to .20 or .35 when DVB-S modulation is used, and either of the three when DVB-S2 is used. Use a small number to reject or filter carriers close to the same frequency.
- 10 Set the input signal spectrum inversion setting (**IQ**), which allows the operator to track and select inverted and non-inverted digital signals. This is normally used to automatically reject or filter out unwanted signals.

When set to Auto, signal is tracked and inverted for correct selection, as required. When set to Opposite, the signal is always inverted. Conversely, when set to Normal, the signal is not inverted.


- 11 The **RF1 22KHz** is only applicable for dual band applications. Select whether to transmit the 22 kHz tone Local Oscillator control signal of RF1. The selections are On, Off, or Auto. Select Auto to use the crossover frequency to determine if the tone is transmitted.
- 12 In the **RF1 Power** drop-down menu, set the power output of RF1 to the external Low Noise Block (LNB).

You can set the RF1 Power to Off, 13V, 18V, V-NIT or H-NIT. When RF1 Power is set to V-NIT or H-NIT, it will use vertical and horizontal polarity until it is automatically read from the NIT.

**Note:** Power will not be applied to the LNB when set to Off.

- 13 In the **RF Input LNB Configuration** section, for RF1, RF2, RF3, and/or RF4, set the lower local oscillator frequency, in GHz, of the LNB in the **LO1 (Ghz)** column. If it is a single band oscillator, set its frequency, in GHz. You can enter a value in a range from 0.0 to 15.0 GHz. This value must be lower than the value for LO2.
- 14 For RF1, RF2, RF3, and/or RF4, set the higher oscillator frequency, in GHz, of the LNB in the **LO2 (Ghz)** column. If it is a single band oscillator, set this value to 0.0. You can enter a value in a range from 0.0 to 15.0 GHz. This value must be higher than the value for LO1. In single-band LNB applications, set this value to 0.0.
- 15 Enter the **Crossover** frequency for RF1, RF2, RF3, and/or RF4. This is an internal threshold frequency used for selecting the LO1 or LO2 frequency, depending on the current downlink frequency settings. This option is only used in dual-band LNB applications.  
You can enter a value in a range from 0.0 to 15.0 GHz. In a single-band LNB applications, set this value to 0.0.
- 16 Select the signal **Polarisation** setting (Horizontal, Vertical, or Automatic). This setting is only applicable when the LNB Power is set to H-NIT or V-NIT. It marks the polarity of the signal connected to the current RF input.

- 17 Set the Orbital Position (**Orbital Posn**) for RF1, RF2, RF3, and/or RF4, in degrees. This is the location in orbit of the satellite currently being used. The satellite position (in degrees) in combination with the direction (either E (East) or W (West)) denotes the satellite position the dish connected to the current RF Input should point. This is used when the satellite is not available in the look-up menu list.  
  
For manual configuration, enter the location of the satellite using the numerical keypad. The receiver will not recognize the satellite name and identify it as Unknown. This setting is required to resolve any ambiguity between RF inputs during automatic disaster recovery.
- 18 Select the **East/West Flag** for RF1, RF2, RF3, or RF4. This is the satellite position the dish connected to the current RF Input should point. The options are East, West, or N/A (Not Applicable).
- 19 Click **Apply**.
- 20 Click **Validate Orbital Position** to validate the RF inputs to match those expected by the network. The receiver will check to see if all frequencies in the Network Information Table (NIT) can be tuned to. The Date is displayed as the last date that the Validate operation was performed.
- 21 Click **Reacquire** to re-acquire the signal using the tuning parameters from user settings. The Reacquire Network Information window is displayed.



Select **Reacquire Tuning & Channel List Only** for the decoder to tune back to the user configured input and frequency and re-acquire the PSI/SI information back to the selected channel. Click **OK**.

**Note:** This operation can take several minutes, depending on the size of the network.

- 22 The **Current Input Status** section displays the current RF status.

| Current Input Status    |            |                    |                          |
|-------------------------|------------|--------------------|--------------------------|
| Downlink Frequency(GHz) | 3.449      | I/Q                | Opposite                 |
| L band Frequency(MHz)   | 1701.0     | Signal Status      | No Lock                  |
| Symbol Rate(Msym)       | 28.3465    | TS ID              |                          |
| FEC                     | N/A        | Input              | RF1                      |
| Modulation Type         | QPSK DVB-S | Acquisition State  | None                     |
| Pilots                  | N/A        | Orbital Validation | None 1901/01/01 00:00:00 |

The following table describes the Current Input Status information displayed:



## Setting up Input Information

| Parameter                | Description   |
|--------------------------|---|
| Downlink Frequency (GHz) | The current downlink frequency, in GHz.   |
| L band Frequency (MHz)   | The current L-Band frequency, in MHz.   |
| Symbol Rate (Msym)       | Symbol rate of the received signal, in Msymbols/second.   |
| FEC                      | The FEC (Forward Error Correction) rate of the received signal (N/A, 1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 7/8, 8/9 or 9/10).   |
| Modulation Type          | The modulation type for the received signal (N/A, QPSK, 8PSK, DVB-S or DVB-S2).   |
| Pilots                   | Indicates whether a Pilot is present for the received signal. The Pilot is set on the modulator for input signal synchronization purposes.  |
| I/Q                      | The IQ (Input Signal Inversion) for the received signal (Inv or NonInv).  |
| Signal Status            | Indicates whether the input signal is locked. <ul style="list-style-type: none"> <li>■ Locked - Indicates the receiver is locked to a carrier with no valid content.</li> <li>■ Lock+Sig - Indicates the receiver is locked to a carrier with valid content.</li> <li>■ No Lock - Indicates the receiver is not locked to a carrier.</li> </ul> |
| TS ID                    | The Transport ID (in the range from 1 to 65535).  |
| Input                    | The active input port receiving the signal (RF1, RF2, RF3, RF4, or ASI).  |
| Acquisition State        | Displays Full if the ASI and PSI tables have all been found. Otherwise, it will display Degraded if there are missing tables or None if no ASI or PSI tables have been found.   |
| Orbital Validation       | Displays the last date that the Validate Orbital Position operation was performed.  |

**23** Click **Apply**.

## Setting up the ASI Input

- 1 From the user interface of the D9854, click **Input > Input Setup**. The Input Setup page is displayed.
- 2 Click on the **ASI** tab.



- 3 Select **Use ASI Input** to tune to the ASI input.  
**Note:** Setting a new input to be active will deactivate the currently active input.
- 4 The **ASI Input Status** section displays the current RF status. The following table describes the ASI Input Status information displayed:

| Parameter         | Description   |
|-------------------|---|
| Active Input      | Indicates the currently selected input source (RF1, RF2, RF3, RF4, or ASI).   |
| Signal Status     | Indicates whether the input signal is locked. <ul style="list-style-type: none"> <li>■ Locked - Indicates the receiver is locked to a carrier with no valid content.</li> <li>■ Lock+Sig - Indicates the receiver is locked to a carrier with valid content.</li> <li>■ No Lock - Indicates the receiver is not locked to a carrier.</li> </ul> |
| Input Rate (Mbps) | Displays the bit rate of the input transport stream, in Mbps.   |
| ASI Link          | Indicates whether there is a transport stream link error (Error, Ok, or N/A).   |


## Setting up Input Information

| Parameter               | Description  |
|-------------------------|--|
| ASI Transport           | Indicates the current transport synchronization status (Error, Ok, or N/A).  |
| ASI Packet Size (bytes) | Indicates the packet size (in bytes) for the ASI input (188, 204, or N/A).   |
| Acquisition State       | Displays Full if the ASI and PSI tables have all been found. Otherwise, it will display Degraded if there are missing tables or None if no ASI or PSI tables have been found.  |
| TS ID                   | The Transport ID (in the range from 1 to 65535).   |
| Network ID              | The Network ID (in the range from 1 to 65535) of the uplink signal the receiver is to receive when using the selected preset. The receiver's Network ID must match the Network ID associated with the transmitted signal that identifies the NIT to be used.<br><br><b>Note:</b> Each network must be assigned a unique ID (number). |

- 1 Click **Apply**.


## Setting up SI Receive Parameters

- 1 From the user interface of the D9854, click **Input > Input Setup**, expand **Input Setup** and then click **SI Receive Setup**. The SI Receive Setup page is displayed.



- 2 In the **Custom Tuning Mode** section, **Acquisition Mode** drop-down menu, select the tables required for the service list creation and signal acquisition. The selections are Auto, Basic, or Custom. The default is Basic. If you select Basic, it requires NIT to be present. If you select Auto, it uses all the available service list tables and it will acquire if any table is present.

If you select Custom, click **Configure Custom SI Recv** and the Configure Custom SI Recv window opens:



- 3 Set the **Frequency Tuning Mode**, which determines whether to use the NIT to tune to other transports, or to force the tuning to user configuration settings. Select NIT and the receiver can change tuning parameters to use all transports available in the NIT. Select User Cfg to force the receiver to use the user selected tuning parameters.
- 4 The **Service List mode** determines which tables are required for tuning. Rigorous requires all service list tables to be present to acquire the signal. Degraded requires any service list table to be present to acquire the signal.
- 5 In the **Network Information Table (NIT)** drop-down menu, select Yes to use the NIT when creating the service list.
- 6 In the **Service Description Table (SDT)** drop-down menu, select Yes to use the SDT when creating the service list.
- 7 In the **Program Association Table (PAT)** drop-down menu, select Yes to use the PAT when creating the service list.  
**Note:** You cannot change the Bouquet Association Table value. It is not supported in the current release.
- 8 Click **OK**.
- 9 Enter the **Network ID** of the uplink signal the receiver is to receive when using the selected preset. The receiver's network ID must match the network ID associated with the transmitted signal that identifies the NIT to be used. You can enter a value in the range from 1 to 65535. The default is 1.
- 10 In the **CA Mode** drop-down list, select how the conditional access will attempt to descramble the scrambled programs. The behavior of this setting is different between PowerVu streams and those that require a CAM.  
For PowerVu Streams:
  - Std - In standard mode, if a program is not authorized, even if some services are not scrambled, the whole program will not be authorized.
  - Open - In open mode, if a program is not authorized, any services in the program that are not scrambled will still be available.
 For Non-PowerVu (CAM) streams:
  - Std - In standard mode, if a program's CA system is not supported by the CAM, the channel is not authorized.
  - Open - In open mode, all the program's CA systems are validated by the CAM. The channel is always authorized.
- 11 The **SI Receive Status** section displays all the current SI Receive settings. It also displays the source of last tuning and the last Preset Number activated. The **Service List From** section displays the current settings of the allowed services (BAT, NIT, SDT, PAT).
- 12 Click **Apply**.

## Setting up Muting Threshold Controls

- 1 From the user interface of the D9854, click **Input > Input Setup**, expand **Input Setup** and then click **Muting Thresholds**. The Muting Thresholds page is displayed.




- 2 Select **Enable Threshold Muting** to mute the transport stream and audio in the event of an unstable, poor, or loss of signal condition. The default is selected.
- 3 The **Transport Mute** for both **DVB-S C/N Margin (dB)** and **DVB-S2 C/N Margin (dB)** sets the DVB-S and DVB-S2 Carrier to Noise margins, in dB, below the transport outputs that will be muted. The receiver uses these thresholds to determine when to mute the transport in the event of a noisy, poor, or loss of signal condition. The adjustable operating range is from -30.0 to 30.0 dB. This setting must be below the respective Restore value. The default setting is 0.0.

**Note:** Enable Threshold Muting must be selected for these settings to be active.

- 4 The **Transport Restore** for both **DVB-S C/N Margin (dB)** and **DVB-S2 C/N Margin (dB)** sets the DVB-S and DVB-S2 Carrier to Noise margins, in dB, above the transport outputs that will be muted. The receiver uses these thresholds to determine when to restore the transport after it has been muted. The adjustable operating range is from -30.0 to 30.0 dB. This setting must be above the respective Mute value. The default setting is 0.1.

**Note:** Enable Threshold Muting must be selected for these settings to be active.

The following displays the Transport Default C/N Margin Relationship:




- 5 The **Audio Mute** for both **DVB-S C/N Margin (dB)** and **DVB-S2 C/N Margin (dB)** sets the DVB-S and DVB-S2 Carrier to Noise margins, in dB, below the audio outputs that will be muted. The receiver uses these thresholds to determine when to mute the audio in the event of a noisy, poor, or loss of signal condition. The adjustable operating range is -30.0 to 30.0 dB. This setting must be below the respective Restore value. The default setting is 0.0.

**Note: Enable Threshold Muting** must be selected for these settings to be active.

- 6 The **Audio Restore** for both **DVB-S C/N Margin (dB)** and **DVB-S2 C/N Margin (dB)** sets the DVB-S and DVB-S2 Carrier to Noise margins, in dB, above the audio outputs that will be restored. The receiver uses these thresholds to determine when to restore the audio after it has been muted. The adjustable operating range is from -30.0 to 30.0 dB. This setting must be below the respective Mute value. The default setting is 0.1.

**Note: Enable Threshold Muting** must be selected for these settings to be active.

The following displays the Audio Default C/N Margin Relationship:



- 7 Click **Apply**.

## Viewing the Input Status

- 1 From the user interface of the D9854, click **Input > Input Setup > Input Status**. The Input Status page is displayed.

The screenshot shows the Cisco D9854 - Advanced Program Receiver web interface. The top navigation bar includes 'Summary', 'Input', 'Audio & Video', 'Transport Stream', 'System Settings', and 'Support'. The left sidebar shows a tree view with 'Input Setup' expanded to 'Input Status'. The main content area is titled 'Input Status' and is divided into two sections: 'Current Input Status' and 'Tuner Performance'.

**Current Input Status**

|                         |            |                    |                          |
|-------------------------|------------|--------------------|--------------------------|
| Downlink Frequency(GHz) | 3.449      | I/Q                | Opposite                 |
| L band Frequency(MHz)   | 1701.0     | Signal Status      | No Lock                  |
| Symbol Rate(Msym)       | 28.3465    | TS ID              |                          |
| FEC                     | N/A        | Input              | ASI                      |
| Modulation Type         | QPSK DVB-S | Acquisition State  | None                     |
| Pilots                  | N/A        | Orbital Validation | None 1901/01/01 00:00:00 |

**Tuner Performance**

|                    |        |             |     |
|--------------------|--------|-------------|-----|
| C/N Margin (dB)    | -2.5   | 21.0        |     |
| Signal Level (dBm) | -85    | -5          |     |
| RF Lock            | NoLock | PV BER      |     |
| AFC                | 0.0    | RF(1) Power | Off |
| LDPC ER            |        | LNB Status  | N/A |
| Packet ER          |        |             |     |

Net ID: 1      Network Name: Unk  
 Input Rate: 0.0      Scrambling Mode: Unk  
 LNB Power Supply Status (Operational): N/A

© 2008-2010 Cisco Systems Inc. All rights reserved.


The **Current Input Status** section displays the same information shown in the Input Setup page. For more information on the parameters displayed, see Setting up the RF Input.

The **Tuner Performance** section displays the satellite dish information, such as the C/N Margin and Signal Level.



## Setting up the Channel Selections

- 1 From the user interface of the D9854, click **Input > Channel > Channel Selection**. The Channel Selection page is displayed.



The screenshot displays the 'Channel Selection' configuration page for a Cisco D9854 Advanced Program Receiver. The page is titled 'Channel Selection' and features a table with 16 rows, each representing a Program Entry (PE1 through PE16). Each row contains a text input field with the value '0:UNKN' and a dropdown arrow. Below the table are 'Apply' and 'Refresh' buttons. The left sidebar shows a navigation menu with 'Channel Selection' highlighted. The top of the page includes the Cisco logo, the device name 'D9854 - Advanced Program Receiver', and user information 'admin (Admin) Log Out About'. The bottom of the page has a copyright notice: '© 2008-2010 Cisco Systems Inc. All rights reserved.'

- 2 Enter a channel number for up to 16 program entries. Alternatively, use the drop-down arrow to select an available channel.

**Note:** Only PE1 supports PowerVu descrambling. Do not assign PowerVu channels to PE2 to PE16. If any PowerVu channels are assigned to PE2 to PE16, all service PIDs associated with these channels will be dropped from the transport output.

- 3 Click **Apply**.

## Viewing the Channel Status

From the user interface of the D9854, click **Input > Channel > Channel Status**. The Channel Status page is displayed.

The screenshot shows the Cisco D9854 web interface. The top navigation bar includes 'Summary', 'Input', 'Audio & Video', 'Transport Stream', 'System Settings', and 'Support'. The left sidebar shows a tree view with 'Input Setup' expanded to 'Channel', which is further expanded to 'Channel Status'. The main content area displays a table titled 'Channel Information Service Status' with the following data:

| PE Index | Channel | Channel Name | Conditional Access System ID | Channel Authorised | Channel Encrypted | Channel Scrambled |
|----------|---------|--------------|------------------------------|--------------------|-------------------|-------------------|
| PE1      | 0       | UNKN         | Unknown                      | Yes                | No                | No                |
| PE2      | 0       | UNKN         | Unknown                      | Yes                | No                | No                |
| PE3      | 0       | UNKN         | Unknown                      | Yes                | No                | No                |
| PE4      | 0       | UNKN         | Unknown                      | Yes                | No                | No                |
| PE5      | 0       | UNKN         | Unknown                      | Yes                | No                | No                |
| PE6      | 0       | UNKN         | Unknown                      | Yes                | No                | No                |
| PE7      | 0       | UNKN         | Unknown                      | Yes                | No                | No                |
| PE8      | 0       | UNKN         | Unknown                      | Yes                | No                | No                |
| PE9      | 0       | UNKN         | Unknown                      | Yes                | No                | No                |
| PE10     | 0       | UNKN         | Unknown                      | Yes                | No                | No                |
| PE11     | 0       | UNKN         | Unknown                      | Yes                | No                | No                |

© 2008-2010 Cisco Systems Inc. All rights reserved.

The following table describes the channel information displayed:

| Parameter                    | Description  |
|------------------------------|--|
| PE Index                     | Indicates the Program Entry number (PE1 to PE32).  |
| Channel                      | Displays the input channel of the current PE. The channel is displayed in a range from 1 to 65535. |
| Channel Name                 | Displays the channel name of the current PE.   |
| Conditional Access System ID | Indicates the type of Conditional Access (CA) system used by the program (SA, BISS, or FTA).       |
| Channel Authorised           | Indicates whether the receiver is authorized to receive the program (Yes or No).                   |
| Channel Encrypted            | Indicates whether the received program is encrypted (Yes or No).                                   |
| Channel Scrambled            | Indicates whether the received program is scrambled (Yes or No).                                   |

| Parameter         | Description  |
|-------------------|--|
| SR Status         | <p>Displays the status of an alternate authorized program/service from the same transport stream when the receiver is not authorized to view the primary program. This is an uplink initiated function that maps the alternate service to the original (primary) service PIDs, replacing the original service with the alternate service at the digital transport output. No local intervention is required by the receiver operator for provision of this service replacement feature. The statuses are Not Started, Primary, or Alternate.</p> <p>Not Started - Indicates that an event has not started.</p> <p>Primary - Indicates that a service replacement event is active, but the primary program is being displayed.</p> <p>Alternate - Indicates that a service replacement event is active, and that the receiver has tuned to and is displaying the alternate program/event as it is not authorized to view the scheduled event.</p> |
| SR Type           | <p>Indicates the type of service replacement event.</p> <p>None - Indicates that no service replacement event is scheduled.</p> <p>Scheduled - Indicates that all receivers will tune to the alternate program at the scheduled time. This setting is only applicable to current PE1 (i.e., PowerVu) programs; not PE2 through PE32.</p> <p>CA - Indicates that only receivers unauthorized to view the scheduled program will tune to the alternate program according to the selected authorization tier bits. This setting is only applicable to current PE1 (i.e., PowerVu) programs; not PE2 through PE32.</p> <p>Cue Trigger - Indicates that only receivers authorized by the Cue Trigger mask will tune to the scheduled program/event. Cue triggers can only be initiated /controlled on PE1 (i.e., PowerVu).</p>  |
| SR Start/End Time | <p>Displays the start/end time of the service replacement event when one is scheduled; otherwise, the default start time is displayed. The default start time is 2007/09/01 00:00:00.</p>  |

## Configuring the Common Interface (CI) Information

- 1 From the user interface of the D9854, click **Input > Conditional Access > CI Setup**. The CI Setup page is displayed.

The screenshot shows the Cisco D9854 - Advanced Program Receiver web GUI. The left sidebar contains a navigation menu with the following items: Input Setup, Channel, Conditional Access (expanded), CI Setup (highlighted), CI Status, CA Status, BISS, and Stream Details. The main content area is titled 'CI Setup' and contains the following configuration options:

- CI CAM QUERY Support: Disable
- CI CAM Auto Reset: Disable
- CA List Management Type: AddDel
- TS/ONID Check: Disable
- Transport ID: 0
- Original Network ID: 0
- CAM TS Handling: ServicesOnly

Below the configuration options is a table titled 'Common Interface Program Description' with the following data:

| PE | CI Slot | Decryption Mode |
|----|---------|-----------------|
| 1  | AUTO    | ON              |
| 2  | TOP     | ON              |
| 3  | TOP     | ON              |
| 4  | TOP     | ON              |
| 5  | TOP     | ON              |
| 6  | TOP     | ON              |
| 7  | TOP     | ON              |
| 8  | TOP     | ON              |
| 9  | TOP     | ON              |
| 10 | TOP     | ON              |
| 11 | TOP     | ON              |
| 12 | TOP     | ON              |

© 2008-2010 Cisco Systems Inc. All rights reserved.

- 2 Select Enable in the **CI CAM QUERY Support** drop-down to query the CAM prior to decryption to ensure that the card can be decrypted. The default is Disable.
- 3 Select Enable in **CI CAM Auto Reset** to automatically reset the card. The default is Disable.
- 4 In the **CA List Management Type**, select whether the Common Interface List Management should add and delete (AddDel) individual programs or update all (UpdateAll) the programs when the list changes.  
**Note:** Updating all the programs will cause temporary loss of service for all the programs when another is being modified.
- 5 Select Enable in the **TS/ONID Check** drop-down if you want to restrict the incoming transport stream to the transport ID and transport original network ID listed below. If the incoming stream does not match the specified transport stream, the CAM will not decrypt. The default is Disable.
- 6 If you set the **TS/ONID Check** to Enable, you must define the **Transport ID** and **Original Network ID**. If the incoming stream does not match the specified IDs here, the CAM will not decrypt. You can enter a value in a range from 0 to 65535.
- 7 In the **CAM TS Handling** drop-down, select EntireTS to use the CAM to decrypt the entire transport stream, or select ServicesOnly to use the CAM to decrypt only the PIDs being used by the active services.

- 8 Select the CAM slot (**CI Slot**) to use for decryption. If you set the CI slot to AUTO for PE1, the software automatically assigns the slot capable of decrypting the stream.

**Note:** If CI Slot is set to AUTO, Decrypt must be set to ON.

Select TOP to use the top CAM slot for decryption or select BOTTOM to use the bottom CAM slot for decryption.

- 9 The **Decryption Mode** Determines whether to decrypt the channel or to specify the specific components to decrypt (ON, OFF, Comp). Select ON (default) to decrypt the entire program entry. Select Comp to decrypt specific components, as specified in the CI Component Setup list.

**Note:** If the CI Slot is set to Auto for PE1, then Decrypt can only be set to ON.

- 10 If you selected Comp, you must configure the parameters in the CI Components Setup section below.
- 11 The **CI Component Setup** section allows you to insert and maintain customized records:

| CI Component Setup |       |      |      |                 |                   |                 |
|--------------------|-------|------|------|-----------------|-------------------|-----------------|
|                    | PE ID | Mode | PID  | Stream Category | Stream Type Value | Stream Instance |
| ○                  | 1     | PID  | 8192 | USER            | 0                 | 1               |

Buttons: Add, Delete

- 12 Each record customizes the PID or stream type to decrypt. The Index number is a read only field that indicates the record number. You can maintain up to 64 records, 32 records for each CAM.
- 13 To insert a new record, click **Add**. A new row appears at the top of the table (see below).

| CI Component Setup |       |      |      |                 |                   |                 |
|--------------------|-------|------|------|-----------------|-------------------|-----------------|
|                    | PE ID | Mode | PID  | Stream Category | Stream Type Value | Stream Instance |
| ○                  | 1     | PID  | 8192 | USER            | 0                 | 1               |
| ○                  |       |      |      |                 |                   |                 |

Buttons: Add, Delete


There are various configurations when creating a new record. The following table summarizes the various methods:

| If you set by     | Parameter Settings  |
|-------------------|---|
| PID ID            | Set <b>Mode</b> to PID and enter PID number.  |
| Stream Type       | Set <b>Mode</b> to Stream, select <b>Stream Category</b> (AUD, VID, SUBT, TTX, or USER) and enter <b>Stream Instance</b> of the stream type.<br><br>There is an additional configuration if you select user as the Stream Category (see below). |
| Stream Type: User | Set <b>Mode</b> to Stream, <b>Stream Category</b> to User, manually enter the stream code in <b>Stream Type Value</b> , and then the <b>Stream Instance</b> of the stream type.   |

- 14 If you know the PID number, ensure that PID is selected under **Mode** and enter the appropriate PID number. Click **Save**.
- 15 To enter the stream type, select Stream under **Mode**, select the stream type in the **Stream Category** (VID, AUD, SUBT, USER, or TTX) and enter the instance of the stream type in **Stream Instance**. You can enter a range from 1 to 64. Click **Save**.
- 16 If you do not know the stream type, you can specify a specific hex value as the stream type. Select Stream under **Mode**, select User under **Stream Category**, enter the hex value of the stream under Stream Type Value and the instance of the customized stream type in **Stream Instance**. You can enter a two digit hexadecimal value for the Stream Type and a range from 1 to 64 for the Stream Instance. Click **Add**.
- 17 To delete a record, select the record you want to remove and click **Delete**.
- 18 The **System ID** section displays the system name and ID number of the CAM for the top/bottom slots.

## Viewing the Common Interface (CI) Status

From the user interface of the D9854, click **Input > Conditional Access**, expand CI Setup and then click CI Status. The CI Status page is displayed.




The following table describes the CI Status:

| CI Status           | Description   |
|---------------------|---|
| CI Slot             | Indicates whether it is the top slot (TOP) or the bottom slot (BOTTOM). |
| CAM Status          | Status of the CAM (Ready or Not Ready).                                 |
| Sys Name            | System name of the CAM.   |
| Comp Name           | Displays the company name of the CAM.                                   |
| Manufacturer Code   | The manufacturer's code.  |
| Manufacturer ID     | The factory loaded application number of the CAM.                       |
| Serial Number       | The unique serial number of the CAM.                                    |
| Hardware Version    | The hardware version number of the CAM.                                 |
| Application Version | The software version number of the CAM.                                 |

## Viewing the CA Status

From the user interface of the D9854, click **Input > Conditional Access > CA Status**. The CA Status page is displayed.




The following describes the columns in the CA Status table:

| Status                   | Description   |
|--------------------------|---|
| Index                    | The ISE number.   |
| ISE User Address         | The ISE User Address. It is a 11 digit address in the following format: ###-###-####-#.   |
| ISE Version Number       | The ISE version number. It consists of 7 characters.  |
| Enc Data pkts passed     | Indicates the number of encrypted Addressable Data Packets successfully processed. Ideally, the ADP Enc Pass and ADP Enc Total numbers should be identical.     |
| Enc Data pkts recvd      | Indicates the number of encrypted Addressable Data Packets received. Ideally, the ADP Enc Pass and ADP Enc Total numbers should be identical.                   |
| Non-Enc Data pkts passed | Indicates the number of non-encrypted Addressed Data Packets successfully processed. Ideally, the ADP Enc Pass and ADP Enc Total numbers should be identical.   |
| Non-Enc Data pkts recvd  | Indicates the total number of non-encrypted Addressable Data Packets received. Ideally, the ADP Non-Enc Pass and ADP Non-Enc Total numbers should be identical. |



## Setting up the BISS Mode


- 1 From the user interface of the D9854, click **Input** > **Conditional Access** > **BISS**. The BISS page is displayed.



- 2 Select the Basic Interoperable Scrambling System (**BISS**) **Mode** for the receiver (Mode 1 or Mode E). All channels assigned to the PE identified as BISS CA-controlled in the PMT will be decrypted.
- 3 If you selected BISS Mode 1, enter a fixed 12-character **BISS Mode-1 Session Word**. Once entered it cannot be viewed and it is only displayed as asterisks (\*). Contact your program provider for the session word.
- 4 If you selected BISS Mode E, enter the 16-character **BISS Mode-E Encrypted Session Word** and the 14-character **BISS Mode-E Injected ID**. Once entered, neither of these values can be viewed and it is only displayed as asterisks. Contact your program provider for the respective session word and/or injected ID.
- 5 Click **Apply**.

## Viewing the PSI Tables

From the user interface of the D9854, click **Input > Stream Details > PSI Tables**. The PSI Tables page is displayed.



You cannot make any changes in the PSI table and can only view the PSI tables received and their settings. The following is a list of the various columns:

| Abbreviation       | Description   |
|--------------------|---|
| Table Type         | Indicates the MPEG table acronym.<br>PAT, CAT, PMT, TSDT, NIT, NIT Other, SDT, SDT Other, BAT, AEIT P/F, OEIT P/F, TDT, RST, ST, TOT, DIT, SIT, ECM Odd, ECM Even, EMM, MPE, DPI, DRI, CDT, MCT, MIT, MAT, ECT, or Invalid Table ID |
| Table ID Extension | Displays the MPEG/DVB Table ID.   |
| Status             | Indicates the reception status of the table.<br>None, Partial, Full, Update, Timeout, or Lost   |
| Version            | Indicates the table version number.   |
| PID                | Indicates the value of the PID on which the table is present.   |
| Number of Sections | Indicates the number of sections in the table.  |

## Viewing PSI Frequency Table Information

From the user interface of the D9854, click **Input > Stream Details > PSI Frequency**. The PSI Frequency page is displayed.



You cannot make any changes in the PSI Frequency table and can only view the available frequency plans stored in the receiver. The following is a list of the various columns:

| Abbreviation        | Description   |
|---------------------|---|
| Transport Stream ID | Displays the transport ID.  |
| Frequency (GHz)     | Displays the downlink frequency, in GHz (0.0 to 15.0 GHz).  |
| Symbol Rate (MSym)  | Displays the symbol rate, in Mbps.  |
| Orbital Position    | Displays the orbital position of the satellite, in degrees (East of West).                                |
| Polarization        | Displays the polarity of the received signal (H,V, or Off).   |
| Flag                | Displays the satellite position (in degrees), in combination with the direction (East or West).           |
| FEC                 | Indicates the Forward Error Correction inner code rate (1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 7/8, 8/9, or 9/10). |
| RF Modulation       | Indicates the modulation of the signal (QPSK DVB-S, QPSK DVB-S2, 8PSK DVB-S2 or 16QAM DVB-S2).            |
| Network ID          | Displays the original network ID.   |

## Viewing the PSI Channels

From the user interface of the D9854, click **Input > Stream Details > PSI Channel**. The PSI Channel page is displayed.




You cannot make any changes in the PSI Channel table and can only view the available channels and their settings. The following is a list of the various columns:

| Abbreviation | Description   |
|--------------|---|
| Service ID   | Indicates the virtual channel number.   |
| TS ID        | Displays the identification number of the transport on which the channel is available. For more information on the transport streams, see <i>Viewing PSI Frequency Information</i> (on page 155). |
| Program Name | Indicates the name of the channel.  |
| PMT PID      | Indicates the PID of the channel's Program Map Table.   |
| ECM PID      | Indicates the PID of the channel's Entitlement Control Message stream.  |

## Viewing the PID Input Status

From the user interface of the D9854, click **Input > Stream Details > PID Input Status**. The PID Input Status page is displayed.




You cannot make any changes in the PID Input Status table and can only view the available channels and their settings. The following is a list of the various columns:

| Abbreviation | Description   |
|--------------|---|
| PE Index     | Indicates the Program Entry number (PE1 or PE32).   |
| Type         | Name assigned to the Program Entry, up to 4 alphanumeric characters.  |
| Detail       | Displays any detail associated with the program PID (e.g., MPG2 PID). The parameters are: MPG1 VID, MPG2 VID, 422 VID, H264 VID, HD VID, MPG4 VID, MPG AUD, MPG2 AUD, DVB AC3, DVB DDP, AAC AUD, HEAAC, AUD, MPG4 AUD, DBE AUD, DTS AUD, DVB TXT, DVB VBI, DVB SUBT, DVB ASYN, DVB SYNS, DVB SYND, DVB MPE, DVB DCAR, DVB OCAR, SA VBI, ATSC AC3, ATSC DDP, SA UTLD, SCTE DPL, SA HSD, SA CDDL, SA WBD, SA SUBT, ECM, EMM, PCR, or UNKNOWN. |
| Language     | Displays the language code carried in the PMT for the current PID, if applicable.   |
| PID          | The program PID number, in the range from 1 to 8192.  |
| Present      | Indicates whether the PID is present in the incoming stream (Yes or No).  |

## Setting up Audio and Video Information

### Setting up the Video Parameters

- 1 From the user interface of the D9854, click **Audio & Video > Audio & Video > Video Decoding**. The Video Setup page is displayed.



- 2 Select the **Primary Video Output** format for local decoding. The options are Auto, HD 720p, HD 1080i, or SD.
- 3 Select whether to enable or disable the **Component Tri-Synch**.
- 4 In the **Standard Definition Output** drop-down, select the actual standard definition output format of the primary video if the PV Output is set to SD. The options are Auto, NTSC, PAL-N (AR), PAL-M, or PAL-B/G/I/D. You must use NTSC for 525-line systems and PAL-B/G/I/D for 625-line systems.
- 5 Select the **Standard Definition Aspect Ratio** of your TV monitor (4:3 or 16:9). The default is 4:3. Set it to the corresponding value.
- 6 Select the **Selected Aspect Ratio Conversion** that the receiver will perform on the incoming signal for the picture to be displayed correctly on your TV, based on the **Standard Definition Aspect Ratio** selection.  
The options are None, Auto, Auto AFD, 16:9 L/B, 4:3 P/B, 14:9, 4:3 CCO, and 16:9 Scale. The default is Auto.
- 7 Select the **Wide Screen Signalling** output mode. It is used to select how the receiver affects PAL WSS when it is present in the VBI line 23. The table below describes each of the options. The default is Auto.

| WSS Mode    | Description   |
|-------------|---|
| Passthrough | Passes WSS unmodified as received by the receiver.  |
| Auto:Create | Creates WSS to output the correct aspect ratio when performing aspect ratio conversion.   |
| Auto:Modify | If WSS is present in the input stream, it is modified to output the correct aspect ratio when performing aspect ratio conversion. If WSS is not present in the input, no WSS will be present in the output. |
| Suppress    | Removes WSS output.   |


- 8 The **Video Status** section displays the current video settings, and the encoding, bit rate, FPS and aspect ratio of the incoming signal. The fields are read-only. The following table describes the video status information displayed:

| Video Status               | Description  |
|----------------------------|--|
| Primary Video Output       | Indicates the actual output video format (Auto, HD 720p, HD 1080i, or SD).   |
| Standard Definition Output | Displays the actual standard definition format of the primary video output if the PV Output is set to SD.                          |
| Aspect Ratio               | Displays the standard definition aspect ratio of your TV monitor.  |
| Wide Screen Signalling     | Displays the Wide Screen Signaling output mode.  |
| Encoding Format            | The input stream type of the received signal/program.  |
| Bit Rate (Mbps)            | Indicates the bit rate of the input video stream, in Mbps.   |
| Frame Rate (fps)           | Indicates the frame rate of the input video stream.  |
| 3:2 Pulldown               | Indicates whether 3:2 pulldown is detected, was recently detected, or not detected in the input video stream (Yes, Recent, or No). |

- 9 Select **Enable Banner Display** to display alarms and warnings on the on-screen display (e.g., TV monitor).
- 10 Click **Apply**.

## Setting up Captions

- 1 From the user interface of the D9854, click **Audio & Video > Audio & Video**, expand **Video Decoding** and then click **Captions**. The Captions page is displayed.



- 2 In the **Preferred Closed Caption Mode**, select the type of closed captioning to use if there are multiple available in the stream. The default is *Auto*.  
**Note:** SA Custom is not supported when telecine video coding is enabled.
- 3 The **Closed Caption Mode** in the **Status** section displays the actual closed caption mode in the output. This is read-only.
- 4 Click **Apply**.



## Setting up Subtitles

- 1 From the user interface of the D9854, click **Audio & Video > Audio & Video**, expand **Video Decoding** and then click **Subtitles**. The Subtitles page is displayed.



- 2 Select the **Subtitle Control** to use to display the program subtitles. The following table describes each of the available options:

| Op Mode Selection | Description   |
|-------------------|---|
| Off               | No subtitles are displayed.   |
| On                | Displays DVB or Imitext subtitles, if available.                                      |
| DVB               | Displays only DVB titles, if available. Otherwise, no subtitles are displayed.        |
| Imitext           | Displays only Imitext subtitles, if available. Otherwise, no subtitles are displayed. |

- 3 Set the **Imitext Position** of the on-screen subtitle text (Standard or Extended).
- 4 The **Imitext Foreground Colour** sets the color for Imitext subtitles. Auto displays text in the color transmitted by the subtitling equipment. Yellow and White overrides the color set by the uplink and display text in the selected color.
- 5 The **Imitext Background Color** sets the text background for Imitext subtitles. The following table identifies the affect each setting has on the displayed subtitle text:

| BackGnd Option | Description                                   |
|----------------|---|
| Auto           | Uses the uplink subtitling equipment setting. |

| BackGnd Option | Description   |
|----------------|---|
| Shadow         | Applies an outline to the right side of each text character. No background box is applied to subtitles, i.e., text is visible directly on top of video. |
| Opaque         | Applies a black box to each text character.   |
| Semi           | Applies a semi-transparent box to subtitle text.  |
| None           | No shadow or outline is applied to subtitle text.   |


- 6 In the **Subtitle Language Settings** section, select the input source for the subtitle language. The default is Language List. Language Entry and PMT Order are more applicable for advanced applications. The following table describes each of the available options and how to set them:

| Select Language By Option | Description  |
|---------------------------|--|
| Language List             | Select the MPEG language to display from the available list. The following are the available options:<br><br>ara (Arabic), btk (Batak (Indonesia), ben (Bengali), bul (Bulgarian), chi (Chinese), cze (Czech), dan (Danish), dut (Dutch), eng (English), fin (Finnish), fre (French), ger (German), gre (Greek), heb (Hebrew), hin (Hindi), hun (Hungarian), ice (Icelandic), ind (Indonesian), ita (Italian), jpn (Japanese), kor (Korean), may (Malay), mul (Multiple Languages), nor (Norwegian), per (Persian), pol (Polish), por (Portuguese), rum (Romanian), rus (Russian), san (Sanskrit), scc (Serbian), sin (Sinhalese), slo (Slovak), som (Somali), spa (Spanish), swe (Swedish), tai (Tai Other), tam (Tamil), tha (Thai), tur (Turkish), ukr (Ukrainian), or vie (Vietnamese) |
| Language Entry            | Enter the three-character code provided by your uplink service provider (e.g., eng for English).<br><br>For a list of language codes, see Language Codes - Sorted by Alpha 3-Letter Code (ISO 639-2).  |
| PMT Order                 | Select the subtitle PID entry to display (First to Eighth). This information is available from your uplink provider.   |

- 7 Click **Apply**.

## Setting up the VBI

- 1 From the user interface of the D9854, click **Audio & Video > Audio & Video**, expand **Video Decoding** and then click **VBI**. The VBI page is displayed.



- 2 Select to enable Vertical Interval Test Signal (VITS) on PAL Lines 17, 18, 330, or 331.
- 3 Click **Apply**.

## Setting up Audio Parameters

- 1 From the user interface of the D9854, click **Audio & Video > Audio & Video > Audio Decoding**. The Audio Decoding page is displayed.

The screenshot shows the Cisco D9854 - Advanced Program Receiver Web GUI. The main navigation bar includes Summary, Input, Audio & Video (selected), Transport Stream, System Settings, and Support. The left sidebar shows a tree view with Audio & Video expanded, and Audio Decoding selected. The main content area is titled 'Audio Decoding' and contains three sections:

**Audio Setup**

| Audio Decode | PMT Source | Audio Mode | AC3 Compression | Left Attenuation | Right Attenuation | Digital Out Preference | DD+ Output |
|--------------|------------|------------|-----------------|------------------|-------------------|------------------------|------------|
| 1            | AUD1       | Stereo     | RF Mode         | 0.0              | 0.0               | PCM Samples            | Trans      |
| 2            | AUD2       | Stereo     | RF Mode         | 0.0              | 0.0               | PCM Samples            | Trans      |

**SDI Audio Group Setup**

| Audio Group | Group Slot | Audio Decode | Channel |
|-------------|------------|--------------|---------|
| 1           | 1          | 1            | 1       |
| 1           | 2          | 1            | 2       |
| 1           | 3          | 2            | 1       |
| 1           | 4          | 2            | 2       |

**Audio Status**

| Audio | PID | Language | Format | Bit Rate | SFR | Buffer |
|-------|-----|----------|--------|----------|-----|--------|
| 1     |     |          | None   | 0        | 0.0 | 0      |
| 2     |     |          | None   | 0        | 0.0 | 0      |

At the bottom of the page, there are 'Apply' and 'Refresh' buttons. The footer text reads '© 2008-2010 Cisco Systems Inc. All rights reserved.'

- 2 There are two audio settings. It allows you to configure the two balanced audio outputs on the rear panel (Audio 1 and Audio 2), known in the Web GUI as 1 and 2, respectively.
- 3 Select the **PMT Source** for the audio channel (None, AUD1 to AUD64).
- 4 Set the **Audio Mode**, which sets the output mixing.  
Select Stereo (Left and Right are passed directly through to Left and Right), R-Mono (Right is passed to both the Left and Right), L-MONO (Left is passed to both the Left and Right), or Mixed (Left is passed to both the Left and Right, and Right is passed to both the Left and Right).
- 5 Set the **AC3 Compression** mode to use if the output is compressed Dolby Digital audio. The selections are Line Mode, Custom 1, Custom 0 or RF Mode. RF Mode is recommended for analog cable modulators.
- 6 **Left Attenuation** is the volume adjustment for the Left audio channel. You can select a value in the range from -6.0 dB to +6.0 dB, in increments of 0.5 dB.
- 7 **Right Attenuation** is the volume adjustment for the Right audio channel. You can select a value in the range from -6.0 dB to +6.0 dB, in increments of 0.5 dB.  
The following options only appear if the D9854 contains SDI:
- 8 Set the Digital Out Preference for the SDI output or AES-3id output. The following describes the options:

| Mode        | Description   |
|-------------|---|
| PCM Samples | If the audio source is MPEG Layer II format, the output will be routed to the SDI output as PCM.    |
| Compressed  | If the audio source is AES compressed, the output will be routed to the AES-3id output, compressed. |

When Digital Out Preference is set to PCM Samples, the output is PCM regardless of whether it's MPEG, Dolby Digital (AC-3) or AAC audio. Additionally, when the output is Compressed, MPEG-1 L1 and L2 will be output PCM, even though Dolby Digital (AC-3) and AAC is compressed (and transcoded)

| Output Input                                      | Digital Output Preference |                                     |  |
|---|---------------------------|-------------------------------------|--|
|   | PCM Samples               | Compressed                          |  |
|   |                           | DDP Mode                            |  |
|   |                           | Transocde (Converter)               | Passthrough  |
| MPEG LA (MPEG-1 and MPEG-2)                       | PCM                       | PCM                                 | PCM  |
| Dolby Digital (AC-3)                              | PCM                       | Dolby Digital (AC-3)                | Dolby Digital (AC-3)                               |
| Dolby Digital Plus (E-AC-3) (Bit rate < 1.5 Mbps) | PCM                       | Dolby Digital (AC-3)                | Dolby Digital Plus (E-AC-3) (no over-clocking, x1) |
| Dolby Digital Plus (E-AC-3) (Bit rate > 1.5 Mps)  | PCM                       | Dolby Digital (AC-3)                | Dolby Digital (AC-3)                               |
| MPEG-2 AAC, MPEG-4 (AAC and HE-AAC)               | PCM                       | MPEG-2 AAC, MPEG-4 (AAC and HE-AAC) | MPEG-2, MPEG-4 (AAC and HE-AAC)                    |

- Set the Dolby Digital Plus output mode (**DD+ Output**). If Trans is selected, it will transcode to Dolby Digital audio output. If Pass (passthrough) is selected and the bitrate is less than 1536 kbps (48 Khz), passthrough is performed and Dolby Digital Plus compressed out is received. If Pass (passthrough) is selected and the bitrate is more than 1536 Kbps, transcoding will be performed. This setting affects only the AES-3id and SDI outputs.

**Note:** Dolby Digital Plus is only available on Audio 1.

**Note:** Ensure that the **Digital Out Preference** is set to Compressed for digital passthrough. Otherwise, only decoded PCM will be available. This parameter has no effect if the audio source is not Dolby Digital Plus.

## Chapter 5 Web GUI Setup and Monitoring

- 10 In the **SDI Audio Group Setup** section, select the audio source (1 or 2) in the **Audio Decode** column and the source audio channel (1 or 2) in the Channel column for **Group Slot** 1 to 4. The Group Slot is the HANC position.
- 11 The **Audio Status** section displays the current audio settings. The following table describes the audio status information:

| Audio Status | Description   |
|--------------|---|
| Audio        | Displays the current audio deocder status.  |
| PID          | Indicates the program PID number (1 to 8191).                                     |
| Language     | Indicates the language code.  |
| Format       | Indicates the format of the audio input stream.                                   |
| Bit Rate     | Displays the bit rate of the audio input stream, in kbps.                         |
| SFR          | Displays the sample rate of the input audio stream, in kHz (32, 44.1, or 48 KHz). |
| Buffer       | Indicates the buffer level of the input audio stream, in bytes.                   |

- 12 Click **Apply**.

## Setting up Cueing Parameters

- 1 From the user interface of the D9854, click **Audio & Video > Other Outputs > Cueing**. The Cueing page is displayed.

The screenshot shows the Cisco D9854 Advanced Program Receiver web interface. The page title is "D9854 - Advanced Program Receiver" and the user is logged in as "admin (Admin)". The navigation menu includes Summary, Input, Audio & Video (selected), Transport Stream, System Settings, and Support. The left sidebar shows a tree view with Audio & Video expanded, Other Outputs expanded, and Cueing selected. The main content area displays the following settings:

|                          |         |
|--------------------------|---------|
| Cueing Mode              | Trigger |
| Trigger polarity         | High    |
| Cueing Tone Repeat Count | 3       |
| Tone Duration (ms)       | 40      |
| Silence Duration (ms)    | 40      |
| Relay Mode               | Alarm   |
| Relay Trigger Bit        | 1       |

There are Apply and Refresh buttons at the bottom of the settings area.

- 2 In the **Cueing Mode** drop-down menu, select whether cueing output should be DTMF tones or trigger pins.  
Tones are standard Dual-Tone Multi-Frequency (DTMF) tones. The tones are generated at the Cue Tone/Relay output on the rear panel of the receiver.  
Trigger refers to open-collector pins which can be generated at the Cue Tone/Relay output on the rear panel of the receiver.
- 3 If Trigger was selected as the Cueing Mode, select the pin polarity in the **Trigger Polarity** drop-down menu. Select High for the pins to act as open or floating collectors on an active cueing signal and as ground on an inactive signal. Select Low for the pins to act as ground on an active cueing signal and as open or floating collectors on an inactive signal.
- 4 If the Cueing Mode was set to Tone, set the number of consecutive tone sequences to be generated in the **Cueing Tone Repeat Count** field. Values greater than 1 are provided when a scenario demands repetition to ensure that the ad insertion equipment receives the signal. You can enter 1, 2, or 3. The default is 3.
- 5 If the Cueing Mode was set to Tone, enter the **Tone Duration** of each tone, in milliseconds, in the range from 0 to 80. The default is 40.

## Chapter 5 Web GUI Setup and Monitoring

- 6 If the Cueing Mode was set to Tone, enter the **Silence Duration** of each silence between tones, in milliseconds. The duration is in the range from 0 to 80. The default is 40.
- 7 Select the **Relay Mode** that can be programmed to respond to an Alarm state, Warning statue, or the state of one of the eight cue trigger pins. The response is generated at the Cue Tone/Relay output on the rear panel of the receiver. The following table shows what the possible field settings are and their relationship to the receiver output:


| Relay Mode | Condition                | Relay Contact |       |
|------------|--------------------------|---------------|-------|
|            |                          | NC - C        | C-NO  |
| Alarm      | Unit Power Off           | Open          | Close |
|            | Alarm State              | Open          | Close |
|            | No Alarm                 | Close         | Open  |
| Trigger    | Active (selected in PNC) | Close         | Open  |
|            | Inactive                 | Open          | Close |

- 8 If the Relay Mode was set to Trigger, select the cue trigger bit/ pin that will activate the relay in the **Relay Trigger Bit** drop-down menu (1 to 8).
- 9 Click **Apply**.



## Setting up Cue Tone Test


- 1 From the user interface of the D9854, click **Audio & Video > Other Outputs**, expand **Cueing** and then click **Cue Tone Test**. The Cue Tone Test page is displayed.



- 2 In the **Test Tones** field, specify the three digit tone sequence. You can enter a value between 000 and 999.
- 3 In the **Sequence Mode** drop-down list, select the tone sequence mode. The following describes the available options:
  - \* - Start tone only
  - # - End tone only
  - \*/# - Start and end tones. The end tone is signaled after waiting the time specified in Delay(sec).
- 4 Click **Apply**.

## Setting up Cue Tones

- 1 From the user interface of the D9854, click **Audio & Video > Other Outputs**, expand **Cueing** and then click **Cue Tone**. The Cue Tone page is displayed.




| Sequence Number | Sequence State | Sequence Tones | Sequence Mode | Sequence Delay |
|-----------------|----------------|----------------|---------------|----------------|
| 1               | Disable        | 0              | *             | 1              |
| 2               | Disable        | 0              | *             | 1              |
| 3               | Disable        | 0              | *             | 1              |
| 4               | Disable        | 0              | *             | 1              |
| 5               | Disable        | 0              | *             | 1              |
| 6               | Disable        | 0              | *             | 1              |
| 7               | Disable        | 0              | *             | 1              |
| 8               | Disable        | 0              | *             | 1              |
| 9               | Disable        | 0              | *             | 1              |
| 10              | Disable        | 0              | *             | 1              |
| 11              | Disable        | 0              | *             | 1              |

- 2 The **Sequence Number** lists the tone sequences. The receiver supports up to 16 tone sequences. You can configure the state, tones, mode, and delay for each tone sequence.
- 3 Set the **Sequence State** (Enabled or Disabled) of the current tone sequence. When disabled, no cue tone is output.
- 4 In the **Sequence Tones** field, set the three digit tone sequence (1 to 999).
- 5 Select the tone **Sequence Mode**.  
Select \* for start tone, # for the end tone, and \*/# for the start and end tones. The end tone is signaled after waiting the time specified in **Sequence Delay**.
- 6 If the **Sequence Mode** was set to \*/# (Start/Stop), set the **Sequence Delay**, in seconds, between the start and stop sequences. You can enter a value in the range from 1 to 255. The default is 30.
- 7 Click **Apply**.

## Setting up SDI

- 1 From the user interface of the D9854, click **Audio & Video > Other Outputs > SDI**. The SDI page is displayed.




- 2 Set the **M1 Port Type** and **M2 Port Type** (SDI or ASI).
- 3 Select **Enable VII/AFD Output in SDI**, **Enable VBI Output in SDI**, **Enable DPI Output in SDI**, and/or **Enable EIA708 Output in SDI** to enable the VII (video index)/AFD, VBI, DPI, and/or EIA-708 outputs in SDI.
- 4 In the **SDI Audio Group Setup** section, you can select the audio channel group and audio channels from the available audio group. The following describes the parameters:

| SDI Audio Group Setup | Description                               |
|-----------------------|---|
| Audio Group           | Displays the channel group (1 to 4).      |
| Group Slot            | Displays the HANC position (1 to 4).      |
| Audio Decode          | Select the audio source (1 or 2).         |
| Channel               | Select the source audio channel (1 or 2). |

- 5 Click **Apply**.

## Setting up Services to be Decoded by the D9854 Receiver

- 1 From the user interface of the D9854, click **Audio & Video > Other Outputs > Decode Enables**. The Decode Enables page is displayed.




- 2 Select the services to be decoded by the receiver. Select/de-select **Enable Decode Engine** to select/de-select all the services in the list.
- 3 Click **Apply**.

# Configuring Transport Stream Information

## Configuring the ASI Output

- 1 From the user interface of the D9854, click **Transport Stream > Transport Handling > ASI Output**. The ASI Output page is displayed.



**Note:** Any changes made to the ASI DPM values will automatically change the Output Mode to Full DPM Control, unless the output mode is set to No Output.

- 2 Select the output **Rate Control**. The following table describes the affect each of the settings has on the output bit rate:

| Rate Control | Description  |
|--------------|--|
| Auto         | The output rate follows that set by the uplink. The output rate will be the same as the input rate (including all null packets). This means the output bit rate is determined automatically based on the input source symbol rate and FEC value. |
| User         | The output rate is specified by the <b>User Rate</b> field. It is determined by the user setting regardless of the input source.   |

- 3 If the Rate Control was set to User, set the maximum output bit rate in the **User Rate** field. This setting is used when the signal source is RF or ASI and allows you to set the output bit rate to a value expected by equipment connected to the ASI output.

You can enter a range from 0 to 206 Mbps.

**Note:** Output data may be lost if this bit rate is set to a value less than the actual signal bit rate.

- 4 Select the **DPM Output Mode** for the current output. With the exception of No Output, selecting a mode will configure the DPM settings to achieve the specified behavior. In this way, they act as DPM presets. Any changes then made to the DPM settings will switch the mode to Full DPM Control. It is highly recommended to use either one of these basic modes, or, for advanced setup, enter the DPM mapping before setting the Output Mode. The following table describes each mode:

| Output Mode               | Description   |
|---------------------------|---|
| No Output                 | No ASI output will be generated and the ASI port will be disabled.  |
| Passthrough               | The output will be identical to the input. All PEs will be set to Pass and other DPM settings will also be set.       |
| Service Channels Only     | This is similar to Passthrough, except that only channels applied to program entries are available on the output.     |
| MAP Passthrough           | The output will be identical to the input, except that channels and PIDs will be mapped using the DPM settings.       |
| MAP Service Channels Only | This is similar to MAP Passthrough, except that only channels applied to program entries are available on the output. |
| Full DPM Control          | The output will be generated according to the DPM settings. This is a manual control setting.                         |

- 5 In **Descrambled** drop-down, select whether the output will be descrambled if the input is scrambled. The following table describes the available options:

| Descramble  | Description   |
|-------------|---|
| Scrambled   | The output channel will remain scrambled even if the PE is authorized and can descramble the channel. |
| Descrambled | Descrambles the output channel, and passes in-the-clear channels.                                     |

- 6 Select Yes to insert null packets into the output to maintain output at a constant bit rate in the **Null Packet Insertion** drop-down menu. Otherwise, select No.
- 7 The **ASI Output Status** section displays the current **Output Rate** (0 to 213 Mbps) and the available bit bandwidth (**Free Bandwidth**), in Mbps.
- 8 Click **Apply**.

## Configuring the DPM ASI Details

**Note:** The following procedure defines all the available fields. For a typical setup of the DPM, see *Typical set up for Digital Program Mapping (DPM)* (on page 188).

- 1 From the user interface of the D9854, click **Transport Stream > Transport Handling**, expand **ASI Output** and then click **Digital Program Mapping**. The Digital Program Mapping page is displayed.

The screenshot shows the Cisco D9854 Advanced Program Receiver web interface. The main content area is titled "Digital Program Mapping". It features a table for "DPM Program Entry Setup" and a section for "DPM General Settings".

| Program Entry | Chl # | Name | Action | Output Ch# | PMT PID |
|---------------|-------|------|--------|------------|---------|
| PE1           | 0     | UNKN | Drop   | 0          | 8191    |
| PE2           | 0     | UNKN | Drop   | 0          | 8191    |
| PE3           | 0     | UNKN | Drop   | 0          | 8191    |
| PE4           | 0     | UNKN | Drop   | 0          | 8191    |
| PE5           | 0     | UNKN | Drop   | 0          | 8191    |
| PE6           | 0     | UNKN | Drop   | 0          | 8191    |
| PE7           | 0     | UNKN | Drop   | 0          | 8191    |
| PE8           | 0     | UNKN | Drop   | 0          | 8191    |
| PE9           | 0     | UNKN | Drop   | 0          | 8191    |
| PE10          | 0     | UNKN | Pass   | 0          | 8191    |
| PE11          | 0     | UNKN | Drop   | 0          | 8191    |
| PE12          | 0     | UNKN | Drop   | 0          | 8191    |

Below the table are buttons for "Edit", "Resynchronize", and "Resynchronize All".

The "DPM General Settings" section includes the following options:

- Remapping Mode: Svc ID & PID
- Duplication Method: PM Copy
- Unreferenced Content: Drop
- Service ID Output: Valid Ch
- SI Regeneration Option: SA Std
- PSI Table Output Option: Chl By Table
- PSI Regeneration Option: Always

A "Table Options" button is located to the right of the settings. A small note at the bottom of the settings section reads: "This table affects all Transport outputs."

- 2 For each DPM **Program Entry**, it displays the input channel number (**Chl #**) and channel **Name**.

**Note:** Any changes made to the DPM Program Entry Setup configuration automatically changes the Output Mode to Full DPM Control in the ASI Output page.

- 3 Select the program entry you want to edit.
- 4 In the **Action** drop-down list, select the DPM program action for the PE (Pass, Map, or Drop). The default is Pass.

- Click **Edit**. The DPM PE PID MAP window opens.


- Enter the **Output Channel #** you want to map to the input channel (**Input Channel #**). This value is only used if the PE Action was set to Map. You can enter a range from 1 to 65535.
- Enter the **Output PMT PID** you want to map to the Input PMT PID.
- In the **PE PID MAP** section, you can select an existing PID mapping entry you want to modify or click **Add Row** to create a new entry.
- The **Input Stream** indicates the input service that will be mapped by the current entry. The **Input PID** displays the input PID (1 to 8190) that will be mapped by the current entry. This is only used if the **Action** is set to Map.
- In the **Action** drop-down, select the action to perform on the current PID. The Drop action is always performed, but the Map option is only applied if the PE action is Map and the **Remapping Mode** is Svc ID & PID.

| Action | Description   |
|--------|---|
| Drop   | The service selected by the Category and Instance will be mapped to the specified PID. This is only applied if the PE action is Map and the Remapping Mode is Svc ID & PID. |
| Map    | The service selected by the Category and Instance will be removed from the PMT and the output stream.   |

- Enter a **Stream Type** to map within a PE to a specified PID (0 to 255).
- Select the **Category** or service to configure. If an input service matches this type and Instance, then the Action will be applied. This value is only used if the Action is set to Map. The categories are: UNKN, CDT, LSDT, DATA, TTX, MPE, DPI, VBI, SUBT, AUD, VID, PCR or INVL.
- Enter the **Instance** (1 to 64) of the service specified by Category to configure. If an input service matches this type and instance, then the Action will be applied.
- If Action is set to Map, select the **Output PID** number (0 to 8192).
- Click **OK**.
- To remove a PID mapping, select the entry you want to remove and click **Delete**.



- 17 In the DPM Program Entry Setup section, each PE output can be synchronized to its input according to one of the four output modes. Select the program entry you want to synchronize and then click **Resynchronize** or click **Resynchronize All** to synchronize the inputs to the outputs according to the service assignments only. The Confirm Resynchronization window is displayed.



- 18 Select whether you want to synchronize the PE output according to the services and then the PIDs assigned to each service, services only, PIDs only, or to synchronize using a template.

| Map Mode  | Description   |
|---|---|
| Resynchronize Program, PMT PID, ES List & ES PIDs | The receiver will synchronize the PE output according to the services and then the PIDs assigned to each service.   |
| Resynchronize ES List                             | The receiver will synchronize the PE output according to the available input services only, and ignore the input to output service PID mapping.                 |
| Resynchronize ES PIDs                             | The receiver will synchronize the PE output according to the input PIDs only, and ignore the service assignment categories/names.                               |
| Resynchronize Template ES List & PIDs             | Allows you to preset the input to output mapping of a PE according to the preset template. This is helpful in pre-configuring any number of PEs for future use. |

- 19 Click **Yes**.
- 20 In the **DPM General Settings** section, you can configure ASI DPM transport stream settings.
- 21 In the **Remapping Mode** drop-down, select the DPM mapping mode for this output. The following table describes each mode:

| Map Mode | Description   |
|----------|---|
| Svc ID   | The elementary PIDs are not changed. Channels are remapped by changing their PSI references. When this mode is selected, PE detailed PID mapping in the PID menu are ignored. |


| Map Mode     | Description  |
|--------------|--|
| Svc ID & PID | Channels and the elementary service PIDs can be mapped in the DPM PE PID MAP window. |

- 22 Select the **Duplication Method** for how to handle duplicate programs. This setting is only used if Remapping Mode is set to Svc ID & PID. The following table describes the each duplication method:

| Duplic Mode | Description   |
|-------------|---|
| PSI Remap   | Every input PID can be mapped to only one output PID. If PID mapping conflicts exist, DPM will use the Precedence Rule to decide which output PID to use. All PMTs using the input PID will be updated to reference the output PID specified by the winner. |
| Pkt Copy    | An input PID can be mapped to multiple output PIDs. The PID will be duplicated as many times as needed (up to a certain hardware limitation).<br><br><b>Note:</b> This may increase the output bandwidth of the stream.                                     |

Pkt Copy is recommended for most applications.

- 23 Select the action to use for **Unreferenced Content**. Unreferenced content is the remainder of the transport stream that is not filtered by the program entries. Select Drop (default) to drop all unreferenced content. Select Pass to pass all unreferenced content to the output unchanged. Select **Mode-i** and then click **Mode-i Options** to open the Mode-i Options (ASI) window.



Mode-i is a customer-specific mode, only to be used if directed by Cisco. For more information, contact Cisco customer support.

- 24 In the **Service ID Output** drop-down, select whether the receiver should always generate PSI tables for the Mapped PE even if the selected input channel is not available, or for only valid service channels/IDs. The following table describes each service ID:

| Svc ID   | Description   |
|----------|---|
| Valid Ch | Only transmits the PSI tables for the mapped program if the program exists on the input stream. |

| Svc ID | Description   |
|--------|---|
| All Ch | Transmits the PSI tables for the mapped program even if the program does not exist in the input stream.<br><br>All Ch is only valid if the PAT, NIT, SDT and PMT are set to Regenerate. |

- 25 If PSI Table Output Option is set to Ctrl by Table, select the regeneration rate for those PSI tables being regenerated in the **SI Regeneration Option** drop-down menu. This parameter is only used if Remapping Control is set to None. The following table describes each PSI rate:

| PSI Rate | Description  |
|----------|--|
| Auto     | Matches the generated PSI tables' output rate to the incoming rate.                            |
| MPEG Min | Transmits the generated PSI tables on the longest intervals that are allowed by MPEG standard. |
| SA Std   | Transmits the generated PSI tables based on PowerVu standard intervals.                        |

- 26 In the **PSI Table Output Option** drop-down menu, select the action to perform on the PSI tables for the output stream. The following table describes each option:

| PSI Options  | Description   |
|--------------|---|
| Pass All     | Transmits the incoming PSI Tables as is; does not modify the content and rate. The SI Regeneration Option and table settings are ignored. |
| Drop All     | Does not transmit any PSI Tables. The SI Regeneration Option and table settings are ignored.  |
| Ctl By Table | The operator can click <b>Table Options</b> to select the table specific output mode for each table.                                      |

- 27 In the **PSI Regeneration Option** drop-down, select whether to regenerate the PSI tables to the output. You can select Always to regenerate all the tables or As Needed to only regenerate the tables if the content has changed.


- 28 If Ctl By Table was selected as the **PSI Table Output Option**, click **Table Options** to configure the DPM table options. The DPM Table Options (ASI) window is displayed.

| Table Name | Option | Table Name | Option |
|------------|--------|------------|--------|
| PAT        | Pass   | TDT        | Pass   |
| CAT        | Regen  | ST         | Pass   |
| PMT        | Regen  | RST        | Pass   |
| TSDT       | Pass   | TOT        | Pass   |
| NIT        | Pass   | DIT        | Pass   |
| NITO       | Pass   | SIT        | Pass   |
| SDT        | Regen  | ECM        | Pass   |
| SDTO       | PwRC   | EMM        | Pass   |
| BAT        | PwRC   | DRT        | Pass   |
| EIT        | Pass   | CDT*       | Pass   |

- 29 Select the tables which will be passed, dropped, regenerated or passed with rate control (PwRC) from the ASI Output. The CDT table is different from the other tables listed. For more information on the table options, see *PSI Table Settings* (on page 107).
- 30 Click **OK**.
- 31 Click **Apply**.

## Configuring the MPEGoIP Output

- 1 From the user interface of the D9854, click **Transport Stream > Transport Handling > MPEG over IP Output**. The MPEG over IP Output page is displayed.



**Note:** Any changes made to the MOIP DPM values will automatically change the Output Mode to Full DPM Control, unless the output mode is set to No Output.

- 2 Select the DPM output **Rate Control**. The following table describes the affect each of the settings has on the output bit rate:

| Rate Control | Description   |
|--------------|---|
| Auto         | The output rate follows that set by the uplink. The output rate will be the same as the input rate (including all null packets). This means the output bit rate is determined automatically based on the input source symbol rate and FEC value. This setting is used when the signal source is RF. |
| User         | The output rate is specified as the Output Rate parameter. It is determined by the user setting regardless of the input source. Null packets are always inserted.   |

- 3 Enter the output **User Rate**, which is only used if **Rate Control** is set to User. If the output bit rate is less than the input, the output data will be partially or completely lost.

**Note:** Output data will be partially lost if the user-selected bit rate is set to a value that is less than the actual signal bit rate. This allows you to set the output bit rate to a value expected by equipment connected to the MPEGoIP output. You can enter a range from 0 to 206 Mbps.

- 4 Select the **DPM Output Mode**. The following table describes each mode:


| Output Mode               | Description   |
|---------------------------|---|
| No Output                 | No MPEGoIP output will be generated.  |
| Passthrough               | The output will be identical to the input. The output channel will not be modified.<br><br>PE/PID remapping options, PSI regeneration and User Rate are not supported in this mode. |
| Service Channels Only     | Only service channels will be output.   |
| MAP Passthrough           | The output will be identical to the input, except that it will be generated using the DPM and PID mapping settings.   |
| MAP Service Channels Only | Only service channels will be output according to the DPM and PID mapping settings.   |
| Full DPM Control          | The output will be generated according to the DPM settings on the Digital Program Mapping (MPEG over IP) page. This is a manual control setting.                                    |

- 5 In Descrambled drop-down, select whether the receiver should scramble the output even if it is authorized to receive the channel. The default is Descrambled.

| Descramble Mode | Description   |
|-----------------|---|
| Scrambled       | Scrambles the output channel even if the PE is authorized and can descramble the channel. |
| Descrambled     | Descrambles the output channel, and passes in-the-clear channels.                         |

- 6 Select Yes to insert null packets in the output stream under **Null Packet Insertion**. Otherwise, select No. Null packets are always inserted if the **Rate Control** is set to User.
- 7 Select the transport **Protocol** to be used for the output stream (RTP or UDP).
- 8 Enter the unicast (valid host IP only) or multicast **Destination IP Address** (224.0.0.0 to 239.255.255.255).
- 9 Select the **Destination Port** number (1 to 65535).  
**Note:** If you selected RTP as the Protocol, you must select an even destination port number.
- 10 Enter the **Source UDP Port** number (1 to 65535).
- 11 In the **Send SAP** drop-down list, select whether to send Session Announcement Protocol messages (Yes or No).
- 12 Select whether to send the **SAP ID Source** (Yes or No), defined in the **User SAP Identifier** below. You can enter the SAP identifier (ID)/string, up to 49 characters.

- 13 Click **Advanced**. The Advanced MPEG over IP Output Settings window is displayed.



- 14 In the **Maximum Transport Packets/Ethernet Frame** field, enter the maximum number of transport packets per IP packet (1 to 7).
- 15 In the **Minimum number Packets/Second** field, enter the minimum number of transport packets per IP packet. You can enter 0 or 2 to 1000.
- 16 In the **Start Ethernet Frame on PCR** drop-down list, select whether to always transmit a new Ethernet Packet when a new Program Clock Reference (PCR) arrives (Yes or No).
- 17 In the **PCR Addition Enabled** drop-down list, select whether to add a PCR to the output stream (Yes or No).
- 18 In the **Data Port** and **Management Port** drop-down lists, select the Management and Data MOIP modes.

**Note:** If No Output was selected for Output Mode, updates to the port modes will have no effect.

The following describes each mode:


| Data Port<br>Management Port | Description                     |
|------------------------------|---------------------------------|
| No Output                    | Disables the MPEGoIP interface. |
| Always Output                | Always output data on the port. |

- 19 Click **OK**.
- 20 The **MoIP Output Status** section displays the current **Output bit Rate** (0 to 213 Mbps) and the available bit bandwidth (**Free Bandwidth**), in Mbps.
- 21 Click **Apply**.

## Configuring the DPM MPEGoIP Output Details

**Note:** The following procedure defines all the available fields. For a typical setup of the DPM, see *Typical set up for Digital Program Mapping (DPM)* (on page 188).


- 1 From the user interface of the D9854, click **Transport Stream > Transport Handling**, expand **MPEG over IP Output** and then click **Digital Program Mapping**. The Digital Program Mapping page is displayed.



- 2 For each DPM **Program Entry**, it displays the input channel number (**Chl #**) and channel **Name**.

**Note:** Any changes made to the DPM Program Entry Setup configuration automatically changes the Output Mode to Full DPM Control in the MPEG over IP Output page.

- 3 Select the program entry you want to edit.
- 4 In the **Action** drop-down list, select the DPM program action for the PE (Pass, Map, or Drop). The default is Pass.
- 5 Click **Edit**. The DPM PE PID MAP window opens.






- 6 Enter the **Output Channel Number** you want to map to the input channel (Input Channel #). This value is only used if the PE **Action** was set to Map. You can enter a range from 1 to 65535.
- 7 Enter the **Output PMT PID** you want to map to the Input PMT PID.
- 8 In the **PE PID MAP** section, you can select an existing PID mapping entry you want to modify or click Add Row to create a new entry.
- 9 The **Input Stream** indicates the input program stream category/service type. The **Input PID** displays the input program PID (1 to 8190). It is only used if the PID Action is set to Map.
- 10 In the **Action** drop-down, select the DPM action for the PID associated with the PE.

| Action | Description  |
|--------|--|
| Drop   | Removes the service and its associated PMT reference from the transport output.  |
| Map    | Provides the flexibility to define all the outgoing PID numbers for a PE, including those not currently on transmission. |

- 11 Enter a **Stream Type** to map within a PE to a specified PID (0 to 255).
- 12 Select the output program stream **Category** or service type. This value is only used if the Action is set to Map. The categories are: UNKN, CDT, LSDT, DATA, TTX, MPE, DPI, VBI, SUBT, AUD, VID, PCR or INVL.
- 13 Enter the Output Stream **Instance** (1 to 64) and the **Output** program **PID** (0 to 8192).
- 14 To remove a PID mapping, select the entry you want to remove and click **Delete**.
- 15 Click **OK**.
- 16 In the **DPM Program Entry Setup** section, each PE output can be synchronized to its input according to one of the four output modes. Select the program entry you want to synchronize and then click **Resynchronize** or click **Resynchronize All** to synchronize all the listed PE outputs to its inputs. The Confirm Resynchronization window is displayed.



- 17 Select whether you want to synchronize services and PIDs, services only, PIDs only, or to synchronize using a template.
- 18 Click Yes.
- 19 In the DPM General Settings section, you can configure MPEGoIP DPM transport stream settings.
- 20 In the Remapping Mode drop-down, select the DPM map mode. The following table describes each mode:

| Map Mode     | Description  |
|--------------|--|
| Svc ID       | The elementary PIDs are not changed. Channels are remapped by changing their PSI references. When this mode is selected, PE detailed PID mapping cannot be edited. |
| Svc ID & PID | Channels and the elementary service PIDs can be mapped.  |

- 21 Select the Duplication Method of the DPM program, which modifies the PSI to duplicate a program and its content. This parameter is only used if Remapping Mode is set to Svc ID & PID. The following table describes the each duplication method:

| Duplic Mode | Description  |
|-------------|--|
| PSI Remap   | Every input PID can be mapped to one output PID. If PID mapping conflicts exist, DPM will use the Precedence Rule to decide which output PID to use. All PMTs using the input PID will be updated to reference the output PID specified by the winner. |
| Pkt Copy    | An input PID can be mapped to multiple output PIDs. The PID will be duplicated as many times as needed (up to a certain hardware limitation).  |

Pkt Copy is recommended for most applications.

Select the DPM action to use for **Unreferenced Content**. Unreferenced content is the remainder of the transport that is not filtered by the program entries. Select Drop (default) to drop all unreferenced content. Select Pass to pass all unreferenced content to the output unchanged.

- 22 In the **Service ID Output** drop-down, select whether the receiver should always generate PSI tables for the Mapped PE even if the selected input channel is not available, or for only valid service channels/IDs. The following table describes each service ID:

| Svc ID   | Description   |
|----------|---|
| Valid Ch | Only transmits the PSI tables for the mapped program if the program exists on the input stream. |

| Svc ID | Description   |
|--------|---|
| All Ch | Transmits the PSI tables for the mapped program even if the program does not exist in the input stream.<br><br>All Ch is only valid if the PAT, NIT, SDT and PMT are set to Regenerate. |

- 23 Select the SI Regeneration Option. This applies the PowerVu rates (consistent with the uplink). This parameter is only used if Remapping Control is set to None. The following table describes each PSI rate:


| PSI Rate | Description  |
|----------|--|
| Auto     | Matches the generated PSI tables' output rate as the incoming rate.                            |
| MPEG Min | Transmits the generated PSI tables on the longest intervals that are allowed by MPEG standard. |
| SA Std   | Transmits the generated PSI tables based on PowerVu standard intervals.                        |

- 24 The **PSI Table Output Option** drop-down allows the operator to specify which PSI tables to include in the program/output stream. The following table describes each option:

| PSI Options  | Description  |
|--------------|--|
| Pass All     | Transmits the incoming PSI Tables as is; does not modify the content and rate.   |
| Drop All     | Does not transmit any PSI Tables.  |
| Ctl By Table | The operator can click Table Options to select the output mode for each table. The default table selections will be all pass, and only with CDT dropped. |

- 25 Select the **PSI Regeneration Option** drop-down, select whether to regenerate the PSI tables. You can select Always or As Needed (only if the content has changed).

- 26 If Ctl By Table was selected as the **PSI Table Output Option**, click **Table Options** to configure the DPM table options. The DPM Table Options (MOIP) window is displayed.



- 27 Select the tables which will be passed, dropped, regenerated or passed with rate control (PwRC) from the ASI Output. The CDT table is different from the other tables listed. For more information on the table options, see *PSI Table Settings* (on page 107).
- 28 Click **OK**.
- 29 Click **Apply**.

#### Typical set up for Digital Program Mapping (DPM)

- 1 Verify that you are receiving a valid signal and that you have set up the channels that you want to pass, drop, or map.
- 2 From the user interface of the D9854, click **Transport Stream**.
- 3 Click **ASI Output** or **MPEG over IP Output**.
- 4 In the **Output Mode** drop-down, select Full DPM Control.
- 5 If necessary, select the **Descrambled** mode according to whether the program is to be scrambled or descrambled for downstream viewing or monitoring.
- 6 Click **Apply**.
- 7 Click **Digital Program Mapping** from the **ASI Output** or **MPEG over IP Output**. The Digital Program Mapping page is displayed.
- 8 In the DPM Program Entry Setup, click **Resynchronize All**. This copies the input services PIDs to the remapped output service PIDs.
- 9 Select the PE containing the channel you want to configure and click **Edit**. The DPM PE PID MAP window is displayed.
- 10 In the **Action** drop-down, select Pass, Drop, or Map.

- 11 Configure the input to output channel mapping in the **Category** drop-down. Video and PCR can be output on the same PID or different PIDs. If output on the same PID, they will appear identical to the input.
- 12 Click **OK**.
- 13 In the DPM General Setting section, set the following parameters:

| Parameter               | Description       |
|-------------------------|-------------------|
| Remapping Mode          | Svc ID & PID      |
| Duplication Method      | Pkt Copy          |
| Unreferenced Content    | Drop              |
| Service ID Output       | Valid Ch/ All Ch  |
| PSI Table Output Option | Ctl By Table      |
| PSI Regeneration Option | Always/ As Needed |

- 14 Click **Table Options**. The DPM Table Options (ASI) window is displayed.
- 15 Set the following parameters:

| Parameter | Description   |
|-----------|---------------|
| PAT       | Regen         |
| CAT       | Regen         |
| PMT       | Regen         |
| TSDT      | Drop          |
| NIT       | Regen or Drop |
| NITO      | Drop          |
| SDT       | Regen         |
| SDTO      | Drop          |
| BAT       | Drop          |
| EIT       | Drop          |
| TDT       | Pass          |
| RST       | Pass          |
| TOT       | Pass          |
| DIT       | Pass          |
| SIT       | Pass          |
| ECM       | Drop          |
| EMM       | Drop          |
| DRT       | Drop          |

## Chapter 5 Web GUI Setup and Monitoring

| Parameter | Description |
|-----------|-------------|
| CDT       | Drop        |

- 16 Click **OK**.
- 17 Click **Apply**.

# Configuring System Settings

## Viewing the System Identification

- 1 From the user interface of the D9854, click **System Settings > System > Identification**. The Identification page is displayed.

The screenshot shows the Cisco D9854 Advanced Program Receiver user interface. The top navigation bar includes 'Summary', 'Input', 'Audio & Video', 'Transport Stream', 'System Settings' (highlighted), and 'Support'. The left sidebar shows a tree view with 'System' expanded and 'Identification' selected. The main content area is titled 'Identification' and contains the following 'Identity Information' table:

| Identity Information             |                           |
|----------------------------------|---------------------------|
| Hostname                         | User cfg name             |
| Model Number                     | D9854                     |
| Model Name                       | Advanced Program Receiver |
| Catalogue Number                 | Unknown                   |
| Customer Code                    | Ukn                       |
| Board ID                         | HDR                       |
| Board Revision                   | 1                         |
| Serial Number                    | Unknown                   |
| Tracking ID                      | Unknown                   |
| Ethernet 1 (Control) MAC Address | 00-02-DE-24-8D-9B         |
| User Address                     | 000-523-0375-3            |

At the bottom of the table, there are 'Apply' and 'Refresh' buttons. The footer of the page reads '© 2008-2010 Cisco Systems Inc. All rights reserved'.

- 2 The System page displays the parameters associated with the D9854 system, such as serial number, model number, and user addresses.
- 3 You may optionally change the **Hostname** (device name) and click **Apply**.

## Viewing Hardware Features and Base License Information

From the user interface of the D9854, click **System Settings > System**, expand **Identification** and then click **Features/Licenses**. The Features/Licenses page is displayed.

The screenshot shows the Cisco D9854 Advanced Program Receiver web GUI. The top navigation bar includes 'Summary', 'Input', 'Audio & Video', 'Transport Stream', 'System Settings' (highlighted), and 'Support'. The left sidebar shows a tree view with 'System' expanded to 'Identification', and 'Features/Licenses' selected. The main content area is titled 'Features/Licenses' and contains two tables.

| Hardware Features |                   |
|-------------------|-------------------|
| Feature           | Present (Stuffed) |
| SDI               | Yes               |
| MPOIP             | No                |
| Eth Filter        | No                |
| D9858             | No                |
| Number of SAT     | 0                 |
| Dolby-E           | No                |
| SFN               | No                |

| Feature License Summary |         |
|-------------------------|---------|
| Feature                 | Enabled |
| HD Decode               | Yes     |
| H.264 Decode            | Yes     |
| DVB-S2                  | Yes     |
| MPEGoIP Out             | Yes     |

© 2008-2010 Cisco Systems Inc. All rights reserved

The **Hardware Features** section displays the hardware options installed in the current D9854 Advanced Program Receiver. For example, it indicates whether the receiver is equipped with an SDI output and the number of transcoding paths.


The **Feature License Summary** section displays a list of software licenses for the D9854 Advanced Program Receiver and whether each of the software licenses are enabled or disabled.

**Note:** All software licenses are enabled for this release (temporarily). Any of these required licenses will need to be purchased from Cisco in subsequent software releases.



## Setting up IP Information

- 1 From the user interface of the D9854, click **System Settings > System > IP Settings**. The IP Settings page is displayed.



- 2 In the top section, you can set the parameters for communicating with other equipment via the Ethernet Data and Management ports for IP applications and upgrading application software.
- 3 Select control or data settings and set the IPv4 **Destination IP Address** for the interface. The address is 12 digits in length (###.###.###.###).
- 4 Set the number of CIDR (Classless Inter-Domain Routing) bits in the network **Mask** (8 to 30).
- 5 Set the **Gateway Address** on the Network, used to expose the receiver to a WAN. The IP Address, IP Mask, and Gateway Address should be changed together, i.e., as a group. The following table shows the most commonly used Subnet mask values to enter for a chosen IP address mask, which will depend on the size of your network.

| Mask | Subnet Mask   |
|------|---------------|
| 8    | 255.0.0.0     |
| 16   | 255.255.0.0   |
| 24   | 255.255.255.0 |

- 6 Select the speed and duplex type of the interface (**PHY Mode**). Select Auto for PHY to negotiate speed and duplex with other devices on the network, or select 10 HD (half-duplex), 10 FD (full-duplex), 100 HD, 100 FD, or 1000 FD to lock into a fixed mode. The default is Auto.

## Chapter 5 Web GUI Setup and Monitoring

- The **Protocol Control** section allows you to control remote access protocols to the IRD (Telnet, SSH, DTX, HTTP, and SNMP). In the **Telnet**, **SSH**, **HTTP**, **DTX**, and **SNMP** drop-down list, select Enable (default) to allow Telnet, Secure Shell, HTTP, DTX, and/or SNMP connections. Otherwise, select Disable.

The following lists the associated port numbers for each protocol:


| Protocol | Port Number    |
|----------|----------------|
| Telnet   | TCP port #23   |
| SSH      | TCP port #22   |
| HTTP     | TCP port #80   |
| DTX      | UDP port #8401 |
| SNMP     | UDP port #161  |

For information on accessing TCP/IP services, see *Accessing TCP and UDP Services* (on page 74).

- In the **Idle Timeout (seconds)** field, enter the number of seconds before the session for all the enabled protocols will timeout due to inactivity.
- Click **Apply**.

## Setting up IP Routing Information

- 1 From the user interface of the D9854, click **System Settings > System**, expand **IP Settings** and then click **IP Routing**. The IP Routing page is displayed.



- 2 In the **MPE Data Filter Model** drop-down, set whether all the MPE data is forwarded to the network (Forward None or Forward All). It can forward up to 5 multicast IP addresses.  
**Note:** This can only be configured on Port 2. Port 1 is fixed to Forward None.  
**Note:** The receiver supports up to a maximum of 10 Mbps throughput when forwarding 1500 byte packets.
- 3 The **Static Unicast Routing** and the **Static Multicast Filtering** sections are not supported in the current release.
- 4 Click **Apply**.

## Setting up SNMP Information and Trap Destinations

- 1 From the user interface of the D9854, click **System Settings > System**, expand IP Settings and then click **SNMP**. The SNMP page is displayed.

The screenshot shows the Cisco D9854 Advanced Program Receiver web GUI. The top navigation bar includes 'Summary', 'Input', 'Audio & Video', 'Transport Stream', 'System Settings' (highlighted), and 'Support'. The left sidebar shows a tree view with 'System' expanded, and 'SNMP' selected under 'IP Settings'. The main content area is titled 'SNMP' and contains the following configuration fields:

- Read Community String: public
- Write Community String: public
- System Name: sysname
- System Location: Toronto
- System Contact: 416-321-xxxx

Below these fields is the 'Trap Destination Configuration' section, which includes a table with the following data:

| Trap Destination IP Address | Community String |
|-----------------------------|------------------|
| 192.131.244.2               | public           |

Buttons for 'Add', 'Delete', 'Apply', and 'Refresh' are located below the table. The footer of the page reads '© 2008-2010 Cisco Systems Inc. All rights reserved'.

- 2 Set the **Read Community String** and the **Write Community String** to public (default) or custom string. Set the password to read/write data from a device and to display diagnostic traps/alarms. This is used when communicating with a device within an SNMP environment. To set a custom community string, enter an alphanumeric character string up to 31 alphanumeric characters in length identifying the password for the device.  
**Note:** The community string is case-sensitive.
- 3 Enter the **System Name**, **System Location**, and **System Contact** information of the D9854 receiver. The system information is sent to the MIB browser, if applicable. The MIB Browser is a third party software used to manage SNMP requests. For more information, contact Cisco customer support.

**To Add a Trap Destination**


- 1 Click **Add** in the Trap Destination Configuration section.

| Trap Destination Configuration   |                             |                      |
|--|-----------------------------|----------------------|
|  | Trap Destination IP Address | Community String     |
| <input type="radio"/>  | 192.131.244.2               | public               |
| <input checked="" type="radio"/>   | <input type="text"/>        | <input type="text"/> |
| <input type="button" value="Add"/> <input type="button" value="Delete"/> |                             |                      |

- 2 Type the **Trap Destination IP Address** that sets the destination for SNMP trap messages for system events (i.e. fault messages). You can enter up to 12 characters (e.g., 155.128.100.200).
- 3 Type the **Community String** for the trap destination (IP Address entered above).
- 4 Enter public or custom string. The default is public. You can enter a string up to 35 characters.
- 5 To edit/delete an existing trap destination, select the trap destination entry by clicking on the radio button. Make the necessary changes, or click **Delete** to remove the address from the Trap Destination Configuration list.
- 6 Click **Apply**.

## Configuring Time/Clock Settings


- 1 From the user interface of the D9854, click **System Settings > System > Time/Clock**. The Time/Clock page is displayed.



- 2 Set the **Date Format** of the receiver. The following formats are supported: YYYY\_MM\_DD, DD\_MM\_YYYY, MM\_DD\_YYYY.
- 3 Set the **Time Format** of the receiver. Current time information is normally broadcast as part of the transmitted digital signal. It is broadcast as GMT (Greenwich Mean Time) with date information in Modified Julian Date format. The following formats are supported: 24Hr, 24 Hr SuspendZero (the leading zero is dropped from the time), 12Hr, 12Hr SuspendZero (the leading zero is dropped from the time).
- 4 Set the **GMT Offset**. The local time is displayed using a time zone (GMT offset). If your local time is not GMT, you must set this time setting in the range from -12.0 to +12.0 hours in 0.5 hour increments.
- 5 The **Current TDT Time/Date** displays the current TDT (Time and Date Table) date and time received from the DVB stream. This is displayed as local time.
- 6 Select **Enable NTP Time Service** to periodically request NTP (Network Time Protocol) timestamps from the NTP server (NTP server address set below) and to synchronize its system (i.e., non-DVB related) time with the NTP server. This is displayed as local time.
- 7 Set the **NTP Server Address**. If the NTP server address is not set (0.0.0.0), the IRD will not attempt to connect to the server.
- 8 Displays the current time in the **Current NTP Time/Date** if IRD receives a valid reply from the NTP server, adjusted for local time zone.
- 9 Click **Apply**.

## Viewing the Alarm/Warning Status

From the user interface of the D9854, click **System Settings > Alarms > Status**. The Status page is displayed.




The Status page displays all the active event messages for the D9854 system. The **Fault Summary** section displays the **Type** of message (alarm or warning) and the number of alarms and warnings that have an active status (**Number Active**).

The following table shows the Alarm/Warning Status table information:

| Status    | Description  |
|-----------|--|
| Type      | Shows whether it is an alarm or a warning message.   |
| Name      | Name of the alarm or warning. For more information on alarm messages, refer to <i>Messages</i> (see " <i>D9854 Receiver Alarm Messages</i> " on page 227). |
| Text      | Content of the message.  |
| Set Since | Date and time of the alarm or warning.   |

## Setting up Alarms and Warnings

- 1 From the user interface of the D9854, click **System Settings > Alarms > Setup**. The Setup - Alarm Setup page is displayed.



- 2 Select **Enable Alarm/Warning Front Panel Reminder** and the highest priority alarm flashes on the LCD display for a two-second interval every 10 seconds. The alarm will continue to flash periodically until it is either cleared or the **Enable Alarm/Warning Front Panel Reminder** is de-selected.
- 3 Select **Enable Video Cutoff on Alarm Condition** to cut off the video output if any enabled alarm is active on the receiver. When video is cut off, there will be no horizontal or vertical synchronization on the output. This is useful for downstream redundancy switching by detecting a loss of video signal.
- 4 Click on the **Trap Configuration** link to view and/or modify SNMP trap destinations. The link will open the SNMP page. For more information, see *Setting up SNMP Information and Trap Destinations* (on page 196).
- 5 The **Alarm Setup** section displays a list of the alarm/fault messages. For more information on alarm messages, refer to *Messages* (see "*D9854 Receiver Alarm Messages*" on page 227).
- 6 Set **Enable/Disable** to Yes and the alarm message will be reported. Set to No and the alarm is disabled and the Relay and Trap settings are ignored.

**Note:** Enable/Disable must be set to Yes for the Relay and Trap settings to be functional.



- 7 If current alarm is enabled, set **Trap** to Yes and the SNMP trap message will be sent when the alarm is set or cleared.

**Note:** No is a read only value that indicates the setting is Yes, but is currently being suppressed because the alarm is disabled (Enb is set to No).


- 8 If current alarm is enabled, set **Relay** to Yes for the rear panel alarm relay to be triggered when the alarm is set or cleared.

**Note:** No is a read only value that indicates the setting is Yes, but is currently being suppressed because the alarm is disabled (Enb is set to No).

- 9 Click **Apply**.

### To Set Up Warnings

- 1 From the Setup - Alarm Setup page, click on the Warning Setup link at the bottom left hand corner of the page. The Setup - Warning Setup page is displayed.



- 2 Select **Enable Alarm/Warning Front Panel Reminder** and the warning flashes on the LCD display for a two-second interval every 10 seconds. The warning will continue to flash periodically until it is either cleared or the **Enable Alarm/Warning Front Panel Reminder** is de-selected.
- 3 The **Warning Setup** section displays a list of the warning messages. For more information on warning messages, refer to *Messages* (see "*D9854 Receiver Alarm Messages*" on page 227).

## Chapter 5 Web GUI Setup and Monitoring

- 4 Set **Enable/Disable** to Yes and the warning message will be reported. Set to No and the warning is disabled and the Relay and Trap settings are ignored.

**Note:** Enable/Disable must be set to Yes for the Relay and Trap settings to be functional.

- 5 If current warning is enabled, set **Trap** to Yes and the SNMP trap message will be sent when the warning is set or cleared.

**Note:** No is a read only value that indicates the setting is Yes, but is currently being suppressed because the warning is disabled (Enb is set to No).

- 6 If current warning is enabled, set **Relay** to Yes for the rear panel alarm relay to be triggered when the warning is set or cleared.

**Note:** No is a read only value that indicates the setting is Yes, but is currently being suppressed because the warning is disabled (Enb is set to No).

- 7 Click **Apply**.

## Viewing Alarm/Warning History

From the user interface of the D9854, click **System Settings > Alarms > History**. The History page is displayed.

The screenshot shows the Cisco D9854 Advanced Program Receiver web interface. The top navigation bar includes 'Summary', 'Input', 'Audio & Video', 'Transport Stream', 'System Settings' (highlighted), and 'Support'. The left sidebar shows a tree view with 'System' expanded to 'Alarms', and 'History' selected. The main content area is titled 'History' and contains a table of 'Fault History'.

| Type  | Name | Text             | Set Date & Time     | Cleared Date & Time |
|-------|------|------------------|---------------------|---------------------|
| Alarm | Fan  | Fans operational | 2007/06/25 07:26:52 | 2007/06/25 07:27:11 |
| Alarm | Fan  | Fans operational | 2007/06/25 07:27:12 | 2007/06/25 07:27:31 |
| Alarm | Fan  | Fans operational | 2007/06/25 07:27:32 | 2007/06/25 07:27:38 |
| Alarm | Fan  | Fans operational | 2007/06/25 07:27:39 | 2007/06/25 07:27:48 |
| Alarm | Fan  | Fans operational | 2007/06/25 07:27:49 | 2007/06/25 07:27:51 |
| Alarm | Fan  | Fans operational | 2007/06/25 07:27:52 | 2007/06/25 07:27:53 |
| Alarm | Fan  | Fans operational | 2007/06/25 07:27:54 | 2007/06/25 07:27:58 |
| Alarm | Fan  | Fans operational | 2007/06/25 07:27:59 | 2007/06/25 07:28:10 |
| Alarm | Fan  | Fans operational | 2007/06/25 07:28:11 | 2007/06/25 07:28:13 |
| Alarm | Fan  | Fans operational | 2007/06/25 07:28:14 | 2007/06/25 07:28:53 |
| Alarm | Fan  | Fans operational | 2007/06/25 07:28:54 | 2007/06/25 07:29:46 |
| Alarm | Fan  | Fans operational | 2007/06/25 07:29:47 | 2007/06/25 07:29:48 |

Below the table are three buttons: 'Refresh', 'Clear Alarms/Warnings History', and 'Export'.

The Alarm and Warning History page displays all the past system event messages and their set and cleared dates and times. For more information on the alarm messages, refer to *Messages* (see "*D9854 Receiver Alarm Messages*" on page 227).

Click **Clear Alarms/Warnings History** to clear all existing history information.

Click **Export** to save the history information to your local hard drive as a *.csv* file.

## Viewing Version Information

From the user interface of the D9854, click **System Settings > Versions > Versions**. The Versions page is displayed.

The screenshot displays the Cisco D9854 Advanced Program Receiver web GUI. The top navigation bar includes 'System Settings' and 'Support'. The left sidebar shows a tree view with 'Versions' selected. The main content area is titled 'Versions' and contains three sections:

- Software Versions:**

|                    |                                   |  |                                      |
|--------------------|-----------------------------------|--|--------------------------------------|
| BOOT1              | 5.00                              | BOOT2  | 1.00                                 |
| Safe APP           | 3.26                              | Current APP  | B03.25.11DD                          |
| Minimum Version    | 99.99.00                          |  |                                      |
| Select APP Version | <input type="text" value="3.26"/> | <input type="button" value="Select &amp; Reboot"/> | <input type="button" value="Erase"/> |
- Firmware Versions:**

|                     |  |  |                                      |
|---------------------|--|--|--------------------------------------|
| CPLD1               | E00.01.02                                | CPLD2  | E00.03.01                            |
| FP PIC              | 1.04                                     | CUE PIC  |                                      |
| FPGA Type           | XC4VFx60                                 | FPGA ID  | Wildcard FPGA ID                     |
| Safe FPGA           | R00.00.04vu                              |  |                                      |
| Current FPGA        | R00.00.03az                              | FPGA Build   | B00.01.12/CR28                       |
| Select FPGA Version | <input type="text" value="R00.00.04vu"/> | <input type="button" value="Select &amp; Reboot"/> | <input type="button" value="Erase"/> |
- Download APP:**

Upgrade File:

Device will not reboot automatically following an FPGA download.  
Device will reboot automatically following an APP download.
- Download Status:**

|           |            |           |   |  |
|-----------|------------|-----------|---|--|
| Triggered | No Trigger | Total CDT | 0 | <input type="button" value="History"/> |
| State     | Ready      | Received  | 0 |  |
|           |            | Rejected  | 0 |  |

© 2008-2010 Cisco Systems Inc. All rights reserved


The **Software Versions** section displays the currently running loaded application version number, the factory loaded application version number, and the Host Boot version numbers. In the **Select APP Version** drop-down, you can choose a different application version number to load. Click **Select & Reboot** to load the selected application and reboot the receiver. Click **Erase** to remove the selected application version. You will be prompted to continue or not. Click **OK** to continue the deletion.

The **Firmware Versions** section displays the current and safe limits for the Field Programmable Gate Array (FPGA) version number, and the Complex Programmable Logic Device (CPLD) version number. In the **Select FPGA Version** drop-down, you can choose a different FPGA application version number to load. Click **Select & Reboot** to load the selected application and reboot the receiver. Click **Erase** to remove the selected application version. You will be prompted to continue or not. Click **OK** to continue the deletion.

In the **Download APP** section, click **Browse** to select the new version of FPGA or the D9854 Advanced Program Receiver's software application. The Choose File dialog opens. Select the upgrade file and click **Open**. Click **Download** to download the selected upgrade file. File formats that can be downloaded include cdt, FPGA, app, etc.

**Note:** For application downloads, once the download is complete, the D9854 receiver will reboot automatically. For FPGA downloads, you must click **Reboot Receiver** in the Service Actions page (**Support > Service Actions**) to manually reboot the D9854 receiver and complete the download. This is to facilitate the typical case in which the user intends to flash the FPGA file (no auto reboot) followed by an APP download (auto reboot).

The **Download Status** section displays the current status of the downloads. Click **History** and the Download History window is displayed.



You can sort the columns by clicking on the column headings. Click **Export** to save the history information to a file.

## Setting up Import/Export Information

- 1 From the user interface of the D9854, click **System Settings > Settings File > Import/Export**. The Import/Export page is displayed.

The screenshot shows the Cisco D9854 web interface. The top navigation bar includes 'Summary', 'Input', 'Audio & Video', 'Transport Stream', 'System Settings' (highlighted), and 'Support'. The left sidebar shows a tree view with 'Import/Export' selected under 'Settings File'. The main content area is titled 'Import / Export' and contains the following sections:

- Device Settings File Transfer:**
  - Export Device Settings & Transport Network Information (with an **Export** button)
  - Export User Device Settings Only
- Settings File:** A text input field containing 'file name', a **Browse...** button, and an **Import** button.
- Configure Offline FTP Settings File Transfer:**
  - Settings Filename: file name
  - FTP Server IP Address: 192.168.0.100
  - FTP User Name: [empty field]
  - FTP Password: [masked field]
  - FTP Port Number: 21
  - Export Device Settings & Transport Network Information
  - Export User Device Settings Only

At the bottom of the form are buttons for **Apply**, **Refresh**, **Export**, and **Import**.

In the **Device Settings File Transfer** section, you can export and/or import device settings and transport network information.

- 2 Select **Export Device Settings & Transport Network Information** and click **Export** to download device settings and transport network information as a file to the designated file folder.
- 3 Select **Export User Device Settings only** and click **Export** to download user settings as a file to the designated file folder.
- 4 In the **Settings File**, click **Browse**. The Choose File dialog opens. Navigate to the appropriate folder and select the file with a *.bkp* file extension and click **Open**. Click **Import**.

- 5 The **Configure Offline FTP Settings File Transfer** section has backup and restore controls.

**Note:** You must have access to an FTP Server (e.g. WinFTP) on a network or a local PC before you can setup backup/restore controls.


- 6 Type the **Settings Filename** of the backup/restore file. You can enter up to 119 characters.

- 7 Set the **FTP Server IP Address** of the FTP server used to restore the backup/restore file. The address is up to 12 characters in length (e.g. 171.300.100.200 and in the range from 0 to 255.
- 8 Set the **FTP User Name** and **FTP Password** to access the FTP server.  
**Note:** The FTP Password is not retained in the receiver. You must re-enter the password before initiating the backup or restore operation.
- 9 Set the **FTP Port Number** of the FTP server used to store the backup/restore file. You can enter a port number in the range from 1 to 65535.
- 10 Select **Export Device Settings & Transport Network Information** to save user settings and tuning information to the backup file. Select **Export User Device Settings Only** to save user settings to the backup file.
- 11 Click **Export** to save the settings to a backup file. Click **Import** to retrieve the last backed up file.

While backup or restore is in progress, the operation status, file transfer percentage, and detailed status windows appear.

## Viewing the Backup/Restore Status

From the user interface of the D9854, click **System Settings > Settings File > Status**. The Status page is displayed.



The following table displays the Settings File Backup/Restore/Operation History information:

| Status                    | Description   |
|---------------------------|---|
| Last Backup File Name     | Name of the file to use.  |
| Backup Time Stamp         | Date and time of the last successful backup file saved.             |
| Last Restored File Name   | Name of the last file that was restored.                            |
| Restore Time Stamp        | Date and time of the last successful restore.                       |
| Operation Status          | Status of the current backup operation (InProgress, Pass, or Fail). |
| Detailed Operation Status | Detailed processing step for tracking backup progress.              |
| Percentage Complete       | Percentage of backup function completed.                            |



## Managing D9854 Web GUI Accounts


You can define up to 10 usernames/passwords for login use via web GUI session on the D9854 receiver.

When a user tries to login, the user is required to provide a username and a password. The user is granted access only if this username/password pair exists in the authentication table.

The factory preset "Admin" account has Admin privileges and is allowed to add new users, delete users, change usernames, and modify its own passwords. Users with non-Admin privileges (for example, User and Guest) are only allowed to modify their own passwords

### To Change the User Login Passwords

- 1 From the user interface of the D9854, click **System Settings > Security/Accounts > Account Management**. The Account Management page is displayed.



To configure the password complexity for all users:

**Note:** This feature is only available to a user with Admin privileges only.

- 2 Set the **Password Complexity** (No Checking, Minimal Checking, Full Complexity Checking). Any changes take effect immediately, and do not require the use of the **Apply** button.

The following describes the rules for each level:

| Password Complexity      | Description   |
|--------------------------|---|
| No Checking              | There are no restrictions on passwords.<br><b>Note:</b> A minimum of one character is required.   |
| Minimal Checking         | A password must comply with the following requirements: <ul style="list-style-type: none"> <li>■ It cannot contain username or reversed username.</li> <li>■ It cannot contain any of the following strings: cisco, sciatl, ocsic, Itaics, atlsci, iclsta, or any string achieved by full or partial capitalization of letters.</li> <li>■ No letter is repeated more than three times in a row.</li> <li>■ Must contain a minimum of four characters.</li> </ul>   |
| Full Complexity Checking | A password must comply with the following requirements: <ul style="list-style-type: none"> <li>■ It cannot contain username or reversed username.</li> <li>■ It cannot contain any of the following strings: cisco, sciatl, ocsic, Itaics, atlsci, iclsta, or any string achieved by full or partial capitalization of letters.</li> <li>■ No letter is repeated more than three times in a row.</li> <li>■ Must contain a minimum of eight characters.</li> <li>■ Must contain a minimum of three of the following types of characters: capital letters, small letters, digits, and special characters.</li> </ul> |

**Note:** The complexity level changes will only affect the new user accounts and password changes. It will not affect existing passwords. Any changes take effect immediately, and do not require the use of the **Apply** button.

To change your login password:


**Note:** You are allowed to only modify your own password.

- 3 The **Change Password for User** displays the password for the current login.
- 4 In the **Enter Current Password**, type the current login password.
- 5 In the **Enter New Password**, type the new login password.
- 6 In the **Re-enter New Password**, type the new login password again to confirm. Once the password change is successful, the user will be directed to the login screen to re-enter their username and password.  
**Note:** The Enter New Password and Re-enter New Password should be identical. Each user, including the admin user, can only modify their own password.
- 7 Click **Apply**.

**To Add a User Account**

**Note:** This feature is available to a user with Admin privileges only.


- 1 From the Account Management page, click on the **Manage User Logins** link. The Login Accounts page is displayed.



- 2 Click **Add** to create a new login account.

**Note:** You can create a maximum of 10 user accounts.

The Add Login Account window is displayed.



- 3 In the **Username** field, enter a user ID. The new username should not match any of the usernames already defined in the Logins Accounts table.

- 4 In the **New Password** field, enter a password to assign the user ID. The password must follow the rules configured in the **Set Password Complexity for All Users** parameter. For more information, see *To Configure the User Login Passwords* (see "To Change the User Login Passwords" on page 209).
- 5 Enter the new password again to confirm in the **Confirm New Password** field.  
**Note:** The New Password and Confirm New Password should be identical.
- 6 In the **Administrator Password** field, enter your Administrator password used to log on to the D9854 web GUI.
- 7 In the **Account Type** drop-down list, select User, Admin, or Guest. The following table illustrates the different login types:


| Account Type | Access   |
|--------------|--|
| Guest        | View settings only.                                |
| User         | View and edit settings.                            |
| Admin        | View, edit settings, and add/delete user accounts. |

- 8 Click **OK**.

#### To Delete a User Account

**Note:** This feature is available to a user with Admin privileges only.


- 1 In the Account Management table, select the user you want to remove.
- 2 Click **Delete**. The Delete Login Account window is displayed.




- 3 Enter your **Administrator Password** to confirm the deletion.
- 4 Click **OK**. The selected user account is deleted.

## Configuring Lock Level Settings

- 1 From the user interface of the D9854, click **System Settings > Security/Accounts > Lock Level Settings**. The Lock Level Settings page is displayed.



- 2 Click **Change Lock Level** and the Change Lock Level window is displayed.



- 3 Select the **Lock Level** which restricts access and prevents unauthorized changes to the receiver settings (0, 1, 2, or 3). The default setting is 0.

**Note:** For details on the four lock levels, see *D9854 Receiver Lock Levels* (on page 302).

- 4 Enter the Password to change the lock level. The default password is 1234.
- 5 Click **Yes**.


If the incorrect lock level or password is entered, an error message appears at the top of the page.

### Changing the Lock Level Password

A unique lock level password (4-digit password) protects the current receiver settings against unauthorized changes. When changing the password, record and keep this number in a secure location. The default password is 1234.

**Important:** Proceed with caution when changing the password as this operation cannot be undone. If the password is lost or is unavailable, contact Cisco customer support.

- 1 In the Lock Level Settings page, click **Change Lock Level Password**. The Change Lock Level Password window is displayed.




- 2 Enter the **Current lock level Password**.
- 3 In the **Enter New Password** field, enter the new password, any number from 0 to 9.
- 4 Re-enter the **New Password** and click **Yes**. A message appears informing you that the password was changed successfully.

**Note:** If the password is lost or is unavailable, contact Cisco customer support.

## Configuring Front Panel Settings

- 1 From the user interface of the D9854, click **System Settings > Security/Accounts > Front Panel**. The Front Panel page is displayed.




- 2 Select the **Enable Automatic Front Panel Keyboard Lock** to enable the front panel keypad lock state.
- 3 The **Keyboard Lock Timeout** sets the keypad lock timeout period. The lock timeout period takes effect when the keypad has not been touched (i.e., a key has not been pressed) when on the Main Menu for the set period. Avoid setting the period to a short duration when the keypad is used often. Enter a value in the range from 5 to 1800 seconds. The default is 60 seconds.
- 4 Click **Apply**.

## Viewing Support Information

### Viewing Contact Information

From the user interface of the D9854, click **Support > Contact > Contact Information**. The Contact Information page is displayed.



The Contact Information page displays all the Cisco customer support information.



## Viewing Diagnostic Logs

From the user interface of the D9854, click **Support > Logs > Diagnostic Logs**. The Diagnostic Logs page is displayed.

The screenshot shows the Cisco D9854 Advanced Program Receiver interface. The top navigation bar includes 'Summary', 'Input', 'Audio & Video', 'Transport Stream', 'System Settings', and 'Support'. The left sidebar shows a tree view with 'Diagnostic Logs' selected. The main content area is titled 'Diagnostic Logs' and contains a table of log history. The table has two columns: 'Set Date and Time' and 'Message'. The log entries are as follows:

| Set Date and Time   | Message  |
|---------------------|--|
| 2007/02/09 10:00:01 | LOG ,WARNING,;1449;807 old messages were lost while log output was inactive on this interface. |
| 2007/02/09 10:00:01 | LOG ,WARNING,;3303;26 messages were lost due to log buffer overflow.                           |
| 2007/02/09 10:00:01 | LOG ,WARNING,;1449;802 old messages were lost while log output was inactive on this interface. |
| 2007/02/09 10:00:01 | LOG ,WARNING,;3303;26 messages were lost due to log buffer overflow.                           |
| 2007/02/09 10:00:01 | LOG ,WARNING,;1449;802 old messages were lost while log output was inactive on this interface. |
| 2007/02/09 10:00:01 | LOG ,WARNING,;3303;26 messages were lost due to log buffer overflow.                           |
| 2007/02/09 10:00:01 | LOG ,WARNING,;1449;802 old messages were lost while log output was inactive on this interface. |
| 2007/02/09 10:00:01 | LOG ,WARNING,;3303;26 messages were lost due to log buffer overflow.                           |
| 2007/02/09 10:00:01 | LOG ,WARNING,;1449;802 old messages were lost while log output was inactive on this interface. |
| 2007/02/09 10:00:01 | LOG ,WARNING,;3303;26 messages were lost due to log buffer overflow.                           |
| 2007/02/09 10:00:12 | LOG ,WARNING,;1446;800 old messages were lost while log output was inactive on this interface. |
| 2007/02/09 10:00:13 | LOG ,WARNING,;3294;46 messages were lost due to log buffer overflow.                           |

Below the table are buttons for 'Refresh', 'Clear', and 'Export'. A tip at the bottom right of the table states 'Tip: This table is sortable'.

The Diagnostic Logs page displays all the system log messages with their dates and times.

Click on the arrow next to **Set Date and Time** column to sort by date and time.

Click **Export** to export the log history to a .csv file. The File Download dialog is displayed. Click **Save** to save the file to your local drive.

## Viewing the Usage Counters

From the user interface of the D9854, click **Support > Logs > Usage Counters**. The Usage Counters page is displayed.

The screenshot shows the Cisco D9854 Advanced Program Receiver web GUI. The top navigation bar includes 'Summary', 'Input', 'Audio & Video', 'Transport Stream', 'System Settings', and 'Support'. The left sidebar shows a tree view with 'Usage Counters' selected under 'Logs'. The main content area displays 'Usage Counter Information' with the following data:

| Usage Counter Information       |   |
|---------------------------------|---|
| Production Date and Time        | 2000/01/01 10:00:00                       |
| Last Power On Date and Time     | 2007/06/24 05:50:13                       |
| Lifetime Hours Powered          | 26  |
| Lifetime Reset Counter          | 6   |
| Clearable Reset Counter         | 6   |
| Hours Since Last Power-On/Reset | 26  |
| Last Reset Reason               | Power up (Power cycle, Manual reset, ...) |

Below the table is a 'Clear Reset Counter' button. The footer of the page reads '© 2008-2010 Cisco Systems Inc. All rights reserved.'

The following table describes the Usage Counter Information:

| Device Status Information         | Description   |
|-----------------------------------|---|
| Production Date & Time            | Displays the date and time when the receiver was manufactured.  |
| Last Power On Date and Time       | Displays the date and time when the receiver was powered up.  |
| Lifetime Hours Powered            | Displays the number of hours since the last power-on.   |
| Lifetime Reset Counter            | Displays the total number of times the receiver has been restarted.   |
| Clearable Reset Counter           | Displays the number of restarts since the last time the restart counter was cleared.<br><br>To clear or reset the Clearable Reset Count, click <b>Clear Reset Counter</b> . |
| Hours Since Last Powered-On/Reset | Displays the total number of hours that the receiver has been operating since the last power-on or restart.   |

**Viewing Support Information**

| <b>Device Status Information</b> | <b>Description</b>   |
|----------------------------------|--|
| Last Reset Reason                | Displays the reason for the last restart, i.e., power cycle or manual reset. |

Click **Clear Reset Counter** to clear the **Clearable Reset Counter** field and it resets the counter back to 0.

## Viewing Operating Board Temperatures

From the user interface of the D9854, click **Support > Logs > Fans & Temperatures**. The Fans & Temperatures page is displayed.

The screenshot shows the Cisco D9854 - Advanced Program Receiver web interface. The top navigation bar includes 'Summary', 'Input', 'Audio & Video', 'Transport Stream', 'System Settings', and 'Support'. The left sidebar contains 'Contact', 'Logs', 'Diagnostic Logs', 'Usage Counters', 'Fans & Temperatures', 'Alarm History', and 'Service Actions'. The main content area is titled 'Fans & Temperatures' and features a 'Board Temperature' table.

| Current | Maximum | Average | Intake 1 | Intake 2 | FPGA Vicinity | FPGA Value |
|---------|---------|---------|----------|----------|---------------|------------|
| 25.0 °C | 26.0 °C | 25.0 °C | 26.0 °C  | 25.0 °C  | 34.0 °C       | 38.0 °C    |

© 2008-2010 Cisco Systems Inc. All rights reserved

The Board Temperature section displays the current operating temperature (**Current**), the maximum operating temperature (**Maximum**) that has been reached, and the average operating temperature (**Average**). The values are displayed in Degrees Celsius.

## Viewing Alarm/Warning History

From the user interface of the D9854, click **Support > Logs > Alarm History**. The Alarm History page is displayed.

The screenshot shows the Cisco D9854 - Advanced Program Receiver web interface. The top navigation bar includes 'Summary', 'Input', 'Audio & Video', 'Transport Stream', 'System Settings', and 'Support'. The left sidebar shows a tree view with 'Logs' expanded to 'Alarm History'. The main content area displays the 'Alarm History' page with a 'Fault History' table.

| Type  | Name | Text             | Set Date & Time     | Cleared Date & Time |
|-------|------|------------------|---------------------|---------------------|
| Alarm | Fan  | Fans operational | 2007/06/25 08:22:26 | 2007/06/25 08:22:29 |
| Alarm | Fan  | Fans operational | 2007/06/25 08:22:30 | 2007/06/25 08:22:34 |
| Alarm | Fan  | Fans operational | 2007/06/25 08:22:35 | 2007/06/25 08:22:45 |
| Alarm | Fan  | Fans operational | 2007/06/25 08:22:46 | 2007/06/25 08:22:57 |
| Alarm | Fan  | Fans operational | 2007/06/25 08:22:58 | 2007/06/25 08:23:20 |
| Alarm | Fan  | Fans operational | 2007/06/25 08:23:21 | 2007/06/25 08:23:26 |
| Alarm | Fan  | Fans operational | 2007/06/25 08:23:27 | 2007/06/25 08:23:33 |
| Alarm | Fan  | Fans operational | 2007/06/25 08:23:35 | 2007/06/25 08:23:50 |
| Alarm | Fan  | Fans operational | 2007/06/25 08:23:51 | 2007/06/25 08:24:21 |
| Alarm | Fan  | Fans operational | 2007/06/25 08:24:22 | 2007/06/25 08:24:54 |
| Alarm | Fan  | Fans operational | 2007/06/25 08:24:55 | 2007/06/25 08:25:07 |
| Alarm | Fan  | Fans operational | 2007/06/25 08:25:08 | 2007/06/25 08:25:33 |


Below the table are buttons for 'Refresh', 'Clear Alarms/Warnings History', and 'Export'. The footer of the interface reads '© 2008-2010 Cisco Systems Inc. All rights reserved'.

The Alarm and Warning History page displays all the past system event messages and their set and cleared dates and times. For more information on the alarm messages, refer to *Messages* (see "*D9854 Receiver Alarm Messages*" on page 227).

Click **Clear Alarms/Warnings History** to clear all the messages in the Fault History table. Click **Export** to export the alarm history to a .csv file. The File Download dialog is displayed. Click **Save** to save the file to your local drive.

## Loading a Software Version

From the user interface of the D9854, click **Support > Service Actions > Service Actions**. The Service Actions page is displayed.



The **S/W Version** drop-down list allows you to select/load a different application version to your receiver. Click **Select & Reboot** to load the selected application version and reboot the receiver.

Click **Erase** to remove the selected application version. You will be prompted to continue or not. Press **OK** to continue the deletion.

Click **Factory Reset** to perform a reset of receiver settings back to the factory set (default) values. A warning message prompts you to confirm the operation. Click **OK** to continue or **No** to cancel the operation.

Click **Reboot Receiver** to reboot the receiver. You will be prompted to verify the operation. Click **Yes** to reboot the receiver or **No** to cancel the operation.

### To Change the Download Application

In the **Download APP** section, click **Browse** to select the new version of FPGA or the D9854 Advanced Program Receiver's software application. The Choose File dialog opens. Select the upgrade file and click Open. Click Download to download the selected upgrade file.

**Note:** For application downloads, once the download is complete, the D9854 receiver will reboot automatically. For FPGA downloads, you must click **Reboot Receiver** to manually reboot the D9854 receiver and complete the download. This is to facilitate the typical case in which the user intends to flash the FPGA file (no auto reboot) followed by an APP download (auto reboot).





# 6

---

## Service and Maintenance

### Overview


This chapter gives information to assist you in upgrading firmware to the D9854 Advanced Program Receiver. It also describes how the status of the D9854 receiver is communicated via front panel LEDs.

### In This Chapter

- Front Panel LEDs ..... 226
- D9854 Receiver Alarm Messages ..... 227

## Front Panel LEDs

To help signal the status of operation or the presence of an alarm, the D9854 receiver makes use of front panel LEDs. The photograph below shows the location of the LEDs on the front panel of the D9854 receiver.



The functions of the LEDs are described in the table below.

| LED    | Signal State/Color | Explanation  |
|--------|--------------------|--|
| ALARM  | Red                | Solid for five seconds indicates a Warning.  |
|        | Red                | Flashing indicates an Alarm.   |
| SIGNAL | Green              | Solid indicates all of the following conditions: <ul style="list-style-type: none"> <li>■ all RF inputs are enabled, all inputs are locked to a signal, and are not muted.</li> <li>■ all routed ASI outputs are operating without an error.</li> </ul>  |
|        | Green              | Flashing indicates one of the following conditions: <ul style="list-style-type: none"> <li>■ difficulty with an input, route or output.</li> <li>■ one or more RF inputs, or the ASI input are not synchronized.</li> <li>■ one or more ASI outputs are routed, but muted by a fault condition.</li> <li>■ no RF signal is present or detected, or it is muted.</li> <li>■ receiver is not authorized to receive the program.</li> </ul> |
|        | Off                | Off indicates all of the following conditions: <ul style="list-style-type: none"> <li>■ no RF input signal is available, enabled or detected, or the input is muted.</li> <li>■ no ASI input is present.</li> <li>■ no valid inputs are available.</li> </ul>  |

## D9854 Receiver Alarm Messages

The status of the D9854 receiver and its immediate surroundings is reported to the front panel in the form of messages and alarms. You can enable or disable messages in the Alarm/Warning settings.

The following table shows an alphabetical list of the available messages and their default alarm status. The Set Messages and Clear Messages are displayed in the Warning History when the messages are set or cleared respectively.

Only alarm conditions can be used to trigger rear panel relays to control external alarm equipment. Warnings are not associated with relay operation.

### Alarms

| Alarm             | Message Type | Message                              | Cause/Remedy  | Description   | Severity |
|-------------------|--------------|--------------------------------------|---|---|----------|
| PSB non-compliant | Set          | PROD incomplete or PSB non-compliant | <p>Cause: Production command exit_weak_state was not issued after production programming was completed.</p> <p>Remedy: The Exit_weak_state command should be issued by the user with PROD credentials if the device has not yet been shipped to the customer. Otherwise, the customer must reset credentials using the Front Panel.</p> | Device is in the WEAK state after production programming is complete. | Major    |
| PSB non-compliant | Clear        | PSB compliant                        |   |   |          |

Chapter 6 Service and Maintenance

| Alarm         | Message Type | Message                   | Cause/Remedy  | Description                             | Severity |
|---------------|--------------|---------------------------|---|---|----------|
| Signal Status | Set          | ASI Signal - No Content   | <p>Cause: Loss of ASI/RF lock. Loss of Transport data. Invalid frequency parameters. External to IRD.</p> <p>Remedy: Check tuning parameters and ASI/RF cables.</p> | ASI Link Locked, but no TS content.     | Minor    |
| Signal Status | Set          | RF Signal - No Content    | <p>Cause: Loss of ASI/RF lock. Loss of Transport data. Invalid frequency parameters. External to IRD.</p> <p>Remedy: Check tuning parameters and ASI/RF cables.</p> | RF Tuner locked, but no TS content.     | Minor    |
| Signal Status | Set          | Signal is lost            | <p>Cause: Loss of ASI/RF lock. Loss of Transport data. Invalid frequency parameters. External to IRD.</p> <p>Remedy: Check tuning parameters and ASI/RF cables.</p> | Loss of signal                          | Minor    |
| Signal Status | Set          | Tuning Parameters Invalid | <p>Cause: Loss of ASI/RF lock. Loss of Transport data. Invalid frequency parameters. External to IRD.</p> <p>Remedy: Check tuning parameters and ASI/RF cables.</p> | One of the tuning parameters is invalid | Minor    |
| Signal Status | Clear        | Signal is locked          |   | Signal OK                               | Minor    |

D9854 Receiver Alarm Messages

| Alarm              | Message Type | Message                               | Cause/Remedy   | Description  | Severity |
|--------------------|--------------|---------------------------------------|--|--|----------|
| Signal Status      | Clear        | Tuning Parameters Valid               |  | Tuning parameters are valid  | Minor    |
| PE n: ISE Not Auth | Set          | Channel is not authorized             | <p>Cause: The channel is unauthorized for the current program.</p> <p>Remedy: Contact your (uplink) service provider to determine whether you are authorized to receive the current program.</p> | Program unauthorized because the tier bits do not match.                           | Minor    |
| PE n: ISE Not Auth | Set          | Channel requires an authorization key | <p>Cause: The channel is unauthorized for the current program.</p> <p>Remedy: Contact your (uplink) service provider to determine whether you are authorized to receive the current program.</p> | Program is unauthorized because the unit does not have an authorization key.       | Minor    |
| PE n: ISE Not Auth | Set          | Channel is blacked out                | <p>Cause: The channel is unauthorized for the current program.</p> <p>Remedy: Contact your (uplink) service provider to determine whether you are authorized to receive the current program.</p> | Program is unauthorized because at a minimum, it needs to match one blackout code. | Minor    |

Chapter 6 Service and Maintenance

| Alarm              | Message Type | Message                                 | Cause/Remedy   | Description                                  | Severity |
|--------------------|--------------|---|--|--|----------|
| PE n: ISE Not Auth | Set          | Channel uses an unknown CA system       | <p>Cause: Conditional access not supported.</p> <p>Remedy: Contact your (uplink) service provider to determine whether you are authorized to receive the current program at this time.</p> | Non-SA conditional access system.            | Minor    |
| PE n: ISE Not Auth | Set          | Channel authorization refused           | <p>Cause: Conditional access not supported.</p> <p>Remedy: Contact your (uplink) service provider to determine whether you are authorized to receive the current program at this time.</p> | There is mismatch in the Conditional access. | Minor    |
| PE n: ISE Not Auth | Set          | Channel requires an IRD with CA support | <p>Cause: Conditional access not supported.</p> <p>Remedy: Contact your (uplink) service provider to determine whether you are authorized to receive the current program at this time.</p> | Conditional access is not supported.         | Minor    |
| PE n: ISE Not Auth | Set          | Channel requires the PE to have an ISE  | <p>Cause: Hardware issue.</p> <p>Remedy: Clear alarms, reset unit, and notify customer service if problem persists.</p>  | Hardware issue.                              | Minor    |

## D9854 Receiver Alarm Messages

| Alarm              | Message Type | Message                           | Cause/Remedy   | Description  | Severity |
|--------------------|--------------|-----------------------------------|--|--|----------|
| PE n: ISE Not Auth | Set          | Channel Unavailable - LEC timeout | <p>Cause: Uplink configuration issue.</p> <p>Remedy: Contact your (uplink) service provider to determine whether the LEC GDS data is being provided in the stream.</p>       | Uplink configuration issue.  | Minor    |
| PE n: ISE Not Auth | Clear        | Fault Reset                       |  |  | Minor    |
| PE n: ISE Not Auth | Clear        | Channel is authorized             |  |  | Minor    |
| CI Top Slot Status | Set          | Initialization Fail               | <p>Cause: CAM is damaged or not fully inserted, hardware issue, CAM software crash or you don't have subscription rights for the card.</p> <p>Remedy: Re-insert the CAM.</p> | Initialization of CAM in top slot failed.                            | Major    |
| CI Top Slot Status | Set          | No Descrambling                   | <p>Cause: CAM is damaged or not fully inserted, hardware issue, CAM software crash or you don't have subscription rights for the card.</p> <p>Remedy: Re-insert the CAM.</p> | All elementary streams of all selected programs are not descrambled. | Major    |
| CI Top Slot Status | Clear        | CAM Operation OK                  |  |  | Major    |

**Chapter 6 Service and Maintenance**

| <b>Alarm</b>          | <b>Message Type</b> | <b>Message</b>          | <b>Cause/Remedy</b>   | <b>Description</b>   | <b>Severity</b> |
|-----------------------|---------------------|-------------------------|---|--|-----------------|
| CI Bottom Slot Status | Set                 | Initialization Fail     | <p>Cause: CAM is damaged or not fully inserted, hardware issue, CAM software crash or you don't have subscription rights for the smart card.</p> <p>Remedy: Re-insert the CAM, and/or check your rights for the smart card.</p> | Initialization of CAM in bottom slot failed.   | Major           |
| CI Bottom Slot Status | Set                 | No Descrambling         | <p>Cause: CAM is damaged or not fully inserted, hardware issue, CAM software crash or you don't have subscription rights for the smart card.</p> <p>Remedy: Re-insert the CAM, and/or check your rights for the smart card.</p> | All elementary streams of all selected programs are not descrambled.                               | Major           |
| CI Bottom Slot Status | Clear               | CAM Operation OK        |   |  | Major           |
| PE n CI Status        | Set                 | Program Not Descrambled | <p>Cause: Hardware issue, CAM software crash or you don't have subscription rights for the smart card.</p> <p>Remedy: Reinsert the CAM and/or check your rights for the smart card.</p>   | All elementary streams for this service selected for descrambling were not descrambled by the CAM. | Major           |



D9854 Receiver Alarm Messages

| Alarm                   | Message Type | Message                      | Cause/Remedy  | Description   | Severity |
|-------------------------|--------------|------------------------------|---|---|----------|
| PE n CI Status          | Set          | 1 or more ES Not Descrambled | Cause: Hardware issue, CAM software crash or you don't have subscription rights for the smart card.<br><br>Remedy: Reinsert the CAM and/or check your rights for the smart card.                      | At least 1 elementary stream is not descrambled, but the CAM is still descrambling other elementary streams for this service. | Major    |
| PE n CI Status          | Clear        | Descrambling OK              |   |   | Major    |
| PE n: Loss of Input     | Set          | Loss of input detected       | Cause: Loss of input.<br><br>Remedy: Ensure input has a valid stream.   | Loss of input.  | Minor    |
| PE n: Loss of Input     | Clear        | Fault reset                  |   |   | Minor    |
| Digital Program Mapping | Set          | PID Collision                | Cause: Uplink settings may have changed since setting up the unit. Please check your DPM settings.<br><br>Remedy: Correct the DPM settings. Check the uplink to find the appropriate system settings. | Two source service PIDs are being mapped to the same output PID. This will cause data corruption in the stream.               | Minor    |
| Digital Program Mapping | Set          | Program Collision            | Cause: Uplink settings may have changed since setting up the unit. Please check your DPM settings.<br><br>Remedy: Correct the DPM settings. Check the uplink to find the appropriate system settings. | Two source channel numbers are being mapped/ passed to the same channel number in the output.                                 | Minor    |

Chapter 6 Service and Maintenance

| Alarm                   | Message Type | Message                      | Cause/Remedy   | Description   | Severity |
|-------------------------|--------------|------------------------------|--|---|----------|
| Digital Program Mapping | Set          | Mode-i PMT out of range      | <p>Cause: Uplink settings may have changed since setting up the unit. Please check your DPM settings.</p> <p>Remedy: Correct the DPM settings. Check the uplink to find the appropriate system settings.</p> | PMT PID to be used for Mode-i is outside of valid MPEG PID range. | Major    |
| Digital Program Mapping | Clear        | Digital Program Mapping - OK |  |   | Major    |
| Shutdown Event          | Set          | DL APP REBOOT                | <p>Cause: User request requires reboot or internal system error.</p> <p>Remedy: If it is an internal system error fault, clear alarms, reset the unit, notify customer service if the problem persists.</p>  | New application downloaded, system requires reboot.               | Major    |
| Shutdown Event          | Set          | User requested FPGA change   | <p>Cause: User request requires reboot or internal system error.</p> <p>Remedy: If it is an internal system error fault, clear alarms, reset the unit, notify customer service if the problem persists.</p>  | Runnable FPGA change requires reboot.                             | Major    |

D9854 Receiver Alarm Messages

| Alarm          | Message Type | Message                      | Cause/Remedy  | Description                                  | Severity |
|----------------|--------------|------------------------------|---|--|----------|
| Shutdown Event | Set          | User requested APP change    | <p>Cause: User request requires reboot or internal system error.</p> <p>Remedy: If it is an internal system error fault, clear alarms, reset the unit, notify customer service if the problem persists.</p> | Runnable application change requires reboot. | Major    |
| Shutdown Event | Set          | User requested factory reset | <p>Cause: User request requires reboot or internal system error.</p> <p>Remedy: If it is an internal system error fault, clear alarms, reset the unit, notify customer service if the problem persists.</p> | Factory reset requires reboot.               | Major    |
| Shutdown Event | Set          | User requested reboot        | <p>Cause: User request requires reboot or internal system error.</p> <p>Remedy: If it is an internal system error fault, clear alarms, reset the unit, notify customer service if the problem persists.</p> | User reboot request.                         | Major    |

Chapter 6 Service and Maintenance

| Alarm          | Message Type | Message                        | Cause/Remedy  | Description                             | Severity |
|----------------|--------------|--------------------------------|---|---|----------|
| Shutdown Event | Set          | User requested service restore | <p>Cause: User request requires reboot or internal system error.</p> <p>Remedy: If it is an internal system error fault, clear alarms, reset the unit, notify customer service if the problem persists.</p> | Restore operation required restart      | Major    |
| Shutdown Event | Set          | PRODUCTION - Protect Flash     | <p>Cause: User request requires reboot or internal system error.</p> <p>Remedy: If it is an internal system error fault, clear alarms, reset the unit, notify customer service if the problem persists.</p> | Reboot after production tables removed. | Major    |
| Shutdown Event | Set          | I2C Failure                    | <p>Cause: Possible software/hardware issue.</p> <p>Remedy: Clear alarms, reset unit, notify customer service if problem persists.</p>   | Internal system error.                  | Major    |
| Shutdown Event | Set          | WDOG: FPGA not loaded          | <p>Cause: Possible software/hardware issue.</p> <p>Remedy: Clear alarms, reset unit, notify customer service if problem persists.</p>   | FPGA has not been loaded.               | Major    |

D9854 Receiver Alarm Messages

| Alarm          | Message Type | Message                         | Cause/Remedy  | Description                       | Severity |
|----------------|--------------|---------------------------------|---|-----------------------------------|----------|
| Shutdown Event | Set          | osal_SetDataForAllTasks         | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | aw_LoadFaultList                | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | osal_Init                       | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | NVS FLASH mounted               | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | DB_Table_Cl::populateNvsRecords | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | STAPI_Init                      | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |

Chapter 6 Service and Maintenance

| Alarm          | Message Type | Message   | Cause/Remedy  | Description                       | Severity |
|----------------|--------------|---|---|-----------------------------------|----------|
| Shutdown Event | Set          | dprm startup                                    | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | dprm clear startup                              | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | DB_Array32_CI init failed                       | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | DB_FlagArray32_CI init failed                   | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | Wrong DB Item detected: item = AAA, table = BBB | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | DB_Item_CI::addItem() failed                    | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |

D9854 Receiver Alarm Messages

| Alarm          | Message Type | Message  | Cause/Remedy  | Description                       | Severity |
|----------------|--------------|--|---|-----------------------------------|----------|
| Shutdown Event | Set          | Memory allocation error on DB table construction | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | DB_Table_Cl::add Table() failed                  | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | DB_Table_Cl::addItem() failed: too many DB Items | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | DBT Init Failed: AAA                             | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | Framework Registration Error                     | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | 7109 exception! Code = X, Address = Y, Task = Z  | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |

Chapter 6 Service and Maintenance

| Alarm          | Message Type | Message   | Cause/Remedy  | Description                       | Severity |
|----------------|--------------|---|---|-----------------------------------|----------|
| Shutdown Event | Set          | Memory Error: AAA, Phase X                        | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | Time Control object creation failed               | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | Wrong UIC Item detected: item = AAA, table BBB    | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | Memory allocation error on UIC table construction | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | Error adding UIC table(AAA)                       | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | HTTP - http_init4() FAILED to create partition    | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |



D9854 Receiver Alarm Messages

| Alarm          | Message Type | Message   | Cause/Remedy  | Description                       | Severity |
|----------------|--------------|---|---|-----------------------------------|----------|
| Shutdown Event | Set          | http_init4:<br>FAILED to allocate scratch buffer                          | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | HTTP - http_init4()<br>FAILED to allocate memory from AVMEM Partition     | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | UD - ud_init_phase_4()<br>FAILED to allocate memory from System Partition | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | UD - ud_init_phase_4()<br>FAILED to create partition                      | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | '--- COMPONENT 'AAA' FAILED TO INIT IN PHASE X, rc=NNN                    | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |
| Shutdown Event | Set          | VBI DB creation failed  | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major    |

**Chapter 6 Service and Maintenance**

| <b>Alarm</b>   | <b>Message Type</b> | <b>Message</b>  | <b>Cause/Remedy</b>   | <b>Description</b>                | <b>Severity</b> |
|----------------|---------------------|---|---|-----------------------------------|-----------------|
| Shutdown Event | Set                 | VBI DB allocation failed  | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major           |
| Shutdown Event | Set                 | VBI Status DB creation failed   | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major           |
| Shutdown Event | Set                 | VBI Status DB allocation failed   | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major           |
| Shutdown Event | Set                 | UIC_ENUM_CL given invalid ENUM_ST: item = AAA, table = BBB, problem with primary: X | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Application initialization error. | Major           |
| Shutdown Event | Set                 | FW: Memory or List Full   | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Internal system error.            | Major           |
| Shutdown Event | Set                 | Framework Registration Error  | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, notify customer service if problem persists. | Internal system error.            | Major           |

D9854 Receiver Alarm Messages

| Alarm          | Message Type | Message                       | Cause/Remedy  | Description   | Severity |
|----------------|--------------|-------------------------------|---|---|----------|
| Shutdown Event | Set          | Watchdog 'AAA' has expired    | Cause: Possible software issue.<br>Remedy: Clear alarms, reset unit, notify customer service if problem persists.   | Software detected an error in operation.  | Major    |
| System Startup | Set          | System Startup                | Cause: The unit has started up and it indicates an expected or unexpected reset.<br>Remedy: If a startup was unexpected, check for last reset cause. Notify customer service if problem persists. | Indicates that the decoder has started up. This alarm will clear itself after one second. | Major    |
| SMI Setup      | Set          | Phase lock error on SMI SDRAM | Cause: Hardware Issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists.  | SDRAM on SMI bus not working.   | Major    |
| SMI Setup      | Set          | SMI SDRAM exhaust test failed | Cause: Hardware Issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists.  | SDRAM on SMI bus not working.   | Major    |
| SMI Setup      | Clear        | SMI SDRAM setup successful    |   | SDRAM on SMI Bus OK.  | Major    |
| SMI Setup      | Clear        | SMI SDRAM exhaust test passed |   | SDRAM on SMI Bus OK.  | Major    |

Chapter 6 Service and Maintenance

| Alarm         | Message Type | Message                             | Cause/Remedy   | Description   | Severity |
|---------------|--------------|-------------------------------------|--|---|----------|
| LMI setup     | Set          | LMI SDRAM exhaust test failed       | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists.     | DDR RAM on LMI bus not working.                     | Major    |
| LMI setup     | Clear        | LMI Video SDRAM exhaust test passed |  | DDR RAM on LMI bus OK.                              | Major    |
| Param Storage | Set          | DB NVS flushing ignored             | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists.     | Non-volatile storage system failed to update fully. | Major    |
| Param Storage | Set          | RAM flush to NVS failed             | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists.     | Non-volatile storage system failed to update fully. | Major    |
| Param Storage | Set          | DB Factory Reset in progress        | Cause: Standard operation.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Non-volatile storage system operation in progress.  | Major    |
| Param Storage | Set          | DB Total Reset in progress          | Cause: Standard operation.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Non-volatile storage system operation in progress.  | Major    |

D9854 Receiver Alarm Messages

| Alarm         | Message Type | Message                  | Cause/Remedy   | Description  | Severity |
|---------------|--------------|--------------------------|--|--|----------|
| Param Storage | Set          | DB NVS flush in progress | Cause: Standard operation.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Non-volatile storage system operation in progress.   | Major    |
| Param Storage | Set          | DB Populate in progress  | Cause: Standard operation.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Non-volatile storage system operation in progress.   | Major    |
| Param Storage | Set          | DB Factory Reset failed  | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists.     | Non-volatile storage system failed during operation. | Major    |
| Param Storage | Set          | DB Total Reset failed    | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists.     | Non-volatile storage system failed during operation. | Major    |
| Param Storage | Set          | DB Populate failed       | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists.     | Non-volatile storage system failed during operation. | Major    |

Chapter 6 Service and Maintenance

| Alarm         | Message Type | Message  | Cause/Remedy   | Description  | Severity |
|---------------|--------------|--|--|--|----------|
| Param Storage | Set          | DB NVS flush failed                                      | Cause: Hardware issue.<br><br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Non-volatile storage system failed during operation.                   | Major    |
| Param Storage | Clear        | DB flushing completed                                    |  | Successful NVS update.   | Major    |
| Param Storage | Clear        | DB Factory Reset completed                               |  | Non-volatile storage system operation successful                       | Major    |
| Param Storage | Clear        | DB Total Reset completed                                 |  | Non-volatile storage system operation successful                       | Major    |
| Param Storage | Clear        | DB NVS flush completed                                   |  | Non-volatile storage system operation successful                       | Major    |
| Param Storage | Clear        | DB Populate completed                                    |  | Non-volatile storage system operation successful                       | Major    |
| Flash Storage | Set          | RECORD: init failed                                      | Cause: Hardware issue.<br><br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Non-volatile storage system corrupted. Possible loss of configuration. | Major    |
| Flash Storage | Set          | RECORD MANAGER: Record contents check error, erasing all | Cause: Hardware issue.<br><br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | NVS Corruption, and loss of configuration data                         | Major    |

D9854 Receiver Alarm Messages

| Alarm         | Message Type | Message  | Cause/Remedy  | Description                             | Severity |
|---------------|--------------|--|---|---|----------|
| Flash Storage | Set          | RECORD: sector setup check error, erasing sector | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists.                    | NVS Corruption, and loss of sector data | Major    |
| Flash Storage | Clear        | RECORD: init done                                |   |   | Major    |
| LNB PS        | Set          | LNBPS: No Load                                   | Cause: Possible wiring or hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | LNB power overload                      | Minor    |
| LNB PS        | Set          | LNBPS: Over Temperature                          | Cause: Possible wiring or hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | LNB power overload                      | Minor    |
| LNB PS        | Set          | LNBPS: Over Loaded                               | Cause: Possible wiring or hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | LNB power overload                      | Minor    |

**Chapter 6 Service and Maintenance**

| <b>Alarm</b>   | <b>Message Type</b> | <b>Message</b>               | <b>Cause/Remedy</b>   | <b>Description</b>   | <b>Severity</b> |
|----------------|---------------------|------------------------------|---|--|-----------------|
| LNB PS         | Set                 | LNBPS: Short Circuit         | Cause: Possible wiring or hardware issue.<br><br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists.           | LNB power overload   | Minor           |
| LNB PS         | Clear               | LNBPS: Normal                |   | LNB power OK   | Minor           |
| LNB PS         | Clear               | LNBPS: Disabled              |   |  | Minor           |
| LNB PS         | Clear               | LNBPS: Off                   |   |  | Minor           |
| Signal Quality | Set                 | Audio Muted due to RF noise  | Cause: RF Signal quality is poor due to interference or signal level issues.<br><br>Remedy: Check RF settings, re-aim dish, and add signal amplifier. | Signal is locked but BER is beyond Audio muting threshold. | Minor           |
| Signal Quality | Set                 | Unstable RF Signal           | Cause: RF Signal quality is poor due to interference or signal level issues.<br><br>Remedy: Check RF settings, re-aim dish, and add signal amplifier. | Signal lock status is toggling frequently.                 | Minor           |
| Signal Quality | Set                 | Poor Quality RF Signal       | Cause: RF Signal quality is poor due to interference or signal level issues.<br><br>Remedy: Check RF settings, re-aim dish, and add signal amplifier. | Signal is locked but BER is beyond muting threshold.       | Minor           |
| Signal Quality | Clear               | Signal Quality Fault Cleared |   |  | Minor           |
| Signal Quality | Clear               | Audio Unmuted                |   |  | Minor           |



D9854 Receiver Alarm Messages

| Alarm                | Message Type | Message                              | Cause/Remedy  | Description   | Severity |
|----------------------|--------------|--------------------------------------|---|---|----------|
| Transport Processing | Set          | PTI lockup                           | Cause: Possible software issue.<br><br>Remedy: Clear alarms, reset unit, and notify customer service if problem persists.             | Programmable transport input module stopped processing any data packet. | Minor    |
| Transport Processing | Clear        | PTI running                          |   |   | Minor    |
| Version Mismatch     | Set          | Version Mismatch between 5514/7109   | Cause: App5514 version does not match App7109 version.<br><br>Remedy: Download code with identical App5514 and App7109 versions.      | Version mismatch between code running 5514 and 7109 processors.         | Major    |
| DL:NVS Flash Failure | Set          | APP5514 Flash Write Failed           | Cause: Possible hardware or software issue.<br><br>Remedy: Clear alarms, reset unit, and notify customer service if problem persists. | Failed to read or write flash memory                                    | Major    |
| DL:NVS Flash Failure | Set          | APP/SAT7109/PPC CRC/Write has Failed | Cause: Possible hardware or software issue.<br><br>Remedy: Clear alarms, reset unit, and notify customer service if problem persists. | Failed to read or write flash memory                                    | Major    |
| DL:NVS Flash Failure | Set          | TEB Flash Write Failed               | Cause: Possible hardware or software issue.<br><br>Remedy: Clear alarms, reset unit, and notify customer service if problem persists. | Failed to read or write flash memory                                    | Major    |

**Chapter 6 Service and Maintenance**

| <b>Alarm</b>           | <b>Message Type</b> | <b>Message</b>                   | <b>Cause/Remedy</b>   | <b>Description</b>                              | <b>Severity</b> |
|------------------------|---------------------|----------------------------------|---|---|-----------------|
| Temperature Alarm      | Set                 | Temperature over Alarm threshold | <p>Cause: Room temperature too high, or air flow is blocked.</p> <p>Remedy: Check openings on front and rear panels for blockage. Lower room temperature or improve air flow to device.</p> | Temperature is above safe operating range.      | Major           |
| Temperature Alarm      | Clear               | Temperature normal               |   |   | Major           |
| Fan                    | Set                 | Fan RPM Alarm                    | <p>Cause: Hardware issue.</p> <p>Remedy: Unit should be returned to customer service as soon as possible.</p>   | Fan RPM out of normal operating range.          | Major           |
| Fan                    | Clear               | Fans Operational                 |   |   | Major           |
| FPGA Temperature Alarm | Set                 | Temperature over Alarm threshold | <p>Cause: Room temperature too high, or air flow is blocked.</p> <p>Remedy: Check openings on front and rear panels for blockage. Lower room temperature or improve air flow to device.</p> | FPGA temperature is above safe operating range. | Major           |
| FPGA Temperature Alarm | Clear               | Temperature normal               |   |   |                 |

D9854 Receiver Alarm Messages

| Alarm          | Message Type | Message   | Cause/Remedy   | Description  | Severity |
|----------------|--------------|---|--|--|----------|
| ASI Out Status | Set          | ASI Overflow.<br>Output Muted.<br>Reduce content. | <p>Cause: Uplink settings may have changed since setup of the unit. Variable Bit Rate/Statmuxed streams may be in use.</p> <p>Remedy: Increase the output rate, drop unreferenced content in DPM Options, and/or drop programs not needed for downstream devices. Contact your (uplink) service provider to verify the expected bit rate settings.</p> | Current transport rate exceeds configured rate for ASI output. Output has been muted to protect downstream devices.          | Minor    |
| ASI Out Status | Clear        | ASI Output Restored                               |  |  | Minor    |
| MPoIP Status   | Set          | MPEGoIP Overflow. Output Muted. Reduce content.   | <p>Cause: Uplink settings may have changed since setup of the unit. Variable Bit Rate/Statmuxed streams may be in use.</p> <p>Remedy: Increase output rate, drop unreferenced content in DPM Options, drop programs not needed for downstream devices. Contact uplink to verify expected bitrate settings.</p>   | Current transport rate exceeds configured rate for MPEG over IP output. Output has been muted to protect downstream devices. | Minor    |

## Chapter 6 Service and Maintenance

| Alarm        | Message Type | Message                 | Cause/Remedy  | Description                                   | Severity |
|--------------|--------------|-------------------------|---|---|----------|
| MPoIP Status | Clear        | MPEGoIP Output Restored |   |   | Minor    |
| Boot Host    | Set          | KB not accessible       | Cause: Hardware issue<br><br>Remedy: Clear alarms, reset unit, and notify customer service if the problem persists. | KB is not detected by Boot code.              | Major    |
| Boot Host    | Set          | LCD not connected       | Cause: Hardware issue<br><br>Remedy: Clear alarms, reset unit, and notify customer service if the problem persists. | LCD is not detected by Boot code.             | Major    |
| Boot Host    | Set          | FLASH Not Found         | Cause: Hardware issue<br><br>Remedy: Clear alarms, reset unit, and notify customer service if the problem persists. | Flash memory not detected.                    | Major    |
| Boot Host    | Set          | EMI SDRAM Test Failed   | Cause: Hardware issue<br><br>Remedy: Clear alarms, reset unit, and notify customer service if the problem persists. | RAM Failure - memory testing failed.          | Major    |
| Boot Host    | Set          | BOOT Invalid            | Cause: Hardware issue<br><br>Remedy: Clear alarms, reset unit, and notify customer service if the problem persists. | Boot SW cannot be read from memory correctly. | Major    |

D9854 Receiver Alarm Messages

| Alarm          | Message Type | Message               | Cause/Remedy   | Description  | Severity |
|----------------|--------------|-----------------------|--|--|----------|
| Boot Host      | Set          | FPGA Invalid          | Cause: Hardware issue<br><br>Remedy: Clear alarms, reset unit, and notify customer service if the problem persists.      | FPGA Image cannot be read from memory correctly.     | Major    |
| Boot Host      | Set          | APP Invalid           | Cause: Hardware issue<br><br>Remedy: Clear alarms, reset unit, and notify customer service if the problem persists.      | Application SW cannot be read from memory correctly. | Major    |
| Boot Host      | Clear        | BOOT passed           |  |  | Major    |
| Boot Secondary | Set          | FLASH Not Found       | Cause: Hardware issue.<br><br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Flash memory not detected.                           | Major    |
| Boot Secondary | Set          | EMI SDRAM Test Failed | Cause: Hardware issue.<br><br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | RAM Failure - memory testing failed.                 | Major    |
| Boot Secondary | Set          | BOOT Invalid          | Cause: Hardware issue.<br><br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Boot SW cannot be read from memory correctly.        | Major    |

## Chapter 6 Service and Maintenance

| Alarm                   | Message Type | Message                 | Cause/Remedy   | Description   | Severity |
|-------------------------|--------------|-------------------------|--|---|----------|
| Boot Secondary          | Set          | FPGA Invalid            | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | FPGA Image cannot be read from memory correctly.                  | Major    |
| Boot Secondary          | Set          | APP Invalid             | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Application SW cannot be read from memory correctly.              | Major    |
| Boot Secondary          | Clear        | BOOT passed             |  |   | Major    |
| Decoder Processor Start | Set          | DB Startup failed       | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Transfer of operational parameters to secondary processor failed. | Major    |
| Decoder Processor Start | Set          | No Response             | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Secondary processor not responding.                               | Major    |
| Decoder Processor Start | Set          | Synchronization Failure | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, and notify customer service if the problem persists. | Communication with secondary processor failing.                   | Major    |

D9854 Receiver Alarm Messages

| Alarm       | Message Type | Message   | Cause/Remedy  | Description   | Severity |
|-------------|--------------|---|---|---|----------|
| LEC Timeout | Set          | LEC Table Missing/timeout: channels currently unavailable | <p>Cause: Possible LEC Server or Uplink issue.</p> <p>Remedy: If using RF input, contact the content provider. If using ASI output, ensure the source has not been changed for the content provider. Clear alarm and notify customer service if the problem persists.</p> | ECT Table is not received in the GDS stream.                                      |          |
| LEC Timeout | Clear        | LEC received  |   |   |          |
| FPGA status | Set          | FPGA Init failed to go high                               | <p>Cause: Hardware issue.</p> <p>Remedy: Clear alarms, reset the unit, notify customer service if the problem persists.</p>   | FPGA setup failure or the FPGA binary identity does not match the FPGA registers. | Major    |
| FPGA status | Set          | FPGA Init and Done failed to go low                       | <p>Cause: Hardware issue.</p> <p>Remedy: Clear alarms, reset the unit, notify customer service if the problem persists.</p>   | FPGA setup failure or the FPGA binary identity does not match the FPGA registers. | Major    |
| FPGA status | Set          | FPGA Init went LOW (CRC error)                            | <p>Cause: Hardware issue.</p> <p>Remedy: Clear alarms, reset the unit, notify customer service if the problem persists.</p>   | FPGA setup failure or the FPGA binary identity does not match the FPGA registers. | Major    |

Chapter 6 Service and Maintenance

| Alarm       | Message Type | Message                                 | Cause/Remedy   | Description   | Severity |
|-------------|--------------|---|--|---|----------|
| FPGA status | Set          | FPGA Done failed to go high             | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, notify customer service if the problem persists. | FPGA setup failure or the FPGA binary identity does not match the FPGA registers. | Major    |
| FPGA status | Set          | SW ver outside upper or lower limit     | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, notify customer service if the problem persists. | FPGA setup failure or the FPGA binary identity does not match the FPGA registers. | Major    |
| FPGA status | Set          | FPGA ID does not match FPGA DESIGNATION | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, notify customer service if the problem persists. | FPGA setup failure or the FPGA binary identity does not match the FPGA registers. | Major    |
| FPGA status | Set          | FPGA ID does not match HW FPGA ID       | Cause: Hardware issue.<br>Remedy: Clear alarms, reset the unit, notify customer service if the problem persists. | FPGA setup failure or the FPGA binary identity does not match the FPGA registers. | Major    |
| FPGA status | Clear        | FPGA loaded successfully and reset      |  |   |          |



## Warnings

| Warning           | Message Type | Message                         | Cause/Remedy  | Description   |
|-------------------|--------------|---------------------------------|---|---|
| ASI TS Overflow   | Set          | ASI Output Overflow             | <p>Cause: Uplink settings may have changed since setting up the unit. Variable bit rate or statmuxed streams may be in use.</p> <p>Remedy: Increase the output rate, drop unreferenced content in DPM Options, and drop the programs that are not needed for downstream devices. Contact your (uplink) service provider to verify the expected bit rate settings.</p> | The output rate is higher than level set by the user. |
| ASI TS Overflow   | Clear        | ASI Output Overflow Cleared     |   |   |
| MPoIP TS Overflow | Set          | MPEGoIP Output Overflow         | <p>Cause: Uplink settings may have changed since setting up the unit. Variable bit rate or statmuxed streams may be in use.</p> <p>Remedy: Increase the output rate, drop unreferenced content in DPM Options, and drop the programs that are not needed for downstream devices. Contact your (uplink) service provider to verify the expected bit rate settings.</p> | The output rate is higher than level set by the user. |
| MPoIP TS Overflow | Reset        | MPEGoIP Output Overflow Cleared |   |   |

**Chapter 6 Service and Maintenance**

| <b>Warning</b>  | <b>Message Type</b> | <b>Message</b>                      | <b>Cause/Remedy</b>  | <b>Description</b>   |
|-----------------|---------------------|-------------------------------------|--|--|
| Transport Error | Set                 | Continuity Count Error              | Cause: Possible uplink or signal issue.<br><br>Remedy: Clear warnings, reset the unit, and notify customer service if the problem persists.  | Transport packet continuity count jumped. Possible packet loss.  |
| Transport Error | Set                 | Buffer Overflow                     | Cause: Possible uplink or signal issue.<br><br>Remedy: Clear warnings, reset the unit, and notify customer service if the problem persists.  | The transport stream is faster than the maximum buffer or the decode engines are having difficulty handling the data sent to them. |
| Transport Error | Set                 | Transport Error Indicator           | Cause: Possible uplink or signal issue.<br><br>Remedy: Clear warnings, reset the unit, and notify customer service if the problem persists.  | Transport packets are marked as "errored" upstream of the decoder.   |
| Transport Error | Set                 | Transport Rate Error: FPGA Overflow | Cause: Uplink settings may have changed since setting up the unit.<br><br>Remedy: Increase the output rate, drop unreferenced content in DPM Options, and/or drop programs not needed for downstream devices. Contact your (uplink) service provider to verify the expected bit rate settings. | The output rate is higher than level set by the user.  |
| Transport Error | Clear               | Continuity Count Error Cleared      |  | Trap expires after 30 seconds.   |
| Transport Error | Clear               | Buffer Overflow Cleared             |  | Trap expires after 30 seconds.   |
| Transport Error | Clear               | Transport Error Indicator Cleared   |  | Trap expires after 30 seconds.   |

## D9854 Receiver Alarm Messages

| Warning                  | Message Type | Message                                     | Cause/Remedy  | Description                                       |
|--------------------------|--------------|---|---|---|
| Transport Error          | Clear        | Transport Rate Error: FPGA Overflow Cleared |   | Trap expires after 30 seconds.                    |
| CI Status                | Set          | Different CA Systems in Top/Bottom Slots    | Cause: Different CA systems are used in the slots.<br><br>Remedy: Replace the CA cards to use the same CA system.   | Different CA Systems in Top/Bottom slots.         |
| CI Status                | Clear        | OK  |   |   |
| Video Format Mismatch    | Set          | Video format mismatch                       |   | Video Format Mismatch.                            |
| Video Format Mismatch    | Clear        | Video format match                          |   |   |
| Temperature Warning      | Set          | Temperature over Warning threshold          | Cause: Room temperature too high, or air flow is blocked.<br><br>Remedy: Check openings on front and rear panels for blockage. Lower the room temperature or improve air flow to the device.        | Temperature is above normal operating range.      |
| Temperature Warning      | Clear        | Temperature normal                          |   |   |
| FPGA Temperature Warning | Set          | Temperature over Warning threshold          | Cause: Room temperature is too high, or air flow is blocked.<br><br>Remedy: Check the openings on front and rear panels for blockage. Lower the room temperature or improve air flow to the device. | FPGA temperature is above normal operating range. |
| FPGA Temperature Warning | Clear        | Temperature normal                          |   |   |

**Chapter 6 Service and Maintenance**

| <b>Warning</b> | <b>Message Type</b> | <b>Message</b>                         | <b>Cause/Remedy</b>  | <b>Description</b>                            |
|----------------|---------------------|--|--|---|
| VBI Data       | Set                 | 2nd VBI PID attempt to write same line | Cause: Uplink configuration issue.<br><br>Remedy: Contact uplink to verify expected VBI settings.  | Conflicting VBI data on second VBI PID.       |
| VBI Data       | Clear               | Line Collision Cleared                 |  |   |
| TDT timeout #  | Set                 | tdt timed out                          | Cause: Uplink is not sending or is sending intermittently.<br><br>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table. | Time Date Table was never received.           |
| TDT timeout #  | Set                 | tdt is lost                            | Cause: Uplink is not sending or is sending intermittently.<br><br>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table. | No longer receiving Time Date.                |
| TDT timeout #  | Clear               | tdt fault cleared                      |  |   |
| SDT timeout #  | Set                 | sdt # timed out                        | Cause: Uplink is not sending or is sending intermittently.<br><br>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table. | Service Description Table was never received. |

D9854 Receiver Alarm Messages

| Warning       | Message Type | Message           | Cause/Remedy  | Description                                   |
|---------------|--------------|-------------------|---|---|
| SDT timeout # | Set          | sdt # is lost     | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | No longer receiving Service Description.      |
| SDT timeout # | Clear        | sdt fault cleared |   |   |
| PMT timeout # | Set          | pmt # timed out   | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | Program Mapping Table was never received.     |
| PMT timeout # | Set          | pmt # is lost     | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | No longer receiving Program Mapping Table.    |
| PMT timeout # | Clear        | pmt fault cleared |   |   |
| PAT timeout # | Set          | pat # timed out   | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | Program Association Table was never received. |

**Chapter 6 Service and Maintenance**

| <b>Warning</b> | <b>Message Type</b> | <b>Message</b>    | <b>Cause/Remedy</b>   | <b>Description</b>                             |
|----------------|---------------------|-------------------|---|--|
| PAT timeout #  | Set                 | pat # is lost     | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | No longer receiving Program Association Table. |
| PAT timeout #  | Clear               | pat fault cleared |   |  |
| NIT timeout #  | Set                 | nit timed out     | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | Network Information Table was never received.  |
| NIT timeout #  | Set                 | nit is lost       | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | No longer receiving Network Information Table. |
| NIT timeout #  | Clear               | nit fault cleared |   |  |
| CAT timeout #  | Set                 | cat timed out     | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | Conditional Access Table was never received.   |

D9854 Receiver Alarm Messages

| Warning       | Message Type | Message           | Cause/Remedy  | Description                                   |
|---------------|--------------|-------------------|---|---|
| CAT timeout # | Set          | cat is lost       | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | No longer receiving Conditional Access Table. |
| CAT timeout # | Clear        | cat fault cleared |   |   |
| DRT timeout # | Set          | drt # timed out   | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | Disaster Recovery Table was never received.   |
| DRT timeout # | Set          | drt # is lost     | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | No longer receiving Disaster Recovery Table.  |
| DRT timeout # | Clear        | drt fault cleared |   |   |
| MCT Timeout # | Set          | mct # timed out   | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | Inband Control Table was never received.      |

**Chapter 6 Service and Maintenance**

| <b>Warning</b>    | <b>Message Type</b> | <b>Message</b>                           | <b>Cause/Remedy</b>   | <b>Description</b>                        |
|-------------------|---------------------|--|---|---|
| MCT Timeout #     | Set                 | mct # is lost                            | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | No longer receiving Inband Control Table. |
| MCT Timeout #     | Clear               | mct fault cleared                        |   |   |
| ECT Timeout #     | Set                 | ect # timed out                          | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | Event Control Table was never received.   |
| ECT Timeout #     | Set                 | ect # is lost                            | <p>Cause: Uplink is not sending or is sending intermittently.</p> <p>Remedy: Clear warning. If the problem persists, determine if uplink is sending the current SI information table. Disable the warning if not using the table.</p> | No longer receiving Event Control Table.  |
| ECT Timeout #     | Clear               | ect fault cleared                        |   |   |
| Memory Usage Host | Set                 | Excessive (stack/partition) memory usage | <p>Cause: Possible software issue.</p> <p>Remedy: Clear warnings, reset the unit, and notify customer service if the problem persists.</p>  | SW exceeding allowable memory usage.      |
| Memory Usage Host | Clear               | Normal (stack/partition) memory usage    |   |   |



D9854 Receiver Alarm Messages

| Warning                | Message Type | Message  | Cause/Remedy   | Description  |
|------------------------|--------------|--|--|--|
| Memory Usage Secondary | Set          | Excessive (stack/partition) memory usage       | Cause: Possible software issue.<br>Remedy: Clear warnings, reset the unit, and notify customer service if the problem persists.  | Software exceeding allowable memory usage.   |
| Memory Usage Secondary | Clear        | Normal (stack/partition) memory usage          |  |  |
| FPGA Code Version      | Set          | FPGA newer than SW, Supported=AAA, Running=BBB | Cause: FPGA version is incompatible with the software.<br>Remedy: Select alternate FPGA, software versions, reset unit, notify customer service if problem persists.   | FPGA version is incompatible with currently operating software. You may encounter operational difficulties |
| FPGA Code Version      | Clear        | FPGA code ver OK                               |  |  |
| Ethernet PHY n         | Set          | Link is down                                   | Cause: No ethernet cable connected, faulty cabling, multiple devices sharing MAC address on same IP segment, or possible HW issue.<br>Remedy: Check cabling, check MAC addresses, clear warnings, reset the unit, and notify customer service if the problem persists. | Ethernet MAC PHY device is attempting to reconnect to external devices.                                    |
| Ethernet PHY n         | Clear        | Connection OK                                  |  |  |
| FW: Resource Use Host  | Set          | Memory or List Near Full                       | Cause: Possible software issue.<br>Remedy: Clear warnings, reset the unit, and notify customer service if the problem persists.  | Software exceeding allowable usage of internal constructs.   |

**Chapter 6 Service and Maintenance**

| <b>Warning</b>          | <b>Message Type</b> | <b>Message</b>           | <b>Cause/Remedy</b>  | <b>Description</b>   |
|-------------------------|---------------------|--------------------------|--|--|
| FW: Resource Use Host   | Clear               | Normal Level             |  |  |
| FW: Resource Use Second | Set                 | Memory or List Near Full | <p>Cause: Possible software issue.</p> <p>Remedy: Clear warnings, reset the unit, and notify customer service if the problem persists.</p>   | Software exceeding allowable usage of internal constructs. |
| FW: Resource Use Second | Clear               | Normal Level             |  |  |
| Restore Failure Reason  | Set                 | FTP Failed               | <p>Cause: FTP settings or the server may not be configured correctly.</p> <p>Remedy: Verify the FTP server configuration and permissions. Verify that FTP settings on the unit. Verify that the server is reachable from the client (such as configuring firewalls or network settings). Retry the Import operation.</p>   | FTP failed to connect to server or transfer file           |
| Restore Failure Reason  | Set                 | Not Accepted             | <p>Cause: Import file is either for a different product or the structure was not compatible with this unit.</p> <p>Remedy: Verify that the correct import file is being used and was created by this product. Verify that the file structure has not been corrupted. If the problem persists, notify customer service.</p> | Import file was rejected and import did not occur          |

D9854 Receiver Alarm Messages

| Warning                | Message Type | Message                               | Cause/Remedy  | Description  |
|------------------------|--------------|---------------------------------------|---|--|
| Restore Failure Reason | Set          | Bad Content                           | <p>Cause: Import file may be corrupted, or from a different version of application software.</p> <p>Remedy: Verify that the correct import file is being used and was created by this product. Verify that the file structure has not been corrupted. If the problem persists, notify customer service.</p> | Item in import file is not valid for this software and import did not occur                  |
| SDI Aud SFR Data       | Set          | SDI Audio sampling frequency mismatch | <p>Cause: SDI audio groups are not configured correctly, or the transport stream has changed the sampling rate of one of the audio streams.</p> <p>Remedy: Configure the SDI audio groups to ensure that all audio channels in a group have the same sampling frequency rate.</p>                           | All audio channels in a given audio group within an SDI do not have identical sampling rate. |
| SDI Aud SFR Data       | Clear        | SDI Audio SFR Mismatch Cleared        |   |  |



# 7

---

## Customer Information

### **If You Have Questions**

If you have technical questions, call Cisco Services for assistance. Follow the menu options to speak with a service engineer.

Access your company's extranet site to view or order additional technical publications. For accessing instructions, contact the representative who handles your account. Check your extranet site often as the information is updated frequently.



# A

## Technical Specifications

### Introduction

This appendix contains the technical specifications for the D9854 Advanced Program Receiver.

**Note:** The technical specifications are subject to change without prior notice.

### In This Appendix

|   |     |
|---|-----|
| ■ L-Band Input and Processing.....              | 272 |
| ■ Video Inputs/Outputs and Processing.....      | 276 |
| ■ Transport Stream Outputs.....                 | 282 |
| ■ Control, Management and Data Interfaces ..... | 284 |
| ■ Power and General Specifications .....        | 286 |

## L-Band Input and Processing

### General

| Parameter           | Specification   |
|---------------------|---|
| System              | MPEG-2/DVB Compatible<br>DVB-S EN 300 421, EN 300 468 |
| Demodulation        | DVB-S QPSK, DVB-S2 QPSK and 8PSK                      |
| Number of RF Inputs | 4 (only one active at a time)                         |

### LNB LO Stability

#### DVB-S and DVB-S2

| Symbol Rate            | Stability          |
|------------------------|--------------------|
| 1 to 4.99 MSymbols/s   | $\leq \pm 125$ kHz |
| 5.0 to 9.99 MSymbols/s | $\leq \pm 1.0$ MHz |
| 10.0 to 45 MSymbols/s  | $\leq \pm 3.0$ MHz |

| Parameter                   | Specification   |
|-----------------------------|---|
| LNB Phase Noise Requirement | -35 dBc/Hz at dF = 100 Hz<br>-53 dBc/Hz at dF = 1 kHz<br>-76 dBc/Hz at dF = 10 kHz<br>-96 dBc/Hz at dF = 100 kHz<br>-106 dBc/Hz at dF = 1 MHz<br>-117 dBc/Hz at dF = 10 MHz |



## LNB Power and Control

| Parameter   | Specification  |
|---|--|
| Voltage<br>(RF1to RF3, RF4 does not have an LNB supply) | 13 V Vertical/circular right,<br>18 V Horizontal/circular left<br>Off            |
| Current   | 350 mA maximum<br><br>LNB Alarms:<br>No load - 6 mA<br>Overload - 360 mA minimum |

## DVB-S/DVB-S2

### DVB-S/DVB-S2 Satellite Receiver

| Parameter                            | Specification                           |
|--------------------------------------|---|
| <b>L-Band Input</b>                  |   |
| Number of Inputs                     | 4 (one active at a time)                |
| Input Connector Type                 | F-type, female, 75 ohms                 |
| Input Impedance                      | 75 ohms                                 |
| Return Loss                          | > 10 dB                                 |
| Isolation Between Inputs             | > 40 dB                                 |
| L-band Frequency                     | 950 to 2150 MHz                         |
| Tuning Step Size                     | 1 MHz                                   |
| Receive Spectrum Sense               | Normal and Inverted                     |
| <b>L-Band Power</b>                  |   |
| Input Power Level per Carrier        | -25 to -65 dBm (full transponder power) |
| <b>DVB-S Modulation (EN 300 421)</b> |   |
| Modulation                           | QPSK                                    |
| Convolutional FEC Rates              | 1/2, 2/3, 3/4, 5/6, 7/8                 |
| Symbol Rate Range                    | 1.0 to 45 MSymbols/s                    |

**Appendix A**  
**Technical Specifications**

| <b>Parameter</b>                      | <b>Specification</b>   |
|---------------------------------------|--|
| Eb/No (C/N) Ratio                     | See DVB-S2 Satellite Receiver Input, DVB-S Eb/No (C/N) Ratio Table |
| <b>DVB-S2 Modulation (EN 302 307)</b> |  |
| Modulation                            | QPSK, 8PSK   |
| Pilots On/Off                         | Pilots On  |
| QPSK LDPC FEC Rates                   | 1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 8/9, 9/10                            |
| 8PSK LDPC FEC Rates                   | 3/5, 2/3, 3/4, 5/6, 8/9, 9/10                                      |
| LDPC FEC Frame Length                 | Normal   |
| Symbol Rate Range                     | 1 to 30 Ms/s   |
| Maximum Channel Bit Rate              | 90 Mb/s  |
| Maximum User Bit Rate                 | 78.55 Mb/s   |

**DVB-S Eb/No (C/N) Ratio**

| <b>Convolutional FEC Rate</b> | <b>Eb/No Ratio (dB) in Linear Channel and IF Loop configuration</b> | <b>C/N at DVB Threshold (BW = Symbol Rate)</b> |
|-------------------------------|---|--|
| 1/2                           | 4.5   | 4.1  |
| 2/3                           | 5.0   | 5.9  |
| 3/4                           | 5.5   | 6.9  |
| 5/6                           | 6.0   | 7.9  |
| 7/8                           | 6.4   | 8.5  |

$$C/N = Eb/No + 10 \log (2 \times FEC \times 188/204)$$

The D9854 receiver displays the C/N Ratio.

**DVB-S2 Error Rate Performance Es/No (C/N) Ratio**

| <b>Mode</b> | <b>Simulated Es/No (dB) for FEC Frame length = 64,800</b> | <b>Typical Performance (dB) in Linear Channel and IF Loop configuration</b> |
|-------------|---|---|
| QPSK 1/2    | 1.00  | 1.2   |
| QPSK 3/5    | 2.23  | 2.4   |
| QPSK 2/3    | 3.10  | 3.2   |
| QPSK 3/4    | 4.03  | 4.2   |

**L-Band Input and Processing**

| <b>Mode</b> | <b>Simulated Es/No (dB) for<br/>FEC Frame length = 64,800</b> | <b>Typical Performance (dB) in<br/>Linear Channel and IF Loop<br/>configuration</b> |
|-------------|---|---|
| QPSK 4/5    | 4.68  | 4.8   |
| QPSK 5/6    | 5.18  | 5.3   |
| QPSK 8/9    | 6.20  | 6.4   |
| QPSK 9/10   | 6.42  | 6.6   |
| 8PSK 3/5    | 5.50  | 5.8   |
| 8PSK 2/3    | 6.62  | 6.8   |
| 8PSK 3/4    | 7.91  | 8.1   |
| 8PSK 5/6    | 9.35  | 9.6   |
| 8PSK 8/9    | 10.69   | 10.9  |
| 8PSK 9/10   | 10.98   | 11.3  |

## Video Inputs/Outputs and Processing

### General

| Parameter | Specification                                   |
|-----------|---|
| System    | MPEG-2/DVB Compatible<br>EN 300 421, EN 300 468 |

### Video Outputs

#### Analog SD Video Output

| Item                                      | Test Signal | Specification CVBS1           | Specification CVBS2            |
|---|-------------|-------------------------------|--------------------------------|
| Number of Channels                        |             | One SD source program         | One SD source program          |
| Video Decompression                       |             | MPEG-2 4:2:0                  | MPEG-2 4:2:0                   |
| Output Impedance                          |             | 75 $\Omega$                   | 75 $\Omega$                    |
| <b>525 Line</b>                           |             |                               |                                |
| Bar level                                 | NTC-7 comp  | 700 mV $\pm$ 7 mV ( $\pm$ 1%) | 700 mV $\pm$ 35 mV ( $\pm$ 5%) |
| Line Time Distortion                      | VITS17      | $\leq$ 1%                     | $\leq$ 1%                      |
| Bar Tilt                                  | NTC-7 comp  | < 0.5%                        | < 0.5%                         |
| Sync Level                                | NTC-7 comp  | 40 IRE $\pm$ 0.5 IRE          | 40 IRE $\pm$ 2.0 IRE           |
| DC Offset                                 | NTC-7 comp  | $\pm$ 100 mV                  | $\pm$ 100 mV                   |
| Chrominance-to-Luminance Gain Inequality  | NTC-7 comp  | 100 $\pm$ 5%                  | 100 $\pm$ 5%                   |
| Chrominance-to-Luminance Phase Inequality | NTC-7 comp  | < 20 ns                       | < 20 ns                        |
| K factor K 2T                             | NTC-7 comp  | < 1%                          | < 1%                           |
| Jitter                                    |             | < 5 ns                        | < 5 ns                         |

## Video Inputs/Outputs and Processing

| Item                                      | Test Signal     | Specification CVBS1   | Specification CVBS2   |
|---|-----------------|---|---|
| Frequency Response                        | FCC multi-burst | 0.5 MHz, 0 dB<br>1.25 MHz, 0 dB ± 0.2 dB<br>2 MHz, 0 dB ± 0.2 dB<br>3 MHz, 0 dB ± 0.3 dB<br>3.58 MHz, 0 dB ± 0.3 dB<br>4.1 MHz, 0 dB ± 0.3 dB | 0.5 MHz, 0 dB<br>1.25 MHz, 0 dB ± 0.2 dB<br>2 MHz, 0 dB ± 0.2 dB<br>3 MHz, 0 dB ± 0.3 dB<br>3.58 MHz, 0 dB ± 0.3 dB<br>4.1 MHz, 0 dB ± 0.3 dB |
| Differential Gain                         | NTC-7 comp      | < 3.0%  | < 3.0%  |
| Differential Phase                        | NTC-7 comp      | < 4°  | < 4°  |
| Luminance Non-linearity                   |                 | < 5%  | < 5%  |
| Line Time Distortion                      | NTC-7 comp      | ≤ 1%  | ≤ 1%  |
| Weighted Signal Video-to-Noise            | 50% Grey Field  | ≤ -70 dB rms  | ≤ -70 dB rms  |
| Weighted Signal Video-to-Noise            | Luminance Ramp  | ≤ -55 dB rms  | ≤ -55 dB rms  |
| Return Loss                               |                 | DC to 10 MHz, > 30 dB   | DC to 10 MHz, > 30 dB   |
| <b>625 Line</b>                           |                 |   |   |
| Bar level                                 | VITS17          | 700 mV ± 7 mV (± 1%)  | 700 mV ± 35 mV (± 5%)   |
| Line Time Distortion                      | VITS17          | ≤ 1%  | ≤ 1%  |
| Bar Tilt                                  | VITS17          | < 0.5%  | < 0.5%  |
| Sync Level                                | VITS17          | 300 mV ± 3 mV   | 300 mV ± 15 mV  |
| DC Offset                                 | VITS17          | ± 100 mV  | ± 100 mV  |
| Chrominance-to-Luminance Gain Inequality  | Colour Bars     | 100 ± 5%  | 100 ± 5%  |
| Chrominance-to-Luminance Phase Inequality | Colour Bars     | < 20 ns   | < 20 ns   |
| K factor K 2T                             | VITS17          | < 1%  | < 1%  |
| Jitter                                    |                 | < 5 ns  | < 5 ns  |

**Appendix A  
Technical Specifications**

| Item                           | Test Signal    | Specification CVBS1  | Specification CVBS2  |
|--------------------------------|----------------|--|--|
| Frequency Response             | VITS18         | 0.5 MHz, 0 dB<br>1 MHz, 0 dB $\pm$ 0.2 dB<br>2 MHz, 0 dB $\pm$ 0.3 dB<br>4 MHz, 0 dB $\pm$ 0.3 dB<br>4.8 MHz, +0 dB, -0.5 dB | 0.5 MHz, 0 dB<br>1 MHz, 0 dB $\pm$ 0.2 dB<br>2 MHz, 0 dB $\pm$ 0.2 dB<br>4 MHz, 0 dB $\pm$ 0.3 dB<br>4.8 MHz, +0 dB, -0.5 dB |
| Differential Gain              | VITS330        | < 3.0%   | < 3.0%   |
| Differential Phase             | VITS330        | < 3°   | < 3°   |
| Luminance Non-linearity        | VITS17         | < 5%   | < 5%   |
| Weighted Signal Video-to-Noise | 50% Grey Field | $\leq$ -70 dB rms  | $\leq$ -70 dB rms  |
| Weighted Signal Video-to-Noise | Luminance Ramp | $\leq$ -55 dB rms  | $\leq$ -55 dB rms  |
| Return Loss                    |                | DC to 10 MHz, > 30 dB  | DC to 10 MHz, > 30 dB  |

**Analog SD Video Output, CVBS1 and CVBS2 for monitoring**

| Item                     | Specification                        |
|--------------------------|--------------------------------------|
| Number of Channels       | One down-converted source HD program |
| Video Decompression Type | MPEG-2 4:2:0                         |
| Output Level             | 1.0 Vpp $\pm$ 5%                     |
| Output Impedance         | 75 ohms                              |

**HD Component Video Output (Monitoring Output)**

| Item                     | Test Signal     | Typical Performance Values |                            |
|--------------------------|-----------------|----------------------------|----------------------------|
|                          |                 | Y                          | Pb, Pr                     |
| Amplitude                | 100% Color Bars | 700 mV $\pm$ 5%            | 700 mV $\pm$ 5%            |
| Sync Amplitude           | 100% Color Bars | 300 mV $\pm$ 5%            | 300 mV $\pm$ 5%            |
| Bandwidth                | Multi-burst     | DC to 30 MHz, $\pm$ 0.6 dB | DC to 15 MHz, $\pm$ 0.6 dB |
| Noise, Unified Weighting | Flat Field      | -70 dB                     | -70 dB                     |

## Video Inputs/Outputs and Processing

|                    |                 |                      |                      |
|--------------------|-----------------|----------------------|----------------------|
| Linearity          | 5-step          | 3%                   | 3%                   |
| Interchannel Delay | 100% Color Bars | 2 ns                 | 2 ns                 |
| DC Offset          |                 | ± 50 mV              | ± 50 mV              |
| Return Loss        |                 | DC to 30 MHz, -20 dB | DC to 30 MHz, -20 dB |

### Aspect Ratio

| Item  |               | Specification                                     |               |
|---|---------------|---|---------------|
| <b>Aspect Ratio Conversions for Down-Conversion</b> |               | <b>Aspect Ratio Conversions for SD Programs</b>   |               |
| <b>4:3</b>  | <b>16:9</b>   | <b>4:3</b>  | <b>16:9</b>   |
| 16:9 Letterbox<br>14:9 Letterbox Center             | Center Cutout | 16:9 Letterbox<br>14:9 Letterbox Center<br>Cutout | Scale to 16:9 |

## Embedded Data in SDI

### VBI Processing

| Item                     | Specification                 |
|--------------------------|-------------------------------|
| <b>Closed Captioning</b> |                               |
| Output formats           | SMPTE-334M embedded in HD-SDI |

### Embedded Audio

| Item                     | Specification                                       |
|--------------------------|---|
| Format                   | According to SMPTE-299M                             |
| Audio sampling frequency | 48 kHz locked to the video. According to SMPTE-272M |
| Resolution               | 20 bits   |

## Audio Outputs

### Analog Audio Outputs

| Item                      | Specification   |
|---------------------------|---|
| Number of Channels        | 2 stereo pairs/4 mono channels, 5.1 channel downmix Audio decompression: MPEG or Dolby Digital. HE-AAC single stereo pair or Dolby Digital Plus single stereo pair available as future software download. |
| Frequency Response        | ±0.5 dB, 20 Hz to 20 kHz (ref., 100 kilohms)  |
| Total Harmonic Distortion | < 0.3% at 1 kHz (ref. 100 kilohms)  |
| Dynamic Range             | 85 dB (CCIR/ Arm weighting)   |
| Crosstalk                 | 80 dB at 1 kHz (typical)  |

### Digital Audio Outputs

| Item               | Specification               |
|--------------------|-----------------------------|
| Number of Channels | 2 (one stereo channel each) |
| Format             | AES-3id                     |
| Connector          | BNC                         |

## Conditional Access

| Item                | Specification   |
|---------------------|---|
| PowerVu CA          | DES or DVB  |
| DVB Scrambling      | BISS Mode 1, BISS Mode E  |
| DVB-CI (Future Use) | <p>Interface: 2 CI slots - EN 50221</p> <p>CA Method: Multicrypt, Simulcrypt, Roscrypt (CI only supports one Roscrypt CAM at a time)</p> <p>CAS: Irdeto, Viaccess, Nagravision, Conax</p> <p>CAS: MediaGuard, Cryptoworks available in an anticipated future software release</p> <p><b>Note:</b> Viasat (uses NDS/VideoGuard) only authorizes decoders equipped with an ASI output to receive/decrypt Viasat-encrypted programs.</p> |





## Transport Stream Outputs

### ASI Output

| Item                      | Specification  |
|---------------------------|--|
| Number of outputs         | 1  |
| Type of connector         | 75 ohms BNC  |
| Output impedance          | 75 ohms according to EN 50083-9  |
| Data amplitude            | 800 mV peak-peak $\pm$ 10% according to EN 50083-9   |
| Return loss               | >17 dB, 27 to 270 MHz  |
| Transport stream bit rate | 1 to 120 Mbit/s $\pm$ 100 ppm  |
| ASI bit rate              | 200 Mbit/s $\pm$ 100 ppm   |
| Transport stream formats  | According to EN 50083-9<br>188 bytes structure<br>204 bytes without Reed Solomon<br>Burst or packet format |

### MPEGoIP Output (optional)

| Item              | Specification             |
|-------------------|---------------------------|
| Number of outputs | 1                         |
| Type of connector | RJ-45, 10/100/1000 BASE-T |
| Output modes      | UDP RAW, RTP              |
| IP Addressing     | Multicast                 |
| TS Streaming      | MPTS                      |
| TS Bit Rate       | 1 to 120 Mbps             |

## MPE Output

| Item              | Specification                         |
|-------------------|---------------------------------------|
| Number of Outputs | 1                                     |
| Type of connector | RJ-45, 100/1000 BASE-T                |
| Output modes      | IPv4 datagrams                        |
| IP Addressing     | Multicast                             |
| TS Input          | up to 5 PIDs                          |
| Bit Rate          | up to 10 Mbps (for 1500 byte packets) |

## Control, Management and Data Interfaces

### Ethernet Management Interface

| Item                 | Specification                               |
|----------------------|---|
| Number of connectors | 1   |
| Type of connector    | Eight-pin RJ-45                             |
| Ethernet type        | 100/1000 BASE-T                             |
| Required setup       | IP address, default gateway and subnet mask |

### Ethernet Data Interface

| Item                 | Specification                               |
|----------------------|---|
| Number of connectors | 1   |
| Type of connector    | Eight-pin RJ-45                             |
| Ethernet type        | 100/1000 BASE-T                             |
| Required setup       | IP address, default gateway and subnet mask |

### RS-232 Data Interface

| Item           | Specification   |
|----------------|---|
| Connector type | 9-pin sub-D female  |
| Data rates     | RS-232 asynchronous data at selectable rates up to 38.4 kb/s: 300, 1200, 2400, 4800, 9600, 19,200, 38,400 b/s |

### Alarm Interface

| Item              | Specification  |
|-------------------|--|
| Number of outputs | 1, with one set of contacts closed and one set open during normal operation. |
| Type of connector | 15-pin sub-D female  |

| Item         | Specification |
|--------------|---------------|
| Max. voltage | 40 V peak     |
| Max. current | 0.5A          |

### Contact Closure Interface

| Item  | Specification  |
|---|--|
| Connector type                                      | 15-pin sub-D female  |
| Minimum duration of event guaranteed to be detected | 250 ms, 1 frame period, e.g., for 1080i/25 Hz 40 ms for DPI applications |
| Max. on generator impedance                         | 100 ohms   |
| Min. off generator impedance                        | 100 kilohms  |

## Power and General Specifications

### General

| Item   | Specification   |
|--------|---|
| LCD    | 2 lines of 40 characters, backlit LCD.                                |
| Keypad | Arrow keys, 0 to 9, SELECT, MENU, INFO, ADV, MAP, APPLY and NAV keys. |
| LEDs   | Green LED for Signal status. Red LED for Alarm indication.            |

### Power

#### AC Power Connector

| Item              | Specification                                       |
|-------------------|---|
| Type of connector | IEC 320 style C14 appliance receptable              |
| AC input          | 100 to 240 V AC, 50/60 Hz                           |
| Power             | 37 W max  |
| Current           | 0.34 A @ 240 V AC typical, 0.5 A @ 120 V AC typical |
| Power Quality     | ANSI/IEEE Std C62.41.1-2002                         |

#### Power

To operate the receiver, you must connect it to an AC power source.



**WARNING:**

Make sure that at least one end of the power cable(s) remains easily accessible for unplugging, if you need to switch off the unit. For example: Ensure that the socket outlet is installed near the product.



**WARNING:**

To avoid electrical shock, connect the three-prong plug on this product to an earth-grounded three-pin socket outlet only.

## Mechanical

| Item   | Specification         |
|--------|-----------------------|
| Height | 1 U (4.37 cm) (1.72") |
| Width  | 44.07 cm (17.35")     |
| Depth  | 35.0 cm (13.78")      |
| Weight | 4.5 kg (10 lb.)       |

## Environment

| Item                      | Specification  |
|---------------------------|--|
| <b>Storage</b>            |  |
| General                   | The product is within the original packaging.  |
| Humidity                  | 5 - 95% non-condensing   |
| Temperature               | -20 - +70°C (-4 to 158°F)  |
| <b>Operation</b>          |  |
| Humidity (non-condensing) | 95% humidity is valid up to 40°C<br>91% humidity is valid up to 45°C<br>70% humidity is valid up to 50°C |
| Temperature               | 0°C - +50°C (32°F to 122°F)  |
| <b>Altitude</b>           |  |
| Operating                 | 10,000 ft. (3048 m) max.   |
| Non-operating             | 30,000 ft. (9144 m ) max.  |





# B

---

## Default Settings

### Introduction

The D9854 Advanced Program Receiver is factory configured with default settings unless you have requested a custom factory configuration. This appendix lists the factory default settings.

### In This Appendix

- Factory Default Settings..... 290
- DPM Default Settings for Different Output Modes..... 297

## Factory Default Settings

### Administration

| Parameter       | Default   |
|-----------------|-----------|
| Lock Level      | 0         |
| Password        | 1234      |
| KB Lock         | Disable   |
| KB Lock Timeout | 60        |
| LCD Contrast    | 30        |
| DL Mode         | Always    |
| Date Format     | YYY_MM_DD |
| Time Format     | 24 Hr     |
| GMT Off         | +05.30    |

### RF Input

| Parameter       | Default        |
|-----------------|----------------|
| Tune Mode       | Basic          |
| CA Ctl          | Std            |
| Select          | UserCfg        |
| LO1 (GHz)       | 5.15           |
| LO2 (GHz)       | 0.0            |
| Crossover (GHz) | 0.0            |
| OrbPos          | 0.0            |
| E/W             | NA             |
| Pol             | H (horizontal) |
| Freq (GHz)      | 3.449          |
| Sym Rate        | 28.3465 MS/s   |
| FEC             | Auto           |
| Modulation      | DVB-S          |
| Roll-off        | .35            |

| Parameter | Default |
|-----------|---------|
| InputIQ   | Auto    |
| NetID     | 1       |
| LNB Power | Off     |
| 22kHz     | Off     |

## Tune Mode

| Parameter               | Default  |
|-------------------------|----------|
| Service List Mode       | Rigorous |
| Frequency Tuning        | NIT      |
| Use BAT in Service List | No       |
| Use NIT in Service List | Yes      |
| Use SDT in Service List | Yes      |
| Use PAT in Service List | Yes      |

## IP

**Note:** A factory reset does not change the IP settings.

| Parameter                   | Default                             |
|-----------------------------|-------------------------------------|
| Port ID                     | 1                                   |
| V4/V6                       | IPv4                                |
| IP Address                  | 192.131.244.6                       |
| Mask                        | 24                                  |
| Gateway                     | 192.131.244.254                     |
| SNMP Read Community String  | public                              |
| SNMP Write Community String | public                              |
| Multicast Forwarding        | Forward All, if Port ID is set to 2 |
| SNTP Server                 | 0.0.0.0                             |
| SNTP Enable                 | No                                  |

## Appendix B Default Settings

| Parameter           | Default                  |
|---------------------|--------------------------|
| Password Complexity | Full Complexity Checking |

### Video

| Parameter                            | Default     |
|--------------------------------------|-------------|
| PV Format                            | Auto        |
| SD Format                            | Auto        |
| Tri-Synch (Front Panel only)         | Disabled    |
| TV A/R                               | 4:3         |
| Convert                              | None        |
| WSS Mode                             | Passthrough |
| Enable Banner Display (Web GUI only) | Enable      |

### Audio

| Parameter              | Default                               |
|------------------------|---------------------------------------|
| Stereo/Mono            | Stereo                                |
| AC3 Compression        | RF Mode                               |
| Left (dB)              | 0                                     |
| Right (dB)             | 0                                     |
| PMT Source             | AUD1 for Audio 1 and AUD2 for Audio 2 |
| DDP (Front Panel only) | Trans                                 |
| Digital Out Pref       | PCM Samples                           |

### Subtitles

| Parameter          | Default        |
|--------------------|----------------|
| Op Mode            | Off            |
| Select Language By | Language Entry |
| Language List      | eng            |

| Parameter        | Default  |
|------------------|----------|
| PMT Order        | First    |
| Entry            | eng      |
| Imitext Position | Standard |
| ForeGnd          | Auto     |
| BackGnd          | Auto     |

## CI

| Parameter  | Default  |
|------------|----------|
| Decrypt    | ON       |
| CI Slot    | Top      |
| Query      | Disabled |
| Auto Reset | Disabled |
| List Mgmt  | AddDel   |
| TS_ON_ID   | Disable  |

## Cueing

| Parameter        | Default |
|------------------|---------|
| Cueing Mode      | Trigger |
| Trigger Polarity | High    |
| Repeat           | 3       |
| Tone (ms)        | 40      |
| Silence (ms)     | 40      |
| Relay Mode       | Alarm   |
| Cue Trigger Bit  | 1       |
| State            | Disable |
| Mode             | *       |
| Delay (sec)      | 1       |

**Appendix B**  
**Default Settings**

## TS Out - ASI

| <b>Parameter</b>   | <b>Default</b> |
|--------------------|----------------|
| Name               | ASI            |
| Rate Control       | User           |
| User Rate          | 68.5 Mbps      |
| Output Mode        | No Output      |
| Descramble Mode    | Descrambled    |
| Insert Null Packet | Yes            |

## TS Out - MOIP1

| <b>Parameter</b>   | <b>Default</b>    |
|--------------------|-------------------|
| Name               | MOIP1             |
| Rate Control       | User              |
| User Rate          | 0                 |
| Output Mode        | No Output         |
| Descramble Mode    | Descrambled       |
| Insert Null Packet | Yes               |
| Instance Name      | MPEG over IP 1    |
| MOIP               | UDP               |
| Send SAP           | No                |
| SAP ID             | Cisco Default SAP |
| DestAddr           | 225.1.1.1         |
| UDPPort            | 49152             |
| SrcPort            | 0                 |
| TS/IP              | 7                 |
| Min IP/s           | 0                 |
| PCR@IP Start       | Yes               |
| Mgmt Port Mode     | No Output         |
| DATA Port Mode     | Always output     |
| PCR Addition       | Yes               |

**DPM - ASI**

| <b>Parameter</b> | <b>Default</b> |
|------------------|----------------|
| PMT              | 8192           |
| Act              | Drop           |
| OutCh            | 0              |
| PMT              | 8191           |
| Map Mode         | SVC ID & PID   |
| Duplic Mode      | Pkt Copy       |
| Unref            | Drop           |
| PSI Options      | Drop All       |
| PSI Rate         | SA Std         |
| Service ID       | Valid Ch       |
| PAT              | Pass           |
| CAT              | Pass           |
| PMT              | Pass           |
| TSDT             | Pass           |
| NIT              | Pass           |
| NITO             | Pass           |
| SDT              | Pass           |
| SDIO             | Pass           |
| BAT              | Pass           |
| EIT              | Pass           |
| TDT              | Pass           |
| RST              | Pass           |
| TOT              | Pass           |
| DIT              | Pass           |
| SIT              | Pass           |
| ECM              | Pass           |
| EMM              | Pass           |
| DRT              | Pass           |

**Appendix B**  
**Default Settings**

| <b>Parameter</b> | <b>Default</b> |
|------------------|----------------|
| CDT              | Pass           |

### Noise Cutoff

| <b>Parameter</b>                    | <b>Default</b> |
|-------------------------------------|----------------|
| Trnsprt (DVB-S/DVB-S2 Marg) Cutoff  | 0.0            |
| Trnsprt (DVB-S/DVB-S2 Marg) Restore | 0.1            |
| Audio (DVB-S/DVB-S2 Marg) Cutoff    | 0.0            |
| Audio (DVB-S/DVB-S2 Marg) Restore   | 0.1            |
| Muting Control                      | Enable         |

### Import/Export (Web GUI only)

| <b>Parameter</b>      | <b>Default</b> |
|-----------------------|----------------|
| Settings File Name    | file name      |
| FTP Server IP Address | 192.168.0.100  |
| FTP Port Number       | 21             |
| FTP User Name         | user           |
| FTP Password          | USER           |



## DPM Default Settings for Different Output Modes

The DPM parameters are preset to default settings for each DPM Output Mode.

The default settings for particular Output modes have been preset to optimize the output when PID mapping is required. If the DPM parameters are changed to values which switch the receiver to Full DPM Control, the receiver may enter a condition where conflicts in the settings may occur, which may require manual manipulation of the DPM or output parameters to obtain the desired output.

If you change any of the DPM parameters listed in this table in any of the MAP Output Modes, the receiver Output Mode will change to DPM Full Control, but will retain the current settings. This is noted in the table below.

| <b>Output Mode Changes to Full DPM Control with DPM Parameter Change</b> | <b>No Output Mode Change with DPM Parameter Change</b> |
|--|--|
| MAP Passthrough  | No Output  |
| MAP Svc Chans Only   | Passthrough  |

The fields labeled “Any” in the table below are not used, in which case, the Output Mode will not change if the parameter is changed. However, if you change any of the other parameters listed in the table for the MAP output modes, the Output Mode will change to Full DPM Control.

| <b>Output Mode</b> | <b>No Output</b> | <b>Passthrough</b> | <b>Service Chans Only</b> | <b>MAP Passthrough</b> | <b>MAP Svc Chans Only</b> | <b>Full DPM Control</b> |
|--------------------|------------------|--------------------|---------------------------|------------------------|---------------------------|-------------------------|
| Rate Control       | Any (unchanged)  | Any (unchanged)    | Any (unchanged)           | Any (unchanged)        | Any (unchanged)           | Any (unchanged)         |
| User Rate          | Any (unchanged)  | Any (unchanged)    | Any (unchanged)           | Any (unchanged)        | Any (unchanged)           | Any (unchanged)         |
| Descramble Mode    | Any (unchanged)  | Any (unchanged)    | Any (unchanged)           | Any (unchanged)        | Any (unchanged)           | Any (unchanged)         |
| Regenerate         | Any (unchanged)  | Any (unchanged)    | Any (unchanged)           | Any (unchanged)        | Any (unchanged)           | Any (unchanged)         |
| Insert Null Packet | Any (unchanged)  | Any (unchanged)    | Any (unchanged)           | Any (unchanged)        | Any (unchanged)           | Any (unchanged)         |
| Map Mode           | Any (not used)   | Svc ID             | Svc ID                    | Svc Id & PID           | Svc ID & PID              | Actual Value            |
| Duplic Mode        | Any (not used)   | PSI Remap          | PSI Remap                 | Pkt Copy               | Pkt Copy                  | Actual Value            |
| Unref              | Drop             | Pass               | Drop                      | Pass                   | Drop                      | Actual Value            |

**Appendix B  
Default Settings**

| <b>Output Mode</b> | <b>No Output</b> | <b>Passthrough</b>   | <b>Service Chans Only</b>  | <b>MAP Passthrough</b>   | <b>MAP Svc Chans Only</b>  | <b>Full DPM Control</b> |
|--------------------|------------------|--|--|--|--|-------------------------|
| PSI Options        | Drop             | Ctl By Table   | Ctl By Table   | Ctl By Table   | Ctl By Table   | Actual Value            |
| PSI Rate           | Any (not used)   | SA Std   | SA Std   | SA Std   | SA Std   | Actual Value            |
| Svc ID             | Any (not used)   | Valid Ch   | Valid Ch   | Valid Ch   | Valid Ch   | Actual Value            |
| PAT                | Not Displayed    | Pass   | Regen  | Regen  | Regen  | Actual Value            |
| CAT                | Not Displayed    | If Descramble Mode is set to Descrambled, it is set to Regen; otherwise, it is set to Pass | If Descramble Mode is set to Descrambled, it is set to Regen; otherwise, it is set to Pass | If Descramble Mode is set to Descrambled, it is set to Regen; otherwise, it is set to Pass | If Descramble Mode is set to Descrambled, it is set to Regen; otherwise, it is set to Pass | Actual Value            |
| PMT                | Not Displayed    | If Descramble Mode is set to Descrambled, it is set to Regen; otherwise, it is set to Pass | If Descramble Mode is set to Descrambled, it is set to Regen; otherwise, it is set to Pass | Regen  | Regen  | Actual Value            |
| TSDT               | Not Displayed    | Pass   | Pass   | Pass   | Pass   | Actual Value            |
| NIT                | Not Displayed    | Pass   | Regen  | Regen  | Regen  | Actual Value            |
| NITO               | Not Displayed    | Pass   | PwRc   | PwRc   | PwRc   | Actual Value            |
| SDT                | Not Displayed    | If Descramble Mode is set to Descrambled, it is set to Regen; otherwise, it is set to Pass | Regen  | Regen  | Regen  | Actual Value            |
| SDTO               | Not Displayed    | If Descramble Mode is set to Descrambled, it is set to Regen; otherwise, it is set to Pass | PwRc   | PwRc   | PwRc   | Actual Value            |

**DPM Default Settings for Different Output Modes**

| <b>Output Mode</b>  | <b>No Output</b> | <b>Passthrough</b>  | <b>Service Chans Only</b> | <b>MAP Passthrough</b> | <b>MAP Svc Chans Only</b> | <b>Full DPM Control</b> |
|---------------------|------------------|---|---------------------------|------------------------|---------------------------|-------------------------|
| BAT                 | Not Displayed    | If Descramble Mode is set to Descrambled, it is set to PwRC; otherwise, it is set to Pass | PwRC                      | PwRC                   | PwRC                      | Actual Value            |
| EIT                 | Not Displayed    | Pass  | Pass                      | Pass                   | Pass                      | Actual Value            |
| TDT                 | Not Displayed    | Pass  | Pass                      | Pass                   | Pass                      | Actual Value            |
| RST                 | Not Displayed    | Pass  | Pass                      | Pass                   | Pass                      | Actual Value            |
| TOT                 | Not Displayed    | Pass  | Pass                      | Pass                   | Pass                      | Actual Value            |
| DIT                 | Not Displayed    | Pass  | Pass                      | Pass                   | Pass                      | Actual Value            |
| SIT                 | Not Displayed    | Pass  | Pass                      | Pass                   | Pass                      | Actual Value            |
| ECM                 | Not Displayed    | Pass  | Pass                      | Pass                   | Pass                      | Actual Value            |
| EMM                 | Not Displayed    | Pass  | Pass                      | Pass                   | Pass                      | Actual Value            |
| DRT                 | Not Displayed    | Pass  | Pass                      | Pass                   | Pass                      | Actual Value            |
| CDT                 | Not Displayed    | Pass  | Pass                      | Pass                   | Pass                      | Actual Value            |
| PE Action (all PEs) | Drop             | Pass  | Pass                      | Map                    | Map                       | Actual Value            |



# C

---

## Lock Levels

### Introduction

This appendix contains the lock levels for the D9854 Advanced Program Receiver.

### In This Appendix

- D9854 Receiver Lock Levels ..... 302

## D9854 Receiver Lock Levels

Four (4) lock levels (0, 1, 2, 3, and 4) are available for protecting your receiver and its settings against unauthorized use or modification (see the table below for full details).

| Level | Description   |
|-------|---|
| 0     | All settings are unlocked (receiver lockout disabled)                                     |
| 1     | All settings are unlocked except Factory Reset, Password options and receiver parameters. |
| 2     | All settings are unlocked except RF and ASI Input Tuning parameters.                      |
| 3     | All settings locked (access via password only), except IP address and RF power.           |
| 4     | All settings locked (can be changed via PNC uplink signal only)                           |

If a change made to the current Lock Level setting is not saved, the previously saved setting is restored.

**Note:** The user cannot select NONE as a Lock Level.

### Video

| Parameter | Lock Level |
|-----------|------------|
| PV Format | 2          |
| SD Format | 2          |

### Aspect Ratio

| Parameter       | Lock Level |
|-----------------|------------|
| SD Aspect Ratio | 2          |
| AR Selection    | 2          |
| AR Conversion   | 2          |
| WSS Mode        | 2          |

## Closed Caption

| Parameter      | Lock Level |
|----------------|------------|
| Preferred Mode | 2          |

## Subtitles

| Parameter        | Lock Level |
|------------------|------------|
| Op Mode          | 2          |
| Lang Menu        | 2          |
| Lang List        | 2          |
| PMT Order        | 2          |
| Manual Entry     | 2          |
| Imitext Position | 2          |
| Foreground       | 2          |
| Background       | 2          |

## Download

| Parameter | Lock Level |
|-----------|------------|
| Mode      | 2          |
| DL Type   | 2          |
| DL Bank   | 2          |
| Command   | 2          |

## Runnable Application

| Parameter | Lock Level |
|-----------|------------|
| Index     | 2          |
| Select    | 2          |
| Erase     | 2          |

**Appendix C**  
**Lock Levels**

### **Runnable FPGA**

| <b>Parameter</b> | <b>Lock Level</b> |
|------------------|-------------------|
| Index            | 2                 |
| Select           | 2                 |
| Erase            | 2                 |

### **Audio**

| <b>Parameter</b> | <b>Lock Level</b> |
|------------------|-------------------|
| Audio Sel Key    | 2                 |
| Mode             | 2                 |
| AC3 Comp         | 2                 |
| Left             | 2                 |
| Right            | 2                 |
| PMT Source       | 2                 |

### **PV Muting Thresholds**

| <b>Parameter</b>  | <b>Lock Level</b> |
|-------------------|-------------------|
| Transport Cutoff  | 2                 |
| Transport Restore | 2                 |
| Audio Cutoff      | 2                 |
| Audio Restore     | 2                 |

### **LDPC Muting Thresholds**

| <b>Parameter</b>  | <b>Lock Level</b> |
|-------------------|-------------------|
| Transport Cutoff  | 2                 |
| Transport Restore | 2                 |
| Audio Cutoff      | 2                 |



| Parameter     | Lock Level |
|---------------|------------|
| Audio Restore | 2          |

## Muting Thresholds

| Parameter        | Lock Level |
|------------------|------------|
| Restore Defaults | 2          |
| Control          | 2          |

## Fixed PID

| Parameter     | Lock Level |
|---------------|------------|
| CH            | 1          |
| Ch Stream IDX | 1          |
| PID           | 1          |
| Stream Type   | 1          |

## IP

| Parameter      | Lock Level |
|----------------|------------|
| Port ID Key    | 3          |
| Name           | 3          |
| V4 IP Addr     | 3          |
| V4 Mask        | 3          |
| V4 Def Gateway | 3          |

## SNMP Comm

| Parameter    | Lock Level |
|--------------|------------|
| Read String  | 2          |
| Write String | 2          |

## Appendix C Lock Levels

| Parameter    | Lock Level |
|--------------|------------|
| Sys Name     | 2          |
| Sys Location | 2          |
| Sys Contact  | 2          |

## Trap Destination

| Parameter | Lock Level |
|-----------|------------|
| Index     | 2          |
| IP Addr   | 2          |

## Active Settings

| Parameter     | Lock Level |
|---------------|------------|
| ACQ Mode      | 1          |
| CA Mode       | 1          |
| Input Sel     | 1          |
| Freq Sel      | 1          |
| Ser List Mode | 1          |
| Use BAT       | 1          |
| Use NIT       | 1          |
| Use SDT       | 1          |
| Use PAT       | 1          |

## Active Tuning

| Parameter | Lock Level |
|-----------|------------|
| Net ID    | 1          |
| ASI       | 1          |
| RF1       | 1          |
| RF2       | 1          |

## D9854 Receiver Lock Levels

| <b>Parameter</b> | <b>Lock Level</b> |
|------------------|-------------------|
| RF3              | 1                 |
| RF4              | 1                 |
| Input            | 1                 |
| Modulation       | 1                 |
| Frequency        | 1                 |
| Sym Rate         | 1                 |
| FEC              | 1                 |
| LNB Power        | 3                 |
| Polarization     | 1                 |
| IQ               | 1                 |
| 22 kHz Tone      | 1                 |
| Rolloff          | 1                 |

## Active Inputs

| <b>Parameter</b> | <b>Lock Level</b> |
|------------------|-------------------|
| RF Sel Key       | 1                 |
| LNB Type         | 1                 |
| LNB Trim1        | 1                 |
| LNB Trim2        | 1                 |
| Crossover        | 1                 |
| LO Select        | 1                 |
| LOF1             | 1                 |
| LOF2             | 1                 |
| Orbital Pos      | 1                 |
| E/W Flag         | 1                 |
| Orb Polarization | 1                 |

**Appendix C**  
**Lock Levels**

### **BISS**

| <b>Parameter</b> | <b>Lock Level</b> |
|------------------|-------------------|
| Mode             | 2                 |
| BISS 1 SW        | 2                 |
| BISS E SW        | 2                 |
| BISS E ID        | 2                 |

### **Program Entry**

| <b>Parameter</b> | <b>Lock Level</b> |
|------------------|-------------------|
| PE Index         | 2                 |
| Channel Num      | 2                 |
| CA Resource      | 2                 |
| Resource ID      | 2                 |
| CH Cmd           | 2                 |

### **Program Status**

| <b>Parameter</b> | <b>Lock Level</b> |
|------------------|-------------------|
| PE Index         | 2                 |
| Channel Num      | 2                 |

### **Decode Enable**

| <b>Parameter</b> | <b>Lock Level</b> |
|------------------|-------------------|
| Decoder          | 2                 |
| Enable           | 2                 |

## Power On

| Parameter       | Lock Level |
|-----------------|------------|
| Clr Reset Count | 0          |

## User Setting

| Parameter       | Lock Level |
|-----------------|------------|
| Date Format     | 2          |
| Time Format     | 2          |
| GMT Offset      | 2          |
| KB Lock Enable  | 2          |
| KB Lock Timeout | 2          |
| M1 Port Type    | 2          |
| M2 Port Type    | 2          |
| Contrast        | 2          |
| Menu Type       | 2          |
| Clear ADP       | 2          |
| Regenerate      | 2          |
| Banner          | 2          |
| Reboot          | 2          |

## Admin

| Parameter           | Lock Level |
|---------------------|------------|
| Lock Level          | 3          |
| Lock Level Pwd      | 3          |
| Lock Level Pwd Cur  | 0          |
| Lock Level Pwd New  | 0          |
| Lock Level Pwd Conf | 0          |
| Factory Reset       | 0          |
| Clean Unused Tbls   | 0          |

**Appendix C  
Lock Levels**

### **DPM Transmit**

| <b>Parameter</b> | <b>Lock Level</b> |
|------------------|-------------------|
| Output Mode      | 2                 |
| Descramble Mode  | 2                 |
| Rate Ctrl        | 2                 |
| Rate             | 2                 |
| Ins Null Pkt     | 2                 |

### **DPM Global Configuration**

| <b>Parameter</b> | <b>Lock Level</b> |
|------------------|-------------------|
| Instance ID      | 2                 |
| Instance Name    | 2                 |
| Map Mode         | 2                 |
| Dup Method       | 2                 |
| Reg Rate         | 2                 |
| Unref Content    | 2                 |
| PSI Output       | 2                 |
| PSI PAT          | 2                 |
| PSI CAT          | 2                 |
| PSI PMT          | 2                 |
| PSI TSDT         | 2                 |
| PSI NIT          | 2                 |
| PSI NITO         | 2                 |
| PSI SDT          | 2                 |
| PSI SDTO         | 2                 |
| PSI BAT          | 2                 |
| PSI EIT          | 2                 |
| PSI TDT          | 2                 |
| PSI ST           | 2                 |

| Parameter     | Lock Level |
|---------------|------------|
| PSI RST       | 2          |
| PSI TOT       | 2          |
| PSI DIT       | 2          |
| PSI SIT       | 2          |
| PSI ECM       | 2          |
| PSI EMM       | 2          |
| PSI DRT       | 2          |
| PSI CDT       | 2          |
| Svc ID Output | 2          |
| Modified      | 2          |
| Activate      | 2          |

### DPM PE Maps

| Parameter      | Lock Level |
|----------------|------------|
| Instance ID    | 2          |
| PE             | 2          |
| Action         | 2          |
| PMT PID        | 2          |
| Output Channel | 2          |
| PID Map        | 2          |

### DPM PID Map

| Parameter     | Lock Level |
|---------------|------------|
| Index         | 2          |
| In Use        | 2          |
| Instance Name | 2          |
| PE            | 2          |
| Row           | 2          |
| Stream Type   | 2          |

## Appendix C Lock Levels

| Parameter   | Lock Level |
|-------------|------------|
| Stream CAT  | 2          |
| Stream Inst | 2          |
| Action      | 2          |
| Output PID  | 2          |

## IP Configuration

| Parameter             | Lock Level |
|-----------------------|------------|
| Enabled               | 2          |
| Instance Name         | 2          |
| TP Proto              | 2          |
| Dest IP Addr          | 2          |
| SAP Multicast IP Addr | 2          |
| Dest Port             | 2          |
| Src Port              | 2          |
| Min IP Per Sec        | 2          |
| PCR Addition          | 2          |
| PCR Start New Pkt     | 2          |
| Send Sap              | 2          |
| Send Sap Str          | 2          |
| Max TPKT Per IP       | 2          |
| SAP Str               | 2          |
| Intf Mode 1           | 2          |
| Intf Mode 2           | 2          |

## Alarm Setting

| Parameter | Lock Level |
|-----------|------------|
| Enable    | 2          |
| Relay     | 2          |
| Trap      | 2          |



## Warning Setting

| Parameter | Lock Level |
|-----------|------------|
| Name      | 2          |
| Enable    | 2          |
| Relay     | 2          |
| Trap      | 2          |

## Fault Status

| Parameter      | Lock Level |
|----------------|------------|
| Text ID        | 2          |
| Fault Num      | 2          |
| Name           | 2          |
| Type           | 2          |
| Severity       | 2          |
| Last Date Time | 2          |
| Trap State     | 2          |
| Details        | 2          |
| Relay          | 2          |

## Fault History

| Parameter       | Lock Level |
|-----------------|------------|
| Sequence        | 2          |
| Name            | 2          |
| Type            | 2          |
| Set Date Time   | 2          |
| Reset Date Time | 2          |
| State           | 2          |
| Details         | 2          |

**Appendix C**  
**Lock Levels**

**Log History**

| <b>Parameter</b> | <b>Lock Level</b> |
|------------------|-------------------|
| Sequence         | 2                 |
| Cur Date         | 2                 |
| Cur Time         | 2                 |
| Message          | 2                 |

# D

---

## Compliance

### Introduction

This appendix contains the compliance information for the D9854 Advanced Program Receiver.

### In This Appendix

- Applicable Standards and Notices ..... 316
- Declaration of Conformity ..... 318

## Applicable Standards and Notices

### Safety

The D9854 Advanced Program Receiver has been approved for safety by the Standards Council of Canada and the OHSA (NRTL) Accredited Testing Laboratory to the following standards:

CAN/CSA C22.2 No. 60065-03 Incl. AM1 - Audio, Video and Similar Electronic Apparatus - Safety Requirements

UL Std. No. 60065-2007 - Audio, Video and Similar Electronic Apparatus - Safety Requirements

Also, this product is being evaluated under the IECEE CB scheme to the following international standard:

IEC 60065 Edition 7 (2001) included Amendment 1

For the CB report and Certificate, the product is evaluated for the country differences outlined in CB Bulletin 110A:

National Differences: AR, AT, AU, BE, CA, CH, CS, DE, DK, ES, FI, FR, GB, GR, HU, IE, IL, IT, MY, NL, NO, PL, PO, SE, SG, SI, SK, UA, US, YU and Group Differences. In addition, JP, KR & CN National Differences of CB Bulletin

### EMC

Electrostatic Discharge (ESD) results from the static electricity buildup on the human body and other objects. This static discharge can degrade components and cause failures.

Take the following precautions against electrostatic discharge.

Use an anti-static bench mat and a wrist strap or ankle strap designed to safely ground ESD potentials through a resistive element.

Keep components in their anti-static packaging until installed.

Avoid touching electronic components when installing a module.

### Electromagnetic Compatibility Regulatory Requirements

Ethernet cables should be of single-shielded or double-shielded type. Coaxial cables should be of the double-braided shielded type. Where this equipment is subject to USA FCC and/or Industry Canada rules, the following statements apply:

## FCC Notices

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions supplied in this manual may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception (which can be determined by turning the equipment off and on), the user is encouraged to try to correct the interference by one or more of the following measures:

- 1 Reorient or relocate the television receiving antenna.
- 2 Increase the separation between the equipment and the receiver.
- 3 Connect the equipment to an AC outlet on a circuit different from that to which the receiver is connected.
- 4 Contact your dealer/ reseller or an experienced radio/ TV technician for help.

The user may find the booklet "Interference handbook" prepared by the Federal Communications Commission helpful. This booklet is available from the U.S. Government Printing Office, Washington, DC 20402, stock no. 004-000-00450-7.

Shielded cables should be used to interconnect this device with any other/peripheral equipment (i.e., data sources, terminals, monitors, etc.) to ensure compliance with Class B limits. Failure to do so may result in radio or TV interference. Cables should be of braided shield construction with metal end shells.

## Industry Canada Notice

This digital apparatus does not exceed the limits for Class B radio noise emissions from digital apparatus as set out in the radio interference regulations of the Industry Canada.

Le présent appareil numérique n'émet pas de bruits radioélectriques qui dépassent les limites applicables aux appareils numériques de Class B prescrites dans le règlement sur le brouillage radioélectrique édicté par Industrie Canada.

## Unauthorized Modifications

The manufacturer is not responsible for any radio or TV interference resulting from unauthorized modifications made to this equipment. It is the responsibility of the user to correct such interference at his own expense.

## Declaration of Conformity



### DECLARATION OF CONFORMITY with regard to the Directives 2006/95/EC (LVD) and 2004/108/EC (EMC)

Cisco Systems Inc & all its affiliates

*Headquarters:*  
170 West Tasman Drive  
San Jose, CA 95134 - USA

Declare under our sole responsibility that the product,

*Brand name:* Cisco  
*Model number:* D9854 / D9854-I  
*Model name:* Advanced Program Receiver

Fulfills the essential requirements of the Directives 2006/95/EC and 2004/108/EC.

With regard to the Directives 2006/95/EC and 2004/108/EC, the following standards were applied:

| Number and Date of Issue          | Title of Standard   |
|-----------------------------------|---|
| EN 60065:2002/A11:2008            | - Audio, video and similar electronic apparatus – Safety requirements   |
| EN 55022:2006, Class B            | - Limits and Methods of Measurement of Radio Interference Characteristics of Information Technology Devices   |
| EN 55013:2003                     | - Electromagnetic Compatibility Requirements - Sound and Television Broadcast Receivers and Associated Equipment                                    |
| EN 55024:1998 +A1:2001 & +A2:2003 | - Information technology equipment - Immunity characteristics - Limits and methods of measurement   |
| EN 61000-3-2: 2001+A1+A2          | - Electromagnetic Compatibility - Part 3: Limits Section 2: Limits for Harmonic Current Emissions (Equipment Input Current less than 16A per phase) |

The product carries the CE Mark, which was first affixed in 2008:



Date & Place of Issue: 1 July 2012, Scarborough ON, Canada

Signature(s):

Steven Lawrence  
Product Compliance Specialist  
Cisco Systems Canada Co.  
100 Middlefield Rd.  
Scarborough ON M1S4M6  
Canada

A handwritten signature in blue ink, appearing to read "Steven Lawrence".

EU Authorized Representative:

Edgard Vangeel  
Cisco Systems Belgium  
De Kleetlaan, 6 A  
B 1831 Diegem - Belgium

D9854\_Cisco\_DMN\_EU\_DOC3

# Index

## A

About Menu • 118  
About the Front Panel • 38  
Accessing TCP and UDP Services • 74  
Active Inputs • 307  
Active Settings • 306  
Active Tuning • 306  
Adding a New User • 32  
Admin • 309  
Administration • 290  
Administrator User Privileges • 32  
Alarm Interface • 284  
Alarm Setting • 312  
Alarms • 227  
Alarms/Warnings • 123  
Analog Audio Outputs • 280  
Analog SD Video Output • 276  
Analog SD Video Output, CVBS1 and CVBS2  
for monitoring • 278  
Applicable Standards and Notices • 316  
ASI Input • 62  
ASI Out • 8  
ASI Output • 282  
ASI/MOIP1 • 102  
Aspect Ratio • 279, 302  
Aspect Ratio Conversions • 77  
Assigning a Program Channel to a PE (Program  
Entry) • 7  
Assigning Program to the Program Entry • 45  
Audio • 80, 292, 304  
Audio Outputs • 280  
Audio Slot • 84

## B

BISS • 308

## C

Captions • 82  
Changing a Password (allowed by all Users) • 33  
Changing a Username • 33  
Changing the Lock Level Password • 214

Changing the Relay Mode for Alarm Monitoring  
• 29  
Channel Authorization Status • 43  
CI • 89, 293  
CI Slots • 38  
Closed Caption • 303  
Common Interface Modules • 35  
Conditional Access • 280  
Configuring Open-collector Outputs • 31  
Configuring System Settings • 191  
Configuring the ASI Output • 173  
Configuring the DPM MPEGoIP Output Details  
• 184  
Configuring the MPEGoIP Output • 181  
Configuring Transport Stream Information • 173  
Connecting AC Power to the D9854 Receiver •  
23  
Connecting the ASI Input • 26  
Connecting the ASI Output • 28  
Connecting the Audio Outputs • 27  
Connecting the Balanced Audio Output • 27  
Connecting the Component Video Output • 26  
Connecting the Composite Video Output • 26  
Connecting the Cue Tone Interface • 31  
Connecting the Cue Trigger Interface • 31  
Connecting the Digital Audio Outputs • 27  
Connecting the Ethernet Management Interface •  
28  
Connecting the HD-SDI Outputs • 26  
Connecting the Input/Output Signals • 26  
Connecting the IP TS Output • 28  
Connecting the Receiver to Other Equipment • 2  
Connecting the RF Inputs • 26  
Connecting the RS-232 Data Interface • 29  
Connecting the Video Outputs • 26  
Connectors for the Digital Audio Output • 27  
Contact Closure Interface • 285  
Control, Management and Data Interfaces • 284  
Cooling • 22  
Cue Tone/Cue Trigger Interface • 30  
Cueing • 93, 293  
Customer Information • 269

**D**

D9854 Advanced Program Receiver • 14  
 D9854 Menus • 131  
 D9854 Receiver Alarm Messages • 227  
 D9854 Receiver Lock Levels • 302  
 D9854 Receiver Rear Connector Panel • 24  
 D9854 Summary Overview • 129  
 D9854 Web GUI Environment • 133  
 Declaration of Conformity • 318  
 Decode • 86  
 Decode Enable • 308  
 Deleting a Program from the Program Entry • 46  
 Deleting a User • 33  
 Diagnostics Menu • 123  
 Digital Audio Outputs • 280  
 Download • 303  
 DPM - ASI • 295  
 DPM - Global • 102  
 DPM Default Settings for Different Output Modes • 297  
 DPM Global Configuration • 310  
 DPM PE Maps • 311  
 DPM PID Map • 311  
 DPM Transmit • 310  
 DVB-ASI Transport Stream Outputs • 17  
 DVB-S Eb/No (C/N) Ratio • 274  
 DVB-S/DVB-S2 • 273  
 DVB-S2 Error Rate Performance Es/No (C/N) Ratio • 274

**E**

Elevated Operating Ambient Temperature • 20  
 Embedded Audio • 279  
 Embedded Data in SDI • 279  
 Environment • 287  
 Equipotential Bonding • 21  
 Ethernet Data Interface • 284  
 Ethernet Management Interface • 284  
 External Alarm System Connector • 29

**F**

Factory Default Settings • 290  
 Fault History • 313  
 Fault Status • 313  
 Fixed PID • 305  
 Front Panel LEDs • 39, 226  
 Front Panel Operation • 37

**G**

General • 118, 272, 276, 286  
 Grounding • 22

**H**

HD Component Video Output (Monitoring Output) • 278  
 HD-SDI Outputs • 18  
 Health Monitor • 126

**I**

Import/Export (Web GUI only) • 296  
 Installation • 19  
 Installing the D9854 Receiver • 22  
 Introduction • 13  
 IP • 70, 291, 305  
 IP Configuration • 312

**K**

Key Features • 14  
 Keypad • 38

**L**

L-Band Input and Processing • 272  
 LCD • 38  
 LCD Panel • 43  
 LCD Symbol • 44  
 LDPC Muting Thresholds • 304  
 Licenses • 119  
 LNB LO Stability • 272  
 LNB Power and Control • 273  
 Locking/Unlocking the Front Panel • 42  
 Log History • 314  
 Logging On to the Web Interface • 128  
 Logs • 123

**M**

M1/M2 • 95  
 Main Menu • 47  
 Main Selection • 47  
 Main Structure • 43  
 Maintenance of EMC Compliance • 3  
 Mechanical • 287  
 Mechanical Loading • 20  
 MOIP1 • 98  
 Mounting the D9854 Receiver to a Rack • 22  
 MPE Output • 17, 283  
 MPEGoIP Output • 17  
 MPEGoIP Output (optional) • 282



Muting Thresholds • 305

## **N**

Navigation/Selection Keypad • 40

Noise Cutoff • 296

## **O**

Optional Features • 15

## **P**

PID Map Menu • 106

Power • 286

Power and General Specifications • 286

Power Connection • 20

Power On • 125, 309

Printing the List of Users • 34

Program Entry • 308

Program PIDs • 54

Program Status • 55, 308

Protocols • 73

PSI - Channels • 124

PSI - Frequency Plan • 124

PSI - Tables • 125

PSI Table Settings • 107

PV Muting Thresholds • 304

## **Q**

Quick Setup - Read Me First! • 1

Quick Setup Instructions for RF Acquisition • 5

## **R**

Rack Installation • 20

Rack Mounted • 22

Re-Acquire • 69

Resetting the Login Credentials • 34

RF Input • 290

RF1, RF2, RF3, RF4 (RFx) Input • 63

RS-232 Data Connector Pin Allocation • 30

RS-232 Data Interface • 284

Runnable Application • 303

Runnable FPGA • 304

## **S**

SDI • 83

Service and Maintenance • 225

Setting Admin User Privileges via a Telnet  
Connection • 32

Setting the DPM Mode • 11

Setting up Audio and Video Information • 158

Setting Up Digital Program Mapping (DPM) •  
108

Setting up for Network Connection • 4

Setting up Input Information • 134

Setting up the HD-SDI Outputs (SDI Model,  
with SD/HD-SDI and AES outputs) • 9

Setting up the MOIP Outputs (Base Model) • 10

Setting up the RF Input • 134

Setting up the Video Parameters • 158

Setup Menu • 57

Alarm/Warning • 113

IP • 69

Noise Cutoffs • 115

SFN Model Receivers • 16

SNMP Comm • 305

Software Update • 16

Starting a Telnet Session • 32

Startup Screen • 43

Status Menu • 48

General • 49

Services • 50

TS Input • 52

TS Output • 55

Structure • 48, 57

Subtitles • 84, 292, 303

Synchronizing Output Services • 110

## **T**

To Add a Trap Destination • 197

To Add a User Account • 211

To Change the Download Application • 223

To Change the User Login Passwords • 209

To Delete a User Account • 212

To Set Up Warnings • 201

Top/Bottom Slot • 91

Transport Stream Outputs • 282

Trap Destination • 306

Trap Destinations • 73

TS Out - ASI • 95, 294

TS Out - DPM • 101

TS Out - MOIP1 • 294

Tune Mode • 67, 291

Typical set up for Digital Program Mapping  
(DPM) • 188

## **U**

User Setting • 309

## **V**

VBI • 83

## Index

VBI Processing • 279  
Versions Menu • 120  
Video • 75, 292, 302  
Video Inputs/Outputs and Processing • 276  
Video Outputs • 276  
Viewing Contact Information • 216  
Viewing Support Information • 216  
Viewing the System Identification • 191

## **W**

Warning Setting • 313  
Warnings • 257  
Web GUI Setup and Monitoring • 127  
Window Buttons • 133





Cisco Systems, Inc.  
5030 Sugarloaf Parkway, Box 465447  
Lawrenceville, GA 30042

678 277-1120  
800 772-2009  
[www.cisco.com](http://www.cisco.com)

This document includes various trademarks of Cisco Systems, Inc. Please see the Notices section of this document for a list of the Cisco Systems, Inc. trademarks used in this document.

Product and service availability are subject to change without notice.

© 2008-2012 Cisco and/or its affiliates. All rights reserved.

August 2012 Printed in USA

Part Number 4021470 Rev H