



## **Cisco 10000 Series Router Line Card Configuration Guide**

November, 2009

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

Text Part Number: OL-8834-04

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCDE, CCENT, CCSI, Cisco Eos, Cisco HealthPresence, Cisco IronPort, the Cisco logo, Cisco Nurse Connect, Cisco Pulse, Cisco SensorBase, Cisco StackPower, Cisco StadiumVision, Cisco TelePresence, Cisco Unified Computing System, Cisco WebEx, DCE, Flip Channels, Flip for Good, Flip Mino, Flipshare (Design), Flip Ultra, Flip Video, Flip Video (Design), Instant Broadband, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn, Cisco Capital, Cisco Capital (Design), Cisco:Financed (Stylized), Cisco Store, Flip Gift Card, and One Million Acts of Green are service marks; and Access Registrar, Aironet, AllTouch, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Lumin, Cisco Nexus, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Continuum, EtherFast, EtherSwitch, Event Center, Explorer, Follow Me Browsing, GainMaker, iLynx, IOS, iPhone, IronPort, the IronPort logo, Laser Link, LightStream, Linksys, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, PCNow, PIX, PowerKEY, PowerPanels, PowerTV, PowerTV (Design), PowerVu, Prisma, ProConnect, ROSA, SenderBase, SMARTnet, Spectrum Expert, StackWise, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0910R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2009 Cisco Systems, Inc. All rights reserved.



## CONTENTS

<b>About This Guide</b>	<b>xvii</b>
Guide Revision History	xvii
Audience	xix
Document Organization	xix
Document Conventions	xix
Related Documentation	xx
Obtaining Documentation and Submitting a Service Request	xxi

---

### PART 1

---

## ATM Line Cards

---

### CHAPTER 1

<b>4-Port OC-3/STM-1 ATM Line Card Configuration</b>	<b>1-1</b>
Software Support	1-1
Checking Hardware and Software Compatibility	1-2
Default Values	1-2
Line Card VC Limitations	1-2
Interface Syntax	1-3
Interface Configuration Examples	1-4
Creating a Subinterface	1-4
Creating a PVC	1-4
Creating a VC Class	1-5
Applying a VC Class	1-5
Enabling ILMI PVC Discovery	1-5
Completing a Configuration	1-6
ATM Commands	1-6
Global Configuration Command	1-7
Interface and Subinterface Commands	1-7
Creating and Entering Subinterfaces	1-8
Attaching an ATM VC Class to an Interface	1-9
Creating ATM PVPs	1-10
Creating a PVC	1-10
Enabling ATM ILMI	1-11
Activating ATM ILMI PVC Discovery	1-11
Specifying the ATM ILMI Keepalive Rate	1-12
Configuring the ATM Clock	1-12

- Specifying the ATM Flag 1-12
- Controlling ATM Alarm Reporting 1-13
- Specifying the ATM Alarm Thresholds 1-14
- Controlling the S1 SONET Overhead Byte 1-14
- Running Loopbacks 1-15
- ATM PVC Commands 1-15
  - Specifying a Protocol 1-15
  - Configuring a Broadcast 1-16
  - Configuring Inverse ARP 1-17
  - Attaching an ATM VC Class to a PVC 1-17
  - Configuring VBR-NRT 1-17
  - Specifying Encapsulation 1-18
  - Enabling ILMI Management 1-18
  - Configuring OAM Retry 1-19
  - Enabling OAM Loopback Cell Generation and Management 1-19
- Useful show Commands 1-19

**CHAPTER 2**

**8-Port E3/DS3 ATM Line Card Configuration 2-1**

- Software Support 2-1
  - Checking Hardware and Software Compatibility 2-1
- Default Values 2-2
- Line Card VC Limitations 2-2
- Interface Syntax 2-3
- Line Card Interface Configuration Examples 2-4
  - Creating a Subinterface 2-4
  - Creating a PVC 2-4
  - Creating an ATM VC Class 2-5
  - Applying a VC Class 2-5
  - Enabling ILMI PVC Discovery 2-5
  - Completing a Configuration 2-6
- Line Card Commands 2-6
  - Global Configuration Commands 2-7
  - ATM Interface and Subinterface Commands 2-7
    - Setting the Line Card to E3 or T3 mode 2-8
    - Changing the Mode of the Line Card 2-8
    - Setting the Line Card Framing 2-9
    - Creating and Entering Subinterfaces 2-10
    - Attaching an ATM VC Class to an Interface or Subinterface 2-12
    - Creating ATM PVPs 2-12



Creating a PVC	2-13
Enabling ATM ILMI	2-14
Activating ATM ILMI PVC Discovery	2-14
Specifying the ATM ILMI Keep-Alive Rate	2-14
Configuring the ATM Clock	2-15
Configuring Cable Length	2-15
Controlling ATM Alarm Reporting	2-15
Running Loopbacks	2-16
ATM PVC Commands	2-16
Specifying a Protocol	2-17
Configuring a Broadcast	2-17
Configuring Inverse ARP	2-18
Attaching an ATM VC Class to a PVC	2-18
Configuring VBR-NRT	2-19
Specifying Encapsulation	2-19
Enabling ILMI Management	2-20
Configuring OAM Retry	2-20
Enabling OAM Loopback Cell Generation and Management	2-20
Useful show Commands	2-21

**CHAPTER 3****1-Port OC-12 ATM Line Card Configuration 3-1**

Software Support	3-1
Checking Hardware and Software Compatibility	3-2
Default Values	3-2
Line Card VC Limitations	3-2
Shaped UBRs on the OC-12 ATM Line Card	3-3
Interface Syntax	3-4
Interface Configuration Samples	3-4
Creating a Subinterface	3-4
Creating a PVC	3-5
Creating a VC Class	3-5
Applying a VC Class	3-6
Enabling ILMI PVC Discovery	3-6
Completing a Configuration	3-6
Commands	3-7
Global Configuration Command	3-7
Interface and Subinterface Commands	3-7
Creating and Entering Subinterfaces	3-8
Attaching an ATM VC Class to an Interface	3-9

- Creating ATM PVPs 3-9
- Creating a PVC 3-10
- Enabling ATM ILMI 3-11
- Activating ATM ILMI PVC Discovery 3-11
- Specifying the ATM ILMI Keepalive Rate 3-12
- Configuring ATM Clock 3-12
- Specifying the ATM Flag 3-12
- Controlling ATM Alarm Reporting 3-12
- Specifying the ATM Alarm Thresholds 3-13
- Controlling the S1 SONET Overhead Byte 3-14
- Running Loopbacks 3-14
- ATM PVC Commands 3-15
  - Specifying a Protocol 3-15
  - Configuring a Broadcast 3-16
  - Configuring Inverse ARP 3-16
  - Attaching an ATM VC Class to a PVC 3-17
  - Configuring VBR-NRT 3-17
  - Specifying Encapsulation 3-18
  - Enabling ILMI Management 3-18
  - Configuring OAM Retry 3-18
  - Enabling OAM Loopback Cell Generation and Management 3-19
- Useful show Commands 3-19

**PART 2**

**Channelized Line Cards**

**CHAPTER 4**

**4-Port Channelized T3 Half-Height Line Card Configuration 4-1**

- Software Support 4-1
  - Checking Hardware and Software Compatibility 4-2
- Feature Overview 4-2
- Default Values 4-3
- Interface Syntax 4-4
- Interface Configuration Sample 4-4
- Unchannelized T3 Commands 4-6
  - Configuring a T3 Interface as Unchannelized 4-7
  - Specifying the DSU Mode 4-7
  - Specifying Subrate T3 Bandwidth 4-7
  - Setting the Framing Type 4-8
  - Enabling Scrambling 4-8
  - Specifying an Idle Character 4-8

Configuring a BER Test	4-9
Specifying the Cable Length	4-10
Entering MDL Messages	4-10
Setting the Clock Source	4-11
Configuring Loopback Mode	4-12
Running Equipment Loopbacks	4-12
Channelized T3 Commands	4-12
Configuring a T3 Interface as Channelized	4-13
Specifying the Cable Length	4-14
Setting the Framing Type	4-14
Entering MDL Messages	4-14
Specifying the Idle Pattern	4-15
Setting the Clock Source	4-16
Configuring Loopback Mode	4-16
Running Equipment Loopbacks	4-17
Channel-Group Command for DS0 Time Slots and T1s	4-17
Channelized T1 Commands	4-19
Setting the Framing Format	4-19
Controlling Yellow Alarms	4-19
Setting the Clock Source	4-20
Configuring FDL	4-20
Configuring a BER Test	4-21
Configuring T1 Loopback Mode	4-22
High Availability Using Line Card Redundancy	4-24
Prerequisites for Line Card Redundancy	4-24
Restrictions for Line Card Redundancy	4-24
Configuring Line Card Redundancy	4-24
Verifying and Monitoring Line Card Redundancy	4-25
Performing a Manual Line Card Switchover	4-29
Removing Line Card Redundancy	4-29
Failover Conditions	4-30
Command Reference	4-31
show controllers t3 bert Command	4-31
linecard-group y-cable Command	4-32
member subslot Command	4-33

Commands and Default Values	5-2
E1 Commands	5-2
E1 Interface Numbering Syntax	5-3
T1 Commands	5-4
T1 Interface Numbering Syntax	5-5
Configuration Task Overview	5-6
E1 Configuration Examples	5-6
Configuring an E1 Controller	5-6
Configuring Full-Rate Unchannelized E1 Bandwidths	5-6
Configuring Full-Rate Channelized E1 Bandwidths	5-8
Configuring Fractional Channelized E1 Bandwidths	5-8
Configuring E1 Serial Interfaces	5-9
T1 Configuration Examples	5-10
Configuring a T1 Controller	5-10
Configuring Full-Rate Channelized T1 Bandwidths	5-10
Configuring Fractional Channelized T1 Bandwidths	5-11
Configuring T1 Serial Interfaces	5-11
Command Descriptions	5-12
Privileged EXEC Commands	5-12
Simulating Line Card Installation and Removal	5-13
Displaying Controller Information	5-13
Displaying Interface Information	5-13
Global Configuration Commands	5-14
Preconfiguring a Line Card	5-15
Shutting Down Line Card Simulation	5-16
Configuring a Controller	5-16
Configuring a Serial Interface	5-17
Controller Configuration Commands	5-17
E1 Port Interface Density	5-18
T1 Port Interface Density	5-18
Controller Commands	5-18
Running a BER Test	5-19
Specifying T1 Short-Haul Cable Length	5-20
Specifying Channel Groups	5-21
Specifying a Clock Source	5-24
Adding a Controller Description	5-24
Enabling T1 Facility Data Link Performance Monitoring	5-24
Specifying Framing	5-25
Specifying Linecoding	5-26

**CHAPTER 6**

Specifying Loopbacks	5-27
Specifying E1 National Reserve Bits	5-28
Specifying a T1 Yellow Alarm	5-28
Specifying Shutdown	5-29
<b>1-Port Channelized OC-12/STM-4 Line Card Configuration</b>	<b>6-1</b>
Software Support	6-2
Checking Hardware and Software Compatibility	6-2
SONET Channelization	6-2
SDH Channelization	6-3
Line Card Default Values	6-4
Line Card Default Values for SONET Framing	6-4
Line Card Default Values for SDH Framing	6-6
Line Card Interface Syntax	6-8
SONET-Framed Interface Configuration Sample	6-8
SDH-Framed Interface Configuration Sample	6-10
Show Controller Command Syntax	6-11
AU-3 Controller Interfaces	6-12
AU-4-TUG-3 Controller Interfaces	6-13
Configuring the SONET Controller for SONET or SDH Framing	6-14
Entering Controller-Configuration Mode	6-14
Selecting SONET or SDH Framing	6-15
Configuring the SONET Controller Loopback Mode	6-15
Creating a T3, VT, or AUG Controller	6-15
Designating an STS-1 Path as a T3 or VT under SONET Framing	6-16
Designating an STM-4 Port as an AU-3 or AU-4-TUG-3 Controller under SDH Framing	6-16
VT Commands under SONET Framing	6-17
Entering Controller Configuration Mode for VT	6-17
Unchannelized T3 Commands under SONET or SDH Framing	6-17
Entering Controller Configuration Mode for T3	6-18
Configuring a T3 Interface on a SONET-Framed Controller as Unchannelized	6-18
Implementing Subrate T3	6-19
Setting a Framing Type	6-19
Specifying a DSU Mode	6-19
Enabling Scrambling	6-20
Specifying the Idle Character	6-20
Running a T3 BER Test under SONET or SDH Framing	6-20
Channelized T3 Commands under SONET or SDH Framing	6-21
Entering Controller Configuration Mode for T3	6-21

- Configuring a T3 Interface as Channelized 6-22
- Setting the Framing Type 6-22
- Entering MDL Messages 6-23
- Specifying the Idle Pattern 6-24
- Setting the T3 Clock Source 6-24
- Configuring the Loopback Mode for a T3 Controller 6-25
- Configuring a T3 Controller to Respond to Remote Loopback Commands 6-25
- Creating T1 or E1 Channel Groups under SONET or SDH Framing 6-26
- Creating Channel Groups for T1 SONET-Framed Interfaces 6-26
- Creating Channel-Groups for SDH-Framed Interfaces 6-27
- Channelized T1 Commands under SONET or SDH Framing 6-29
- Setting the Framing Format 6-29
- Controlling Yellow Alarms 6-30
- Setting the T1 Clock Source 6-30
- Configuring FDL 6-30
- Configuring a T1 BER Test 6-31
- Configuring Loopback Mode 6-31

**CHAPTER 7**

**4-Port Channelized OC-3/STM-1 Line Card Configuration 7-1**

- Software Support 7-2
  - Checking Hardware and Software Compatibility 7-2
- SONET Channelization 7-2
- SDH Channelization 7-3
- Default Values 7-4
  - Default Values for SONET Framing 7-4
  - Default Values for SDH Framing 7-6
- Interface Syntax 7-8
- SONET-Framed Interface Configuration Sample 7-8
- SDH-Framed Interface Configuration Sample 7-10
  - Show Controller Command Syntax 7-11
  - AU-3 Controller Interfaces 7-12
  - AU-4-TUG-3 Controller Interfaces 7-13
- Configuring the SONET Controller for SONET or SDH Framing 7-14
  - Entering Controller-Configuration Mode 7-14
  - Selecting SONET or SDH Framing 7-14
  - Configuring the SONET Controller Loopback Mode 7-15
- Creating a T3, VT, or AUG Controller 7-15
  - Designating an STS-1 Path as a T3 or VT under SONET Framing 7-15
  - Designating an STM-4 Port as an AU-3 or AU-4-TUG-3 Controller under SDH Framing 7-16

VT Commands under SONET Framing	7-17
Entering Controller Configuration Mode for VT	7-17
Unchannelized T3 Commands under SONET or SDH Framing	7-17
Entering Controller Configuration Mode for T3	7-18
Configuring a T3 Interface on a SONET-Framed Controller as Unchannelized	7-18
Implementing Subrate T3	7-18
Setting a Framing Type	7-19
Specifying a DSU Mode	7-19
Enabling Scrambling	7-19
Specifying the Idle Character	7-19
Running a T3 BER Test under SONET or SDH Framing	7-20
Channelized T3 Commands under SONET or SDH Framing	7-21
Entering Controller Configuration Mode for T3	7-21
Configuring a T3 Interface as Channelized	7-22
Setting the Framing Type	7-22
Entering MDL Messages	7-23
Specifying the Idle Pattern	7-24
Setting the T3 Clock Source	7-24
Configuring the Loopback Mode for a T3 Controller	7-25
Configuring a T3 Controller to Respond to Remote Loopback Commands	7-25
Creating T1 or E1 Channel Groups under SONET or SDH Framing	7-26
Creating Channel Groups for T1 SONET-Framed Interfaces	7-26
Creating Channel-Groups for SDH-Framed Interfaces	7-27
Channelized T1 Commands under SONET or SDH Framing	7-29
Setting the Framing Format	7-29
Controlling Yellow Alarms	7-30
Setting the T1 Clock Source	7-30
Configuring FDL	7-30
Configuring a T1 BER Test	7-31
Configuring Loopback Mode	7-31

**CHAPTER 8****6-Port Channelized T3 Line Card Configuration 8-1**

Software Support	8-1
Checking Hardware and Software Compatibility	8-2
Default Values	8-2
Interface Syntax	8-3
Interface Configuration Sample	8-3
Unchannelized T3 Commands	8-5
Entering Controller Configuration Mode for T3	8-6

- Configuring a T3 Interface as Unchannelized 8-6
- Implementing Subrate T3 8-6
- Setting the Framing Type 8-7
- Specifying the DSU Mode 8-7
- Enabling Scrambling 8-7
- Specifying an Idle Character 8-8
- Running a BER Test 8-8
- Channelized T3 Commands 8-9
  - Entering Controller Configuration Mode for T3 8-9
  - Configuring a T3 Interface as Channelized 8-10
  - Specifying the Cable Length 8-10
  - Setting the Framing Type 8-11
  - Entering MDL Messages 8-11
  - Specifying the Idle Pattern 8-12
  - Setting the Clock Source 8-13
  - Configuring Loopback Mode 8-13
  - Running Equipment Loopbacks 8-14
- Channel-Group Command for DS0 Timeslots and T1s 8-14
- Channelized T1 Commands 8-15
  - Setting the Framing Format 8-16
  - Controlling Yellow Alarms 8-16
  - Setting the Clock Source 8-17
  - Configuring FDL 8-17
  - Configuring a BER Test 8-17
  - Configuring Loopback Mode 8-18

---

**PART 3**

**Fast Ethernet and Gigabit Ethernet  
Line Cards**

---

**CHAPTER 9**

**8-Port Fast Ethernet Half-Height Line Card Configuration 9-1**

- Software Support 9-1
  - Checking Hardware and Software Compatibility 9-2
- Default Values 9-2
- Management Port 9-2
- Configuring the Interface 9-3
  - Specifying the Interface for Configuration 9-3
  - Configuring the IP Address 9-4
  - Specifying Full or Half Duplex Mode 9-4
  - Configuring 802.1Q VLAN Encapsulation 9-4



	Configuring Routing	9-4
	Saving the Configuration	9-5
	Viewing the Configuration	9-5
	Disabling the Interface	9-5
<b>CHAPTER 10</b>	<b>1-Port Gigabit Ethernet Half-Height Line Card Configuration</b>	<b>10-1</b>
	Software Support	10-1
	Checking Hardware and Software Compatibility	10-2
	Default Values	10-2
	Interface Syntax	10-2
	Configuring an Interface	10-3
	Configuration Commands	10-3
	Specifying Auto-Negotiation	10-3
	Assigning a MAC Address	10-4
	Setting and Changing Loopback Mode	10-4
<b>CHAPTER 11</b>	<b>1-Port Gigabit Ethernet Line Card Configuration</b>	<b>11-1</b>
	Software Support	11-1
	Checking Hardware and Software Compatibility	11-2
	Default Values	11-2
	Interface Syntax	11-2
	Configuring an Interface	11-3
	Configuration Commands	11-3
	Specifying Auto-Negotiation	11-4
	Assigning a MAC Address	11-4
	Setting and Changing Loopback Mode	11-5
<b>PART 4</b>	<b>Packet over SONET Line Cards</b>	
<b>CHAPTER 12</b>	<b>6-Port OC-3/STM-1 Packet over SONET Line Card Configuration</b>	<b>12-1</b>
	Software Support	12-1
	Checking Hardware and Software Compatibility	12-2
	Default Values	12-2
	Interface Syntax	12-3
	Configuring the Interface	12-3
	Configuration Commands	12-4
	Setting the Clock Source	12-4

- Configuring Framing 12-4
- Specifying SONET Overhead 12-5
- Controlling the S1 SONET Overhead Byte 12-5
  - Controlling a Transmitted S1 Overhead Byte 12-5
  - Reacting to a Received S1 Overhead Byte 12-5
- Configuring Packet over SONET SPE Scrambling 12-6
- Configuring Loopback Testing 12-6
- Configuring APS 12-7

**CHAPTER 13**

**1-Port OC-12 Packet over SONET Line Card Configuration 13-1**

- Software Support 13-1
  - Checking Hardware and Software Compatibility 13-2
- Default Values 13-2
- Interface Syntax 13-3
- Configuring the Interface 13-3
- Other Configuration Commands 13-4
  - Setting the Clock Source 13-4
  - Configuring Framing 13-4
  - Specifying SONET Overhead 13-4
  - Controlling the S1 SONET Overhead Byte 13-5
    - Controlling a Transmitted S1 Overhead Byte 13-5
    - Reacting to a Received S1 Overhead Byte 13-5
  - Configuring Packet over SONET SPE Scrambling 13-6
  - Configuring Loopback Testing 13-6

**CHAPTER 14**

**1-Port OC-48/STM-16 Packet over SONET Line Card Configuration 14-1**

- Software Support 14-1
  - Checking Hardware and Software Compatibility 14-2
- Default Values 14-2
- SDCC Default Values 14-2
- Interface Syntax 14-3
- Configuring the Interface 14-3
- MAC Protocol Selection Command 14-4
- Interface Configuration Mode Command 14-4
- SDCC Interface Configuration Commands 14-5
  - Enabling the SDCC Interface Configuration Mode 14-5
  - Enabling an SDCC Interface 14-5
  - Interface Selection Command 14-5

Enabling Loopback Tests	14-6
Configuring CRC Size	14-6
Configuring MTU Size	14-6
Configuring Hold Queue Size	14-7
Other Configuration Commands	14-7
Setting the Clock Source	14-7
Configuring Framing	14-7
Configuring SONET Overhead	14-8
Configuring Packet over SONET SPE Scrambling	14-8
Configuring Loopback Testing	14-8

**PART 5****Unchannelized Line Card****CHAPTER 15****8-Port Unchannelized E3/T3 Line Card Configuration 15-1**

Software Support	15-1
Checking Hardware and Software Compatibility	15-2
Default Values	15-2
Naming Convention	15-3
Interface Syntax	15-3
Configuration Task Overview	15-4
Configuration Examples	15-5
Configuring an E3 Interface	15-5
Configuring a T3 Interface	15-5
Controller Configuration Commands	15-6
Cablelength Command	15-6
Clock Source Command	15-7
Controller Description Command	15-7
Controller dsx3mode Command	15-8
Shutdown Command	15-8
Interface Configuration Commands	15-8
Running a BER Test	15-9
Interface Description Command	15-10
Specifying DSU Mode	15-10
Specifying DSU Bandwidth	15-11
Creating a Subrate E3 or T3 Interface	15-11
Encapsulation Command	15-11
Equipment Loopback Command	15-12
Fallback-Clocking Command	15-12
Setting the Framing Type	15-13

Specifying the Idle-Character 15-13  
 Performing Loopback Tests 15-14  
 Entering MDL Messages 15-14  
 Setting the National Bit 15-16  
 Enabling Scrambling 15-16

**PART 6**

**Configuration Notes and Examples**

**CHAPTER 16**

**Preparing for Line Card Installation and Configuration 16-1**

Treatment of Newly Inserted Line Cards 16-1  
 Preprovisioning Line Card Slots 16-2  
     Changing the Provisioning of a Line Card Slot 16-2  
     Feature History for Line Card Slot Preprovisioning 16-2  
     card Command 16-3  
 Resetting Line Cards 16-5

**CHAPTER 17**

**Provisioning a Subrate E3 or T3 Interface 17-1**

Implementing a Subrate T3 or E3 Interface 17-1  
 Subrate T3 Bandwidth Tables 17-2  
 Subrate E3 Bandwidth Tables 17-26

**CHAPTER 18**

**Configuration Examples 18-1**

Example 1: Configuring an Unchannelized Subrate T3 Port, Point to Multipoint Frame Relay, and OSPF 18-1  
 Example 2: OSPF, BGP, Channelized Full Rate T1 18-3  
 Example 3: Quality of Service Policy Propagation Using Border Gateway Protocol 18-5  
 Example 4: MPLS Virtual Private Networks 18-8

**GLOSSARY**

**INDEX**



## About This Guide

---

This guide describes how to configure Cisco 10000 series router line cards. For information about features that are supported on the Cisco 10000 series router using the line cards, such as ATM PVC autoprovisioning, automatic protection switching (APS), or quality of service (QoS), see the following configuration guides:

- *Cisco 10000 Series Router Software Configuration Guide* at the following URL:  
<http://www.cisco.com/en/US/docs/routers/10000/10008/configuration/guides/broadband/bba.html>
- *Cisco 10000 Series Router Quality of Service Configuration Guide* at the following URL:  
<http://www.cisco.com/en/US/docs/routers/10000/10008/configuration/guides/qos/qoscf.html>

This document describes the following topics:

- [Guide Revision History](#), page xvii
- [Audience](#), page xix
- [Document Organization](#), page xix
- [Document Conventions](#), page xix
- [Related Documentation](#), page xx
- [Obtaining Documentation and Submitting a Service Request](#), page xxi

## Guide Revision History

Cisco IOS Release	Part Number	Publication Date
Release 12.2(31)SB2	OL-8834-04	November, 2006

### Description

Added Performance Routing Engine 3 (PRE3) support information for the 1-Port Gigabit Ethernet, 1-Port Gigabit Ethernet Half-Height, 1-Port OC-12, and 1-Port Channelized OC-12/STM-4 line cards.

Added VC limitations per priority level per port for the 1-port OC-12, 4-port OC-3, and 8-port E3/DS3 ATM line cards.

Cisco IOS Release	Part Number	Publication Date
Release 12.2(28)SB2	OL-8834-03	July, 2006

**Description**

Added the “[Management Port](#)” section on page 9-2 of [Chapter 9, “8-Port Fast Ethernet Half-Height Line Card Configuration](#)” to indicate that the Fast Ethernet interface 0/0/0 is only used for management purposes. Subinterfaces cannot be configured on this interface.

Changed the format of the Guide Revision History.

Cisco IOS Release	Part Number	Publication Date
Release 12.2(28)SB	OL-8834-02	March, 2006

**Description**

Added [Chapter 4, “4-Port Channelized T3 Half-Height Line Card Configuration](#)”.

Added the 4-Port Channelized T3 Half-Height line card to the list of supported line cards in [Chapter 17, “Provisioning a Subrate E3 or T3 Interface](#)”.

Added the “Controlling the S1 SONET Overhead Byte” section to the configuration chapters for the: 4-Port OC-3/STM-1 ATM line card, 1-Port OC-12 ATM line card, 6-Port OC-3/STM-1 Packet over SONET line card, and 1-Port OC-12 Packet over SONET line card.

Removed a chapter on configuring MLP connections. Refer to the MLP information in the [Cisco 10000 Series Router Software Configuration Guide](#) and the [Cisco 10000 Series Quality of Service Configuration Guide](#).

Cisco IOS Release	Part Number	Publication Date
Release 12.3(7)XI7	OL-8834-01	December, 2005

**Description**

Retired OL-0716-10 and created this guide with the same organization as the [Cisco 10000 Series Router Line Card Hardware Installation Guide](#), using a book part for each type of line card, such as ATM.

Because more up-to-date and complete information is included in the [Cisco 10000 Series Router Software Configuration Guide](#) and the [Cisco 10000 Series Quality of Service Configuration Guide](#), the Qos and APS chapters were not ported to the new guide.

Removed several sections that have been moved to more appropriate locations in other guides:

- Configuring the router at startup (moved to the [Cisco 10008 Quick Start Guide](#) and the [Cisco 10008 Router Hardware Installation Guide](#))
- Managing file systems (moved to the [Cisco 10008 Quick Start Guide](#) and the [Cisco 10008 Router Hardware Installation Guide](#))
- Managing PRE redundancy (moved to the [Cisco 10000 Series Router Performance Routing Engine Installation](#))
- Upgrading software (moved to the [Cisco 10000 Series Router Performance Routing Engine Installation](#))
- Managing system boot parameters (moved to the [Cisco 10008 Router Hardware Installation Guide](#))

Incorporated information on provisioning a subrate E3 or T3 interface, formerly documented in a feature guide, as [Chapter 17, “Provisioning a Subrate E3 or T3 Interface](#)” in this guide.

Added the minimum IOS releases that are supported by each line card.

Revised information for preprovisioning a line card.

## Audience

The Cisco 10000 Series Router Line Card Configuration Guide is designed for the person who will configure and maintain the line cards on a Cisco 10000 series router. To benefit from this guide, this person must be experienced using Cisco IOS.

## Document Organization

The *Cisco 10000 Series Router Line Card Configuration Guide* is organized as follows:

Chapter	Title	Description
Chapter 1 -15	Line card configuration	Each chapter provides configuration information for a specific Cisco 10000 series router line card, including minimum software release information, hardware and software compatibility information, and the commands you use to configure the line card.
Chapter 16	Preparing for Line Card Installation and Configuration	Describes the treatment of a new line card, preprovisioning a line card, and resetting a line card.
Chapter 17	Provisioning a Subrate E3 or T3 Interface	Describes provisioning a subrate E3 or T3 interface.
Chapter 18	Configuration Examples	Provides several large configuration examples.

## Document Conventions

This document uses the following conventions:

Convention	Description
^ or Ctrl	The ^ and Ctrl symbols represent the Control key. For example, the key combination ^D or Ctrl-D means hold down the Control key while you press the D key. Keys are indicated in capital letters but are not case sensitive.
<i>string</i>	A string is a nonquoted set of characters shown in italics. For example, when setting an SNMP community string to public, do not use quotation marks around the string or the string will include the quotation marks.

Command syntax descriptions use the following conventions:

Convention	Description
<b>bold</b>	Bold text indicates commands and keywords that you enter literally as shown.
<i>italics</i>	Italic text indicates arguments for which you supply values.
[x]	Square brackets enclose an optional element (keyword or argument).
	A vertical line indicates a choice within an optional or required set of keywords or arguments.

Convention	Description
[x   y]	Square brackets enclosing keywords or arguments separated by a vertical line indicate an optional choice
{x   y}	Braces enclosing keywords or arguments separated by a vertical line indicate a required choice.

Nested sets of square brackets or braces indicate optional or required choices within optional or required elements. For example:

Convention	Description
[x {y   z}]	Braces and a vertical line within square brackets indicate a required choice within an optional element.

Examples use the following conventions:

Convention	Description
screen	Examples of information displayed on the screen are set in Courier font.
<b>bold screen</b>	Examples of text that you must enter are set in Courier bold font.
< >	Angle brackets enclose text that is not printed to the screen, such as passwords.
!	An exclamation point at the beginning of a line indicates a comment line. (Exclamation points are also displayed by the Cisco IOS software for certain processes.)
[ ]	Square brackets enclose default responses to system prompts.

The following conventions are used to attract the attention of the reader:



**Caution**

Means reader be careful. In this situation, you might do something that could result in equipment damage or loss of data.



**Note**

Means reader take note. Notes contain helpful suggestions or references to materials not contained in this manual.

## Related Documentation

For more information about the Cisco 10000 series router, its features, and hardware, go to the Cisco 10000 series router documentation roadmap, located at the following URL:

[http://www.cisco.com/en/US/products/hw/routers/ps133/products\\_documentation\\_roadmap09186a00804ba4f3.html](http://www.cisco.com/en/US/products/hw/routers/ps133/products_documentation_roadmap09186a00804ba4f3.html)

For information about Cisco IOS Release 12.2, including command reference and system error messages, go to the Cisco IOS Release 12.2 documentation web page, located at the following URL:



[http://www.cisco.com/en/US/products/sw/iosswrel/ps1835/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/sw/iosswrel/ps1835/tsd_products_support_series_home.html)

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.





## **PART 1**

### **ATM Line Cards**





# CHAPTER 1

## 4-Port OC-3/STM-1 ATM Line Card Configuration

This chapter describes the procedures for configuring the Cisco 10000 series 4-Port OC-3/STM-1c ATM line card, hereafter known as the 4-Port OC-3/STM-1 ATM line card.

The 4-Port OC-3/STM-1 ATM line card is a NEBS-compliant device that performs Layer 2 Asynchronous Transfer Mode (ATM) functions. This line card receives and transmits ATM cells on each network physical interface connected to a line card port, and simultaneously transmits and receives packets from the Cisco 10000 series router backplane.

This chapter contains the following sections:

- [Software Support, page 1-1](#)
- [Default Values, page 1-2](#)
- [Line Card VC Limitations, page 1-2](#)
- [Interface Syntax, page 1-3](#)
- [Interface Configuration Examples, page 1-4](#)
- [ATM Commands, page 1-6](#)

## Software Support

[Table 1-1](#) shows the minimum Cisco IOS release on each release train that supports the 4-Port OC-3/STM-1 ATM line card.

**Table 1-1** 4-Port OC-3/STM-1 ATM Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE1	Cisco IOS Release 12.0(21)SX and later releases of Cisco IOS Release 12.0SX Cisco IOS Release 12.0(20)ST and later releases of Cisco IOS Release 12.0ST Cisco IOS Release 12.0(22)S and later releases of Cisco IOS Release 12.0S Cisco IOS Release 12.2(8)BZ and later releases of Cisco IOS Release 12.2BZ
PRE2	Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS 12.3XI Cisco IOS Release 12.2(15)BX and later releases of Cisco IOS Release 12.2BX Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Default Values

Table 1-2 lists default configuration values for the 4-Port OC-3/STM-1 ATM line card. This table also includes the command used to modify a default value, and provides information about values to set on the remote end of the connection.

**Table 1-2** 4-Port OC-3/STM-1 ATM line card Defaults

Command Name	Default Setting	Command Syntax	Remote Side Setting
mtu (maximum transmission unit)*	4470 bytes	[no] mtu bytes	same
atm clock internal	no atm clock internal	[no] atm clock internal	opposite
loopback	loopback none	[no] loopback [line   diagnostic {parallel   path   serial}]	—

## Line Card VC Limitations

The Cisco 10000 series router supports four ATM service categories for virtual circuits (VCs):

- Constant Bit Rate (CBR)
- Variable Bit Rate-non-real-time (VBR-nrt)
- Unspecified Bit Rate (UBR) with a peak cell rate (PCR), referred to as shaped UBR
- UBR without a PCR, referred to as unshaped UBR

The segmentation and reassembly (SAR) mechanism configures priority and additional traffic management parameters for the various ATM service categories. Table 1-3 lists the priority levels the SAR sets for the service categories.

**Table 1-3** ATM Service Categories

Parameter	CBR	VBR-rt	VBR-nrt	Shaped UBR	Unshaped UBR
Priority	0	1	2	3	None

The number of SAR priority levels and the service categories supported at each priority level vary from line card to line card. For example, the 4-port OC-3 line card supports the two levels of priority and the service categories listed in [Table 1-4](#).

The ATM line cards support a maximum number of VCs per priority. That VC limit depends on the VC limit of the SAR (SAR limit) and the number of priority levels configured. [Table 1-4](#) describes how to determine the VC limit per priority level per port for the 4-port OC-3 line card.

**Table 1-4** Maximum Number of VCs per Priority

ATM Line Card	SAR Priority Levels	VC Rate	Maximum Number of VCs per Priority
4-Port OC-3	0 = CBR, VBR-nrt VCs 1 = UBR VCs	Half line rate and below	SAR limit / number of PHYs / number of priority levels 2 priority system: $65,536 / 4 / 2 = 8192$ VCs per priority level per port

Configuring more channels or VCs than there are available priority locations can cause random channels or VCs to get stuck in the SAR. This occurs when an active channel tries to reschedule itself, but no priority locations are available. Therefore, the channel cannot find a place to reschedule itself, which results in a lost event for the channel, and the channel becomes stuck in the SAR.

On the PRE2, when a VC becomes stuck in the SAR, the PRE2 scheduler stops forwarding traffic on only the VC that is stuck in the SAR; the other VCs still carry traffic. On the PRE3, the PRE3 scheduler stops forwarding traffic on all the VCs configured on that ATM line card.

## Interface Syntax

To specify an interface number in a configuration command, use the syntax in [Table 1-5](#) to identify main interfaces and subinterfaces on the 4-Port OC-3/STM-1 ATM line card in Cisco Series 10000 routers.

**Table 1-5** 4-Port OC-3 ATM Interface Syntax

Type of Interface	Router	Slot	Subslot	Port	Subinterface
Main interface	10008	1 through 8/	0/	0 to 3	—
Subinterface	10008	1 through 8/	0/	0.n to 3.n	n = 1 to 4294967295
Main interface	10005	1 through 5/	0/	0 to 3	—
Subinterface	10005	1 through 5/	0/	0.n to 3.n	n = 1 to 4294967295

Examples:

- Modify a PVC associated with the main interface.

```
Router(config)# interface atm 2/0/0
Router(config-if)# pvc 0/200
Router(config-if-atm-vc)#
```

- Modify a permanent virtual circuit (PVC) associated with a subinterface.

```
Router(config)# interface atm 7/0/0.1
Router(config-subif)# pvc 0/101
Router(config-if-atm-vc)#
```

# Interface Configuration Examples

This section provides sample procedures for creating ATM subinterfaces, permanent virtual circuits (PVCs), and virtual circuit (VC) classes, and procedures for enabling Integrated Local Management Interface (ILMI).

## Creating a Subinterface

Use the following procedure to create a subinterface.

- Step 1** Separate the ATM interface into subinterfaces using the **interface** command. You can create either a point-to-point or multipoint subinterface.

In the following example, multipoint subinterface number 1 is created on port 0 of the 4-Port OC-3/STM-1 ATM line card in slot 2.

```
Router(config)# interface atm 2/0/0.1 multipoint
Router(config-subif)#
```

- Step 2** Assign an IP address and subnet mask to the created interface using the **ip address** configuration subcommand, as shown in the following example:

```
Router(config-subif)# ip address 172.27.48.209 255.255.0.0
Router(config-subif)#
```

You have created ATM subinterface 2/0/0.1. To configure or modify this interface, use the following command:

```
Router(config)# interface atm 2/0/0.1
Router(config-subif)#
```

## Creating a PVC

You can create multiple PVCs on a 4-Port OC-3/STM-1 ATM line card interface. You can create PVCs on the main interface or on a subinterface.

To create a PVC

- Step 1** Enter interface or subinterface configuration mode.

Use the **pvc** command to specify a virtual path identifier (VPI) value between 0 and 255 and a virtual channel identifier (VCI) value between 0 and 65535. The following example shows how to create a PVC with a VPI value of 0 and VCI value of 100 on a subinterface.

```
Router(config-subif)# pvc 0/100
Router(config-if-atm-vc)#
```

- Step 2** Use the **protocol ip** configuration subcommand to assign a peer IP address to the PVC, as shown in the following example:

```
Router(config-if-atm-vc)# protocol ip 172.16.32.49
Router(config-if-atm-vc)#
```



## Creating a VC Class

This procedure demonstrates how to create an ATM VC class. An ATM VC class is a PVC boilerplate—a PVC description that you can apply to one or more PVCs.

To create a PVC boilerplate:

- Step 1** Use the global configuration mode **vc-class atm name** command, where *name* is the name value you assign. The following example shows how to create the ATM VC class named *boston*.

```
Router(config)# vc-class atm boston
Router(config-vc-class)#
```

- Step 2** Enter commands to describe the ATM VC class you named *boston*. This example shows how to specify that the *boston* class uses AAL5+MUX encapsulation with a variable bit-rate non real-time (VBR-NRT) PVC.

```
Router(config-vc-class)# encaps aal5mux ip
Router(config-vc-class)# vbr-nrt 30000 20000 128
Router(config-vc-class)# exit
Router(config)#
```

You have created a VC class named *boston*. The next procedure describes how to apply this class to a PVC or subinterface.

## Applying a VC Class

You can apply a VC class (created in the previous procedure) to a PVC or an interface.

- In the following example, the class named *boston* is applied to subinterface 5/0/0.1.

```
Router(config)# interface atm 5/0/0.1
Router(config-subif)# class-int boston
Router(config-subif)#
```

- In the following example, the class named *boston* is applied to a new PVC (0/102) in subinterface 5/0/0.2.

```
Router(config)# interface atm 5/0/0.2
Router(config-subif)# pvc 0/102
Router(config-if-atm-vc)# class-vc boston
Router(config-if-atm-vc)#
```

You have completed the steps for assigning a VC class to a PVC.

## Enabling ILMI PVC Discovery

You can enable ILMI to automatically discover PVCs on neighboring switches and duplicate those PVC entries on the 4-Port OC-3/STM-1 ATM line card.

To enable ILMI:

**Step 1** Create PVC 0/16 on the main interface as shown in the following example:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/16 ilmi
Router(config-if-atm-vc)# exit
Router(config-if)#
```

**Step 2** In the following example, ILMI PVC discovery is enabled for the selected port on the 4-Port OC-3/STM-1 ATM line card (step 1 references port 0).

```
Router(config-if)# atm ilmi-pvc-discovery
```

You have completed the steps required for running ILMI PVC discovery. You can use the **show atm pvc** command to display the PVCs on the Cisco 10000 series router.

## Completing a Configuration

This section offers general information on creating and completing a configuration of an 4-Port OC-3/STM-1 ATM line card.

To configure and interface:

**Step 1** Enter interface configuration mode and then specify necessary parameters, such as the IP address and subnet mask.

**Step 2** After you enter all of the configuration subcommands to complete the configuration, enter **Ctrl-Z** (hold down the **Control** key while you press **Z**) to exit configuration mode.

**Step 3** Write the new configuration to memory:

```
Router# copy running-config startup-config
```

The system displays an OK message when the configuration is stored. After you have completed your configuration, you can check it by using **show** commands.

## ATM Commands

Each 4-Port OC-3/STM-1 ATM line card permits you to specify up to four OC-3 interfaces. You can put all the PVCs on the main interfaces, or you can create associated subinterfaces. This section describes the principal commands for customizing interfaces and PVCs:

- [Global Configuration Command, page 1-7](#)
- [Interface and Subinterface Commands, page 1-7](#)
- [ATM PVC Commands, page 1-15](#)
- [Useful show Commands, page 1-19](#)

## Global Configuration Command

A PVC boilerplate is a PVC description that you can apply to one or more PVCs or interfaces.

To create a PVC boilerplate, use the global configuration mode **vc-class atm** command:

```
vc-class atm class_name
```

Where *class\_name* is any value that describes the VC class.

After you enter the **vc-class atm** command, you are placed in VC class configuration mode. In this mode, you describe the action you want the class to take by entering commands and their arguments. These commands and arguments are described in the “[ATM PVC Commands](#)” section on page 1-15.

In the following example, an ATM VC class named *cambridge* is created and defined. This example shows how to specify that the class uses AAL5+MUX encapsulation and a VBR-NRT PVC.

```
Router(config)# vc-class atm cambridge
Router(config-vc-class)# encaps aal5mux ip
Router(config-vc-class)# vbr-nrt 30000 20000 128
Router(config-vc-class)# exit
Router(config)#
```

For information on applying a VC class name, see the “[Attaching an ATM VC Class to an Interface](#)” section on page 1-9 and the “[Attaching an ATM VC Class to a PVC](#)” section on page 1-17.

## Interface and Subinterface Commands

This section describes principal commands for configuring ATM interfaces and subinterfaces. This section describes the following global configuration commands:

- [Creating and Entering Subinterfaces](#), page 1-8
- [Attaching an ATM VC Class to an Interface](#), page 1-9
- [Creating ATM PVPs](#), page 1-10
- [Creating a PVC](#), page 1-10
- [Enabling ATM ILMI](#), page 1-11
- [Activating ATM ILMI PVC Discovery](#), page 1-11
- [Specifying the ATM ILMI Keepalive Rate](#), page 1-12
- [Configuring the ATM Clock](#), page 1-12
- [Specifying the ATM Flag](#), page 1-12
- [Controlling ATM Alarm Reporting](#), page 1-13
- [Specifying the ATM Alarm Thresholds](#), page 1-14
- [Controlling the S1 SONET Overhead Byte](#), page 1-14
- [Running Loopbacks](#), page 1-15

## Creating and Entering Subinterfaces

Use the **interface** command to segment an OC-3 ATM main interface into multiple subinterfaces to simplify line card management, to create interfaces with different MTU sizes, and to create connections to different networks.

```
interface atm slot/subslot/port.subinterface type
no interface atm slot/subslot/port.subinterface type
```

Where:

- *slot* is 1 to 5 for a Cisco 10005 router
- *slot* is 1 to 8 for a Cisco 10008 router
- *subslot* is always 0 for a full-height line card
- *port* is 0 to 3
- *subinterface* is a value from 1 to 4294967295
- *type* is always **point-to-point** or **multipoint**

To enter the subinterface at a later time, you do not need to specify the type.

To remove a subinterface and its PVCs, use the **no interface** command. To change a subinterface type, you must first remove the subinterface.

Examples:

- Create subinterface number 1 at port 3 for 4-Port OC-3/STM-1 ATM line card in slot 1.

```
Router(config)# interface atm 1/0/3.1 point-to-point
Router(config-subif)#
```

- Enter an existing subinterface.

```
Router(config)# interface atm 1/0/3.1
Router(config-subif)#
```

- Use a multipoint subinterface.


If you want multiple PVCs to go to the same network, you must create a multipoint subinterface. For example:

```
Router(config)# interface atm 4/0/2.2 multipoint
Router(config-subif)#
```

After you create the subinterface, you can create PVCs that are attached to the same network.

[Figure 1-1](#) shows a multipoint subinterface on a fully meshed network. Fully meshed indicates that any workstation can communicate with any other workstation.

Figure 1-1 Multipoint ATM Configuration



The following example commands for routers A, B, and C show how to configure the ATM interfaces for each router shown in Figure 1-1. These examples show the configuration commands you must enter to configure the multipoint connections in that network:

#### Router A

```
Router(config) # interface atm 4/0/0.2 multi
Router(config-subif) # ip address 131.108.168.1 255.255.255.0
Router(config-subif) # pvc 0/35
Router(config-if-atm-vc) # protocol ip 131.108.168.2 broadcast
Router(config-if-atm-vc) # en
Router(config-subif) # pvc 0/36
Router(config-if-atm-vc) # protocol ip 131.108.168.3 broadcast
Router(config-if-atm-vc) # en
Router(config-subif) # en
```

#### Router B

```
Router(config) # interface atm 2/0/0.1 multi
Router(config-subif) # ip address 131.108.168.2 255.255.255.0
Router(config-subif) # pvc 0/35
Router(config-if-atm-vc) # protocol ip 131.108.168.1 broadcast
Router(config-if-atm-vc) # en
Router(config-subif) # pvc 0/37
Router(config-if-atm-vc) # protocol ip 131.108.168.3 broadcast
Router(config-if-atm-vc) # en
Router(config-subif) # en
```

#### Router C

```
Router(config) # interface atm 5/0/0.1 multi
Router(config-subif) # ip address 131.108.168.3 255.255.255.0
Router(config-subif) # pvc 0/36
Router(config-if-atm-vc) # protocol ip 131.108.168.1 broadcast
Router(config-if-atm-vc) # en
Router(config-subif) # pvc 0/37
Router(config-if-atm-vc) # protocol ip 131.108.168.2 broadcast
Router(config-if-atm-vc) # ex
Router #
```

## Attaching an ATM VC Class to an Interface

Use the **class-int** command to attach an ATM VC class to an interface. If you customize a PVC, its customization takes precedence over the interface class.

```
class-int class_name
```

Where *class\_name* is the name of the class created using the global configuration **class-vc atm** command.

In the following example, a VC class named *cambridge* is created and attached to subinterface 3/0/0.1.

```
Router(config)# vc-class atm cambridge
Router(config-vc-class)# encaps aal5mux ip
Router(config-vc-class)# vbr-nrt 30000 20000 128
Router(config-vc-class)# exit
Router(config)# interface atm 3/0/0.1
Router(config-subif)# class-int cambridge
```

## Creating ATM PVPs

To create a permanent virtual path (PVP) used to multiplex one or more VBR-NRT VCs, use the **atm pvp** interface configuration command.

```
atm pvp vpi peak-rate [no-f4-oam]
no atm pvp vpi
```

Where:

- **vpi** is the ATM network virtual path identifier (VPI) of the VC used to multiplex the permanent virtual path. The range is 0 to 255. You must use a VPI value that is not already in use (by a VC).
- *peak-rate* is the maximum rate in Kbps at which the PVP can transmit data. You can enter values from 84 Kbps to 74,880 Kbps, and you can also enter 149,760 Kbps. The PVP peak rate value supersedes all rate values set for VBR-NRT PVCs associated with the PVP.
- **no-f4-oam** (optional) restricts the PVP from passing operations/administration/maintenance (OAM) packets. When you create a PVP, the system creates (by default) PVCs with VCI values of 3 and 4 for each PVP, which pass OAM packets.

To verify the configuration of a PVP, use the **show atm vp exec** command.

The following example shows how to create a PVP with a peak rate of 50,000 Kbps. The subsequent created VCs are multiplexed onto this virtual path.

```
Router(config)# interface atm 7/0/0
Router(config-if)# atm pvp 25 50000
Router(config-if)# pvc 25/100
Router(config-if-atm-vc)# vbr-nrt 10000 5000 16
Router(config-if-atm-vc)# exit
Router(config-if)# pvc 25/101
Router(config-if-atm-vc)# vbr-nrt 10000 5000 16
Router(config-if-atm-vc)# exit
Router(config-if)# pvc 25/102
Router(config-if-atm-vc)# vbr-nrt 10000 5000 16
Router(config-if-atm-vc)# exit
Router(config)#
```

## Creating a PVC

This section describes how to create a permanent virtual circuit.



### Note

You can only create one PVC on a point-to-point interface. Multiple PVCs can be created on a multipoint interface.

You can establish an unspecified bit rate (UBR) PVC by entering the **pvc** command:

```
pvc [word] [vpi_value/]{vci_value} [ilmi]
```

Where:

- *vpi\_value* is in the range from 0 to 255. If you do not specify a VPI value, the system assigns the value 0.
- *vci\_value* is in the range 1 to 65535. The VCI value should be 33 or greater because all lower-numbered PVCs are already assigned.
- *word* is an optional name referring to this connection.
- **ilmi** parameter maps the ILMI channel to the PVC for this interface. You can only use this argument for PVCs created on the main interface. We recommend that you use this argument with PVC 0/16. For more information about activating ILMI, see the [“Activating ATM ILMI PVC Discovery” section on page 1-11](#).

By default, the **pvc** command creates a UBR PVC. To specify a VBR-NRT PVC, see the [“Configuring VBR-NRT” section on page 1-17](#).

Examples:

- Create PVC 0/105 on the main interface.

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 105
Router(config-if-atm-vc)
```

- Create PVC 2/102 on a subinterface.

```
Router(config)# interface atm 5/0/0.1
Router(config-subif)# pvc 2/102
Router(config-if-atm-vc)#
```

## Enabling ATM ILMI

Use the **atm ilmi-enable** interface configuration command to enable ILMI on a port.

```
atm ilmi-enable
no atm ilmi-enable
```

The default is ILMI is enabled, but you should disable the ILMI if the peer does not support ILMI. For peers to be able to exchange ILMI information, you must create PVC 0/16 using the **ilmi** argument.

The following example shows how to disable ILMI:

```
Router(config)# interface atm 5/0/0
Router(config-if)# no atm ilmi-enable
```

## Activating ATM ILMI PVC Discovery

This command causes ILMI-compliant devices to propagate PVCs. Use the **atm ilmi-pvc-discovery** interface configuration command to activate ATM PVC discovery.

```
atm ilmi-pvc-discovery [subinterface]
no atm ilmi-pvc-discovery [subinterface]
```

Where:

- **subinterface** instructs the software to associate all PVCs with existing subinterface numbers equal to their VPI numbers. For example: PVC 2/102 would be listed under subinterface 7/0/0.2, PVC 12/156 would be listed under 7/0/0.12, and so on.



**Note** The **subinterface** argument associates PVCs only with subinterfaces that have already been created. If there is no subinterface for a VPI value, the system associates the PVC with the main interface.

The following example shows how to enable PVC discovery on the ATM main interface 7/0/0, for port 0, on a 4-Port OC-3/STM-1 ATM line card that has ILMI enabled.

```
Router(config)# interface atm 7/0/0
Router(config-if)# pvc 0/16 ilmi
Router(config-if-atm-vc)# exit
Router(config-if)# atm ilmi-pvc-discovery
```

## Specifying the ATM ILMI Keepalive Rate

Use the **atm ilmi-keepalive** command to specify the ILMI keepalive rate.

```
atm ilmi-keepalive [seconds [retry counts]]
```

Where:

- *seconds* is a value from 1 to 65535
- **retry counts** is a value from 2 to 5

The default value for seconds is 5000 and for retry counts is 4.

The following example shows how to enable ILMI keepalives for the ATM interface 5/0/0:

```
Router(config)# interface atm 5/0/0
Router(config-if)# atm ilmi-keepalive 10000 retry 3
```

## Configuring the ATM Clock

Use the **atm clock internal** command to configure the clock source as internal.

```
atm clock internal
no atm clock internal
```

The default clock setting is **no atm clock internal**, which means that clocking is derived from the line.

In the following example, clocking is set from the router.

```
Router(config)# interface atm 5/0/0
Router(config-if)# atm clock internal
```

## Specifying the ATM Flag

This command is typically used to meet a standards requirement or to ensure interoperability with another vendor's equipment. Use the **atm flag s1s0** command to specify the ATM flag value for the s1 and s0 bits.

```
atm flag s1s0 value
```



Where:

- **s1s0** is part of the payload pointer byte
- *value* is from 0 to 3

The default s1s0 value is 0.

The following example shows how to assign a value of 2 to the ATM flag:

```
Router(config)# interface atm 5/0/0
Router(config-if)# atm flag s1s0 2
```

## Controlling ATM Alarm Reporting

To control selected SONET alarms so that they are logged to the console for an ATM interface, use the **atm report** interface configuration command.

```
atm report {b1-tca | b2-tca | b3-tca | lais | lcd | lrldi | pais | plop | prdi | rdool |
sd-ber | sf-ber | slof | slos}
```

```
no atm report {b1-tca | b2-tca | b3-tca | lais | lcd | lrldi | pais | plop | prdi | rdool |
sd-ber | sf-ber | slof | slos}
```

Where:

- **b1-tca**—B1 bit error rate (BER) threshold crossing alarm
- **b2-tca**—B2 BER threshold crossing alarm
- **b3-tca**—B3 BER threshold crossing alarm
- **lais**—Line Alarm Indication Signal
- **lcd**—Loss of cell delineation
- **lrldi**—Line Remote Defect Indication
- **pais**—Path Alarm Indication Signal
- **plop**—Path Loss of Pointer
- **prdi**—Path Remote Defect Indication
- **rdool**—Receive Data Out Of Lock
- **sd-ber**—Line bit interleave parity error (LBIP) BER in excess of signal degrade (SD) threshold
- **sf-ber**—LBIP BER in excess of signal fail (SF) threshold
- **slof**—Section Loss of Frame
- **slos**—Section Loss of Signal

To disable logging of select SONET alarms, use the **no** form of this command.

Reporting an alarm means that the alarm can be logged to the console. Not all alarms are logged. SONET alarm hierarchy rules dictate that only the most severe alarm of an alarm group is reported. Whether an alarm is reported or not, you can view the current state of a defect by checking the Active Defects line from the **show controllers atm** command output.

The following example shows how to enable reporting of SD-BER and LAIS alarms on the interface:

```
Router(config)# interface atm 3/0/0
Router(config-if)# atm report sd-ber
Router(config-if)# atm report lais
Router(config-if)# end
Router#
```

## Specifying the ATM Alarm Thresholds

Specify the bit error rate (BER) threshold by using the **atm threshold** command:

```
atm threshold {b1-tca | b2-tca | b3-tca | sd-ber | sf-ber} value
```

Where:

- **b1-tca**—B1 BER threshold crossing alarm
- **b2-tca**—B2 BER threshold crossing alarm
- **b3-tca**—B3 BER threshold crossing alarm
- **sd-ber**—Set Signal Degrade BER threshold
- **sf-ber**—Set Signal Fail BER threshold
- *value* is an exponential value from  $10^{-3}$  to  $10^{-9}$  representing the BER at which an alarm occurs.

The default for all thresholds, except **sf-ber**, is  $10^{-6}$ . The default for **sf-ber** is  $10^{-3}$ .

The following example shows how to specify the B1 BER threshold crossing alarm value of 4:

```
Router(config)# interface atm 5/0/0
Router(config-if)# atm threshold b1-tca 4
```

## Controlling the S1 SONET Overhead Byte

On Cisco 10000 series routers, ATM line cards run over SONET. In most situations, the default value for the S1 SONET overhead byte (0x0) does not need to be changed. Refer to the SONET standards for information about the possible values for the S1 SONET overhead byte and the definition of each value.

### Controlling a Transmitted S1 Overhead Byte

In Cisco IOS Release 12.2(28)SB, use the **pos flag s1-byte tx** command in interface configuration mode to control the transmission of the S1 SONET overhead byte.

```
pos flag s1-byte tx value
```

Where:

- *value* is in the range of 0x0 to 0xF
- 0x0 is the default value

In the following example the S1 SONET overhead byte is set to 0xF:

```
pos flag s1-byte tx 0xF
```

### Reacting to a Received S1 Overhead Byte

In Cisco IOS Release 12.2(28)SB, use the **pos flag s1-byte rx-communicate** command to direct the router to switch the clock source to internal when it receives an S1 SONET overhead byte with a value of 0xF. When the S1 SONET overhead byte changes from 0xF to any other value, the clock source reverts back to the clock source specified in the user configuration.

The S1 overhead byte is ignored by the receiving router unless the **pos flag s1-byte rx-communicate** command is issued.

```
pos flag s1-byte rx-communicate
no pos flag s1-byte rx-communicate
```

The following example directs the router to switch to internal clocking when it receives an S1 SONET overhead byte with a value of 0xF:

```
pos flag s1-byte rx-communicate
```

The default for the **pos flag s1-byte rx-communicate** command is disabled or off.

## Running Loopbacks

Use the **loopback** command to run a loopback diagnostic tests.

```
loopback {line | diagnostic {parallel | path | serial}}
no loopback {line | diagnostic {parallel | path | serial}}
```

Where:

- **line** is the line loopback
- **diagnostic** starts an internal diagnostic loopback
- **parallel** is the internal diagnostic parallel loopback
- **path** is the internal diagnostic path loopback
- **serial** is the internal diagnostic serial loopback

The following example shows how to run the diagnostic serial loopback:

```
Router(config)# interface atm 5/0/0
Router(config-if)# loopback diagnostic serial
```

## ATM PVC Commands

After you create a PVC using the **pvc** command, you can customize the PVC or a VC class by using the commands described in this section.

- [Specifying a Protocol, page 1-15](#)
- [Configuring a Broadcast, page 1-16](#)
- [Configuring Inverse ARP, page 1-17](#)
- [Attaching an ATM VC Class to a PVC, page 1-17](#)
- [Configuring VBR-NRT, page 1-17](#)
- [Specifying Encapsulation, page 1-18](#)
- [Enabling ILMI Management, page 1-18](#)
- [Configuring OAM Retry, page 1-19](#)
- [Enabling OAM Loopback Cell Generation and Management, page 1-19](#)

## Specifying a Protocol

Use the **protocol ip** command in interface-ATM-VC configuration mode or VC-class configuration mode to do one or both of the following:

- Configure a static map for an ATM PVC or VC class.

- Enable Inverse ARP or Inverse ARP broadcasts on an ATM PVC by either configuring Inverse ARP directly on the PVC or in a VC class (applies to IP protocols only).

```
protocol ip {protocol-address | inarp} [[no] broadcast]
no protocol ip {protocol-address | inarp} [[no] broadcast]
```

Where:

- *protocol-address* is the peer destination address that is being mapped to a PVC.
- **inarp** (valid only for IP protocols on PVCs) enables Inverse ARP on an ATM PVC. If you specify a *protocol-address* instead of **inarp**, Inverse ARP is automatically disabled for that protocol.
- **[no] broadcast** (optional) indicates that this PVC sends out broadcast packets (for example, IGRP updates). Pseudo broadcasting is supported. The **broadcast** keyword of the **protocol ip** command takes precedence if you previously configured the **broadcast** command on the ATM PVC.

For PVCs created under point-to-point subinterfaces, **broadcast** is enabled by default. For PVCs created under multipoint subinterfaces, use the **broadcast** argument to propagate IP routes.

Use the **no** form of this command to remove a static map or disable Inverse ARP.



#### Note

Use the **inarp** command to configure Inverse ARP frequency.

The following example shows how to specify IP protocol on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# protocol ip 172.16.32.49
```

## Configuring a Broadcast

Use the **broadcast** command to configure broadcast packet duplication and transmission for an ATM PVC or VC class.

The **broadcast** command is not used to enable ATM *cell-level* multicast, broadcast, replication, or to set up the broadcast of user level traffic. The **broadcast** command indicates which PVC (or PVCs) sends out broadcast traffic. This is typically limited to traffic associated with routing protocols and routing updates (for example, OSPF hello packets).



#### Note

The **broadcast** argument within the **protocol ip** command takes precedence over the **broadcast** command. See the [“Specifying a Protocol” section on page 1-15](#) for more information.

Use the default form of this command to restore the default behavior described below.

```
broadcast
no broadcast
```

The default is **broadcast**.

Use the **no** form of this command to disable transmission of broadcast packets.

For PVCs created under point-to-point subinterfaces, **broadcast** is enabled by default. For PVCs created under multipoint subinterfaces, you should use the **broadcast** command if you want to propagate IP routes (only the first PVC on a multipoint interface receives broadcast traffic).

The following example shows how to use the **broadcast** command to restore the default behavior:

```
Router(config)# interface atm 5/0/0.4
Router(config-subif)# pvc 0/105
Router(config-if-atm-vc)# broadcast
Router(config-if-atm-vc)#
```

## Configuring Inverse ARP

Use the **inarp** command in interface-ATM-VC configuration mode or VC-class configuration mode to configure the Inverse ARP time period for an ATM PVC or VC class.

```
inarp minutes
no inarp minutes
```

Where *minutes* is the inverse ARP frequency from 1 to 60 minutes.

The default frequency is 15 minutes.

Use the **no** form of this command to restore the default inverse ARP time period behavior.



### Note

This command is supported only for AAL5+SNAP encapsulation (the default) when Inverse ARP is enabled. Use the **encapsulation** command to configure AAL5+SNAP encapsulation and the **protocol** command to enable Inverse ARP.

The following example shows how to specify an inverse ARP frequency of 40 minutes on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# inarp 40
```

## Attaching an ATM VC Class to a PVC

Use the **class-vc** command to attach an ATM VC class to a PVC.

```
class-vc name
```

Where:

- *name* is the name of the class created with the global configuration **class-vc atm** command.

The following example shows how to assign an ATM VC class named *boston* to an ATM PVC:

```
Router(config)# interface atm 5/0/0.4
Router(config-subif)# pvc 2/100
Router(config-if-atm-vc)# class-vc boston
```

## Configuring VBR-NRT

Use the **vbr-nrt** command to configure the variable bit rate non real-time (VBR-NRT) traffic management type and specify output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC or VC class.

You can use the **vbr-nrtv** command in PVC configuration mode or VC-class configuration mode.

```
vbr-nrt peak_cell_rate sustainable_cell_rate maximum_burst_size
no vbr-nrt peak_cell_rate sustainable_cell_rate maximum_burst_size
```

Where:

- *peak* is the peak cell rate (PCR) from 38 Kbps to 149,760 Kbps. The PCR must be at least equal to the sustainable cell rate (SCR)
- *sustainable* is the sustainable cell rate (SCR) from 38 Kbps to the PCR
- *maximum* is a number from 1 to 65,535, which represents maximum burst size (MBS) in cells

The default class of service is unspecified bit rate (UBR) running at the maximum line rate of the physical interface.

Use the **no** form of this command to remove the VBR-NRT parameters and return the PVC to its default of unspecified bit rate (UBR).

The following example shows how to configure the VBR-NRT traffic parameters on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# vbr-nrt 50000 20000 200
```

## Specifying Encapsulation

Use the **encapsulation** command in PVC configuration mode or VC-class configuration mode to specify the ATM adaptation layer (AAL) and encapsulation type for an ATM PVC or VC class.

```
encapsulation {aal5mux ip | aal5snap}
no encapsulation {aal5mux ip | aal5snap}
```

Where:

- **aal5mux ip** is AAL5+MUX encapsulation
- **aal5snap** is AAL5+LLC/SNAP encapsulation (the default)

Use the **no** form of this command to return an encapsulation to the default SNAP.

The following example shows how to specify **aal5mux ip** encapsulation for an ATM PVC:

```
Router(config)# interface atm 5/0/0.4
Router(config-subif)# pvc 0/105
Router(config-if-atm-vc)# encaps aal5mux ip
```

## Enabling ILMI Management

Use the **ilmi manage** command in PVC configuration mode or VC-class configuration mode to enable ILMI management on an ATM PVC. This command changes the convergence of higher-level protocols based on link-state changes.

```
ilmi manage
no ilmi manage
```

Use the **no** form of this command to disable ILMI management.

The following example shows how to enable ILMI management on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# ilmi manage
```

## Configuring OAM Retry

Use the **oam retry** command in PVC configuration mode or VC-class configuration mode to configure OAM retry.

```
oam retry up_value [down_value frequency]
no oam retry up_value [down_value frequency]
```

Where:

- *up\_value* is a number from 1 to 600 that represents the OAM retry count before declaring that a VC is up.  
The default is 3 retries.
- *down\_value* is a number from 1 to 600 that represents the OAM retry count before declaring a VC is down.  
The default is 5 retries.
- *frequency* is a number from 1 to 1000 that represents the OAM retry polling frequency, in seconds.  
The default is 1 second.

Use the **no** form of this command to return OAM retry to its default values.

The following example shows how to configure OAM retry for an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# oam retry 10 10 5
```

## Enabling OAM Loopback Cell Generation and Management

To enable end-to-end F5 OAM loopback cell generation and OAM management for an ATM PVC or VC class, use the **oam-pvc** command in PVC configuration mode or VC-class configuration mode.

```
oam-pvc [manage] [frequency]
no oam-pvc [manage] [frequency]
```

Where:

- **manage** is an optional keyword that brings down the interface or subinterface if the PVC loopback fails.
- *frequency* (optional) is the number of seconds between transmitting OAM loopback cells. Values range from 0 to 600 seconds.

The default value is 10 seconds.

Use the **no** form of this command to disable generation of OAM loopback cells and OAM management.

The following example shows how to enable OAM loopback cell generation for an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# oam-pvc 300
```

## Useful show Commands

### **show atm vc**

Use the **show atm vc** command to display information about the VCs on the interface.

```
Router#show atm vc
```

Interface	VCD / Name	VPI	VCI	Type	Encaps	Peak Kbps	Avg/Min Kbps	Burst Cells	Sts
2/0/0	1	0	16	PVC	ILMI149760UP				
2/0/0	9	0	100	PVC	MUX 149760UP				
2/0/0.2	7	2	32	PVC	SNAP149760UP				
2/0/0	8	2	33	PVC	SNAP149760UP				
2/0/0	18	2	100	PVC	SNAP149760UP				
2/0/0.2	6	4	24	PVC	SNAP149760UP				
2/0/0	2	25	3	PVC	F4-OAM 50000UP				
2/0/0	3	25	4	PVC	F4-OAM 50000UP				
2/0/0	14	25	100	PVC	SNAP 50000 50000			0UP	
2/0/0	16	25	101	PVC	SNAP 50000 50000			0UP	
2/0/0	17	25	102	PVC	SNAP 50000 50000			0UP	
2/0/0	10	26	3	PVC	F4-OAM 50000UP				
2/0/0	11	26	4	PVC	F4-OAM50000UP				
2/0/0	12	27	3	PVC	F4-OAM 50000UP				
2/0/0	13	27	4	PVC	F4-OAM 50000UP				
2/0/0	19	33	100	PVC	SNAP 10000 8000			10UP	

```
Router#
```

**show atm vp**

Use the **show atm vp** command to display information about the VPs on the interface.

```
Router#show atm vp
```

Interface	VPI	Data VCs	CES VCs	Peak Kbps	CES Kbps	Status
ATM2/0/0	25	3	0	50000	0	ACTIVE
ATM2/0/0	26	0	0	50000	0	ACTIVE
ATM2/0/0	27	0	0	50000	0	ACTIVE

```
Router#
```

**show atm pvc**

Use the **show atm pvc vpi\_number/vci\_number** command to display detailed information about a specific PVC.

```
Router#show atm pvc 0/100
```

```
ATM2/0/0: VCD: 9, VPI: 0, VCI: 100
UBR, PeakRate: 149760
AAL5-MUX, etype:0x800, Flags: 0xC23, VCmode: 0x0
OAM frequency: 0 second(s), OAM retry frequency: 1 second(s)
OAM up retry count: 3, OAM down retry count: 5
OAM Loopback status: OAM Disabled
OAM VC state: Not Managed
ILMI VC state: Not Managed
InARP DISABLED
InPkts: 0, OutPkts: 0, InBytes: 0, OutBytes: 0
InProc: 0, OutProc: 0, Broadcasts: 0
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
InPktDrops: 0, OutPktDrops: 0
Out CLP=1 Pkts: 0
OAM cells received: 0
F5 InEndloop: 0, F5 InSegloop: 0, F5 InAIS: 0, F5 InRDI: 0
OAM cells sent: 0
F5 OutEndloop: 0, F5 OutSegloop: 0, F5 OutRDI: 0
OAM cell drops: 0
PVC Discovery: NOT_VERIFIED
Status: UP
Router#
```





## CHAPTER 2

# 8-Port E3/DS3 ATM Line Card Configuration

This chapter describes procedures for configuring the Cisco 10000 series 8-Port E3/DS3 ATM line card, hereafter known as the 8-Port E3/DS3 ATM line card.

The 8-Port E3/DS3 ATM line card has eight E3 or DS3 (T3) copper interface terminations that provide Asynchronous Transfer Mode (ATM) serial interfaces and perform Layer 2 ATM functions.

This chapter contains the following sections:

- [Software Support, page 2-1](#)
- [Default Values, page 2-2](#)
- [Line Card VC Limitations, page 2-2](#)
- [Interface Syntax, page 2-3](#)
- [Line Card Interface Configuration Examples, page 2-4](#)
- [Line Card Commands, page 2-6](#)

## Software Support

[Table 2-1](#) shows the minimum Cisco IOS release on each release train that supports the 8-Port E3/DS3 ATM line card.

**Table 2-1** 8-Port E3/DS3 ATM Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE2	Cisco IOS Release 12.2(16)BX and later releases of Cisco IOS Release 12.2BX Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS Release 12.3XI Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Default Values

Table 2-2 lists default configuration values for the 8-Port E3/DS3 ATM line card. This table also includes the commands used to modify a default values, and provides information about values to set on the remote end of the connection.

**Table 2-2 8-Port E3/DS3 ATM Line Card Defaults**

Command Name	Default Setting	Command Syntax	Remote Side Setting
mtu (maximum transmission unit)	4470 bytes	[no] mtu bytes	same
atm clock internal	line	[no] atm clock internal	opposite
loopback	loopback none	[no] loopback [line   diagnostic   payload]	—

## Line Card VC Limitations

The Cisco 10000 series router supports four ATM service categories for virtual circuits (VCs):

- Constant Bit Rate (CBR)
- Variable Bit Rate-non-real-time (VBR-nrt)
- Unspecified Bit Rate (UBR) with a peak cell rate (PCR), referred to as shaped UBR
- UBR without a PCR, referred to as unshaped UBR

The segmentation and reassembly (SAR) mechanism configures priority and additional traffic management parameters for the various ATM service categories. Table 2-3 lists the priority levels the SAR sets for the service categories.

**Table 2-3 ATM Service Categories**

Parameter	CBR	VBR-rt	VBR-nrt	Shaped UBR	Unshaped UBR
Priority	0	1	2	3	None

The number of SAR priority levels and the service categories supported at each priority level vary from line card to line card. For example, the 8-port E3/DS3 supports the two levels of priority and the service categories listed in the Table 2-4.

The ATM line cards support a maximum number of VCs per priority. That VC limit depends on the VC limit of the SAR (SAR limit) and the number of priority levels configured. Table 2-4 describes how to determine the VC limit per priority level per port for the 8-port E3/DS3 line card.

**Table 2-4** Maximum Number of VCs per Priority per Port

ATM Line Card	SAR Priority Levels	VC Rate	Maximum Number of VCs per Priority
8-Port E3/DS3	0 = CBR VCs 0 = VBR-nrt VCs 1 = UBR VCs	Half line rate and below	SAR limit / number of PHYs / number of priority levels 2 priority system: $65,536 / 8 / 2 = 4096$ VCs per priority level per port

Configuring more channels or VCs than there are available priority locations can cause random channels or VCs to get stuck in the SAR. This occurs when an active channel tries to reschedule itself, but no priority locations are available. Therefore, the channel cannot find a place to reschedule itself, which results in a lost event for the channel, and the channel becomes stuck in the SAR.

On the PRE2, when a VC becomes stuck in the SAR, the PRE2 scheduler stops forwarding traffic on only the VC that is stuck in the SAR; the other VCs still carry traffic. On the PRE3, the PRE3 scheduler stops forwarding traffic on all the VCs configured on that ATM line card.

## Interface Syntax

To specify an interface number in a configuration command, use the syntax in [Table 2-5](#) to identify interfaces and subinterfaces on the 8-Port E3/DS3 ATM line card in the Cisco series 10000 router.

**Table 2-5** 8-Port E3/DS3 ATM Line Card Interface Syntax

Type of Interface	Router	Slot	Subslot	Port	Subinterface
8-Port E3/DS3 interface	10008	1 through 8/	0/	0 to 7	—
8-Port E3/DS3 subinterface	10008	1 through 8/	0/	0.n to 7.n	n = 1 to 4294967295
8-Port E3/DS3 interface	10005	1 through 5/	0/	0 to 7	—
8-Port E3/DS3 subinterface	10005	1 through 5/	0/	0.n to 7.n	n = 1 to 4294967295

Examples:

- Modify a permanent virtual circuit (PVC) associated with an interface.

```
Router(config)# interface atm 2/0/0
Router(config-if)# pvc 0/200
Router(config-if-atm-vc)#
```

- Modify a PVC associated with a subinterface.

```
Router(config)# interface atm 7/0/0.1
Router(config-subif)# pvc 0/101
Router(config-if-atm-vc)#
```

# Line Card Interface Configuration Examples

This section provides sample procedures for configuring the 8-Port E3/DS3 ATM line card for E3 or T3 connections, as well as creating ATM subinterfaces, permanent virtual circuits (PVCs), and virtual circuit (VC) classes. Procedures for enabling Integrated Local Management Interface (ILMI) are also included.

## Creating a Subinterface

Use the following procedure to create a subinterface on an 8-Port E3/DS3 ATM line card interface.

- Step 1** Separate the ATM interface into subinterfaces using the **interface** command. You can create either a point-to-point or multipoint subinterface.

In the following example, multipoint subinterface number 1 is created on port 0 of the 8-Port E3/DS3 ATM line card in slot 2.

```
Router(config)# interface atm 2/0/0.1 multipoint
Router(config-subif)#
```

- Step 2** Assign an IP address and subnet mask to the subinterface using the **ip address** command, as shown in the following example:

```
Router(config-subif)# ip address 172.27.48.209 255.255.0.0
```

You created ATM subinterface 2/0/0.1. To configure or modify this interface, use the following command:

```
Router(config)# interface atm 2/0/0.1
Router(config-subif)#
```

## Creating a PVC

You can create multiple PVCs on an 8-Port E3/DS3 ATM line card interface. You can create PVCs on an interface or subinterface.

To create a PVC, perform the following steps:

- Step 1** Enter interface or subinterface configuration mode.

Use the **pvc** command to specify a virtual path identifier (VPI) value between 0 and 255 and a virtual channel identifier (VCI) value between 0 and 65535. The following example shows how to create a PVC with a VPI value of 0 and VCI value of 100 on a subinterface.

```
Router(config-subif)# pvc 0/100
Router(config-if-atm-vc)#
```

- Step 2** Use the **protocol ip** command to assign a peer IP address to the PVC, as shown in the following example:

```
Router(config-if-atm-vc)# protocol ip 172.16.32.49
Router(config-if-atm-vc)#
```

## Creating an ATM VC Class

This procedure demonstrates how to create an ATM VC class. An ATM VC class is a PVC boilerplate—a PVC description that you can apply to one or more PVCs.

To create an ATM VC class, perform the following steps:

- Step 1** From global configuration mode, enter the **vc-class atm name** command, where *name* is the name value you assign. The following example shows how to create the ATM VC class named *boston*.

```
Router(config)# vc-class atm boston
Router(config-vc-class)#
```

- Step 2** Enter commands to describe the ATM VC class you named *boston*. This example shows how to specify that the *boston* class uses AAL5+MUX encapsulation with a variable bit-rate non real-time (VBR-NRT) PVC.

```
Router(config-vc-class)# encapsulation aal5mux ip
Router(config-vc-class)# vbr-nrt 30000 20000 128
Router(config-vc-class)# exit
Router(config)#
```

You have created a VC class named *boston*. The next procedure describes steps for applying this class to a PVC or subinterface.

## Applying a VC Class

You can apply a VC class (created in the previous procedure) to a PVC or a subinterface.

- In the following example, the class named *boston* is applied to a new PVC (0/102) in subinterface 5/0/0.2.

```
Router(config)# interface atm 5/0/0.2
Router(config-subif)# pvc 0/102
Router(config-if-atm-vc)# class-vc boston
Router(config-if-atm-vc)#
```

- In the following example, the class named *boston* is applied to subinterface 5/0/0.1.

```
Router(config)# interface atm 5/0/0.1
Router(config-subif)# class-int boston
Router(config-subif)#
```

You have completed the steps for assigning a VC class to a PVC.

## Enabling ILMI PVC Discovery

You can enable ILMI to automatically discover PVCs on neighboring switches and duplicate those PVC entries on the 8-Port E3/DS3 ATM line card.

To enable ILMI, perform the following steps:

**Step 1** Create PVC 0/16 on the main interface as shown in the following example:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/16 ilmi
Router(config-if-atm-vc)# exit
Router(config-if)#
```

**Step 2** Enable ILMI PVC discovery for the selected port (step 1 references port 0).

```
Router(config-if)# atm ilmi-pvc-discovery
```

You have completed the steps required to run ILMI PVC discovery. You can use the **show atm pvc** command to display the PVCs on the Cisco 10000 series router.

## Completing a Configuration

This section offers general information on creating and completing a configuration of an 8-Port E3/DS3 ATM line card.

To configure an interface, perform the following steps:

**Step 1** Enter interface configuration mode and specify necessary parameters, such as the IP address and subnet mask.

**Step 2** After you enter all of the commands to complete the configuration, press **Ctrl-Z** (hold down the **Control** key while you press **Z**) to exit configuration mode.

**Step 3** Write the new configuration to memory:

```
Router# copy running-config startup-config
```

The system displays an OK message when the configuration is stored.

To check your completed configuration, use the **show** commands. For more information about show commands, see [Useful show Commands, page 2-21](#).

## Line Card Commands

The 8-Port E3/DS3 ATM line card allows you to specify eight E3 or eight T3 interfaces. You can put all the PVCs on the interfaces, or you can create associated subinterfaces. This section describes the principal commands for customizing interfaces and PVCs:

- [Global Configuration Commands, page 2-7](#)
- [ATM Interface and Subinterface Commands, page 2-7](#)
- [ATM PVC Commands, page 2-16](#)
- [Useful show Commands, page 2-21](#)

## Global Configuration Commands

A PVC boilerplate is a PVC description that you can apply to one or more PVCs or interfaces.

To create a PVC boilerplate, use the **vc-class atm** command in global configuration mode:

```
vc-class atm class_name
```

Where *class\_name* is any value that describes the VC class.

After you enter the **vc-class atm** command, you enter VC class configuration mode. In this mode, you describe the action you want the class to take by entering commands and their arguments. These commands and arguments are described in the “[ATM PVC Commands](#)” section on page 2-16.

In the following example, an ATM VC class named *paris* is created and defined. This example shows how to specify that the class uses AAL5+MUX encapsulation and a VBR-NRT PVC.

```
Router(config)# vc-class atm paris
Router(config-vc-class)# encapsulation aal5mux ip
Router(config-vc-class)# vbr-nrt 30000 20000 128
Router(config-vc-class)# exit
Router(config)#
```

For information on applying a VC class name, see the “[Attaching an ATM VC Class to an Interface or Subinterface](#)” section on page 2-12 and the “[Attaching an ATM VC Class to a PVC](#)” section on page 2-18.

## ATM Interface and Subinterface Commands

This section describes how to configure ATM interfaces and subinterfaces using the principle commands described in the following sections:

- [Setting the Line Card to E3 or T3 mode, page 2-8](#)
- [Setting the Line Card Framing, page 2-9](#)
- [Changing the Mode of the Line Card, page 2-8](#)
- [Creating and Entering Subinterfaces, page 2-10](#)
- [Attaching an ATM VC Class to an Interface or Subinterface, page 2-12](#)
- [Creating ATM PVPs, page 2-12](#)
- [Creating a PVC, page 2-13](#)
- [Enabling ATM ILMI, page 2-14](#)
- [Activating ATM ILMI PVC Discovery, page 2-14](#)
- [Specifying the ATM ILMI Keep-Alive Rate, page 2-14](#)
- [Configuring the ATM Clock, page 2-15](#)
- [Configuring Cable Length, page 2-15](#)
- [Controlling ATM Alarm Reporting, page 2-15](#)
- [Running Loopbacks, page 2-16](#)

## Setting the Line Card to E3 or T3 mode

You must configure the 8-Port E3/DS3 ATM line card for either E3 or T3 from interface configuration mode.



### Note

When you configure the 8-Port E3/DS3 ATM line card for E3 or T3, all 8 ports of the line card operate in the mode you have selected.

```
atm dsx3mode {e3 | t3}{adm | plcp}
```

Where:

**adm** means ATM direct mapping

**plcp** means physical layer convergence procedure (PLCP)—specifications that map ATM cells into physical media, such as T3 or E3, and define certain management information.

The default is t3 adm.

In the following example, the 8-Port E3/DS3 ATM line card located in slot 2 is configured for E3 mode with PLCP:

```
Router(config)# interface atm 2/0/0
Router(config-if)# atm dsx3mode e3 plcp
```

## Changing the Mode of the Line Card

The 8-Port E3/DS3 ATM line card has four modes (e3 adm, e3 plcp, t3 adm and t3 plcp), the default mode being t3 adm. Each mode has its own bandwidth and cell delay variation tolerance (CDVT) values.

When a line card is freshly inserted, the default mode of the card can be changed. However, if VCs, VPs or subinterfaces have already been configured on the line card, the line card must first be removed and reprovisioned prior to the mode change.

To change the mode of an already provisioned card use the following commands in the configuration mode:

```
hw-module slot <> shut
no card <>
no hw-module slot <> shut
```

After the line card is restarted you can change the mode, and re-apply the configurations that were lost during module shutdown.

The following example shows how to change the mode of an already provisioned card, from E3 mode with ADM to E3 mode with PLCP.

```
Router(config)# hw-module slot 2/0 shut
Router(config)# no card 2/0
Router(config)# no hw-module slot 2/0 shut
```

To change the mode of the line card:

```
Router(config)# interface atm 2/0/0
Router(config-if)# atm dsx3mode e3 plcp
```

To re-apply the configurations to the line card:

```
Router(config)#interface atm 2/0/0.1 point-to-point
Router(config-subif)#pvc 1/100
Router(config-if-atm-vc)#vbr-nrt 4000 4000
```



```
Router(config-if-atm-vc)#end
```

## Setting the Line Card Framing

The 8-Port E3/DS3 ATM line card supports ADM and PLCP framing on E3 and T3 connections. The following sections describe how to set T3 ADM, T3 PLCP, E3 ADM, and E3 PLCP framing.

### Setting T3 ADM Framing

If you configured the 8-Port E3/DS3 ATM line card for T3 ADM using the **atm dsx3mode ds3 adm** command, configure the framing using the **atm framing** command in interface configuration mode.

```
[no] atm framing {cbitadm | m23adm}
```

Where:

**cbitadm** is C-bit ADM T3 Framing

**m23adm** is M23 ADM T3 Framing

The default is cbitadm.

In the following example, M23 ADM T3 framing is set:

```
Router(config)# interface atm 2/0/0
Router(config-if)# atm framing m23adm
```

### Setting T3 PLCP Framing

If you configured the 8-Port E3/DS3 ATM line card for T3 PLCP using the **atm dsx3mode ds3 plcp** command, configure the framing using the **atm framing** command from interface configuration mode.

```
[no] atm framing {cbitplcp | m23plcp}
```

Where:

**cbitplcp** is C-bit PLCP T3 Framing

**m23plcp** is M23 PLCP T3 Framing

The default cbitplcp

In the following example, C-bit PLCP T3 framing is set:

```
Router(config)# interface atm 2/0/0
Router(config-if) atm framing cbitplcp
```

### Setting E3 ADM Framing

If you configured the 8-Port E3/DS3 ATM line card for E3 ADM using the **atm dsx3mode e3 adm** command, configure the framing using the **atm framing** command in interface configuration mode.

```
[no] atm framing {g751adm | g832adm}
```

Where:

**g751adm** is G.751 ADM E3 framing

**g832adm** is G.832 ADM E3 framing

The default is g751adm.

In the following example, G.751 ADM E3 framing is set:

```
Router(config)# interface atm 2/0/0
```

```
Router(config-if)# atm framing g751adm
```

## Setting E3 PLCP Framing

If you configured the 8-Port E3/DS3 ATM line card for E3 PLCP using the **atm dsx3mode e3 plcp** command, configure the framing using the **atm framing** command in interface configuration mode.

```
[no] atm framing g751plcp
```

Where **g751plcp** is G.751 PLCP E3 framing

The default is g751plcp.

In the following example, G.751 PLCP E3 framing is set:

```
Router(config)# interface atm 2/0/0
Router(config-if)# atm framing g751plcp
```

## Creating and Entering Subinterfaces

Use the **interface** command to segment an E3 or T3 ATM main interface into multiple subinterfaces to simplify line card management, to create interfaces with different MTU sizes, and to create connections to different networks.

```
interface atm slot/subslot/port.subinterface type
no interface atm slot/subslot/port.subinterface type
```

Where:

- *slot* is 1 to 5 for a Cisco 10005 router.
- *slot* is 1 to 8 for a Cisco 10008 router.
- *subslot* is always 0 for a full-height line card.
- *port* is 0 to 3.
- *subinterface* is a value from 1 to 4294967295.
- *type* is always **point-to-point** or **multipoint**.

To remove a subinterface and its PVCs, use the **no interface** command. To change a subinterface type, you must first remove the subinterface.

Examples:

- Create subinterface number 1 at port 3 for 8-Port E3/DS3 ATM line card in slot 1.

```
Router(config)# interface atm 1/0/3.1 point-to-point
Router(config-subif)#
```

- Enter an existing subinterface.

```
Router(config)# interface atm 1/0/3.1
Router(config-subif)#
```

- Use a multipoint subinterface.


If you want multiple PVCs to go to the same network, you must create a multipoint subinterface.

For example:

```
Router(config)# interface atm 4/0/2.2 multipoint
Router(config-subif)#
```

After you create the subinterface, you can create PVCs that are attached to the same network. [Figure 2-1](#) shows a multipoint subinterface on a fully meshed network. Fully meshed indicates that any workstation can communicate with any other workstation.

**Figure 2-1 Multipoint ATM Configuration**



The following examples show the commands used to configure the ATM interfaces for routers A, B, and C (see [Figure 2-1](#)), including the configuration commands you must enter to configure the multipoint connections in that network:

#### Router A

```
Router(config)# interface atm 4/0/0.2 multi
Router(config-subif)# ip address 131.108.168.1 255.255.255.0
Router(config-subif)# pvc 0/35
Router(config-if-atm-vc)# protocol ip 131.108.168.2 broadcast
Router(config-if-atm-vc)# exit
Router(config-subif)# pvc 0/36
Router(config-if-atm-vc)# protocol ip 131.108.168.3 broadcast
Router(config-if-atm-vc)# exit
Router(config-subif)# exit
Router(config)#
```

#### Router B

```
Router(config)# interface atm 2/0/0.1 multi
Router(config-subif)# ip address 131.108.168.2 255.255.255.0
Router(config-subif)# pvc 0/35
Router(config-if-atm-vc)# protocol ip 131.108.168.1 broadcast
Router(config-if-atm-vc)# exit
Router(config-subif)# pvc 0/37
Router(config-if-atm-vc)# protocol ip 131.108.168.3 broadcast
Router(config-if-atm-vc)# exit
Router(config-subif)# exit
Router(config)#
```

#### Router C

```
Router(config)# interface atm 5/0/0.1 multi
Router(config-subif)# ip address 131.108.168.3 255.255.255.0
Router(config-subif)# pvc 0/36
Router(config-if-atm-vc)# protocol ip 131.108.168.1 broadcast
Router(config-if-atm-vc)# exit
Router(config-subif)# pvc 0/37
Router(config-if-atm-vc)# protocol ip 131.108.168.2 broadcast
Router(config-if-atm-vc)# exit
Router(config)#
```

## Attaching an ATM VC Class to an Interface or Subinterface

Use the **class-int** command to attach an ATM VC class to an interface or subinterface. If you customize a PVC, that customization takes precedence over the interface class.

```
class-int class_name
```

Where *class\_name* is the name of the class created using the global configuration **class-vc atm** command.

In the following example, a VC class named *paris* is created and attached to subinterface 3/0/0.1.

```
Router(config)# vc-class atm paris
Router(config-vc-class)# encapsulation aal5mux ip
Router(config-vc-class)# vbr-nrt 30000 20000 128
Router(config-vc-class)# exit
Router(config)# interface atm 3/0/0.1
Router(config-subif)# class-int paris
```

## Creating ATM PVPs

To create a permanent virtual path (PVP) used to multiplex one or more VBR-NRT VCs, use the **atm pvp** interface configuration command.

```
atm pvp vpi peak-rate [no-f4-oam]
no atm pvp vpi
```

Where:

- *vpi* is the ATM network virtual path identifier (VPI) of the VC used to multiplex the permanent virtual path. The range is 0 to 255. You must use a VPI value that is not already in use by a VC.
- *peak-rate* is the maximum rate in kilobits per second (kbps) at which the PVP can transmit data. For an E3 interface, you can enter values from 38 kbps to 34,368 kbps. For a T3 interface, you can enter values from 38 kbps to 44,200 kbps. The PVP peak rate value supersedes all rate values set for VBR-NRT PVCs associated with the PVP.

Interface Type	Allowable Kbps Range for <i>peak-rate</i>
E3	38 to 34,368
T3	38 to 44,200

- **no-f4-oam** (optional) restricts the PVP from passing operations/administration/maintenance (OAM) packets. When you create a PVP, the system creates (by default) PVCs with VCI values of 3 and 4 for each PVP which passes OAM packets.

To verify the configuration of a PVP, use the **show atm vp exec** command.

The following example shows how to create a PVP with a peak rate of 30,000 kbps. Subsequently, the created VCs are multiplexed onto this virtual path.

```
Router(config)# interface atm 7/0/0
Router(config-if)# atm pvp 25 30000
Router(config-if)# pvc 25/100
Router(config-if-atm-vc)# vbr-nrt 10000 5000 16
Router(config-if-atm-vc)# exit
Router(config-if)# pvc 25/101
Router(config-if-atm-vc)# vbr-nrt 10000 5000 16
Router(config-if-atm-vc)# exit
Router(config-if)# pvc 25/102
Router(config-if-atm-vc)# vbr-nrt 10000 5000 16
Router(config-if-atm-vc)# exit
Router(config)#
```

## Creating a PVC

This section describes how to create a permanent virtual circuit.



### Note

You can only create one PVC on a point-to-point interface. Multiple PVCs can be created on a multipoint interface.

You can establish an unspecified bit rate (UBR) PVC by entering the **pvc** command:

```
pvc [word] [vpi_value/{vci_value}] [ilmi]
```

- Where:
- *word* is an optional name referring to this connection.
- *vpi\_value* is in the range from 0 to 255. If you do not specify a VPI value, the system assigns the value 0.
- *vci\_value* is in the range 1 to 65535. The VCI value should be 33 or greater because all lower-numbered PVCs are already assigned.
- **ilmi** parameter maps the ILMI channel to the PVC for this interface. You can only use this argument for PVCs created on the main interface. We recommend that you use this argument with PVC 0/16. For more information about activating ILMI, see the [“Activating ATM ILMI PVC Discovery” section on page 2-14](#).

By default, the **pvc** command creates a UBR PVC. To specify a VBR-NRT PVC, see the [“Configuring VBR-NRT” section on page 2-19](#).

Examples:

- Create PVC 0/105 on the interface.

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 105
Router(config-if-atm-vc)#
```

- Create PVC 2/102 on a subinterface.

```
Router(config)# interface atm 5/0/0.1
Router(config-subif)# pvc 2/102
Router(config-if-atm-vc)#
```

## Enabling ATM ILMI

Use the **atm ilmi-enable** interface configuration command to enable ILMI on a port.

```
atm ilmi-enable
no atm ilmi-enable
```

The default is ILMI is enabled, but you should disable the ILMI if the peer does not support ILMI. For peers to be able to exchange ILMI information, you must create PVC 0/16 using the **ilmi** argument.

The following example shows how to disable ILMI:

```
Router(config)# interface atm 5/0/0
Router(config-if)# no atm ilmi-enable
```

## Activating ATM ILMI PVC Discovery

This command causes ILMI-compliant devices to propagate PVCs. Use the **atm ilmi-pvc-discovery** command in interface configuration mode to activate ATM PVC discovery.

```
atm ilmi-pvc-discovery [subinterface]
no atm ilmi-pvc-discovery [subinterface]
```

Where:

- **subinterface** instructs the software to associate all PVCs with existing subinterface numbers equal to their VPI numbers. For example: PVC 2/102 is listed under subinterface 7/0/0.2, PVC 12/156 is listed under 7/0/0.12, and so on.




---

**Note** The **subinterface** argument associates PVCs only with subinterfaces that have already been created. If there is no subinterface for a VPI value, the system associates the PVC with the main interface.

---

The following example shows how to enable PVC discovery on the ATM interface 7/0/0, for port 0, on an 8-Port E3/DS3 ATM line card that has ILMI enabled.

```
Router(config)# interface atm 7/0/0
Router(config-if)# pvc 0/16 ilmi
Router(config-if-atm-vc)# exit
Router(config-if)# atm ilmi-pvc-discovery
```

## Specifying the ATM ILMI Keep-Alive Rate

Use the **atm ilmi-keepalive** command to specify the ILMI keep-alive rate.

```
atm ilmi-keepalive [seconds [retry counts]]
```

Where:

- *seconds* is a value from 1 to 65535
- **retry counts** is a value from 2 to 5

The default value for seconds is 5000 and for retry counts is 4.

The following example shows how to enable ILMI keepalives for the ATM interface 5/0/0:

```
Router(config)# interface atm 5/0/0
Router(config-if)# atm ilmi-keepalive 10000 retry 3
```

## Configuring the ATM Clock

Use the **atm clock internal** command to configure the clock source as internal.

```
atm clock {internal | line}
no atm clock internal
```

The default clock setting is **no atm clock internal**, which means that clocking is derived from the line.

In the following example, clocking is set to internal.

```
Router(config)# interface atm 5/0/0
Router(config-if)# atm clock internal
```

## Configuring Cable Length

The **atm lbo** command improves signal strength for losses associated with lengthy cables. To specify whether the cable attached to the interface is short or long, use the **atm lbo** command in the following format:

```
atm lbo {short | long}
```

Where:

**short** is for a cable that is less than 225 feet.

**long** is for a cable that is 225 feet or greater.

The default is short.

In the following example, the cable length is set to short:

```
Router(config)# interface 2/0/0
Router(config-controller)# atm lbo short
```

## Controlling ATM Alarm Reporting

To control alarms so that they are logged to the console for an ATM interface, use the **atm report** command in interface configuration mode.

```
atm report {los | oof | ais | ferf | lcd}
no atm report {los | oof | ais | ferf | lcd}
```

Where:

- **los**—Loss of Signal
- **oof**—Out of Frame
- **ais**—Alarm Indication Signal
- **ferf**—Far End Receive Failure
- **lcd**—Loss of cell delineation

To disable logging of alarms, use the **no** form of this command.

Reporting an alarm means that the alarm can be logged to the console. Not all alarms are logged. The alarm hierarchy rules dictate that only the most severe alarm of an alarm group is reported. Whether an alarm is reported or not, you can view the current state of a defect by checking the Active Defects line from the **show controllers atm** command output.

The following example shows how to enable reporting of SD-BER and AIS alarms on the interface:

```
Router(config)# interface atm 3/0/0
Router(config-if)# atm report los
Router(config-if)# atm report ais
Router(config-if)# end
Router#
```

## Running Loopbacks

Use the **loopback** command to run a loopback tests.

```
loopback {diagnostic | payload | line}
no loopback {diagnostic | payload | line}
```

Where:

- **diagnostic** means transmit data is looped to receive data.
- **payload** means the DS3 or E3 overhead bits are regenerated and inserted into the received DS3 or E3 data stream, and the resulting stream is transmitted.
- **line** means the received data stream is looped to the transmit data stream.

The following example shows how to run the diagnostic loopback:

```
Router(config)# interface atm 5/0/0
Router(config-if)# loopback diagnostic
```

## ATM PVC Commands

After you create a PVC using the **pvc** command, you can customize the PVC or a VC class by using the commands described in this section.

- [Specifying a Protocol, page 2-17](#)
- [Configuring a Broadcast, page 2-17](#)
- [Configuring Inverse ARP, page 2-18](#)
- [Attaching an ATM VC Class to a PVC, page 2-18](#)
- [Configuring VBR-NRT, page 2-19](#)
- [Specifying Encapsulation, page 2-19](#)
- [Enabling ILMI Management, page 2-20](#)
- [Configuring OAM Retry, page 2-20](#)
- [Enabling OAM Loopback Cell Generation and Management, page 2-20](#)



## Specifying a Protocol

Use the **protocol ip** command in interface-ATM-VC configuration mode or VC-class configuration mode to configure a static map for an ATM PVC or VC class.

```
protocol ip {protocol-address | arp | cdp | clns | clns_es | clns_is | cmns |
compressedtcp | {ip {address} | ppp | pppoe | snapshot}} [[no] broadcast]}

no protocol ip {protocol-address | arp | cdp | clns | clns_es | clns_is | cmns |
compressedtcp | {ip {address} | ppp | pppoe | snapshot}} [[no] broadcast]}
```

Where:

- *protocol-address* is the peer destination address that is being mapped to a PVC.
- **arp** (valid only for IP protocols on PVCs) enables ARP on an ATM PVC.
- **cdp** is the Cisco Discovery Protocol.
- **clns** is ISO Connectionless Network Service (CLNS).
- **clns\_es** is ISO CLNS end system.
- **clns\_is** is ISO CLNS intermediate system.
- **cmns** is ISO Connection-Mode Network Service (CMNS).
- **compressedtcp** is compressed TCP.
- **ip** is IP.
- **ppp** is LLC PPP over AAL5 encapsulation.
- **pppoe** is PPP over Ethernet.
- **snapshot** is Snapshot routing support.
- **[no] broadcast** (optional) indicates that this PVC sends out broadcast packets (for example, IGRP updates). Pseudo broadcasting is supported. The broadcast keyword of the **protocol ip** command takes precedence if you previously configured the **broadcast** command on the ATM PVC.

For PVCs created under point-to-point subinterfaces, **broadcast** is enabled by default. For PVCs created under multipoint subinterfaces, use the **broadcast** argument to propagate IP routes.

Use the **no** form of this command to remove a static map.



### Note

Use the **inarp** command to configure Inverse ARP frequency.

The following example shows how to specify IP protocol on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# protocol ip 172.16.32.49
```

## Configuring a Broadcast

Use the **broadcast** command to configure broadcast packet duplication and transmission for an ATM PVC or VC class.

The **broadcast** command is not used to enable ATM *cell-level* multicast, broadcast, replication, or to set up the broadcast of user level traffic. The **broadcast** command indicates which PVC (or PVCs) sends out broadcast traffic. This is typically limited to traffic associated with routing protocols and routing updates (for example, OSPF hello packets).

**Note**

The **broadcast** argument within the **protocol ip** command takes precedence over the **broadcast** command. See the “[Specifying a Protocol](#)” section on page 2-17 for more information.

Use the default form of this command to restore the default behavior described below.

```
broadcast
no broadcast
```

The default is broadcast.

Use the **no** form of this command to disable transmission of broadcast packets.

For PVCs created under point-to-point subinterfaces, **broadcast** is enabled by default. For PVCs created under multipoint subinterfaces, you should use the **broadcast** command if you want to propagate IP routes (only the first PVC on a multipoint interface receives broadcast traffic).

The following example shows how to use the **broadcast** command to restore default behavior:

```
Router(config)# interface atm 5/0/0.4
Router(config-subif)# pvc 0/105
Router(config-if-atm-vc) # broadcast
Router(config-if-atm-vc) #
```

## Configuring Inverse ARP

Use the **inarp** command in interface-ATM-VC configuration mode or VC-class configuration mode to configure the inverse ARP time period for an ATM PVC or VC class.

```
inarp minutes
no inarp minutes
```

Where *minutes* is the inverse ARP frequency from 1 to 60 minutes.

The default frequency is 15 minutes.

Use the **no** form of this command to restore the default inverse ARP time period behavior.

**Note**

This command is supported only for AAL5+SNAP encapsulation (the default) when Inverse ARP is enabled. Use the **encapsulation** command to configure AAL5+SNAP encapsulation and the **protocol** command to enable Inverse ARP.

The following example shows how to specify an inverse ARP frequency of 40 minutes on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc) # inarp 40
```

## Attaching an ATM VC Class to a PVC

Use the **class-vc** command to attach an ATM VC class to a PVC.

```
class-vc name
```

Where:

- *name* is the name of the class created with the global configuration **class-vc atm** command.

The following example shows how to assign an ATM VC class named *boston* to an ATM PVC:

```
Router(config)# interface atm 5/0/0.4
Router(config-subif)# pvc 2/100
Router(config-if-atm-vc)# class-vc boston
```

## Configuring VBR-NRT

Use the **vbr-nrt** command to configure the variable bit rate non real-time (VBR-NRT) traffic management type and specify output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC or VC class.

You can use the **vbr-nrt** command in PVC configuration mode or VC-class configuration mode.

```
vbr-nrt peak_cell_rate sustainable_cell_rate maximum_burst_size
no vbr-nrt peak_cell_rate sustainable_cell_rate maximum_burst_size
```

Where:

- *peak\_cell\_rate* is the peak cell rate (PCR). For an E3 interface, you can enter values from 38 kbps to 34,368 kbps. For a T3 interface, you can enter values from 38 kbps to 44,200 kbps. The PCR must be at least equal to the sustainable cell rate (SCR).
- *sustainable\_cell\_rate* is the sustainable cell rate (SCR) from 38 kbps to the PCR.
- *maximum\_burst\_size* is a number from 1 to 65,535, which represents maximum burst size (MBS) in cells.

The default class of service is unspecified bit rate (UBR) running at the maximum line rate of the physical interface.

Use the **no** form of this command to remove the VBR-NRT parameters and return the PVC to its default of UBR.

The following example shows how to configure the VBR-NRT traffic parameters on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# vbr-nrt 10000 5000 200
```

## Specifying Encapsulation

Use the **encapsulation** command in PVC configuration mode or VC-class configuration mode to specify the ATM adaptation layer (AAL) and encapsulation type for an ATM PVC or VC class.

```
encapsulation {aal5mux ip | aal5snap}
no encapsulation {aal5mux ip | aal5snap}
```

Where:

- **aal5mux ip** is AAL5+MUX encapsulation.
- **aal5snap** is AAL5+LLC/SNAP encapsulation (the default).

Use the **no** form of this command to return an encapsulation to the default SNAP.

The following example shows how to specify **aal5mux ip** encapsulation for an ATM PVC:

```
Router(config)# interface atm 5/0/0.4
Router(config-subif)# pvc 0/105
Router(config-if-atm-vc)# encapsulation aal5mux ip
```

## Enabling ILMI Management

Use the **ilmi manage** command in PVC configuration mode or VC-class configuration mode to enable ILMI management on an ATM PVC. This command changes the convergence of higher-level protocols based on link-state changes.

```
ilmi manage
no ilmi manage
```

Use the **no** form of this command to disable ILMI management.

The following example shows how to enable ILMI management on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# ilmi manage
```

## Configuring OAM Retry

Use the **oam retry** command in PVC configuration mode or VC-class configuration mode to configure OAM retry.

```
oam retry up_value [down_value frequency]
no oam retry up_value [down_value frequency]
```

Where:

- *up\_value* is a number from 1 to 600 that represents the OAM retry count before declaring that a VC is up.  
The default is 3 retries.
- *down\_value* is a number from 1 to 600 that represents the OAM retry count before declaring a VC is down.  
The default is 5 retries.
- *frequency* is a number from 1 to 1000 that represents the OAM retry polling frequency, in seconds.  
The default is 1 second.

Use the **no** form of this command to return OAM retry to its default values.

The following example shows how to configure OAM retry for an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# oam retry 10 10 5
```

## Enabling OAM Loopback Cell Generation and Management

To enable end-to-end F5 OAM loopback cell generation and OAM management for an ATM PVC or VC class, use the **oam-pvc** command in PVC configuration mode or VC-class configuration mode.

```
oam-pvc [manage] [frequency]
no oam-pvc [manage] [frequency]
```

Where:

- **manage** is an optional keyword that brings down the interface or subinterface if the PVC loopback fails.

- *frequency* (optional) is the number of seconds between transmitting OAM loopback cells. Values range from 0 to 600 seconds.

The default value is 10 seconds.

Use the **no** form of this command to disable generation of OAM loopback cells and OAM management.

The following example shows how to enable OAM loopback cell generation for an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# oam-pvc 300
```

## Useful show Commands

You can use the following **show** commands to view ATM interfaces and subinterfaces, and to troubleshoot ATM problems.

### show atm vc

Use the **show atm vc** command to display information about the VCs on the interface.

```
Router# show atm vc
```

Interface	VCD / Name	VPI	VCI	Type	Encaps	Peak Kbps	Avg/Min Kbps	Burst Cells	Sts
2/0/0	1	0	16	PVC	ILMI149760UP				
2/0/0	9	0	100	PVC	MUX149760UP				
2/0/0.2	7	2	32	PVC	SNAP149760UP				
2/0/0	8	2	33	PVC	SNAP149760UP				
2/0/0	18	2	100	PVC	SNAP149760UP				
2/0/0.2	6	4	24	PVC	SNAP149760UP				
2/0/0	2	25	3	PVC	F4-OAM 50000UP				
2/0/0	3	25	4	PVC	F4-OAM 50000UP				
2/0/0	14	25	100	PVC	SNAP 50000	50000			0UP
2/0/0	16	25	101	PVC	SNAP 50000	50000			0UP
2/0/0	17	25	102	PVC	SNAP 50000	50000			0UP
2/0/0	10	26	3	PVC	F4-OAM 50000UP				
2/0/0	11	26	4	PVC	F4-OAM50000UP				
2/0/0	12	27	3	PVC	F4-OAM 50000UP				
2/0/0	13	27	4	PVC	F4-OAM 50000UP				
2/0/0	19	33	100	PVC	SNAP 10000	8000			10UP

```
Router#
```

### show atm vp

Use the **show atm vp** command to display information about the VPs on the interface.

```
Router# show atm vp
```

Interface	VPI	Data VCs	CES VCs	Peak Kbps	CES Kbps	Status
ATM2/0/0	25	3	0	50000	0	ACTIVE
ATM2/0/0	26	0	0	50000	0	ACTIVE
ATM2/0/0	27	0	0	50000	0	ACTIVE

```
Router#
```

### show atm pvc

Use the **show atm pvc vpi\_number/vci\_number** command to display detailed information about a specific PVC.

```
Router# show atm pvc 0/100
```

```
ATM2/0/0: VCD: 9, VPI: 0, VCI: 100
UBR, PeakRate: 149760
AAL5-MUX, etype:0x800, Flags: 0xC23, VCmode: 0x0
OAM frequency: 0 second(s), OAM retry frequency: 1 second(s)
OAM up retry count: 3, OAM down retry count: 5
OAM Loopback status: OAM Disabled
OAM VC state: Not Managed
ILMI VC state: Not Managed
InARP DISABLED
InPkts: 0, OutPkts: 0, InBytes: 0, OutBytes: 0
InProc: 0, OutProc: 0, Broadcasts: 0
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
InPktDrops: 0, OutPktDrops: 0
Out CLP=1 Pkts: 0
OAM cells received: 0
F5 InEndloop: 0, F5 InSegloop: 0, F5 InAIS: 0, F5 InRDI: 0
OAM cells sent: 0
F5 OutEndloop: 0, F5 OutSegloop: 0, F5 OutRDI: 0
OAM cell drops: 0
PVC Discovery: NOT_VERIFIED
Status: UP
Router#
```



# CHAPTER 3

## 1-Port OC-12 ATM Line Card Configuration

This chapter describes procedures for configuring the Cisco 10000 series 1-Port OC-12 ATM line card, hereafter known as the 1-Port OC-12 ATM line card.

The 1-Port OC-12 ATM line card is a trunk uplink for the Cisco 10000series routers that provides IP packet routing over ATM virtual circuit connections using a single-mode fiber intermediate reach SC connector.

This chapter contains the following sections:

- [Software Support, page 3-1](#)
- [Default Values, page 3-2](#)
- [Line Card VC Limitations, page 3-2](#)
- [Interface Syntax, page 3-4](#)
- [Interface Configuration Samples, page 3-4](#)
- [Commands, page 3-7](#)

## Software Support

[Table 3-1](#) shows the minimum Cisco IOS release on each release train that supports the 1-Port OC-12 ATM line card.

**Table 3-1** 1-Port OC-12 ATM Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE1	Cisco IOS Release 12.0(22)S and later releases of Cisco IOS Release 12.0S
PRE2	Cisco IOS Release 12.0(10)SL and later releases of Cisco IOS Release 12.0SL Cisco IOS Release 12.0(22)S and later releases of Cisco IOS Release 12.0S Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS 12.3XI Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB
PRE3	Cisco IOS Release 12.2(31)SB2 and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Default Values

Table 3-2 lists default configuration values for the 1-Port OC-12 ATM line card. This table also includes the command used to modify a default value, and provides information about values to set on the remote end of the connection.

**Table 3-2 1-Port OC-12 ATM Line Card Defaults**

Command Name	Default Setting	Command Syntax	Remote Side Setting
mtu (maximum transmission unit)	9180 bytes	[no] mtu bytes	same
atm clock internal	no atm clock internal	[no] atm clock internal	opposite
loopback	loopback none	[no] loopback [line   diagnostic {parallel   path   serial}]	—
pvc encapsulation	aal5snap	encapsulation [aal5snap   aal5mux ip]	same

## Line Card VC Limitations

The Cisco 10000 series router supports four ATM service categories for virtual circuits (VCs):

- Constant Bit Rate (CBR)
- Variable Bit Rate-non-real-time (VBR-nrt)
- Unspecified Bit Rate (UBR) with a peak cell rate (PCR), referred to as shaped UBR
- UBR without a PCR, referred to as unshaped UBR

The segmentation and reassembly (SAR) mechanism configures priority and additional traffic management parameters for the various ATM service categories. Table 3-3 lists the priority levels the SAR sets for the service categories.

**Table 3-3 ATM Service Categories**

Parameter	CBR	VBR-rt	VBR-nrt	Shaped UBR	Unshaped UBR
Priority	0	1	2	3	None



The number of SAR priority levels and the service categories supported at each priority level vary from line card to line card. For example, the 1-port OC-12/STM-1 line card supports the four levels of priority and the service categories listed in [Table 3-4](#).

The ATM line cards support a maximum number of VCs per priority. That VC limit depends on the VC limit of the SAR (SAR limit) and the number of priority levels configured. [Table 3-4](#) describes how to determine the VC limit per priority level for the 1-port OC-12/STM-1 line card.

**Table 3-4** Maximum Number of VCs per Priority

ATM Line Card	SAR Priority Levels	VC Rate	Maximum Number of VCs per Priority
1-Port OC-12/ STM-1	0 = CBR VCs 1 = VBR-rt VCs 2 = VBR-nrt VCs 3 = UBR VCs	Full line rate	SAR limit / 2 / number of priority levels With 4 priority system: 65,536 / 2 / 4 = 8192 VCs per priority level
		Half line rate and below	SAR limit / number of priority levels 4 priority system: 65,536 / 4 = 16,384 VCs per priority level

Configuring more channels or VCs than there are available priority locations can cause random channels or VCs to get stuck in the SAR. This occurs when an active channel tries to reschedule itself, but no priority locations are available. Therefore, the channel cannot find a place to reschedule itself, which results in a lost event for the channel, and the channel becomes stuck in the SAR.

On the PRE2, when a VC becomes stuck in the SAR, the PRE2 scheduler stops forwarding traffic on only the VC that is stuck in the SAR; the other VCs still carry traffic. On the PRE3, the PRE3 scheduler stops forwarding traffic on all the VCs configured on that ATM line card.

## Shaped UBRs on the OC-12 ATM Line Card

On an OC-12 ATM line card, when you configure UBR PVCs with a shaped value (UBR-PCR) and the shaped value is greater than one-half of the line rate (for example, 299,520 Kbps), the following limitations apply:

- The number of VCs the OC-12 line card supports is up to one-half of the VC scaling limit of 16,384 VCs. Cisco IOS software counts each UBR-PVC above 299,520 as two VCs. Therefore, the active VC count must be maintained at the following:

$$16,384 > (\text{number of VCs at } 299,520 \text{ and above} * 2) + (\text{number of VCs below } 299,520)$$

At any time, if more VCs are active than the allowed number above, the SAR on the line card leaks buffers, which results in a reduced buffer pool for active VCs and the SAR might fail if enough buffers are lost. To recover the lost buffers, reboot the system.

- The router allows you to enter shaping values between 299,520 and 599,040, which the SAR does not support. The SAR performs shaping in the range of 599,040 and 299,520 to 299,538. If you configure a shaping value between 299,528 and 399,032, the shape rate the SAR returns is unclear.
- If you initially set a shaping rate of 599,040 and then change to another rate, or you initially configure a shape rate and change to a rate of 599,040, the router accepts the command and the **show** commands display the new rate. However, the SAR does not perform shaping correctly until the next reload.

If you change the shaping rate from 599,040 to a lower rate, the LP shaper in VTMS allows the average rate to be met. However, during traffic bursts, ATM-level shaping is not accurate.

## Interface Syntax

To specify an interface number in a configuration command, use the syntax in [Table 3-5](#) to identify interfaces on the 1-Port OC-12 ATM line card.

**Table 3-5 1-Port OC-12 ATM Interface Syntax**

Type of Interface	Slot	Subslot	Port	Subinterface
Main interface	1 to 8/	0/	0.	—
Subinterface	1 to 8/	0/	0.	1 to 4294967295

Examples:

- Modify a PVC associated with the main interface.

```
Router(config)# interface atm 2/0/0
Router(config-if)# pvc 0/200
Router(config-if-atm-vc)#
```

- Modify a permanent virtual circuit (PVC) associated with a subinterface.

```
Router(config)# interface atm 7/0/0.1
Router(config-subif)# pvc 0/101
Router(config-if-atm-vc)#
```

## Interface Configuration Samples

This section provides sample procedures for creating subinterfaces, permanent virtual circuits (PVCs), virtual circuit (VC) classes, and for enabling Integrated Local Management Interface (ILMI).

### Creating a Subinterface

Use the following procedure to create a subinterface.

- Step 1** Divide the ATM interface into subinterfaces using the **interface** command. You can create either a point-to-point or multipoint subinterface.

In the following example, multipoint subinterface number 1 is created on an 1-Port OC-12 ATM line card in slot 2.

```
Router(config)# interface atm 2/0/0.1 multipoint
Router(config-subif)#
```

- Step 2** Assign an IP address and subnet mask to the interface using the **ip address** configuration subcommand, as shown in the following example:

```
Router(config-subif)# ip address 172.27.48.209 255.255.0.0
Router(config-subif)#
```

You have created interface 2/0/0.1. To enter this interface, use the following command:

```
Router(config)# interface atm 2/0/0.1
Router(config-subif)#
```

---

## Creating a PVC

You can create up multiple PVCs on the 1-Port OC-12 ATM line card interface. You can create PVCs on the main interface or on a subinterface.

To create a PVC

**Step 1** Enter interface or subinterface configuration mode.

Use the **pvc** command to specify a virtual path identifier (VPI) value between 0 and 255 and a virtual channel identifier (VCI) value between 0 and 65535. The following example creates a PVC with a VPI value of 0 and VCI value of 100 on a subinterface.

```
Router(config-subif)# pvc 0/100
Router(config-if-atm-vc)#
```

**Step 2** Assign a peer IP address to the PVC using the **protocol ip** configuration subcommand, as in the following example:

```
Router(config-if-atm-vc)# protocol ip 172.16.32.49
Router(config-if-atm-vc)#
```

---

## Creating a VC Class

This procedure demonstrates how to create an ATM VC class. An ATM VC class is a PVC boilerplate—a PVC description that you can apply to one or more PVCs.

**Step 1** To create a PVC boilerplate, use the global configuration mode **vc-class atm** command. The following example creates the ATM VC class named *boston*.

```
Router(config)# vc-class atm boston
Router(config-vc-class)#
```

**Step 2** Enter commands to describe the ATM VC class named *boston*. This example shows how to specify that the class uses AAL5+MUX encapsulation and configure a variable bit rate-nonreal time (VBR-NRT) PVC.

```
Router(config-vc-class)# encaps aal5mux ip
Router(config-vc-class)# vbr-nrt 30000 20000 128
Router(config-vc-class)# exit
Router(config)#
```

You have created a VC class named *boston*. The next procedure describes how to apply this class to a PVC or subinterface.

---

## Applying a VC Class

You can apply a VC class (created in the previous procedure) to a PVC or an interface.

- In the following example, the class named *boston* is applied to subinterface 5/0/0.1.

```
Router(config)# interface atm 5/0/0.1
Router(config-subif)# class-int boston
Router(config-subif)#
```

- In the following example, the class named *boston* is applied to a new PVC (0/102) in subinterface 5/0/0.2.

```
Router(config)# interface atm 5/0/0.2
Router(config-subif)# pvc 0/102
Router(config-if-atm-vc)# class-vc boston
Router(config-if-atm-vc)#
```

You have completed the steps for assigning a VC class to a PVC.

## Enabling ILMI PVC Discovery

You can enable ILMI to automatically discover PVCs on neighboring switches and duplicate those PVC entries on the 1-Port OC-12 ATM line card.

To enable ILMI

- 
- Step 1** Create PVC 0/16 on the main interface, as shown in the following example:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/16 ilmi
Router(config-if-atm-vc)# exit
Router(config-if)#
```

- Step 2** In the following example, ILMI PVC discovery is enabled for the 1-Port OC-12 ATM line card.

```
Router(config-if)# atm ilmi-pvc-discovery
```

You have completed the steps required for running ILMI PVC discovery. You can use the **show atm pvc** command to display the PVCs on the Cisco 10000 series router.

---

## Completing a Configuration

This section offers general information on completing a configuration of an 1-Port OC-12 ATM line card.

- 
- Step 1** After you configure the interfaces for ATM, you may need to enter interface configuration mode and specify routing protocols, network addresses, and so on.
- Step 2** After you have included all of the configuration subcommands to complete the configuration, enter **Ctrl-Z** (hold down the **Control** key while you press **Z**) to exit configuration mode.
- Step 3** Write the new configuration to memory:

```
Router# copy running-config startup-config
```

The system displays an OK message when the configuration is stored. After you have completed your configuration, you can check it by using **show** commands.

---

## Commands

The 1-Port OC-12 ATM line card consists of a single OC-12 interface. You can put all the PVCs on this interface, or you can create subinterfaces. This section describes the principal commands for customizing interfaces and PVCs:

- [Global Configuration Command, page 3-7](#)
- [Interface and Subinterface Commands, page 3-7](#)
- [ATM PVC Commands, page 3-15](#)
- [Useful show Commands, page 3-19](#)

## Global Configuration Command

A PVC boilerplate is a PVC description that you can apply to one or more PVCs or interfaces

To create a PVC boilerplate, use the global configuration mode **vc-class atm** command.

```
vc-class atm class_name
```

Where *class\_name* is any word that describes the class.

After you create the class, you enter VC class configuration mode. In this mode, you describe the action you want the class to take by entering commands and arguments. These commands and arguments are described in the “[ATM PVC Commands](#)” section on page 3-15.

In the following example, an ATM VC class named *cambridge* is created and defined. This example shows how to specify that the class uses AAL5+MUX encapsulation and a VBR-NRT PVC.

```
Router(config)# vc-class atm cambridge
Router(config-vc-class)# encaps aal5mux ip
Router(config-vc-class)# vbr-nrt 30000 20000 128
Router(config-vc-class)# exit
Router(config)#
```

For information on applying a VC class name, see the “[Attaching an ATM VC Class to an Interface](#)” section on page 3-9 and the “[Attaching an ATM VC Class to a PVC](#)” section on page 3-17.

## Interface and Subinterface Commands

This section describes principal commands for configuring ATM interfaces and subinterfaces. This section describes the following global configuration commands:

- [Creating and Entering Subinterfaces, page 3-8](#)
- [Attaching an ATM VC Class to an Interface, page 3-9](#)
- [Creating ATM PVPs, page 3-9](#)
- [Creating a PVC, page 3-10](#)
- [Enabling ATM ILMI, page 3-11](#)

- [Activating ATM ILMI PVC Discovery, page 3-11](#)
- [Specifying the ATM ILMI Keepalive Rate, page 3-12](#)
- [Configuring ATM Clock, page 3-12](#)
- [Specifying the ATM Flag, page 3-12](#)
- [Controlling ATM Alarm Reporting, page 3-12](#)
- [Specifying the ATM Alarm Thresholds, page 3-13](#)
- [Controlling the S1 SONET Overhead Byte, page 3-14](#)
- [Running Loopbacks, page 3-14](#)

## Creating and Entering Subinterfaces

Use the **interface** command to divide the 1-Port OC-12 ATM line card interface into multiple subinterfaces to simplify management of the card, create interfaces with different MTU sizes, and create connections to different networks.

```
interface atm slot/subslot/port.subinterface type
no interface atm slot/subslot/port.subinterface type
```

Where:

- *slot* is 1 to 8
- *subslot* and *port* are both 0
- *subinterface* is a number from 1 to 4,294,967,295
- *type* is **point-to-point** or **multipoint**

To enter the subinterface at a later time, you do not need to specify the type.

To remove a subinterface and its PVCs, use the **no interface** command. To change a subinterface type, you must first remove the subinterface.

Examples:

- Create subinterface number 1 for an 1-Port OC-12 ATM line card in slot 1.

```
Router(config)# interface atm 1/0/0.1 point-to-point
Router(config-subif)#
```

- Enter an existing subinterface.

```
Router(config)# interface atm 1/0/0.1
Router(config-subif)#
```

- Use a multipoint subinterface.

If you want multiple PVCs to go to the same network, you must create a multipoint subinterface. For example:

```
Router(config)# interface atm 4/0/0.2 multipoint
Router(config-subif)#
```

After creating the subinterface, you can create PVCs that go to the same network. [Figure 3-1](#) shows a multipoint subinterface on a fully meshed network. Fully meshed indicates that any workstation can communicate with any other workstation.


**Figure 3-1 Multipoint ATM Configuration**

Table 3-6 provides the configuration commands used to configure the multipoint connections in the network shown in Figure 3-1.

**Table 3-6 Multipoint Configuration Example**

Router A	Router B	Router C
<pre>interface atm 4/0/0.2 multi ip address 131.108.168.1 255.255.255.0 pvc 0/35 protocol ip 131.108.168.2 broadcast pvc 0/36 protocol ip 131.108.168.3 broadcast</pre>	<pre>interface atm 2/0/0.1 multi ip address 131.108.168.2 255.255.255.0 pvc 0/35 protocol ip 131.108.168.1 broadcast pvc 0/37 protocol ip 131.108.168.3 broadcast</pre>	<pre>interface atm 5/0/0.1 multi ip address 131.108.168.3 255.255.255.0 pvc 0/36 protocol ip 131.108.168.1 broadcast pvc 0/37 protocol ip 131.108.168.2 broadcast</pre>

## Attaching an ATM VC Class to an Interface

To attach an ATM VC class to an interface, use the **class-int** command. If you customize a PVC, its customization takes precedence over the interface class.

```
class-int class_name
```

Where *class\_name* is the name of the class created using the global configuration **class-vc atm** command.

In the following example, a VC class named *cambridge* is created and attached to subinterface 3/0/0.1.

```
Router(config)# vc-class atm cambridge
Router(config-vc-class)# encaps aal5mux ip
Router(config-vc-class)# vbr-nrt 30000 20000 128
Router(config-vc-class)# exit
Router(config)# interface atm 3/0/0.1
Router(config-subif)# class-int cambridge
```

## Creating ATM PVPs

To create a permanent virtual path (PVP) used to multiplex one or more VBR-NRT VCs, use the **atm pvp** interface configuration command.

```
atm pvp vpi peak-rate [no-f4-oam]
no atm pvp vpi
```

Where:

- **vpi** is the ATM network virtual path identifier (VPI) of the VC used to multiplex the permanent virtual path. The range is 0 to 255. You must use a VPI value that is not already in use (by a VC).
- *peak-rate* is the maximum rate in Kbps at which the PVP can transmit data. You can enter values from 84 Kbps to 299,520 Kbps and you can also enter 599,040 Kbps. The PVP peak rate value supersedes all cell rate values set for VBR-NRT PVCs.
- **no-f4-oam** (optional) restricts the PVP from passing operations/administration/maintenance (OAM) packets. When you create a PVP, the system creates PVCs with VCI values of 3 and 4 for each PVP, which pass OAM packets.

To verify the configuration of a PVP, use the **show atm vp EXEC** command.

The following example shows how to create a PVP with a peak rate of 50000 Kbps. The subsequent VCs created are multiplexed onto this virtual path.

```
Router(config)# interface atm 7/0/0
Router(config-if)# atm pvp 25 50000
Router(config-if)# pvc 25/100
Router(config-if-atm-vc)# vbr-nrt 10000 5000 16
Router(config-if-atm-vc)# exit
Router(config-if)# pvc 25/101
Router(config-if-atm-vc)# vbr-nrt 10000 5000 16
Router(config-if-atm-vc)# exit
Router(config-if)# pvc 25/102
Router(config-if-atm-vc)# vbr-nrt 10000 5000 16
Router(config-if-atm-vc)# exit
```

## Creating a PVC

You can create a unspecified bit rate (UBR) PVC by entering the **pvc** command:

```
pvc [word] [vpi_value/]{vci_value} [ilmi]
```

Where:

- *vpi\_value* is in the range from 0 to 255. If you do not specify a VPI value, the system assigns the value of 0.
- *vci\_value* is in the range from 1 to 65535. The VCI value should be at least 33, because all of the lower-numbered PVCs are generally used for specific purposes.
- *word* is a name referring to this connection.
- the **ilmi** parameter maps the ILMI channel to the PVC for this interface. You can only use this argument for PVCs created on the main interface. It is highly recommended that you use this argument with PVC 0/16. For more information about activating ILMI, see the section [“Activating ATM ILMI PVC Discovery” section on page 3-11](#).

By default, the **pvc** command creates a UBR PVC; to create a VBR-NRT PVC, see the [“Configuring VBR-NRT” section on page 3-17](#).



### Note

You can only create one PVC on a point-to-point interface. Multiple PVCs can be created on a multipoint interface.



Examples:

- Create PVC 0/105 on the main interface.

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 105
Router(config-if-atm-vc)
```

- Create PVC 2/102 on a subinterface.

```
Router(config)# interface atm 5/0/0.1
Router(config-subif)# pvc 2/102
Router(config-if-atm-vc)#
```

## Enabling ATM ILMI

Use the **atm ilmi-enable** interface configuration command to enable the ILMI on a port.

```
atm ilmi-enable
no atm ilmi-enable
```

The default is ILMI is enabled, but you should disable the ILMI if the peer does not support ILMI. In order for peers to exchange ILMI information, you must create PVC 0/16, using the **ilmi** argument.

The following example disables ILMI:

```
Router(config)# interface atm 5/0/0
Router(config-if)# no atm ilmi-enable
```

## Activating ATM ILMI PVC Discovery

To activate ATM PVC discovery, use the **atm ilmi-pvc-discovery** interface configuration command. This command causes ILMI-compliant devices to propagate PVCs.

```
atm ilmi-pvc-discovery [subinterface]
no atm ilmi-pvc-discovery [subinterface]
```

Where:

- **subinterface** instructs the software to associate all PVCs with existing subinterface numbers equal to their VPI numbers. For example: PVC 2/102 would be listed under subinterface 7/0/0.2, PVC 12/156 would be listed under 7/0/0.12, and so on.



**Note** The **subinterface** argument associates PVCs only with subinterfaces that have already been created. If there is no subinterface for a VPI value, the system associates the PVC with the main interface.

The following example shows how to enable PVC Discovery on the ATM main interface 7/0/0 on an 1-Port OC-12 ATM line card that has ILMI enabled.

```
Router(config)# interface atm 7/0/0
Router(config-if)# pvc 0/16 ilmi
Router(config-if-atm-vc)# exit
Router(config-if)# atm ilmi-pvc-discovery
```

## Specifying the ATM ILMI Keepalive Rate

To specify the ILMI keepalive rate, enter the **atm ilmi-keepalive** command.

```
atm ilmi-keepalive [seconds [retry counts]]
```

Where:

- *seconds* is a value from 1 to 65535
- **retry counts** is a value from 2 to 5

The default value for seconds is 5000 and for retry counts is 4.

The following example shows how to enable ILMI keepalives for the ATM interface 5/0/0:

```
Router(config)# interface atm 5/0/0
Router(config-if)# atm ilmi-keepalive 10000 retry 3
```

## Configuring ATM Clock

To configure the clock source as internal, use the **atm clock internal** command:

```
atm clock internal
no atm clock internal
```

The default clock setting is **no atm clock internal**, which means that clocking is derived from the line.

In the following example, clocking is set from the router.

```
Router(config)# interface atm 5/0/0
Router(config-if)# atm clock internal
```

## Specifying the ATM Flag

To specify the ATM flag value for the s1s0 bit, use the **atm flag s1s0** command. This command is typically used to meet a standards requirement or to ensure interoperability with another vendor's equipment.

```
atm flag s1s0 value
```

Where:

- **s1s0** is part of the payload pointer byte
- *value* is from 0 to 3

The default s1s0 value is 0.

The following example assigns a value of 2 to the ATM flag:

```
Router(config)# interface atm 5/0/0
Router(config-if)# atm flag s1s0 2
```

## Controlling ATM Alarm Reporting

To control selected SONET alarms so that they are logged to the console for an ATM interface, use the **atm report** interface configuration command.

```
atm report {b1-tca | b2-tca | b3-tca | lais | lcd | lrldi | pais | plop | prdi | rdool |
sd-ber | sf-ber | slof | slof}
```

```
no atm report {b1-tca | b2-tca | b3-tca | lais | lcd | lrldi | pais | plop | prdi | rdool |
sd-ber | sf-ber | slof | slof}
```

Where:

- **b1-tca**—B1 bit error rate (BEF) threshold crossing alarm
- **b2-tca**—B2 BER threshold crossing alarm
- **b3-tca**—B3 BER threshold crossing alarm
- **lais**—Line Alarm Indication Signal
- **lcd**—Loss of cell delineation
- **lrldi**—Line Remote Defect Indication
- **pais**—Path Alarm Indication Signal
- **plop**—Path Loss of Pointer
- **prdi**—Path Remote Defect Indication
- **rdool**—Receive Data Out Of Lock
- **sd-ber**—Line bit interleave parity error (LBIP) BER in excess of signal degrade (SD) threshold
- **sf-ber**—LBIP BER in excess of signal fail (SF) threshold
- **slof**—Section Loss of Frame
- **slos**—Section Loss of Signal

To disable logging of select SONET alarms, use the **no** form of this command.

Reporting an alarm means that the alarm can be logged to the console. Not all alarms are logged. SONET alarm hierarchy rules dictate that only the most severe alarm of an alarm group is reported. Whether an alarm is reported or not, you can view the current state of a defect by checking the Active Defects line from the **show controllers atm** command output. A defect is a problem indication that is a candidate for an alarm.

The following example shows how to enable reporting of SD-BER and LAIS alarms on the interface:

```
Router(config)# interface atm 3/0/0
Router(config-if)# atm report sd-ber
Router(config-if)# atm report lais
Router(config-if)# end
Router#
```

## Specifying the ATM Alarm Thresholds

Specify the bit error rate (BER) threshold by using the **atm threshold** command:

```
atm threshold {b1-tca | b2-tca | b3-tca | sd-ber | sf-ber} value
```

Where:

- **b1-tca**—B1 BER threshold crossing alarm
- **b2-tca**—B2 BER threshold crossing alarm
- **b3-tca**—B3 BER threshold crossing alarm
- **sd-ber**—Set Signal Degrade BER threshold
- **sf-ber**—Set Signal Fail BER threshold
- *value* is an exponential value from  $10^{-3}$  to  $10^{-9}$  representing the BER at which an alarm occurs.

The default for all thresholds, except **sf-ber**, is  $10^{-6}$ . The default for **sf-ber** is  $10^{-3}$ .

The following example shows how to specify the B1 BER threshold crossing alarm value of 4:

```
Router(config)# interface atm 5/0/0
Router(config-if)# atm threshold b1-tca 4
```

## Controlling the S1 SONET Overhead Byte

On Cisco 10000 series routers, ATM line cards run over SONET. In most situations, the default value for the S1 SONET overhead byte (0x0) does not need to be changed. Refer to the SONET standards for information about the possible values for the S1 SONET overhead byte and the definition of each value.

### Controlling a Transmitted S1 Overhead Byte

In Cisco IOS Release 12.2(28)SB, use the **pos flag s1-byte tx** command in interface configuration mode to control the transmission of the S1 SONET overhead byte.

**pos flag s1-byte tx** *value*

Where:

- *value* is in the range of 0x0 to 0xF
- 0x0 is the default value

In the following example the S1 SONET overhead byte is set to 0xF:

```
pos flag s1-byte tx 0xF
```

### Reacting to a Received S1 Overhead Byte

In Cisco IOS Release 12.2(28)SB, use the **pos flag s1-byte rx-communicate** command to direct the router to switch the clock source to internal when it receives an S1 SONET overhead byte with a value of 0xF. When the S1 SONET overhead byte changes from 0xF to any other value, the clock source reverts back to the clock source specified in the user configuration.

The S1 overhead byte is ignored by the receiving router unless the **pos flag s1-byte rx-communicate** command is issued.

**pos flag s1-byte rx-communicate**

**no pos flag s1-byte rx-communicate**

The following example directs the router to switch to internal clocking when it receives an S1 SONET overhead byte with a value of 0xF:

```
pos flag s1-byte rx-communicate
```

The default for the **pos flag s1-byte rx-communicate** command is disabled or off.

## Running Loopbacks

You can run a loopback by using the **loopback** command:

```
loopback {line | diagnostic {parallel | path | serial}}
no loopback {line | diagnostic {parallel | path | serial}}
```

Where:

- **line** is the line loopback
- **diagnostic** starts an internal diagnostic loopback
- **parallel** is the internal diagnostic parallel loopback

- **path** is the internal diagnostic path loopback
- **serial** is the internal diagnostic serial loopback

The following example shows how to run the diagnostic serial loopback:

```
Router(config)# interface atm 5/0/0
Router(config-if)# loopback diagnostic serial
```

## ATM PVC Commands

After you create a PVC using the **pvc** command, you can customize the PVC or a VC class by using the commands described in this section.

- [Specifying a Protocol, page 3-15](#)
- [Configuring a Broadcast, page 3-16](#)
- [Configuring Inverse ARP, page 3-16](#)
- [Attaching an ATM VC Class to a PVC, page 3-17](#)
- [Configuring VBR-NRT, page 3-17](#)
- [Specifying Encapsulation, page 3-18](#)
- [Enabling ILMI Management, page 3-18](#)
- [Configuring OAM Retry, page 3-18](#)
- [Enabling OAM Loopback Cell Generation and Management, page 3-19](#)

### Specifying a Protocol

Use the **protocol ip** command in interface-ATM-VC configuration mode or VC-class configuration mode to do one or both of the following:

- Configure a static map for an ATM PVC or VC class.
- Enable Inverse ARP or Inverse ARP broadcasts on an ATM PVC by either configuring Inverse ARP directly on the PVC or in a VC class (applies to IP protocols only).

```
protocol ip {protocol-address | inarp} [[no] broadcast]
no protocol ip {protocol-address | inarp} [[no] broadcast]
```

Where:

- *protocol-address* is the peer destination address that is being mapped to a PVC.
- **inarp** (valid only for IP protocols on PVCs) enables Inverse ARP on an ATM PVC. If you specify a protocol-address instead of inarp, Inverse ARP is automatically disabled for that protocol.
- **[no] broadcast** (optional) indicates that this PVC sends out broadcast packets (for example, IGRP updates). Pseudo broadcasting is supported. The **broadcast** keyword of the protocol ip command takes precedence if you previously configured the broadcast command on the ATM PVC.

For PVCs created under point-to-point subinterfaces, broadcast is enabled by default. For PVCs created under multipoint subinterfaces, you should use the **broadcast** argument if you want to propagate IP routes.

Use the **no** form of this command to remove a static map or disable Inverse ARP.

**Note**


---

Use the **inarp** command to configure Inverse ARP frequency.

---

The following example shows how to specify IP protocol on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# protocol ip 172.16.32.49
```

## Configuring a Broadcast

To configure broadcast packet duplication and transmission for an ATM PVC or VC class, use the **broadcast** command.

The **broadcast** command is not used to enable ATM *cell-level* multicast, broadcast, replication, or to set up the broadcast of user level traffic. The **broadcast** command indicates which PVC (or PVCs) sends out broadcast traffic. This is typically limited to traffic associated with routing protocols and routing updates (for example, OSPF hello packets).

**Note**


---

The **broadcast** argument within the **protocol ip** command takes precedence over the **broadcast** command. See the [“Specifying a Protocol” section on page 3-15](#) for additional information about the **protocol ip** command.

---

Use the default form of this command to restore the default behavior described below.

```
broadcast
no broadcast
```

The default is **broadcast**.

Use the **no** form of this command to disable transmission of broadcast packets.

For PVCs created under point-to-point subinterfaces, **broadcast** is enabled by default. For PVCs created under multipoint subinterfaces, you should use the **broadcast** command if you want to propagate IP routes (only the first PVC on a multipoint interface receives broadcast traffic).

The following example shows how to use the **broadcast** command to restore the default behavior:

```
Router(config)# interface atm 5/0/0.4
Router(config-subif)# pvc 0/105
Router(config-if-atm-vc)# broadcast
Router(config-if-atm-vc)#
```

## Configuring Inverse ARP

To configure the Inverse ARP time period for an ATM PVC or VC class, use the **inarp** command in interface-ATM-VC configuration mode or VC-class configuration mode.

```
inarp minutes
no inarp minutes
```

Where *minutes* is the Inverse ARP frequency from 1 to 60 minutes.

The default frequency is 15 minutes.

Use the **no** form of this command to restore the default Inverse ARP time period behavior.

**Note**

This command is supported only for AAL5+SNAP encapsulation (the default) when Inverse ARP is enabled. Use the **encapsulation** command to configure AAL5+SNAP encapsulation and the **protocol** command to enable Inverse ARP.

The following example shows how to specify an Inverse ARP frequency of 40 minutes on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# inarp 40
```

## Attaching an ATM VC Class to a PVC

To attach an ATM VC class to a PVC, use the **class-vc** command.

```
class-vc name
```

Where:

- *name* is the name of the class created with the global configuration **class-vc atm** command.

The following example shows how to assign an ATM VC class named *boston* to an ATM PVC:

```
Router(config)# interface atm 5/0/0.4
Router(config-subif)# pvc 2/100
Router(config-if-atm-vc)# class-vc boston
```

## Configuring VBR-NRT

To configure the variable bit rate-nonreal time (VBR-NRT) traffic management type and specify output peak cell rate, output sustainable cell rate, and output maximum burst cell size for an ATM PVC or VC class, use the **vbr-nrt** command. Use **vbr-nrt** in interface-ATM-VC configuration mode or VC-class configuration mode.

```
vbr-nrt peak_cell_rate sustainable_cell_rate maximum_burst_size
no vbr-nrt peak_cell_rate sustainable_cell_rate maximum_burst_size
```

Where:

- *peak* is the peak cell rate (PCR) from 84 Kbps to 299,520 Kbps and 599,040 Kbps. The PCR must be at least equal to the sustainable cell rate (SCR)
- *sustainable* is the sustainable cell rate (SCR) from 84 Kbps to 299,520 Kbps and 599,040 Kbps.
- *maximum* is a number from 1 to 256 that represents Maximum Burst Size (MBS) in cells

The default class of service is unspecified bit rate (UBR) running at the maximum line rate of the physical interface.

Use the **no** form of this command to remove the VBR-NRT parameters and return the PVC to its default of unspecified bit rate (UBR).

You can create up to 254 VBR-NRT PVCs on an 1-Port OC-12 ATM line card.

The following example shows how to configure the VBR-NRT traffic parameters on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# vbr-nrt 50000 20000 200
```

## Specifying Encapsulation

To specify the ATM adaptation layer (AAL) and encapsulation type for an ATM PVC or VC class, use the **encapsulation** command in interface-ATM-VC configuration mode or VC-class configuration mode.

```
encapsulation {aal5mux ip | aal5snap}
no encapsulation {aal5mux ip | aal5snap}
```

Where:

- **aal5mux ip** is AAL5+MUX encapsulation
- **aal5snap** is AAL5+LLC/SNAP encapsulation (the default)

Use the **no** form of this command to remove an encapsulation from a PVC or VC class.

The following example shows how to specify **aal5mux ip** encapsulation for an ATM PVC:

```
Router(config)# interface atm 5/0/0.4
Router(config-subif)# pvc 0/105
Router(config-if-atm-vc)# encaps aal5mux ip
```

## Enabling ILMI Management

To enable ILMI management on an ATM PVC, use the **ilmi manage** command in interface-ATM-VC configuration mode or VC-class configuration mode. This command changes the convergence of higher-level protocols based on link-state changes.

```
ilmi manage
no ilmi manage
```

Use the **no** form of this command to disable ILMI management.

The following example shows how to enable ILMI management on an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# ilmi manage
```

## Configuring OAM Retry

To configure OAM retry, use the **oam retry** command in interface-ATM-VC configuration mode or VC-class configuration mode.

```
oam retry up_value [down_value frequency]
no oam retry up_value [down_value frequency]
```

Where:

- *up\_value* is a number from 1 to 600 that represents the OAM retry count before declaring a VC is up.  
Default is 3 retries.
- *down\_value* is a number from 1 to 600 that represents the OAM retry count before declaring a VC is down.  
Default is 5 retries.
- *frequency* is a number from 1 to 1000 that represents the OAM retry polling frequency, in seconds.  
Default is 1 second.

Use the **no** form of the command to remove oam retry parameters.



The following example shows how to configure OAM retry to an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# oam retry 10 10 5
```

## Enabling OAM Loopback Cell Generation and Management

To enable end-to-end F5 OAM loopback cell generation and OAM management for an ATM PVC or VC class, use the **oam-pvc** command in interface-ATM-VC configuration mode or VC-class configuration mode.

```
oam-pvc [manage] [frequency]
no oam-pvc [manage] [frequency]
```

Where:

- **manage** is an optional keyword that brings down the line if the PVC loopback fails.
- *frequency* (optional) is the number of seconds between transmitting OAM loopback cells. Values range from 0 to 600 seconds.

The default value is 10 seconds.

Use the **no** form of this command to disable generation of OAM loopback cells and OAM management.

The following example enables OAM loopback cell and OAM management to an ATM PVC:

```
Router(config)# interface atm 5/0/0
Router(config-if)# pvc 0/105
Router(config-if-atm-vc)# oam-pvc 300
```

## Useful show Commands

### show atm vc

Use the **show atm vc** command to display information about the VCs on the interface.

```
Router# show atm vc
```

Interface	VCD / Name	VPI	VCI	Type	Encaps	Peak Kbps	Avg/Min Kbps	Burst Cells	Sts
2/0/0	1	0	16	PVC	ILMI	599040			UP
2/0/0	9	0	100	PVC	MUX	599040			UP
2/0/0.2	7	2	32	PVC	SNAP	599040			UP
2/0/0	8	2	33	PVC	SNAP	599040			UP
2/0/0	18	2	100	PVC	SNAP	599040			UP
2/0/0.2	6	4	24	PVC	SNAP	599040			UP
2/0/0	2	25	3	PVC	F4-OAM	50000			UP
2/0/0	3	25	4	PVC	F4-OAM	50000			UP
2/0/0	14	25	100	PVC	SNAP	50000	50000	0	UP
2/0/0	16	25	101	PVC	SNAP	50000	50000	0	UP
2/0/0	17	25	102	PVC	SNAP	50000	50000	0	UP
2/0/0	10	26	3	PVC	F4-OAM	50000			UP
2/0/0	11	26	4	PVC	F4-OAM	50000			UP
2/0/0	12	27	3	PVC	F4-OAM	50000			UP
2/0/0	13	27	4	PVC	F4-OAM	50000			UP
2/0/0	19	33	100	PVC	SNAP	10000	8000	10	UP

```
Router#
```

### show atm vp

Use the **show atm vp** command to display information about the VPs on the interface.

```
Router# show atm vp

```

Interface	VPI	Data VCs	CES VCs	Peak Kbps	CES Kbps	Status
ATM2/0/0	25	3	0	50000	0	ACTIVE
ATM2/0/0	26	0	0	50000	0	ACTIVE
ATM2/0/0	27	0	0	50000	0	ACTIVE

```
Router#
```

### show atm pvc

Use the **show atm pvc vpi\_number/vci\_number** command to display detailed information about a specific PVC.

```
Router# show atm pvc 0/100

```

```
ATM2/0/0: VCD: 9, VPI: 0, VCI: 100
UBR, PeakRate: 599040
AAL5-MUX, etype:0x800, Flags: 0xC23, VCmode: 0x0
OAM frequency: 0 second(s), OAM retry frequency: 1 second(s)
OAM up retry count: 3, OAM down retry count: 5
OAM Loopback status: OAM Disabled
OAM VC state: Not Managed
ILMI VC state: Not Managed
InARP DISABLED
InPkts: 0, OutPkts: 0, InBytes: 0, OutBytes: 0
InProc: 0, OutProc: 0, Broadcasts: 0
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
InPktDrops: 0, OutPktDrops: 0
Out CLP=1 Pkts: 0
OAM cells received: 0
F5 InEndloop: 0, F5 InSegloop: 0, F5 InAIS: 0, F5 InRDI: 0
OAM cells sent: 0
F5 OutEndloop: 0, F5 OutSegloop: 0, F5 OutRDI: 0
OAM cell drops: 0
PVC Discovery: NOT_VERIFIED
Status: UP
Router#
```



## **PART 2**

### **Channelized Line Cards**





# CHAPTER 4

## 4-Port Channelized T3 Half-Height Line Card Configuration

---

This chapter describes the Cisco 10000 series 4-Port Channelized T3 Half-Height line card, hereafter known as the 4-Port Channelized T3 Half-Height line card.

The 4-Port Channelized T3 Half-Height line card provides the Cisco 10000 router with four DS3 ports of high-density T3 service (eight T3 ports per slot).

This chapter contains the following sections:

- [Software Support, page 4-1](#)
- [Feature Overview, page 4-2](#)
- [Default Values, page 4-3](#)
- [Interface Syntax, page 4-4](#)
- [Interface Configuration Sample, page 4-4](#)
- [Unchannelized T3 Commands, page 4-6](#)
- [Channelized T3 Commands, page 4-12](#)
- [Channel-Group Command for DS0 Time Slots and T1s, page 4-17](#)
- [Channelized T1 Commands, page 4-19](#)
- [High Availability Using Line Card Redundancy, page 4-24](#)
- [Command Reference, page 4-31](#)

## Software Support

[Table 4-1](#) shows the minimum Cisco IOS release on each release train that supports the 4-Port OC-3/STM-1 ATM line card.

**Table 4-1** 4-Port OC-3/STM-1 ATM Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE2	Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Feature Overview

The 4-Port Channelized T3 Half-Height line card is very similar in function to the 6-Port Channelized T3 line card. The differences are summarized in the following features list for the 4-Port Channelized T3 Half-Height line card:

- Provides the Cisco 10000 series router with four DS3 ports of high-density T3 service (eight T3 ports per slot)
- Supports full line rate transfers of packet sizes from 64 bytes to 8000 bytes
- Supports 256 serial data channels for the first three ports, and 255 serial data channels for the last port, or 1023 channels per half-height module
- The 256 (255) serial data channels per port are configurable up to:
  - 1 DS3 interface
  - 28 DS1 interfaces
  - 256 (255) N x DS0 interfaces
  - Or any combination of these interfaces that does not exceed the bandwidth of the port



---

**Note** Port 3 supports only 255 channels.

---

- Provides high availability when two 4-Port Channelized T3 Half-Height line cards are installed and interconnected with a Y-cable in a redundant configuration
- Supports six T1 BER tests simultaneously for each set of two ports
- Adds new BER test patterns (3in24, 1in8, and 2in8) and the **show bert** command to display BER test statistics
- Adds remote loopback inband looping codes (2in5 and 3in5) for T1 SF and ESF framing



**Note**

---

For information on installing half-height line cards in subslots, refer to the [Cisco 10000 Series Routers Line Card Hardware Installation Guide](#).

---

## Default Values

Table 4-2 lists default values for the 4-Port Channelized T3 Half-Height line card and indicates which values apply to which line speeds. The table includes the command used for modifying a default value and indicates whether a value needs to be the same (or opposite) on the remote end of the connection.

**Table 4-2 4-Port Channelized T3 Half-Height Line Card Default Values**

Command Name	Default Setting	Command Syntax	Remote Side Setting	DS0	T1	Ch T3	Unch T3
<b>Controller Configuration Mode</b>							
cable length	249	<code>cablelength feet</code>	—			X	X
channelized	channelized	<code>[no] channelized</code>	—			X	X
clock source	internal	<code>clock source [line   internal]</code>	At least one side set to <b>internal</b>			X	X
T1 clock source	internal	<code>t1 t1-number clock source [line   internal]</code>	At least one side set to <b>internal</b>		X		
framing	auto-detect	<code>framing [c-bit   m23   auto-detect]</code>	Same			X	
T1 framing	esf	<code>t1 t1-number framing [esf   sf [hdlc-idle {0x7e   0xff}]]</code>	Same		X		
idle pattern	0x7e (flags)	<code>idle pattern [0x0 to 0xff]</code>	Same		X	X	
<b>Interface Configuration Mode</b>							
crc (cyclical redundancy check)	16	<code>[no] crc [16   32]</code>	Same	X	X		X
dsu bandwidth	44,210	<code>dsu bandwidth bandwidth</code>	Same				X
dsu mode	cisco	<code>dsu mode mode</code>	Same				X
encapsulation	HDLC	<code>encapsulation [hdlc   ppp   frame-relay]</code>	Same	X	X		X
framing	c-bit	<code>framing [c-bit   m13]</code>	Same				X
idle character	flags (0x7e)	<code>idle character [flags   marks]</code>	Same				X
keepalive	keepalive (10 sec)	<code>keepalive</code>	Same	X	X		X
mtu (maximum transmission unit)	1500	<code>mtu size</code>	Same	X	X		X
scramble	No scrambling	<code>[no] scramble</code>	Same				X

# Interface Syntax

To specify an interface number in a configuration command, use the syntax in [Table 4-3](#) to identify interfaces on the 4-Port Channelized T3 Half-Height line card.

**Table 4-3 4-Port Channelized T3 Half-Height line card Interface Syntax**

Type of Interface	Slot	Subslot	Port (T3 Number)	T1 Number	Channel Group Number
Unchannelized	1 to 8/	0 or 1/	0 to 3	—	—
Channelized	1 to 8/	0 or 1/	0 to 3/	1 to 28	0 to 23

Examples:

- Modifying T1 interface 6 in controller configuration mode:

```
Router(config)# controller t3 2/0/0
Router(config-controller)# t1 6
```

- Modifying T1 interface 6, channel group number 8 in interface configuration mode:

```
Router(config)# interface serial 2/0/0/6:8
Router(config-if)#
```

## Interface Configuration Sample

Each T3 controller can be configured as a single T3 interface (full or subrate), as 28 T1 interfaces, or as an even larger number of fractional T1s. The following procedure walks you through the basic steps for creating full-rate and subrate T3 interfaces, as well as T1 and fractional T1 interfaces:

- Step 1** Create an interface. In the following examples, each type of interface is created in a different T3 controller (2/0/0 through 2/0/3).

### Full-Rate T3 Interface

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/0
Router(config-controller)#
```

- b. To create a full-rate T3 interface, you must eliminate the T1 interfaces by entering the **no channelized** command.

```
Router(config-controller)# no channelized
Router(config-controller)# exit
Router(config)#
```

- c. Go to interface configuration mode:

```
Router(config)# interface serial 2/0/0
```

- d. You can now continue to Step 2.



### Subrate T3 Interface

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/1
Router(config-controller)#
```

- b. To create a subrate T3 interface, first create a full-rate one.

```
Router(config-controller)# no channelized
Router(config-controller)# exit
Router(config)#
```

- c. Then go into interface configuration mode, where you can use the **dsu bandwidth** command to create a subrate T3 interface. In this example, a subrate T3 interface is created that has a bandwidth of 16,000 kbps.

```
Router(config)# interface serial 2/0/1
Router(config-if)# dsu mode digital-link
Router(config-if)# dsu bandwidth 16000
```

- d. You can now continue to Step 2.

### Full T1 Interface

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/2
Router(config-controller)#
```

- b. Use the **t1 channel group** command to create a T1 interface. In the following example, T1 interface 1 (of 28) is defined as being made up of a single channel group, number 20 (any number between 0 and 23). This channel group consists of all 24 DS0 time slots.

```
Router(config-controller)# t1 1 channel-group 20 timeslots 1-24
```

- c. Go to interface configuration mode for the channel group you just created.

```
Router(config)# interface serial 2/0/2/1:20
```

- d. You can now continue to Step 2.

### Fractional T1 Interface

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/3
Router(config-controller)#
```

- b. Use the **t1 channel group** command to create fractional T1 interfaces. In the following example, T1 interface 3 (of 28) is defined as being made up of three channel groups, numbers 19, 20, and 21. (Numbers between 0 and 23 are allowed.) The channel groups consist of a total of 24 DS0 time slots. Each channel group represents a separate interface.

```
Router(config-controller) t1 3 channel-group 19 timeslots 1-6, 10
Router(config-controller) t1 3 channel-group 20 timeslots 7,8,9
Router(config-controller) t1 3 channel-group 21 timeslots 11-24
```

- c. Go to interface configuration mode for one of the channel groups; for example:

```
Router(config)# interface serial 2/0/3/3:19
```

- d. You can now continue to Step 2.

**Step 2** Enter the encapsulation method. This example shows the command for using Frame Relay encapsulation. You can also choose PPP or HDLC.

```
Router(config-if)# encapsulation frame relay
```

**Step 3** If IP routing is enabled on the system, assign an IP address and subnet mask; for example:

```
Router(config-if)# ip address 172.16.32.49 255.255.0.0
```

**Step 4** Add any configuration subcommands required to enable routing protocols and set the interface line characteristics.

**Step 5** Change the shutdown state to up, which enables the interface.

```
Router(config-if)# no shutdown
```

**Step 6** When you have entered all of the configuration subcommands to complete the configuration, press **Ctrl-Z** to exit configuration mode.

**Step 7** To write the new configuration to NVRAM, type

```
Router# copy running-config startup-config
```

---

After you create an interface configuration, you can modify it at any time by using the appropriate Cisco IOS configuration commands.

## Unchannelized T3 Commands

By default, a T3 interface on a 4-Port Channelized T3 Half-Height line card is channelized into 28 T1 interfaces. You must unchannelize the T3 interface in order to create a full-rate or subrate T3 interface. This section describes the commands you use to create, customize, and test full-rate and subrate T3 interfaces. This section describes the following:

- [Configuring a T3 Interface as Unchannelized, page 4-7](#)
- [Specifying the DSU Mode, page 4-7](#)
- [Specifying Subrate T3 Bandwidth, page 4-7](#)
- [Setting the Framing Type, page 4-8](#)
- [Enabling Scrambling, page 4-8](#)
- [Specifying an Idle Character, page 4-8](#)
- [Configuring a BER Test, page 4-9](#)
- [Specifying the Cable Length, page 4-10](#)
- [Entering MDL Messages, page 4-10](#)
- [Setting the Clock Source, page 4-11](#)
- [Configuring Loopback Mode, page 4-12](#)
- [Running Equipment Loopbacks, page 4-12](#)



### Note

Configuring a T3 interface as unchannelized must occur in controller configuration mode. All other configuration of an unchannelized T3 interface must occur in *interface* configuration mode.

---

## Configuring a T3 Interface as Unchannelized

The default value for a T3 interface is channelized. To create an unchannelized T3 interface, you must first enter controller configuration mode for the T3 controller you want to configure.

```
controller T3 slot/sub-slot/port
```

After entering controller configuration mode, you can configure the T3 interface as unchannelized (clear channel) by entering the **no channelized** command. Use the **channelized** command to return the interface to its default (channelized).

```
[no] channelized
```



### Caution

The **no channelized** command removes all channel groups from a channelized T3 interface. If you have already configured channel groups, use this command with caution.

In the following example, an unchannelized T3 interface is created:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# no channelized
```

## Specifying the DSU Mode

To specify a DSU mode for a selected T3 interface, use the **dsu mode** command from interface configuration mode. This command configures the line card to emulate a manufacturer's proprietary multiplexing scheme.

```
[no] dsu mode [Adtran | cisco | Digital-link | Kentrox | Larscom | verilink-highbit |
verilink-lowbit]
```

The default DSU mode is **cisco**.

Use the **no** form of the command to return the DSU mode to its default.

In the following example, the DSU mode is set to **cisco**:

```
Router(config)# interface serial 1/0/0
Router(config-if)# dsu mode cisco
```

## Specifying Subrate T3 Bandwidth

To specify subrate T3 bandwidth, use the **dsu bandwidth** *bandwidth* command from interface configuration mode.

```
[no] dsu bandwidth bandwidth
```

Where *bandwidth* is a numeric value between 0 and 44210 kbps.

The default bandwidth is 44210 kbps.

To return to the default bandwidth, use the **no** form of this command.

When you specify a value, the software sets the bandwidth to the closest acceptable bandwidth, based on the time slot size for the current DSU mode.

To use the **dsu bandwidth** command, the remote side of the connection must also support the same DSU modes.

In the following example, a bandwidth of 16000 kbps is specified:

```
Router(config)# interface serial 1/0/0
Router(config-if)# dsu bandwidth 16000
```

## Setting the Framing Type

To specify a framing type for the unchannelized T3 controller, use the **framing** command.

```
[no] framing [c-bit | m13]
```

The default framing type is C-bit.

Use the **no** form of this command to restore the default framing type.

In the following example, framing is set to m13:

```
Router(config)# interface serial 1/0/0
Router(config-if)# framing m13
```

## Enabling Scrambling

To enable scrambling on an unchannelized T3 interface, use the **scramble** command from interface configuration mode.

```
[no] scramble
```

The default setting for this command is **no scramble** (scrambling disabled).

Both sides of the link should have the same scrambling setting.

In the following example, scrambling is enabled on the specified T3 interface:

```
Router(config)# interface serial 1/0/0
Router(config-if)# scramble
```

## Specifying an Idle Character

To set a specific character on the unchannelized T3 interface to be transmitted between HDLC packets, use the **idle character** command from interface configuration mode.

```
[no] idle-character [flags | marks]
```

Where:

- **flags** sets an idle character of 0x7e.
- **marks** sets an idle character of all 0xff.

The default idle character is 0x7e.



### Note

Because **flags** is the default, the output of the **show running-config** command does not display the **flags** idle character setting.

Use the **no** form of the command to return the idle character to its default.

In the following example, the idle character is set to **flags**:

```
Router(config)# interface serial 1/0/0
Router(config-if)# idle-character flags
```



**Note**

Some systems interpret marks (or 0xff) as an abort signal. Therefore, flags (or 0x7e) is preferred.

## Configuring a BER Test

You can configure an unchannelized T3 interface to run a bit error rate (BER) test. The test can be used in checking cables and solving signal problems in the field. To send a BER test pattern on an unchannelized T3 interface, use the following interface configuration command:

```
[no] bert [errors number | pattern pattern] interval time
```

Where:

- **errors number** is 1 to 255.
- **pattern pattern** is
  - 0s—Repetitive test pattern of all zeros (00000..)
  - 1s—Repetitive test pattern of all ones (11111..)
  - 2<sup>15</sup>—Pseudorandom O.151 test pattern (32,768 bits long)
  - 2<sup>20</sup>-O153—Pseudorandom O.153 test pattern (1,048,575 bits long)
  - QRSS-2<sup>20</sup>—Pseudorandom QRSS O.151 test pattern (1,048,575 bits long)
  - 2<sup>23</sup>—Pseudorandom O.151 test pattern (8,388,607 bits long)
  - alt-0-1—Repetitive alternating test pattern of zeros (0s) and ones (1s), for example 01010101
- **interval time** is 1 to 1440 minutes.

You can terminate a BER test at any time using the **no bert** command.

For more information, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

The following are example of configuring a BER test:

- Send a BER test pseudorandom pattern of 2<sup>20</sup> through T3 interface 1/0/0 for 5 minutes.

```
Router(config)# interface serial 1/0/0
Router(config-if)# bert pattern 2^20 interval 5
```

- Send a repetitive pattern of all 1s through T3 interface 1/0/0 for 1440 minutes.

```
Router(config)# interface serial 1/0/0
Router(config-if)# bert pattern 1s interval 1440
```

To show BER test statistics, use the **show controllers t3 slot/subslot/port bert** command in EXEC or privileged EXEC mode:

```
Router# show controllers t3 6/1/0 bert
T3 6/1/0 is up.
BERT test result (done)
Test Pattern : 2^15, Status : Not Sync, Sync Detected : 1
Interval : 5 minute(s), Time Remain : 0 minute(s)
Bit Errors (since BERT started): 0 bits,
Bits Received (since BERT started): 13025 Mbits
Bit Errors (since last sync): 0 bits
Bits Received (since last sync): 13025 Mbits
```

## Specifying the Cable Length

To specify the cable length for the T3 controller, use the **cablelength** command.

```
[no] cablelength feet
```

Where *feet* is a number from 0 to 450.

The default value is 249 feet.

Use the **no** form of this command to restore the default cable length.

In the following example, the cable length value is set to 40 feet.

```
Router(config)# interface serial 1/0/0
Router(config-if)# cablelength 40
```



### Note

This command causes the system to use one of two settings for impedance matching and pulse shaping, one setting for any cable length between 0 and 249 feet and another setting for any cable length greater than 250 feet. The exact value you enter is stored in the configuration file.

## Entering MDL Messages

You can configure maintenance data link (MDL) messages (as defined in the ANSI T1.107a-1990 specification) on the unchannelized T3 interface.



### Note

MDL messages are supported only when the T3 framing is set for C-bit parity. (See the [“Setting the Framing Type”](#) section on page 4-8.)

To configure MDL messages, use the **mdl** command.

```
[no] mdl {transmit {path | idle-signal | test-signal} | string {eic | lic | fic | unit | pfi |
port | generator} id_string}
```

Where:

- **transmit path** enables transmission of the MDL path message.
- **transmit idle-signal** enables transmission of the MDL idle signal message.
- **eic** is the equipment identification code (up to 10 characters).
- **lic** is the location identification code (up to 11 characters).
- **fic** is the frame identification code (up to 10 characters).
- **unit** is the unit identification code (up to 6 characters).
- **pfi** is the facility identification code to include in the MDL path message (up to 38 characters).
- **port** is the equipment port (which initiates the idle signal) to include in the MDL idle signal message (up to 38 characters).
- **generator** is the generator number to include in the MDL test signal message (up to 38 characters).

The default is that no MDL message is configured.

Use the **no** form of the command to remove an MDL message.

Examples of configuring MDL messages follow:

- Enable the MDL path message transmission.  

```
Router(config)# interface serial 1/0/0
Router(config-if)# mdl transmit path
```
- Enable the MDL idle signal message transmission.  

```
Router(config-if)# mdl transmit idle-signal
```
- Enable the MDL test signal message transmission.  

```
Router(config-if)# mdl transmit test-signal
```
- Enter the equipment identification code.  

```
Router(config-if)# mdl string eic router A
```
- Enter the location identification code.  

```
Router(config-if)# mdl string lic test network
```
- Enter the frame identification code.  

```
Router(config-if)# mdl string fic building b
```
- Enter the unit identification code.  

```
Router(config-if)# mdl string unit abc
```
- Enter the facility identification code.  

```
Router(config-if)# mdl string pfi string
```
- Enter the port number to send in the MDL idle signal message.  

```
Router(config-if)# mdl string port string
```
- Enter the generator number to send in the MDL test signal message.  

```
Router(config-if)# mdl string generator string
```

## Setting the Clock Source

At the prompt, set the internal or line clock source for the selected T3 controller using the **clock source** command. This command is set in controller configuration mode.

```
clock source {internal | line}
```

Where:

- **internal** specifies that the internal clock source is used.
- **line** specifies that the network clock source is used.

The default is clock source internal.

In this example, a T3 controller is instructed to use a line clock source.

```
Router(config)# interface serial 1/0/0
Router(config-if)# clock source line
```



### Note

The clock source cannot be specified as **line** on both ends of the connection.

## Configuring Loopback Mode

You can configure the T3 controller for loopback mode using the **loopback** command.

```
[no] loopback [local | network | remote]
```

Local and network loopbacks are the same.

To cancel a loopback, use the **no** form of the command.

For more information on the **loopback** command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Examples:

- Configure the T3 controller for local loopback.

```
Router(config)# interface serial 1/0/0
Router(config-if)# loopback local
```

- Configure the T3 controller for remote loopback.

```
Router(config)# interface serial 1/0/0
Router(config-if)# framing c-bit
Router(config-if)# loopback remote
```




---

**Note** Remote loopback works only when framing is set to **c-bit**.

---

## Running Equipment Loopbacks

Use the **equipment loopback** command to run loopbacks in conjunction with remote equipment.

```
[no] equipment [customer | network] loopback
```

Where:

- **customer** enables the line card to respond to remote T3 loopback commands from the remote T3 equipment.
- **network** causes the line card to ignore remote T3 loopback commands.

Use the **no** form of the command to terminate the loopback.

For more information on the **loopback** command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

In the following example, an equipment network loopback is configured:

```
Router(config)# interface serial 1/0/0
Router(config-if)# equipment network loopback
```

## Channelized T3 Commands

By default, a T3 interface on a 4-Port Channelized T3 Half-Height line card is channelized into 28 T1 interfaces. This section describes the commands you use to customize and test a channelized T3 interface. This section describes:

- [Configuring a T3 Interface as Channelized, page 4-13](#)
- [Specifying the Cable Length, page 4-14](#)




- [Setting the Framing Type, page 4-14](#)
- [Entering MDL Messages, page 4-14](#)
- [Specifying the Idle Pattern, page 4-15](#)
- [Setting the Clock Source, page 4-16](#)
- [Configuring Loopback Mode, page 4-16](#)
- [Running Equipment Loopbacks, page 4-17](#)

To use the channels for subscriber traffic, you must configure the T1 and DS0 components. For more information, see the “[Channel-Group Command for DS0 Time Slots and T1s](#)” section on page 4-17.

Figure 4-1 shows the levels of configurable interface bandwidth that channelization offers.

**Figure 4-1 Channelization of T3s**



## Configuring a T3 Interface as Channelized

All configuration of a T3 channelized interface must occur in controller configuration mode.

```
controller T3 slot/sub-slot/port
```

A T3 interface is channelized by default. Use the **channelized** command if you had previously made the interface unchannelized and want to change the setting.

```
[no] channelized
```



### Caution

The **no channelized** command removes all channel groups from a channelized T3 interface. If you have already configured channel groups, use this command with caution.

The following example shows the creation of a channelized T3 interface:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# channelized
```

## Specifying the Cable Length

To specify the cable length for the T3 controller, use the **cablelength** command.

```
[no] cablelength feet
```

Where *feet* is a number from 0 to 450.

The default value is 249 feet.

Use the **no** form of this command to restore the default cable length.

In the following example, the cable length value is set to 40 feet.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# cablelength 40
```



### Note

This command causes the system to use one of two settings for impedance matching and pulse shaping, one setting for any cable length between 0 and 249 feet and another setting for any cable length greater than 250 feet. The exact value you enter is stored in the configuration file.

## Setting the Framing Type

To specify a framing type for the channelized T3 controller, use the **framing** command.

```
[no] framing [c-bit | m23 | f]
```

The default is **auto-detect**.

Use the **no** form of the command to return the framing type to its default.

You can instruct the 4-Port Channelized T3 Half-Height line card to detect the framing type from the far end and transmit that same framing type as follows:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# framing auto-detect
```

## Entering MDL Messages

You can configure maintenance data link (MDL) messages (as defined in the ANSI T1.107a-1990 specification) on the channelized T3 interface.



### Note

MDL messages are supported only when the T3 framing is set for C-bit parity. (See the “[Setting the Framing Type](#)” section on page 4-14.)

To configure MDL messages, use the **mdl** command.

```
[no] mdl {transmit {path | idle-signal | test-signal} | string {eic | lic | fic | unit | pfi |
port | generator} id_string}
```

Where:

- **transmit path** enables transmission of the MDL path message.
- **transmit idle-signal** enables transmission of the MDL idle signal message.
- **eic** is the equipment identification code (up to 10 characters).

- **lic** is the location identification code (up to 11 characters).
- **fic** is the frame identification code (up to 10 characters).
- **unit** is the unit identification code (up to 6 characters).
- **pfi** is the facility identification code to include in the MDL path message (up to 38 characters).
- **port** is the equipment port (which initiates the idle signal) to include in the MDL idle signal message (up to 38 characters).
- **generator** is the generator number to include in the MDL test signal message (up to 38 characters).

The default is that no MDL message is configured.

Use the **no** form of the command to remove an MDL message.

Examples of configuring MDL messages follow:

- Enable the MDL path message transmission.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# mdl transmit path
```

- Enable the MDL idle signal message transmission.

```
Router(config-controller)# mdl transmit idle-signal
```

- Enable the MDL test signal message transmission.

```
Router(config-controller)# mdl transmit test-signal
```

- Enter the equipment identification code.

```
Router(config-controller)# mdl string eic router A
```

- Enter the location identification code.

```
Router(config-controller)# mdl string lic test network
```

- Enter the frame identification code.

```
Router(config-controller)# mdl string fic building b
```

- Enter the unit identification code.

```
Router(config-controller)# mdl string unit abc
```

- Enter the facility identification code.

```
Router(config-controller)# mdl string pfi string
```

- Enter the port number to send in the MDL idle signal message.

```
Router(config-controller)# mdl string port string
```

- Enter the generator number to send in the MDL test signal message.

```
Router(config-controller)# mdl string generator string
```

## Specifying the Idle Pattern

You can set a specific pattern to be transmitted between HDLC packets on all unconfigured time slots that belong to a channelized T3 interface. To do so, use the **idle pattern** command.

```
[no] idle pattern patterns
```

Where *patterns* is a number in the range of 0x0 to 0xff (hexadecimal) or 0 to 255 (decimal). You can enter this value in either hexadecimal or decimal form. Values of 0 to 254 set the idle pattern to HDLC flags (0x7e); a value of 255 sets the pattern to 0xff (all ones).



---

**Note** Some systems interpret marks (or 0xf) as an abort signal. Therefore, flags (or 0x7e) is preferred.

---

The default idle pattern is 0x7e.

Use the **no** form of the command to return the idle pattern to its default value.

Examples:

- Set a hexadecimal idle pattern.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# idle pattern 0x10
```

- Set a decimal idle pattern.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# idle pattern 23
```

## Setting the Clock Source

At the prompt, set the internal or line clock source for the selected T3 controller using the **clock source** command. This command is set in controller configuration mode.

```
clock source {internal | line}
```

Where:

- **internal** specifies that the internal clock source is used
- **line** specifies that the network clock source is used

The default is clock source internal.

In this example, a T3 controller is instructed to use a line clock source.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# clock source line
```



---

**Note** The clock source cannot be specified as **line** on both ends of the connection.

---

## Configuring Loopback Mode

You can configure the T3 controller for loopback mode using the **loopback** command.

```
[no] loopback [local | network | remote]
```

Local and network loopbacks are the same.

To cancel a loopback, use the **no** form of the command.



---

**Note** When you configure loopback under a channelized T3 controller, all the T1 interfaces are configured to loopback mode.

---

For more information on the **loopback** command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Examples:

- Configure the T3 controller for local loopback.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# loopback local
```

- Configure the T3 controller for remote loopback.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# framing c-bit
Router(config-controller)# loopback remote
```



---

**Note** Remote loopback works only when framing is set to **c-bit**.

---

## Running Equipment Loopbacks

Use the **equipment loopback** command to run loopbacks in conjunction with remote equipment.

```
[no] equipment [customer | network] loopback
```

Where:

- **customer** enables the line card to respond to remote T3 loopback commands from the remote T3 equipment.
- **network** causes the line card to ignore remote T3 loopback commands.

Use the **no** form of the command to terminate the loopback.

For more information on the **loopback** command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

In the following example, an equipment network loopback is configured:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# equipment network loopback
```

## Channel-Group Command for DS0 Time Slots and T1s

Each channelized T3 consists of 28 T1s, each of which is divided into 24 time slots (or DS0s). To create an interface that supports subscriber traffic, you must combine the time slots into channel groups. Use the **t1 channel-group** command to create a channel group.

Channel groups have these characteristics:

- A channel group is an interface.
- A channel group can be one time slot to 24 time slots in size.
  - A channel group that consists of 24 time slots is a T1 interface.
  - A channel group that consists of fewer than 24 time slots can be described as a fractional T1 interface.
- Each group of 24 time slots can be divided into multiple fractional T1 interfaces.
- A channel group cannot be part of more than one T1.

Figure 4-1 illustrates channelization possibilities on the 4-Port Channelized T3 Half-Height line card.

You create a logical channel group using the following command:

```
[no] t1 t1-number channel-group channel-group-number timeslots list-of-timeslots [speed
{56 | 64}]
```

Where:

- *t1-number* is T1 interface number 1 to 28.
- **channel-group** *channel-group-number* identifies the channel group with any number from 0 to 23.
- **timeslots** *list-of-timeslots* can be 1 to 24 or a combination of subranges within 1 to 24. You can indicate a range using a hyphen, commas, or a combination of both. One time slot equals one DS0. Refer to the examples below.
- **speed** {56 | 64} is an optional argument that specifies the speed of a time slot as either 56 or 64 kbps. The default is 64. (The 56-kbps time slots are generally used with older T1 equipment that does not support B8ZS and are associated with SF framing.)

Use the **no** form of the command to remove a logical channel group.

The following examples show how to use the **t1 channel-group** command:

- In this example, T1 interface 3 includes channel group 20 and consists of nine channelized time slots:

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 3 channel-group 20 timeslots 1-8, 10
```

To enter interface configuration mode for this channel group, enter the following:

```
Router(config)# interface serial 1/0/0/3:20
```

- In the following example, T1 interface 4 includes channel group 18 and consists of all 24 time slots, creating a full T1 interface:

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 4 channel-group 18 timeslots 1-24
```

To enter interface configuration mode for this channel group, you enter the following:

```
Router(config)# interface serial 1/0/0/4:18
```

- In the following example, T1 interface number 5 is divided into three channel groups, which total 11 time slots:

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 5 channel-group 19 timeslots 1-6
Router(config-controller)# t1 5 channel-group 20 timeslots 10
Router(config-controller)# t1 5 channel-group 21 timeslots 7-9, 24
```

- In the following example, channel group 20 is removed:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# no t1 1 channel-group 20
```

## Channelized T1 Commands

From controller configuration mode for a T3 interface, you can enter commands to modify aspects of a T1 interface. This section describes the following:

- [Setting the Framing Format, page 4-19](#)
- [Controlling Yellow Alarms, page 4-19](#)
- [Setting the Clock Source, page 4-20](#)
- [Configuring FDL, page 4-20](#)
- [Configuring a BER Test, page 4-21](#)
- [Configuring T1 Loopback Mode, page 4-22](#)

After you configure a T1 interface, you can add encapsulation, routing, and other instructions by entering interface configuration mode; for example:

```
Router(config)# interface serial 1/0/0/4:18
```

### Setting the Framing Format

You can specify the T1 interface framing format using the following command:

```
[no] t1 t1-number framing {esf | sf [hdlc-idle {0x7e | 0xff}]}
```

Where:

- *t1-number* is T1 interface number 1 to 28.
- **framing** is either extended super frame (ESF) or super frame (SF). You can set SF hdlc-idle to 0x7e or 0xff.
- **hdlc-idle** options allow you to set the idle pattern for the T1 interface to either 0x7e (the default) or 0xff.

The default framing format is extended super frame (ESF).

Use the **no** form of the command to return framing to its default value.

The following are examples of setting the framing format:

- Set SF framing format for T1 interface 6.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# t1 6 framing sf
```

- Set ESF framing format for T1 interface 16.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# t1 16 framing esf
```

### Controlling Yellow Alarms

Use the **t1 yellow** command to turn the detection or generation of a yellow alarm on or off.

```
[no] t1 t1-number yellow {detection | generation}
```

Where:

- *t1-number* is T1 interface 1 to 28.

- **detection** means that the interface is told it is failing by the remote device, causing Cisco IOS to send a message to the console.
- **generation** means that the interface notifies the remote device if it is failing, causing Cisco IOS to send a message to the console.

When you select SF framing for a full T1 interface (24 time slots) that uses the default speed of 64, consider using the **no t1-number yellow detection** command to turn off yellow alarm detection, because the yellow alarm can be incorrectly detected with SF framing.

In the following example, T1 interface 1 is set to yellow detection:

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 1 yellow detection
```

## Setting the Clock Source

You can set the internal or line (network) clock source for a T1 interface using the **controller** command.

```
t1 t1-number clock source {internal | line}
```

Where:

- *t1-number* is T1 interface 1 to 28.
- **internal** specifies that the internal clock source is used.
- **line** specifies that the network clock source is used.

The default is clock source internal.

In the following example, the interface is instructed to get its clock source from the line:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# t1 1 clock source line
```

## Configuring FDL

You can enable 1-second transmissions of performance reports through the facility data link (FDL) according to the ANSI T1.403 specification, on both ends of the T1 connection. To do so, use the following command:

```
[no] t1 t1-number fdl ansi
```

Where *t1-number* is T1 interface 1 to 28.

Use the **no** form of the command to disable this feature.



### Note

---

You can use this command only when the T1 framing is ESF.

---

In the following example, FDL is enabled:

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 2 fdl ansi
```



## Configuring a BER Test

You can configure an individual T1 interface to run an independent BER test. The test is used to check cables and solve signal problems in the field. To send a BER test pattern on a T1 interface, use the following command in controller configuration mode:

```
[no] t1 t1-number bert pattern pattern interval time [unframed]
```

Where:

- *t1-number* is T1 interface number 1 to 28.
- *time* is 1 to 14,400 minutes.
- *pattern* is
  - 0s—Repetitive test pattern of all zeros (00000..)
  - 1s—Repetitive test pattern of all ones (11111..)
  - 2<sup>11</sup>—Pseudorandom test pattern (2048 bits long)
  - 2<sup>15</sup>—Pseudorandom O.151 test pattern (32,768 bits long)
  - 2<sup>20</sup>-O153—Pseudorandom O.153 test pattern (1,048,575 bits long)
  - 2<sup>20</sup>-QRSS—Pseudorandom QRSS O.151 test pattern (1,048,575 bits long)
  - 2<sup>23</sup>—Pseudorandom O.151 test pattern (8,388,607 bits long)
  - alt-0-1—Repetitive alternating test pattern of zeros (0s) and ones (1s), for example 01010101
  - 3in24—Fixed test pattern of F0100 0100 0000 0000 0000 0100 (3 bits are 1s in 24 bits)
  - 1in8—Fixed pattern of F0100 0000 (1 bit is a 1 in 8 bits)
  - 2in8—Fixed pattern of F0100 0010 (2 bits are 1s in 8 bits)
- **unframed** causes the BER test pattern to use the entire T1 bandwidth, including the T1 framing and payload bits. If **unframed** is omitted, the T1 is either SF or ESF framed as configured by the T1 framing command, and the BER test pattern occupies only the T1 payload bits.




---

**Note** For each T3, you can run only one BER test at a time.

---

You can terminate a BER test at any time using the **no** form of the command.

For more information, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

The following are examples of configuring a BER test:

- Send a BER test pseudorandom pattern of 2<sup>20</sup> through T1 interface 10 for 5 minutes.
 

```
Router(config)# controller T3 1/0/0
Router(config-controller)# t1 10 bert pattern 2^20 interval 5 unframed
```
- Send a repetitive pattern of all 1s through T1 interface 10 for 14,400 minutes (240 hours).
 

```
Router(config)# controller T3 1/0/0
Router(config-controller)# t1 10 bert pattern 1s interval 14400 unframed
```

To show BER test statistics, use the **show controllers t3 slot/subslot/port t1-number bert** command in EXEC or privileged EXEC mode:

```
Router# show controllers t3 6/1/1/1 bert
T3 6/1/1/1 is up. Hardware is C10K Half Height CT3 line card
T1 1
```

```

BERT test result (running)
Test Pattern : 2^15, Status : Sync, Sync Detected : 1
Interval : 5 minute(s), Time Remain : 5 minute(s)
Bit Errors (since BERT started): 0 bits,
Bits Received (since BERT started): 36 Mbits
Bit Errors (since last sync): 0 bits
Bits Received (since last sync): 36 Mbits

```

The 4-Port Channelized T3 Half-Height line card supports any combination of six T1 BER tests simultaneously for each set of two ports. That is, six T1 BER tests for ports 0 and 1, and six T1 BER tests for ports 2 and 3. [Table 4-4](#) shows a sample BER test distribution for the four ports of the 4-Port Channelized T3 Half-Height line card.

**Table 4-4** Sample BER Test Distribution

Port Number	BER Tests
Port 0	6 T1 BER tests
Port 1	1 T3 BER test
Port 2	3 T1 BER tests
Port 3	3 T1 BER tests

## Configuring T1 Loopback Mode

If problems occur when you configure a T1 interface, you can troubleshoot the line card by using the following command from controller configuration mode:

```

[no] t1 t1-number loopback [local | network {line | payload} | remote [line [fdl {ansi | bellcore}] | inband [maintenance]] | payload [fdl | ansi]]]

```

Where:

- *t1-number* is T1 interface 1 to 28.
- **local** loops the router output data back toward the router at the T1 framer and sends an alarm indication signal (AIS) out toward the network.
- **network {line | payload}** loops the data back toward the network and automatically sets a local loopback at the HDLC controllers (*line*) or loops the payload data back toward the network and automatically sets a local loopback at the HDLC controller (*payload*).
- **remote line fdl {ansi | bellcore}** sends a repeating, 16-bit ESF data link keyword to the remote end, requesting that it enter into a network line loopback. You can specify an ANSI or Bellcore keyword.



**Note** Loopback codes are defined in ANSI T1.404-1989 Table 3 (Assigned Bit-Oriented ESF Data-Link Messages).

The 4-Port Channelized T3 Half-Height line card sends the following code for remote line FDL ANSI loopback:

- Line Loopback Active Code: 0 000111 01111111
- Line Loopback Deactivate Code: 0 010010 01111111

The 4-Port Channelized T3 Half-Height line card sends the following code for remote line FDL Bellcore (SmartJack) loopback:

- Network Use (loopback active) Code: 0 001001 01111111
- Network Use (loopback deactivate) Code: 0 010010 01111111
- **remote line inband [maintenance]** sends a repeating inband pattern to the remote end, requesting entry into a network line loopback. The inband loopback request overwrites all data in the T1 with the loop request pattern. The remote end responds to this code only after it receives the pattern continuously for at least five seconds.

The **maintenance** keyword is new in 12.2(28)SB. The **maintenance** keyword sends loopback codes to an interface on the remote end of the connection. This sets loopback on the remote end interface. (Note that the 4-Port Channelized T3 Half-Height line card does not *respond* to inband maintenance codes.)

- Repeating Inband Loopback Activate Code (SF framing): 00001 loop up code
- Repeating Inband Loopback Deactivate Code (SF framing): 001 loop down code
- Repeating Inband Loopback Activate Code (SF and ESF framing): 2 in 5 loop up code
- Repeating Inband Loopback Deactivate Code (SF and ESF framing): 3 in 5 loop down code
- **remote payload [fdl | ansi]** sends a repeating, 16-bit ESF data link code word to the remote end, requesting entry into a network payload loopback. Using **fdl** and **ansi** enables the remote payload facility data link (FDL) ANSI bit loopback on the T1 channel. Loopback codes are defined in ANSI T1.404-1989 Table 3 (Assigned Bit-Oriented ESF Data-Link Messages).



**Note** Due to hardware constraints, when you execute the **t1 loopback remote payload command**, the type of loopback that is implemented is line loopback.

The 4-Port Channelized T3 Half-Height line card sends the following code for remote payload FDL ANSI loopback:

- Payload Loopback Active Code: 0 001010 011111111
- Payload Loopback Deactivate Code: 0 011001 011111111

Use the **no** form of the command to terminate a loopback.

For more information on this command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

The following are examples of configuring loopback mode:

- Configure the T3 controller for local loopback on T1 interface 1.

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 1 loopback local
```

- Configure the T3 controller for remote FDL ANSI loopback on T1 interface 1.

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 1 loopback remote line fdl ansi
```

# High Availability Using Line Card Redundancy

You can configure one-to-one line card redundancy using the optional Y-cables and configuring 4-Port Channelized T3 Half-Height line cards for redundancy. This redundancy provides automatic failover protection at the line card level for the 4-Port Channelized T3 Half-Height line card. Because the redundancy is at the line card level, all ports are switched over during a failover.

The redundant line cards occupy the two subslots within the same chassis line card slot. There is one Y-cable for receive and one for transmit for each of the four ports for the two redundant line cards. For information about installing redundant 4-Port Channelized T3 Half-Height line cards and the Y-cables, see the *Cisco 10000 Series Router Line Card Hardware Installation Guide*.

This section contains the following topics:

- [Prerequisites for Line Card Redundancy, page 4-24](#)
- [Restrictions for Line Card Redundancy, page 4-24](#)
- [Configuring Line Card Redundancy, page 4-24](#)
- [Verifying and Monitoring Line Card Redundancy, page 4-25](#)
- [Performing a Manual Line Card Switchover, page 4-29](#)
- [Removing Line Card Redundancy, page 4-29](#)
- [Failover Conditions, page 4-30](#)

## Prerequisites for Line Card Redundancy

Before configuring line card redundancy, the Y-cables must be installed; before deconfiguring redundancy the Y-cables must be removed.

## Restrictions for Line Card Redundancy

The following restrictions apply to line card redundancy:

- Port-level redundancy is not supported.
- Redundant cards must occupy the two subslots within the same physical line card slot.
- The line card that will act as the primary line card must be the first line card configured, and it must occupy subslot 1.

## Configuring Line Card Redundancy

After verifying that the Y-cables are installed, you are ready to configure one-to-one redundancy between two 4-Port Channelized T3 Half-Height line cards. To configure line card redundancy, enter the following commands beginning in global configuration mode:

	Command	Purpose
<b>Step 1</b>	Router(config)# <b>redundancy</b>	Enters redundancy mode.
<b>Step 2</b>	Router(config-red)# <b>linecard-group</b> <i>linecard-groupId</i> <b>y-cable</b>	Enters line card redundancy group mode and creates a line card redundancy group.  <i>linecard-groupId</i> —An unsigned integer in the range 0 to the (maximum number of chassis line card subslots/2) –1. For the 4-Port Channelized T3 Half-Height line card, the range is 0 to 7.  <b>y-cable</b> —Specifies Y-cable as the link protection type for the line card group.
<b>Step 3</b>	Router(config-red-lc)# <b>description</b> <i>description string</i>	(Optional) Adds a description for the line card group.
<b>Step 4</b>	Router(config-red-lc)# <b>member subslot</b> <i>slot/subslot</i> <b>primary</b>	Configures the redundancy role of the primary (active) line card.  The line card that will act as the primary line card must be the first line card configured, and it must occupy subslot 1.  <b>Note</b> Configuring redundancy on the primary line card interrupts traffic and applies the default configuration to the line card.
<b>Step 5</b>	Router(config-red-lc)# <b>member subslot</b> <i>slot/subslot</i> <b>secondary</b>	Configures the redundancy role of the secondary (standby) line card.  The line card that will act as the secondary line card must be the second line card configured, and it must occupy subslot 0.  <b>Note</b> Configuring redundancy on the secondary line card resets the line card, interrupts traffic, and applies the default configuration to the line card.

[Example 4-1](#) configures two 4-Port Channelized T3 Half-Height line cards that are installed in line card slot 2 for one-to-one redundancy.

#### **Example 4-1 Configuring Line Card Redundancy**

```
Router(config)# redundancy
Router(config-red)# linecard-group 1 y-cable
Router(config-red-lc)# member subslot 2/1 primary
Router(config-red-lc)# member subslot 2/0 secondary
```

## Verifying and Monitoring Line Card Redundancy

To verify line card redundancy and to display information about a line card or a line card group, use the **show redundancy linecard** command. The following table describes the type of information provided by some of the command options.

Command	Description
<b>show redundancy linecard all</b>	Displays the redundancy state of all line card slots
<b>show redundancy linecard subslot</b>	Displays the redundancy state of the line card in a subslot
<b>show redundancy linecard group</b>	Displays the redundancy state of line cards in a line card group
<b>show redundancy linecard history</b>	Displays recent activity in line card redundancy
<b>show redundancy linecard sub-block</b>	Displays troubleshooting information

The output examples in this section use the following configuration:

```
!
redundancy
 linecard-group 0 y-cable
   member subslot 8/1 primary
   member subslot 8/0 secondary
 mode sso
!
controller T3-RED 8/1/0
controller T3-RED 8/1/1
controller T3-RED 8/1/2
controller T3-RED 8/1/3
!
```

**Example 4-2** shows output from the **show redundancy linecard all** command. It shows the redundancy state of all line card slots. The line card group is indicated as “None” if the slot is empty, or if it contains a line card that has not been configured for redundancy.

For a redundant line card, the mode can be primary or secondary and is established when redundancy is configured. The mode of a line card does not change. For the 4-Port Channelized T3 Half-Height line card, the line card in subslot 0 is always secondary, and the line card in subslot 1 is always primary.

The line card role indicates which line card in a redundant configuration is sending and receiving traffic. The line card with the active role is sending and receiving traffic. The other line card in a redundant configuration has the role of standby. Unlike the line card mode, the role of a line card can change.

In **Example 4-2** you can see there has been a switchover at some point, because the line card in slot 8, subslot 0 has the active role, even though its mode is secondary.

#### **Example 4-2 show redundancy linecard all Command Output**

```
Router# show redundancy linecard all
      LC      My      Peer      Peer  Peer
Slot Subslot Group State   State  Slot Subslot Role  Mode
-----
  1    0      None  Init   -      None  None  None  None
  1    1      None  Init   -      None  None  None  None
  2    0      None  Init   -      None  None  None  None
  2    1      None  Init   -      None  None  None  None
  3    0      None  Init   -      None  None  None  None
  3    1      None  Init   -      None  None  None  None
  4    0      None  Init   -      None  None  None  None
  4    1      None  Init   -      None  None  None  None
  5    0      None  Init   -      None  None  None  None
  5    1      None  Init   -      None  None  None  None
  6    0      None  Init   -      None  None  None  None
  6    1      None  Init   -      None  None  None  None
```

7	0	None	Init	-	None	None	None	None
7	1	None	Init	-	None	None	None	None
8	0	0	Active	Stdby Hot	8	1	Active	Secondary
8	1	0	Stdby Hot	-	8	0	Standby	Primary

[Example 4-3](#) shows output from the **show redundancy linecard subslot** command. It displays information for a particular line card.

#### **Example 4-3** *show redundancy linecard subslot Command Output*

```
Router# show redundancy linecard subslot 8/1
Redundant LC Group Number: 0
LC Slot: 8
LC Subslot: 1
Redundant LC Name: 8/1
Redundant LC Mode: Primary
Redundant LC Role: Standby
Redundant LC My State: Stdby Hot
Redundant LC Peer State: -

Router# show redundancy linecard subslot 8/0
Redundant LC Group Number: 0
LC Slot: 8
LC Subslot: 0
Redundant LC Name: 8/0
Redundant LC Mode: Secondary
Redundant LC Role: Active
Redundant LC My State: Active
Redundant LC Peer State: Stdby Hot
```

[Example 4-4](#) shows output from the **show redundancy linecard group** command. It shows line card information for a specific line card group, which in this example is group 0. Note that the **show redundancy linecard group** command displays only the static line card configuration information. For example, it shows the line card mode (primary or secondary) but not the line card role, which changes in a switchover. The line card in slot 8, subslot 1, is primary even though it currently has the standby role.

Because there is only one line card group in the sample configuration, the **show redundancy linecard group all** command would display the same output as shown in [Example 4-4](#).

#### **Example 4-4** *show redundancy linecard group Command Output*

```
Router# show redundancy linecard group 0
Group Identifier: 0
NON-revertive
Group Redundancy Type: Y_CABLE
Group Redundancy Class: 1:1
Group Redundancy Configuration Type: LINECARD GROUP
Primary: Slot 8
        Subslot 1
Secondary: Slot 8
        Subslot 0
```

The **show redundancy linecard history** command and the **show redundancy linecard sub-block** command provide information that can be helpful to Cisco technical support personnel when they are assisting you in troubleshooting a redundancy problem. The output in [Example 4-5](#) was collected after a line card switchover.

**Note**

**Example 4-5** and **Example 4-6** identify the slot/subslot by an integer called a slot unit. The slot unit is a platform-defined number that uniquely identifies the slot/subslot as an integer. For example, a line card in slot 1, subslot 0 is identified as slot unit 2, and a line card in slot 1, subslot 1, is slot unit 3. The line card in slot 8, subslot 0, is slot unit 16; the line card in slot 8, subslot 1, is slot unit 17.

**Example 4-5 show redundancy linecard history Command Output**

```
Router# show redundancy linecard history
Aug 29 2005 06:03:16 46400671 - Slot(17): MY State Change, (Stdby Wait) -> (Stdby Hot)
Aug 29 2005 06:03:16 46400671 - Slot(16): PEER State Change, (Stdby Wait) -> (Stdby Hot)
Aug 29 2005 06:03:16 46400671 - Slot(16): PEER FSM Execution , Active:Stdby Wait:State
Ntfy
Aug 29 2005 06:03:16 46400671 - Slot(17): MY State Change, (Stdby LC Feat Sync) -> (Stdby
Wait)
Aug 29 2005 06:03:16 46400671 - Slot(16): PEER State Change, (Stdby LC Feat Sync) ->
(Stdby Wait)
Aug 29 2005 06:03:16 46400671 - Slot(16): PEER FSM Execution , Active:Stdby LC Feat
Sync:Feat Sync Done
Aug 29 2005 06:03:16 46400671 - Slot(17): MY State Change, (Stdby FIB Dnld) -> (Stdby LC
Feat Sync)
Aug 29 2005 06:03:16 46400671 - Slot(16): PEER State Change, (Stdby FIB Dnld) -> (Stdby LC
Feat Sync)
Aug 29 2005 06:03:16 46400671 - Slot(16): PEER FSM Execution , Active:Stdby FIB Dnld:Feat
Sync Req
Aug 29 2005 06:03:16 46400671 - Slot(17): MY State Change, (Stdby LC Cfg Dnld) -> (Stdby
FIB Dnld)
Aug 29 2005 06:03:16 46400671 - Slot(16): PEER State Change, (Stdby LC Cfg Dnld) -> (Stdby
FIB Dnld)
Aug 29 2005 06:03:16 46400671 - Slot(16): PEER FSM Execution , Active:Stdby LC Cfg
Dnld:Cfg Dnld Done
Aug 29 2005 06:03:16 46400671 - Slot(17): MY State Change, (Stdby Cold) -> (Stdby LC Cfg
Dnld)
Aug 29 2005 06:03:16 46400671 - Slot(16): PEER State Change, (Stdby Cold) -> (Stdby LC Cfg
Dnld)
Aug 29 2005 06:03:16 46400644 - Slot(16): PEER FSM Execution , Active:Stdby Cold:Cfg Dnld
Aug 29 2005 06:03:16 46400644 - Slot(17): MY State Change, (Init) -> (Stdby Cold)
Aug 29 2005 06:03:16 46400644 - Slot(16): PEER State Change, (Init) -> (Stdby Cold)
Aug 29 2005 06:03:16 46400644 - Slot(16): PEER FSM Execution , Active:Init:Up
Aug 23 2005 21:18:03 49333 - Slot(16:-1): Checkpoint State Update, (Active:Init)
Aug 23 2005 21:18:03 49333 - Slot(17:-1): Checkpoint State Update, (Init:Init)
Aug 23 2005 21:18:03 49332 - Slot(16:-1): Checkpoint State Update, (Active Cold:Init)
Aug 23 2005 21:18:03 49332 - Slot(17:16): Checkpoint State Update, (Active:Active Cold)
Aug 23 2005 21:11:07 7881 - Slot(17:-1): Checkpoint State Update, (Active:Stdby Hot)
Aug 23 2005 21:11:07 7881 - Slot(16:-1): Checkpoint State Update, (Stdby Hot:Init)
Aug 23 2005 21:10:42 6393 - Slot(16): MY FSM execution, Init:Init:Reset
```

**Example 4-6 show redundancy linecard sub-block Command Output**

```
Router# show redundancy linecard sub-block all
SlotIndex  Port      H-IDB M-HW A-HW  Type      Role      Flag
-----
16         0         5     21   13    Physical  None      0x15
16         1         7     22   15    Physical  None      0x15
16         2         9     23   17    Physical  None      0x15
16         3         11    24   19    Physical  None      0x15
17         0         21    13   5     Virtual   -         0x3
17         0         13    21   5     Physical  None      0x5
17         1         22    15   7     Virtual   -         0x3
```



17	1	15	22	7	Physical	None	0x5
17	2	23	17	9	Virtual	-	0x3
17	2	17	23	9	Physical	None	0x5
17	3	24	19	11	Virtual	-	0x3
17	3	19	24	11	Physical	None	0x5

## Performing a Manual Line Card Switchover

To initiate a manual switchover of the active 4-Port Channelized T3 Half-Height line card to the standby 4-Port Channelized T3 Half-Height line card, enter the following command in privileged Exec mode:

Command	Purpose
Router# <b>redundancy linecard-group switchover from subslot slot/subslot</b>	Forces the switchover of the active line card to the standby line card.  Performing a switchover does not change the existing line card configuration, and traffic is not interrupted.

[Example 4-7](#) shows how you can force the switchover of the active line card in slot 2, subslot 1, to the standby line card in slot 2, subslot 0.

### Example 4-7 Manual Line Card Switchover

```
Router# redundancy linecard-group switchover from subslot 2/1
```

## Removing Line Card Redundancy

After verifying that the Y-cables are removed, you are ready to remove one-to-one redundancy between two 4-Port Channelized T3 Half-Height line cards. To remove line card redundancy, enter the following commands beginning in global configuration mode:

	Command	Purpose
<b>Step 1</b>	Router(config)# <b>redundancy</b>	Enters redundancy mode.
<b>Step 2</b>	Router(config-red)# <b>linecard-group linecard-groupId y-cable</b>	Enters line card redundancy group configuration mode for the specified line card redundancy group.  <i>linecard-groupId</i> —An unsigned integer in the range 0 to the (maximum number of chassis line card subslots/2) -1. For the 4-Port Channelized T3 Half-Height line card, the range is 0 to 7.  <b>y-cable</b> —Specifies Y-cable as the link protection type for the line card group.

	Command	Purpose
Step 3	Router(config-red-lc)# no member subslot slot/subslot secondary	Removes the redundancy role of the secondary (standby) line card.  You must remove redundancy from the secondary line card before removing redundancy from the primary line card.  <b>Note</b> Removing redundancy resets the line card (traffic is interrupted) and applies the default configuration to the line card. If you remove redundancy from the secondary line card only, traffic is not interrupted through the primary line card.
Step 4	Router(config-red-lc)# no member subslot slot/subslot primary	(Optional) Removes the redundancy role of the primary (active) line card.  You must remove redundancy from the secondary line card before removing redundancy from the primary line card.  <b>Note</b> Removing redundancy resets the line card (traffic is interrupted) and applies the default configuration to the line card. If you remove redundancy from the secondary line card only, traffic is not interrupted through the primary line card.
Step 5	Router(config-red-lc)# exit	Returns to redundancy mode.
Step 6	Router(config-red)# no linecard-group linecard-groupId y-cable	Removes the line card redundancy group.

[Example 4-8](#) removes one-to-one redundancy between two 4-Port Channelized T3 Half-Height line cards that are installed in slot 2 for one-to-one redundancy.

#### Example 4-8 Removing Line Card Redundancy

```
Router(config)# redundancy
Router(config-red)# linecard-group 1 y-cable
Router(config-red-lc)# no member subslot 2/0 secondary
Router(config-red-lc)# no member subslot 2/1 primary
Router(config-red-lc)# exit
Router(config-red)# no linecard-group 1 y-cable
```

## Failover Conditions

The following describes the conditions under which the primary line card will fail over to the secondary line card when line card redundancy is configured.

- User-initiated switchover—You have performed a manual switchover using the **redundancy linecard-group switchover from subslot** command.
- Line card-initiated switchover—The line card detects a failover condition and sends a cutover interrupt to the performance routing engine (PRE).
- PRE-initiated OIR switchover—The PRE detects the removal of the primary line card.
- PRE-initiated keepalive timeout switchover—More than 20 seconds have elapsed since the PRE received a keepalive message from the line card.

# Command Reference

The following commands are new in Cisco IOS Release 12.2(28)SB:

- **show controllers t3 bert**
- **linecard-group y-cable**
- **member subslot**

## show controllers t3 bert Command

To display BER test statistics, use the **show controllers t3 bert** command in EXEC or privileged EXEC mode.

```
show controllers t3 {slot/subslot/port} [/t1-number] bert
```

### Syntax Description

<i>slot</i>	Chassis line card slot number.
<i>subslot</i>	Chassis line card subslot number.
<i>port</i>	Interface number on the line card.
<i>t1-number</i>	(Optional) Logical T1 interface number.
<b>bert</b>	Displays BER test statistics.

### Command Modes

EXEC  
Privileged EXEC

### Command History

Release	Modification
12.2(28)SB	This command was introduced on the Cisco 10000 series routers.

### Examples

The following example shows BER test statistics for an unchannelized T3 interface:

```
Router# show controllers t3 6/1/0 bert
T3 6/1/0 is up.
BERT test result (done)
Test Pattern : 2^15, Status : Not Sync, Sync Detected : 1
Interval : 5 minute(s), Time Remain : 0 minute(s)
Bit Errors (since BERT started): 0 bits,
Bits Received (since BERT started): 13025 Mbits
Bit Errors (since last sync): 0 bits
Bits Received (since last sync): 13025 Mbits
```

The following example shows BER test statistics for a channelized T3 interface:

```
Router# show controllers t3 6/1/0 bert
T3 6/1/0 is up.
BERT test result (running)
Test Pattern : 2^15, Status : Sync, Sync Detected : 1
Interval : 3 minute(s), Time Remain : 1 minute(s)
Bit Errors (since BERT started): 0 bits,
```

```
Bits Received (since BERT started): 5493 Mbits
Bit Errors (since last sync): 0 bits
Bits Received (since last sync): 5493 Mbits
```

The following example shows BER test statistics for a T1 interface:

```
Router# show controllers t3 6/1/1/1 bert
T3 6/1/1/1 is up. Hardware is C10K Half Height CT3 line card
T1 1
BERT test result (running)
Test Pattern : 2^15, Status : Sync, Sync Detected : 1
Interval : 5 minute(s), Time Remain : 5 minute(s)
Bit Errors (since BERT started): 0 bits,
Bits Received (since BERT started): 36 Mbits
Bit Errors (since last sync): 0 bits
Bits Received (since last sync): 36 Mbits
```

**Related Commands**

Command	Description
<b>bert</b>	Configures a BER test for an unchannelized or channelized T3 interface.
<b>t1 bert pattern</b>	Configures a BER test for a T1 interface.

## linecard-group y-cable Command

To create a line card group for one-to-one line card redundancy, use the **linecard-group y-cable** command in redundancy mode. To remove the line card redundancy group, use the **no** form of this command.

**linecard-group** *linecard-groupId* **y-cable**

**no linecard-group** *linecard-groupId* **y-cable**

**Syntax Description**

<i>linecard-groupId</i>	An unsigned integer in the range 0 to the (maximum number of chassis line card slots/2) -1.
<b>y-cable</b>	The link protection type for the line card group.

**Defaults**

No default behavior or values.

**Command Modes**

Redundancy

**Command History**

Release	Modification
12.2(28)SB	This command was introduced on the Cisco 10000 series router.

**Usage Guidelines**

The **no linecard-group y-cable** command removes the line card redundancy group and frees the *linecard-groupId* for reuse. The **no linecard-group y-cable** command succeeds only if there are no subslot members in the line card redundancy group.

**Examples**

The following example creates line card group number 1 for one-to-one line card redundancy:

```
Router(config)# redundancy
Router(config-red)# linecard-group 1 y-cable
```

**Related Commands**

Command	Description
<b>member subslot</b>	Configures the redundancy role of a line card in the line card group.
<b>redundancy</b>	Enters redundancy mode.
<b>show redundancy linecard</b>	Displays information about a redundant line card or line card group.

**member subslot Command**

To configure the redundancy role of a line card, use the **member subslot** command in line card redundancy group mode. To remove the redundancy role of a line card, use the **no** form of this command.

```
member subslot slot/subslot {primary | secondary}
```

```
no member subslot slot/subslot {primary | secondary}
```

**Syntax Description**

<i>slot</i>	Chassis line card slot number.
<i>subslot</i>	Chassis line card subslot number.
<b>primary   secondary</b>	Configures the redundancy role of the line card. <ul style="list-style-type: none"> <li><b>primary</b>—Active line card.</li> <li><b>secondary</b>—Standby line card.</li> </ul>

**Defaults**

No default behavior or values

**Command Modes**

Line card redundancy group

**Command History**

Release	Modification
12.2(28)SB	This command was introduced on the Cisco 10000 series routers.

**Usage Guidelines**

The primary line card must be the first line card configured and must occupy subslot 1. The secondary line card must be the second line card configured and must occupy subslot 0. Only one primary line card and one secondary line card can be configured.

**Examples**

The following creates line card group number 1 for one-to-one line card redundancy. It also specifies the line card in subslot 1 as the primary (active) line card, and the line card in subslot 0 as the secondary (standby) line card:

```
Router(config)# redundancy
Router(config-red)# linecard-group 1 y-cable
Router(config-red-lc)# member subslot 2/1 primary
Router(config-red-lc)# member subslot 2/0 secondary
```

**Related Commands**

Command	Description
<b>linecard-group y-cable</b>	Creates a line card group for one-to-one line card redundancy.
<b>redundancy</b>	Enters redundancy mode.
<b>show redundancy linecard</b>	Displays information about a redundant line card or line card group.



# CHAPTER 5

## 24-Port Channelized E1/T1 Line Card Configuration

---

This chapter describes the procedures for configuring the Cisco 10000 series 24-Port Channelized E1/T1 line card, hereafter known as the 24-Port Channelized E1/T1 line card.

The 24-Port Channelized E1/T1 line card provides Cisco 10000 routers with 24 copper channelized or unchannelized interface ports that you can configure as E1 or T1 interfaces.

This chapter contains the following sections:

- [Software Support, page 5-1](#)
- [Commands and Default Values, page 5-2](#)
- [Configuration Task Overview, page 5-6](#)
- [Command Descriptions, page 5-12](#)
- [Controller Configuration Commands, page 5-17](#)

### Software Support

[Table 5-1](#) shows the minimum Cisco IOS release on each release train that supports the 24-Port Channelized E1/T1 line card.

**Table 5-1** 24-Port Channelized E1/T1 Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE1	Cisco IOS Release 12.0(22)S and later releases of Cisco IOS Release 12.0S
PRE2	Cisco IOS Release 12.2(15)BX and later releases of Cisco IOS Release 12.2BX Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS 12.3XI Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Commands and Default Values

You can operate all the line card ports to accept either E1 or T1 lines, but not both. Once you configure a line card in E1 or T1 mode, you configure all ports on that line card as the same type controller. The commands for configuring either E1 or T1 interfaces are described in the following sections.

### E1 Commands

Table 5-2 lists line card commands, default values, and specifies the command syntax you use. This table also includes the commands to use to modify a default value, and indicates whether a similar value (on the remote end of the connection) must be the same (or opposite).

**Table 5-2 E1 Line Card Commands and Default Values**

Command Name	Default Value	Command Syntax	Remote Device Setting
<b>Enable Commands</b>			
hw-module (reset)	—	<b>hw-module slot slot reset   subslot slot/subslot reset</b>	—
show controllers	—	<b>show controllers e1 slot/subslot/port</b>	—
show interfaces	—	<b>show interface serial slot/subslot/port:channel-group {accounting   controller   crb   description   fair-queue   irb   mac-accounting   mpls-exp   precedence   random-detect   rate-limit   shape}</b>	—
<b>Configure Commands</b>			
card	mode e1	<b>[no] card slot/subslot 24che1t1-1 mode {e1   t1}</b>	—
hw-module (shutdown)	no hw-module	<b>[no] hw-module {slot slot shutdown   subslot slot/subslot shutdown}</b>	—
controller	—	<b>controller {e1   t1} slot/subslot/port</b>	—
interface	—	<b>[no] interface serial slot/subslot/port:channel-group</b>	—



Table 5-2 E1 Line Card Commands and Default Values (continued)

Command Name	Default Value	Command Syntax	Remote Device Setting
<b>Controller Configuration Commands</b>			
bert	No bert	[no] bert pattern {2^11   2^15   2^20-0153   2^20-QRSS} interval minutes	—
channel-group	No channel-group	[no] channel-group channel number {timeslots timeslots [speed 64]   unframed}	—
clock source	line	[no] clock source {internal   line}	At least one side set to internal
description	No description	[no] description text	—
framing	crc4	[no] framing {crc4 [australia]   no-crc4 [australia]}	—
linecode	hdb3	[no] linecode hdb3	—
loopback	No loopback	[no] loopback {local   network {line   payload}}	—
national reserve	No national reserve (0)	[no] national reserve int sa4 sa5 sa6 sa7 sa8	—
shutdown	no shutdown	[no] shutdown	—

## E1 Interface Numbering Syntax

You can use the line card in different Cisco series 10000 router chassis. To specify line card E1 interfaces, use the syntax listed in Table 5-3 for the router chassis in use.

Table 5-3 E1 Line Card Interface Syntax

Router	Con troller	Slot	Subslot	Port Number	Channel Group Number
Cisco 10008	E1	1 to 8	/0	/0 to /23	:1 to:31
Cisco 10005	E1	1 to 5	/0	/0 to /23	:1 to:31



### Note

Because this is a full-height line card, its subslot value is always 0.

Examples:

- Modify E1 controller 0 in slot 2 in controller configuration mode:

```
Router(config)# controller e1 2/0/0
Router(config-controller)# command
Router(config-controller)#
```

- Modifying E1 controller 0, channel-group number 8 in interface configuration mode:

```
Router(config)# interface serial 2/0/0:8
Router(config-if)# command
Router(config-if)#
```

You use the syntax in [Table 5-3](#) to specify slot, subslot, port numbers, and channel-group numbers when configuring ports for E1 operation on a 24-Port Channelized E1/T1 line card.

You can configure a maximum of 744 channelized E1 interfaces on the 24 line card ports (24 ports x 31 E1 timeslots). To do this, you assign a channel-group number to the timeslots of the E1 interface you configure at each port (see the “[Specifying E1 Channel Groups](#)” section on [page 5-21](#)).

## T1 Commands

[Table 5-4](#) lists T1 configuration default values, line card commands, and specifies the values you use. The table includes the commands you use for modifying a default value and indicates whether a similar value, on the remote end of the connection, needs to be the same (or opposite).

**Table 5-4 T1 Line Card Commands and Default Values**

Command Name	Default Values	Command Syntax	Remote Device Setting
<b>Enable Commands</b>			
hw-module (reset)	—	<b>hw-module slot slot reset   subslot slot/subslot reset</b>	—
show controllers	—	<b>show controllers t1 slot/subslot/port [remote performance]</b>	—
show interface	—	<b>show interface serial slot/subslot/port:channel-group {accounting   controller   crb   description   fair-queue   irb   mac-accounting   mpls-exp   precedence   random-detect   rate-limit   shape}</b>	—
<b>Configure Commands</b>			
card	mode e1	<b>[no] card slot/subslot 24chelt1-1 [mode {e1   t1}]</b>	—
hw-module (shutdown)	no hw-module	<b>[no] hw-module {slot slot shutdown   subslot slot/subslot shutdown}</b>	—
controller	—	<b>controller {e1   t1} slot/subslot/port</b>	—
interface	—	<b>[no] interface serial slot/subslot/port:channel-group</b>	—
<b>Controller Configuration Commands</b>			
bert	No bert	<b>[no] bert pattern {2^11   2^15   2^20-0153   2^20-QRSS} interval minutes</b>	—
cablelength	No cablelength	<b>[no] cablelength short {110   220   330   440   550   660}</b>	—
channel-group	No channel-group	<b>[no] channel-group channel number timeslots timeslots [speed {56   64}]</b>	—

**Table 5-4 T1 Line Card Commands and Default Values (continued)**

Command Name	Default Values	Command Syntax	Remote Device Setting
clock source	line	[no] clock source {internal   line}	At least one side set to internal
description	No description	[no] description text	—
fdl	No fdl	[no] fdl {ansi   att}	—
framing	esf	[no] framing {esf   sf}	—
linecode	b8zs	[no] linecode {ami   b8zs}	—
loopback	No loopback	[no] loop {local   network {line   payload}   remote {esf {line   payload}   iboc}}	—
shutdown	no shutdown	[no] shutdown	—
yellow	yellow	[no] yellow {generation   detection}	—

## T1 Interface Numbering Syntax

You can use the line card in different Cisco series 10000 router chassis. To specify line card T1 interfaces, use the syntax listed in [Table 5-5](#) for the router chassis in use.

**Table 5-5 T1 Line Card Interface Syntax**

Router	Line Interface	Slot	Subslot	Port Number	Channel Group Number
Cisco 10008	T1	1 to 8	/0	/0 to /23	:1 to:24
Cisco 10005	T1	1 to 5	/0	/0 to /23	:1 to:24

Examples:

- Modify T1 controller 0 on slot 2 in controller configuration mode:

```
Router(config)# controller T1 2/0/0
Router(config-controller)# command
Router(config-controller)#
```

- Modifying T1 controller 0, channel-group number 8 in interface configuration mode:

```
Router(config)# interface serial 2/0/0:8
Router(config-if)# command
Router(config-if)
```

You use the syntax in [Table 5-4](#) to specify slot, subslot, port numbers, and channel-group numbers when configuring a port as an T1 controller on a 24-Port Channelized E1/T1 line card.

You can configure a maximum of 576 channelized T1 interfaces on the 24 line card ports (24 ports x 24 T1 timeslots). To do this, you assign a T1 channel-group number to the timeslots of each interface you configure at each port (see the [“Specifying T1 Channel Groups”](#) section on page 5-22).

## Configuration Task Overview

You can configure the ports of the 24-Port Channelized E1/T1 line card as channelized or unframed E1 interfaces, or as channelized T1 interfaces. To configure an E1 or T1 line card interface, perform the following procedure:

- 
- Step 1** Designate the card mode as T1 or E1.
  - Step 2** Configure the controller parameters and save the configuration to NVRAM.
  - Step 3** Create one or more serial interfaces at each active port.
  - Step 4** Specify the interface parameters for each port channel-group and save the configuration to NVRAM.




---

**Note** Each time you change the card mode (from E1 to T1 or from T1 to E1), the existing *running* configuration for the card interface is erased. If you want to keep a line card configuration, you must save it before you change the card mode.

---

## E1 Configuration Examples

The examples in this section familiarize you with the line card configuration tasks and typify how you apply the commands listed in [Table 5-2](#) and the syntax in [Table 5-3](#) to configure a port as an E1 controller. These examples also show how to configure E1 channel-group bandwidth at any of the 24 available ports on the line card. The example steps are intended to quickly familiarize you with the procedures you use to set up an E1 port as an E1 controller.




---

**Note** You must be in privileged EXEC mode to specify and configure a port as an E1 controller on any line card port.

---

### Configuring an E1 Controller

From the IOS global configuration mode, you use the **config terminal** command to enter the controller configuration mode and to configure a card as E1 mode (see the “[Configuring a Controller](#)” section on [page 5-16](#) for details).

### Configuring Full-Rate Unchannelized E1 Bandwidths

To configure the full-rate unchannelized E1 bandwidth at a port, you assign the maximum bandwidth (2048 kbps) when you include **unframed** on the command line in controller configuration mode. The following example shows the steps you use to create full-rate unchannelized E1 operation at any port.

- 
- Step 1** **Specify a Controller:** To configure the available full E1 bandwidth on an unchannelized port, you select the E1 controller from the global configuration mode:

```
Router> enable
Password: (you enter your administrative password)
Router# config terminal
Enter Configuration commands, one per line. End with CNTRL/Z.
Router(config)# controller e1 2/0/0
```

- Step 2 Specify a Channel Group:** To specify a channel group number as a full-rate unchannelized E1 port, you assign a channel-group number from 1 to 31 and specify **unframed**:

```
Router(config-controller)# channel-group 6 unframed
Router(config-controller)
```



**Note** You can not make timeslot assignments on unframed E1 ports.

The **channel group** command assigns channel-group number 6 to timeslots 0 to 31 (the entire available E1 unframed bandwidth) and subslot 0 at port 0 of the 24-Port Channelized E1/T1 line card in router chassis slot 2.

Whenever you configure an E1 channel-group as **unframed**, you assign all 32 timeslots (the entire available 2048 kbps E1 bandwidth) to that port and channel group.



**Note** When you specify **unframed** for an E1 channel, you only configure a single channel on a port.

- Step 3 Specify Additional Controller Parameters:** Specify any other E1 controller parameters for this port and other ports (see [Table 5-2 on page 5-2](#) and the “[Controller Configuration Commands](#)” section on [page 5-17](#)).
- Step 4** Save the controller configuration to NVRAM
- ```
Router(config-if)# end
Router# write
```
- Step 5 Specify Interface Parameters:** Go to interface configuration mode for any channel group you created in the controller configuration mode:
- ```
Router(config)# interface serial 2/0/2:6
Router(config-if)#
```
- Step 6** Enter a value for protocol encapsulation. This example shows the command for using frame relay. You can also choose PPP or HDLC (default).
- ```
Router(config-if)# encapsulation frame-relay
Router(config-if)#
```
- Step 7** If IP routing is enabled on the system, assign an IP address and subnet mask. For example:
- ```
Router(config-if)# ip address 10.16.32.49 255.255.240.0
```
- Step 8** Add any other serial interface configuration commands required to enable other routing protocols and to set other interface characteristics.
- Step 9** Be sure all physical port connections have been made on the 24-Port Channelized E1/T1 line card in the Cisco series 10000 router chassis (see the [Cisco 10000 Series Router Line Card Hardware Installation Guide](#)).
- Step 10** When you have entered all of the necessary interface configuration commands (see the [Cisco IOS Interface and Hardware Component Configuration Guide](#)), to complete the configuration, return to the privileged EXEC mode.
- ```
Router(config-if)# end
Router#
```

**Step 11** Write the new configuration to NVRAM:

```
Router# copy running-config startup-config
Router#
```

---

## Configuring Full-Rate Channelized E1 Bandwidths

The following example shows you the steps you use to create a channelized full-rate interface:

**Step 1 Specify a Controller:** To configure the available channelized full-rate bandwidth of an interface on port 1 of a line card in router chassis slot 2, you must first select the E1 controller from the global configuration mode:

```
Router(config)# controller e1 2/0/1
Router(config-controller)
```

**Step 2 Specify a Channel Group:** To specify a channel group number for a full-rate channelized E1 port, you assign a channel-group number from 1 to 31 from the controller configuration mode:

```
Router(config-controller)# channel-group 7 timeslots 1-31
Router(config-controller)
```

This command assigns channel-group number 7 and timeslots 1 through 31 (the maximum available 1984 kbps channelized E1 bandwidth) to port 1 of the line card in router chassis slot 2.

**Step 3 Specify Controller Parameters:** to specify any other controller parameters you enter the controller parameters for the port you have selected (see [Table 5-2 on page 5-2](#) and the “[Controller Configuration Commands](#)” section on page 5-17).

**Step 4 Specify Interface Parameters:** Go to interface configuration mode for any channel group you created and specify interface parameters:

```
Router(config)# interface serial 2/0/2:6
Router(config-if)#
```

---

## Configuring Fractional Channelized E1 Bandwidths

To configure an available channelized (framed) fractional E1 bandwidth on a port, you must select the E1 controller from the global configuration mode.

**Step 1** The following two examples in this step show you how to configure all the available port 2 E1 timeslots into two interfaces:

Example 1:

```
Router(config)# controller e1 2/0/2
Router(config-controller)# channel-group 8 timeslots 1, 2, 5, 11-31
Router(config-controller)#
```

These commands configure port 2 time slots 1, 2, 5, and 11 to 31, of the line card in router chassis slot 2 as channel-group (interface) number 8.

Example 2:

```
Router(config-controller)# channel-group 9 timeslots 3, 4, 6-10
Router(config-controller)#
```

Because you are still in the controller configuration mode, you use this command to configure channel-group (interface) number 9 and remaining timeslots 3, 4, and 6 to 10 on port 2 of the 24-Port Channelized E1/T1 line card in router chassis slot 2.

- Step 2 Specify Controller Parameters:** to specify any other controller parameters you enter the controller parameters for the port you have selected (see [Table 5-2 on page 5-2](#) and the “[Controller Configuration Commands](#)” section on page 5-17).

To view the available commands you use to configure E1 controller parameters, type a question mark on the command line from the controller configuration mode (see step 2 of the “[Configuring Full-Rate Unchannelized E1 Bandwidths](#)” section on page 5-6).

## Configuring E1 Serial Interfaces

For a detailed description of how to configure, monitor, and troubleshoot an E1 serial interface, see the [Configuration Fundamentals Configuration Guide](#) and the [Cisco IOS Interface and Hardware Component Configuration Guide](#). This section describes the general procedure you use for configuring an E1 controller and an E1 serial interface on any E1/T1 line-card port from the interface configuration mode.

- Step 1** Enter the controller configuration mode to configure the controller (see the “[Configuring a Controller](#)” section on page 5-16 for details).
- Step 2** Use the **channel-group** command to assign framed or unframed E1 bandwidth allotments to the line card ports (see the “[Specifying Channel Groups](#)” section on page 5-21 for details).
- Step 3** Go to interface configuration mode for any channel group you created in the controller configuration mode (see the “[Configuring a Serial Interface](#)” section on page 5-17 for details).
- Step 4** Enter a value for protocol encapsulation. This example shows the command for using frame relay. You can also choose PPP or HDLC (default).
- ```
Router(config-if)# encapsulation frame-relay
Router(config-if)#
```
- Step 5** If IP routing is enabled on the system, assign an IP address and subnet mask. For example:
- ```
Router(config-if)# ip address 10.16.32.49 255.255.240.0
```
- Step 6** Add any other serial interface configuration commands required to enable other routing protocols and to set other interface characteristics.
- Step 7** Be sure all physical port connections have been made on the 24-Port Channelized E1/T1 line card in the Cisco series 10000 router chassis (see the [Cisco 10000 Series Router Line Card Hardware Installation Guide](#)).
- Step 8** When you have entered all of the necessary interface configuration commands (see the [Cisco IOS Interface and Hardware Component Configuration Guide](#)), to complete the configuration, return to the privileged EXEC mode.
- ```
Router(config-if)# end
Router#
```

**Step 9** Write the new configuration to NVRAM:

```
Router# copy running-config startup-config
Router#
```

---

After you create the port serial interface configurations, you can modify them at any time using the appropriate Cisco IOS commands described in the following sections and in the [Cisco IOS Interface and Hardware Component Configuration Guide](#) and the [Cisco IOS Command References](#).

## T1 Configuration Examples

The examples in this section familiarize you with the line card configuration tasks and typify how you apply the commands listed in [Table 5-4](#) and the syntax in [Table 5-5](#) to configure a T1 controller. These examples also show how to configure T1 channel-group bandwidth at any of the 24 available ports on the line card. The example steps are intended to quickly familiarize you with the procedures you use to set up a T1 port.



### Note

---

You must be in privileged EXEC mode to specify and configure a controller for T1 operation on any line card port.

---

## Configuring a T1 Controller

From the IOS global configuration mode, you use the **config terminal** command to enter the global configuration mode (see the “[Configuring a Controller](#)” section on page 5-16 for details).

## Configuring Full-Rate Channelized T1 Bandwidths

To configure the available channelized (framed) full-rate T1 bandwidth on a line card port, you must select a T1 controller from the global configuration mode. The following example shows you the steps you use to create a channelized full-rate T1 controller:

---

**Step 1 Specify a Controller:** To configure the available T1 channelized full-rate bandwidth of an interface on port 1 of a line card in router chassis slot 2, you select a T1 controller from the global configuration mode and then specify all available timeslots from the controller configuration mode:

```
Router(config)# controller t1 2/0/1
Router(config-controller)# channel-group 7 timeslots 1-24
Router(config-controller)
```

These commands assign channel-group number 7 and timeslots 1 through 24 (the maximum available framed T1 bandwidth) to port 1 of the line card in router chassis slot 2.

**Step 2 Specify Controller Parameters:** to specify any other controller parameters you enter the controller parameters for the controller you have selected (see [Table 5-4 on page 5-4](#) and the “[Controller Configuration Commands](#)” section on page 5-17).

---



## Configuring Fractional Channelized T1 Bandwidths

To configure an available channelized (framed) fractional T1 bandwidth on a port, you must select a T1 controller from the global configuration mode. The following example shows the procedure you use to create a fractional channelized T1 interface.

- Step 1** The following two examples in this step show you how to configure all the available T1 mode port 2 timeslots as interfaces:

Example 1:

```
Router(config)# controller t1 2/0/2
Router(config-controller)# channel-group 8 timeslots 1, 2, 5, 11-24
Router(config-controller)#
```

These commands configure port 2 time slots 1, 2, 5, and 11 to 24, of the line card in router chassis slot 2 as T1 channel-group (interface) number 8.

Example 2:

```
Router(config-controller)# channel-group 9 timeslots 3, 4, 6-10
Router(config-controller)#
```

Because you are still in the controller configuration mode, you use this command to configure T1 channel-group (interface) number 9 and remaining timeslots 3, 4, and 6 to 10 on port 2 of the line card in router chassis slot 2.

- Step 2** **Specify Controller Parameters:** to specify any other controller parameters you enter the controller parameters for the controller you have selected (see [Table 5-4 on page 5-4](#) and the “[Controller Configuration Commands](#)” section on page 5-17).

## Configuring T1 Serial Interfaces

For a detailed description of how to configure, monitor, and troubleshoot a T1 serial interface, see the [Configuration Fundamentals Configuration Guide](#) and the [Cisco IOS Interface and Hardware Component Configuration Guide](#). This section describes the general procedure you use for configuring a T1 serial interface on any line-card port from the interface configuration mode.

- Step 1** Enter the controller configuration mode to configure the T1 controller (see the “[Configuring a T1 Controller](#)” section on page 5-10).
- Step 2** Use the **channel-group** command to assign framed T1 bandwidths to the line card ports.
- Step 3** Go to interface configuration mode for any T1 channel group you created in the controller configuration mode and specify the serial interface channel-group number:

```
Router(config)# interface serial 2/0/2:20
Router(config-if)#
```

- Step 4** Enter a value for protocol encapsulation. This example shows the command for using frame relay. You can also choose PPP or HDLC (default).

```
Router(config-if)# encapsulation frame relay
Router(config-if)#
```

- Step 5** If IP routing is enabled on the system, assign an IP address and subnet mask. For example:

```
Router(config-if)# ip address 10.16.32.49 255.255.240.0
```

- Step 6** Add any other configuration commands required to enable other routing protocols and to set other interface characteristics.
- Step 7** Be sure all physical port connections have been made on the line card in the Cisco series 10000 router chassis (see the *Cisco 10000 Series Router Line Card Hardware Installation Guide*).
- Step 8** When you have entered all of the necessary interface configuration commands (see the *Cisco IOS Interface and Hardware Component Configuration Guide* publication), to complete the configuration, return to the privileged EXEC mode.
- ```
Router(config-if)# end
Router#
```
- Step 9** Write the new configuration to NVRAM:
- ```
Router# copy running-config startup-config
Router#
```

---

After you create the port interface configurations, you can modify them at any time using the appropriate Cisco IOS commands described in the following sections and in the *Cisco IOS Interface and Hardware Component Configuration Guide* and the *Cisco IOS Command References*.

## Command Descriptions

You invoke the various IOS commands using the following Cisco IOS command modes (see [Table 5-2 on page 5-2](#)):

- Privileged EXEC
- Global Configuration
- Controller Configuration
- Interface Configuration

You must begin configuring the 24-Port Channelized E1/T1 line card from the privileged EXEC command mode.

## Privileged EXEC Commands

The Cisco IOS privileged EXEC mode commands are:

- hw-module
- show controllers
- show interfaces

You enter the privileged EXEC configuration mode from the user EXEC mode:

```
Router> enable
Password: (you enter your administrative password)
Router#
```

When your prompt changes to Router# you are in the privileged EXEC mode.

## Simulating Line Card Installation and Removal

You use this **hw-module** command to simulate installation and removal of a line card at any router chassis slot you previously referenced using the **card** command (see the “[Preconfiguring a Line Card](#)” section on page 5-15):

```
Router# hw-module {slot slot reset | subslot slot/subslot reset}
Router#
```

Example:

```
Router# hw-module slot 5 reset
```

This command simulates removal and installation of any line card in router chassis slot 5.

This command does not have a **no** form.

## Displaying Controller Information

You use the **show controllers** command to display information about an E1 or T1 controller configuration at any of the 24 line card ports. Use the following syntax for an E1 controller:

```
show controllers e1 slot/subslot/port
```

Example 1: The following example shows the output displayed on the system console for line card E1 operation in router chassis slot 1, subslot 0, port 0 when this command executes:

```
Router# show controller e1 1/0/0
1 1/0/0 is down.
Applique type is Channelized E1 - balanced
Receiver has loss of signal.
Framing is CRC4, Line Code is HDB3, Clock Source is Line.
International Bit: 1, National Bits: 11111
Data in current interval (12 seconds elapsed):
0 Line Code Violations, 0 Path Code Violations
0 Slip Secs, 0 Fr Loss Secs, 0 Line Err Secs, 0 Degraded Mins
0 Errored Secs, 0 Bursty Err Secs, 0 Severely Err Secs, 12 Unavail Secs
Hardware is C10K CHE1T1 line card
Router#
```

Example 2: The following example shows the output displayed on the system console for a line card operating in T1 mode in router chassis slot 1, subslot 0, port 0 when this command executes:

```
Router# show controller t1 1/0/0
1 1/0/0 is down.
Applique type is Channelized T1 - balanced
Receiver has loss of signal.
Framing is esf, Line Code is ami, Clock Source is Line.
Data in current interval (12 seconds elapsed):
0 Line Code Violations, 0 Path Code Violations
0 Slip Secs, 0 Fr Loss Secs, 0 Line Err Secs, 0 Degraded Mins
0 Errored Secs, 0 Bursty Err Secs, 0 Severely Err Secs, 12 Unavail Secs
Hardware is C10K CHE1T1 line card
Router#
```

## Displaying Interface Information

You use the **show interface** command to display information about the current E1/T1 channel-group (interface) at any of the 24 24-Port Channelized E1/T1 line card ports using the following syntax:

```
show interfaces serial slot/subslot/port:channel-group [subcommand]
```

The Following example shows the output displayed on the system console for the serial interface configuration on router chassis slot 1, subslot 0, port 0, and channel-group 0 when this command executes:

```
Router# show interfaces serial 1/0/0:0
Serial1/0/0:0 is down, line protocol is down
Hardware is Channelized E1T1 controller
MTU 1500 bytes, BW 64 Kbit, DLY 20000 usec, rely 255/255, load 1/255
Encapsulation HDLC, crc 16, loopback not set
Keepalive set (10 sec)
Last input never, output never, output hang never
Last clearing of "show interface" counters 00:00:18
Queueing strategy: PXF First-In-First-Out
Output queue 0/32, 0 drops; input queue 0/75, 0 drops
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
0 packets input, 0 bytes, 0 no buffer
Received 0 broadcasts, 0 runts, 0 giants, 0 throttles
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
0 packets output, 0 bytes, 0 underruns
0 output errors, 0 collisions, 0 interface resets
0 output buffer failures, 0 output buffers swapped out
0 carrier transitions alarm present
Timeslot(s) Used: 1, subrate: 64Kb/s, transmit delay is 0 flags
non-inverted data
Router#
```

This command does not have a **no** form. You must specify at least one channel group when you use this command. You can also specify a subcommand from a number of associated subcommands (see [Table 5-2 on page 5-2](#) and [Table 5-4 on page 5-4](#)).

## Global Configuration Commands

The line card Cisco IOS global configuration commands are:

- card
- hw-module (shutdown)
- controller
- interface

You use the **configure terminal** command to enter the global mode from the privileged EXEC mode:

Example:

```
Router> enable
Password: (you enter your administrative password)
Router# config terminal
Enter Configuration commands, one per line. End with CNTRL/Z.
Router(config)#
```

When your prompt changes to `Router(config)#` you are in the global configuration mode.

## Preconfiguring a Line Card

Using the **card** command you can preconfigure a router chassis slot for a specific line card and operating mode in the absence of such a line card in that slot. After you have preconfigured a router chassis slot for a 24-Port Channelized E1/T1 line card and E1 or T1 operation, when you install a 24-Port Channelized E1/T1 line card into the preconfigured slot, that line card is ready to operate in the preconfigured mode.

When you install a 24-Port Channelized E1/T1 line card in the router chassis slot you have preconfigured, a power-on self test (POST) should immediately take place and the line card should then be ready for operation.

You use the **card** command in the global configuration mode to preprovision any Cisco 10000 series router chassis slot for line card E1 or T1 operation when no line card is available, or to change modes for a line card that is already installed:

```
Router(config)# [no] card slot/subslot 24che1t1-1 [mode {e1 | t1}]
Router(config)#
```

Where:

- **24che1t1-1** is the Cisco E1/T1 line-card Cisco product reference, which you select from a list of optional product references for any line card you can install and configure in a Cisco series 10000 router chassis.




---

**Note** The -1 number specifies the current 24-Port Channelized E1/T1 line card revision and may change.

---

- **mode e1** configures all the line card ports for the E1 framing format.
- **mode t1** configures the line card ports for the T1 framing format.

The following examples show how to use the **card** command to simulate the line card controller E1 mode and E1 operation:

- **Example 1:** In the following example, you configure router chassis slot 3 for E1 operation and use the **hw-module** and **card** commands to simulate a 24-Port Channelized E1/T1 line card installation:

```
Router> enable
Password: (you enter your administrative password)
Router# hw-module slot 3 reset
Router# config terminal
Enter Configuration commands, one per line. End with CNTRL/Z.
Router(config)# card 3/0 24che1t1-1 mode e1
Router(config)#
```

- **Example 2:** In the following example, you configure router chassis slot 3 for the T1 operation and use the **hw-module** and **card** commands to simulate a 24-Port Channelized E1/T1 line card installation:

```
Router> enable
Password: (you enter your administrative password)
Router# hw-module slot 3 reset
Router# config terminal
Enter Configuration commands, one per line. End with CNTRL/Z.
Router(config)# card 3/0 24che1t1-1 mode t1
Router(config)#
```

The following relationships exist between the Cisco series 10000 router on-line insertion (OIR) feature and the **card** command:

- When you install a 24-Port Channelized E1/T1 line card into a router chassis slot for which a **24che1t1-1** entry already exists in the running configuration, the OIR feature invokes the existing E1 or T1 controller configuration.
- When you install a 24-Port Channelized E1/T1 line card into a router chassis slot for which no **24che1t1-1** entry exists in the running configuration, the OIR feature invokes the default configuration.
- When you install a 24-Port Channelized E1/T1 line card into a router chassis slot for which a product reference other than **24che1t1-1** exists, the OIR feature invokes the default configuration.
- In this example you simulate the removal of a 24-Port Channelized E1/T1 line card from router chassis slot 3, which you previously specified with the **card** command.



**Note** To use the “no” form of card command, the line card must be physically removed from the chassis.

```
Router(config)# hw-module slot 3 shutdown
Router(config)# no card 3/0
Router(config)#
```

## Shutting Down Line Card Simulation

You use this command to turn on and shut down simulated 24-Port Channelized E1/T1 line card operation using the following syntax:

```
Router (config)# [no] hw-module {slot slot shutdown | subslot subslot/slot shutdown}
```

The following examples show how you use the **hw-module shutdown** command to shut down or turn on the E1/T1 line-card simulated running configuration:

- In this example, you shut down a simulated running configuration in router chassis slot 5:

```
Router(config)# hw-module slot 5 shutdown
Router(config)#
```

- In this example, you turn on the simulated running configuration of the line card in router chassis slot 5:

```
Router(config)# no hw-module slot 5 shutdown
Router(config)#
```

## Configuring a Controller

You use the **configure terminal** command to enter the global configuration mode and to configure the E1 or T1 controller. To select a chassis slot, subslot, and port E1 controller, you use the following syntax from the global configuration mode:

```
Router(config)# controller {t1 | e1} slot/subslot/port
```

Example 1: In the following example, you select chassis slot 2 E1 controller:

```
Router> enable
Password: (you enter your administrative password)
Router# config terminal
Enter Configuration commands, one per line. End with CNTRL/Z.
Router(config)# controller e1 2/0/0
Router(config-controller)#
```

Example 2: In the following example, you select chassis slot 2 T1 controller:

```
Router> enable
Password: (you enter your administrative password)
Router# config terminal
Enter Configuration commands, one per line. End with CNTRL/Z.
Router(config)# controller t1 2/0/0
Router(config-controller)#
```

## Configuring a Serial Interface

For each port you configure at the controller configuration level, you must also configure various associated serial interface parameters for each channel group you previously created at that port. To configure 24-Port Channelized E1/T1 line card serial interfaces for their serial interface parameters, you must be in the interface configuration mode. To specify interface parameters for any channel group you previously created, use the following syntax:

```
[no] interface serial slot/subslot/port:channel-group
```

Use the **no** form of the channel-group command (see the “[Specifying E1 Channel Groups](#)” section on page 5-21 and the “[Specifying T1 Channel Groups](#)” section on page 5-22) to disable a serial interface at an E1 or T1 port, respectively, and a channel group you previously provisioned.

Example:

```
Router> enable
Password: (you enter your administrative Password)
Router# config terminal
Enter Configuration commands, one per line. End with CNTRL/Z.
Router(config)# interface serial 2/0/0:20
Router(config-if)#
```

These commands establishes the interface configuration mode for the 24-Port Channelized E1/T1 line card in router chassis slot 2, subslot 0, port 0 and channel-group 20. When your prompt changes to Router(config-if)# you can configure the channel group serial interface parameters.



### Note

You can not specify a channel group until you have first selected an E1 or T1 controller.

## Controller Configuration Commands

After installing a 24-Port Channelized E1/T1 line card into a router chassis slot, you configure it in controller configuration mode. You can also preconfigure a router chassis slot and the line-card ports for E1 or T1 mode, and as serial interfaces, before you install a line card into the preconfigured slot (see the “[Preconfiguring a Line Card](#)” section on page 5-15).

The controller configuration commands listed in [Table 5-2](#) and in [Table 5-4](#) are those you use to preconfigure or configure a 24-Port Channelized E1/T1 line card controller. You also use these commands to provide the line card with its system functionality. To configure the line card at the E1 or T1 controller level, you perform the following general procedure:

- 
- Step 1** Configure or preconfigure a chassis slot for E1 or T1 mode.
- Step 2** Configure or preconfigure controller timeslots as channel groups (interfaces).
- Step 3** Specify any other E1 or T1 controller parameters.
- Step 4** Save the controller configuration by writing it to NVRAM.
- 

## E1 Port Interface Density

Using all 24 line card ports, you can configure as many as 744 CE1 interfaces (channels) of any 24-Port Channelized E1/T1 line card you install in a router chassis slot. You can also preconfigure as many channels for that same chassis slot even though the slot does not contain a line card. You use the **card** command (see the [“Preconfiguring a Line Card” section on page 5-15](#)) to preconfigure any router chassis slot, subslot, and port for E1 controller mode that does not contain a line card.

## T1 Port Interface Density

Using all 24 line card ports, you can configure as many as 576 CT1 interfaces (channels) of any 24-Port Channelized E1/T1 line card you install in a router chassis slot. You can also preconfigure as many channels for that same chassis slot even though the slot does not contain a T1 line card. You use the **card** command (see the [“Preconfiguring a Line Card” section on page 5-15](#)) to preconfigure any router chassis slot, subslot, and port for T1 controller mode that does not contain a line card.

## Controller Commands

This section describes the commands you use to create, customize, and test an E1 or T1 interface at the system level.

After you configure the line card, slot, subslot, port, and channel-group numbers, you can configure other E1 or T1 controller parameters (see the [“E1 Configuration Examples” section on page 5-6](#) and the [“T1 Configuration Examples” section on page 5-10](#)). You configure the E1 or T1 controller configuration parameters using the commands described in this section:

- [Running a BER Test, page 5-19](#)
- [Specifying T1 Short-Haul Cable Length, page 5-20](#)
- [Specifying Channel Groups, page 5-21](#)
- [Specifying a Clock Source, page 5-24](#)
- [Adding a Controller Description, page 5-24](#)
- [Enabling T1 Facility Data Link Performance Monitoring, page 5-24](#)
- [Specifying Framing, page 5-25](#)
- [Specifying Linecoding, page 5-26](#)
- [Specifying Loopbacks, page 5-27](#)
- [Specifying E1 National Reserve Bits, page 5-28](#)
- [Specifying a T1 Yellow Alarm, page 5-28](#)
- [Specifying Shutdown, page 5-29](#)



## Running a BER Test

You can configure an interface to run a BERT (Bit Error Rate Test). You use a BERT to isolate cable signal problems in the field, to check network cabling, and to isolate apparent signaling problems in the field.

Before you begin a network BERT, you need to set up a remote loopback from the far-end (remote) DSU/CSU (see the “[Specifying Loopbacks](#)” section on page 5-27).

Use the following loopback commands to set the near end devices (CSU/DSUs) to perform loopbacks:

- **loopback local line**—Use this loopback submode on both E1 and T1 ports. This submode configures the line card to loop transmitted packets back as received packets after the framer. The line card also receives all incoming packets and outgoing packets are also transmitted to the remote network device.
- **loopback network**—Use this loopback mode on both E1 and T1 ports. This mode configures the line card to loop packets transmitted from the line card to a remote device back to the line card as received packets. This loopback mode has the following submodes:
  - **loopback network line**—Use this loopback submode on both E1 and T1 ports. This submode configures the line card to loop received packets back to the remote device without first framing them.
  - **loopback network payload**—Use this loopback submode on both E1 and T1 ports. This submode configures the line card to loop received packets back to the remote device after first framing them.
- **loopback remote** — Operates in T1 mode only (see the “[Specifying T1 Loopbacks](#)” section on page 5-27). This loopback mode has the following submodes:
  - **loopback remote line**—Use this loopback submode on T1 ports to configures the far-end device to loop received packets back to the line card without first framing them.
  - **loopback remote payload**—Use this loopback submode on T1 ports to configures the far-end device to loop received packets back to the line card after framing them.

## Running an E1 BERT

You can only run a BERT (bit-rate error test) over the full bandwidth of an E1 controller in **unframed** mode. To send a BERT pattern on a line card E1 interface, use the following controller configuration command syntax:

```
[no] bert pattern pattern interval time [unframed]
```

Where:

- **pattern** *pattern* is:
  - **2^11**—pseudorandom test pattern (32,768 bits long)
  - **2^15**—pseudorandom O.151 test pattern (32,768 bits long)
  - **2^20-O153**—pseudorandom O.153 test pattern (1,048,575 bits long)
  - **2^20-QRSS**—pseudorandom QRSS O.151 test pattern (1,048,575 bits long)
- **interval** *time* is 1 to 1440 minutes.

The **no** form of the bert command is the default. You can terminate a BERT at any time using the **no bert** command.

**Note**

The **no bert** command terminates a running BERT and, whether running or stopped, inhibits the display of BERT information on the console when you invoke the **show controllers** command (see the “[Displaying Controller Information](#)” section on page 5-13).

Example:

To send a BERT pseudorandom pattern of 2<sup>20</sup>-O.153 through E1 interface 1/0/0 for 5 minutes:

```
Router(config)# controller e1 1/0/0
Router(config-controller)# bert pattern 2^20-0153 interval 5 unframed
Router(config-controller)#
```

For more information, see the *Cisco IOS Interface and Hardware Component Configuration Guide* and the *Cisco 10000 Series Internet Router Troubleshooting Guide*.

**Running a T1 BERT**

In addition to the **local** and **network loopback** configurations described in the “[Running a BER Test](#)” section on page 5-19, you can also perform **remote** loopback testing on T1 interfaces.

**Note**

You can only perform **remote** loopback testing on T1 ports that also have C-bit parity framing configured.

To send a BERT pattern on a line card T1 interface configured for remote loopback, use the following controller configuration command syntax:

```
[no] bert pattern pattern interval time
```

Use the following command to send a BERT pattern to the far-end device:

Example:

To send a BERT pseudorandom pattern of 2<sup>20</sup>-O.153 through T1 interface 1/0/0 to the far-end device for 5 minutes:

```
Router(config)# controller t1 1/0/0
Router(config-controller)# bert pattern 2^20-0153 interval 5
Router(config-controller)#
```

**Specifying T1 Short-Haul Cable Length**

You can only use the **cablelength** command on T1 ports. Use this command to compensate short haul lines (under 660 feet) for signal losses associated with line length. To specify cable length for short-haul cables use the following controller configuration command syntax:

```
[no] cablelength short {110 | 220 | 330 | 440 | 550 | 660}
```

Use [Table 5-6](#) to specify the proper short-haul cable length value for cables up to 660 feet long.

**Table 5-6 T1 Short-Haul Line Buildout**

Line Length (feet)	Cable Length Value
0 to 110	110
110 to 220	220
220 to 330	330

**Table 5-6 T1 Short-Haul Line Buildout**

Line Length (feet)	Cable Length Value
330 to 440	440
440 to 550	550
550 to 660	660

## Specifying Channel Groups

A channel group is a serial interface. At a framed E1 port, you can assign bandwidth to as many as 31 channel groups numbered from 1 to 31 in 64-kbps increments called timeslots. When you specify an E1 port as unframed, you only assign a single channel group whose bandwidth is 2048 kbps. At a T1 port, you can assign bandwidth to as many as 24 channel groups in 56- or 64-kbps timeslot increments. T1 ports can not operate in unframed mode.

### Specifying E1 Channel Groups

An E1 port has 32 fixed timeslots available. In framed mode, timeslot 0 is used for framing and can not be used. Each E1 timeslot is a 64-kbps DS0 band. To create E1 interfaces that supports subscriber traffic rates from 64 kbps to 2048 kbps on any of the 24 line card ports, you combine timeslots into channel groups. You use the **channel-group** command to create one or more interfaces at any port operating in E1 mode.

The E1 channel groups have these characteristics:

- A channel group is an interface.
- You partition each line card port into channel groups. A framed port can have as many as 31 E1 channel groups consisting of from 0 to 31 timeslots. At any port:
  - A channel group that includes all 32 timeslots (0 to 31) is a single *unframed* (unchannelized) E1 interface whose bandwidth is 2048 kbps.
  - A channel group that includes 31 timeslots (1 to 31) is a single *framed* (channelized) E1 interface whose bandwidth is 2048 kbps.
  - A channel group that consists of fewer than 31 timeslots is a single framed fractional E1 interface whose bandwidth you assign from the port timeslot pool (see the “[Configuring an E1 Controller](#)” section on page 5-6).
- Each group of 31 framed timeslots can be grouped into multiple fractional E1 interfaces.
- A timeslot cannot be part of more than one E1 channel group.

After you configure a line card as an E1 controller, you can create one or more logical E1 channel groups from the timeslots available at each port using the following controller command syntax:

```
[no] channel-group channel-group-number {timeslots list-of-timeslots [speed 64] | unframed}
```

Where:

- **channel-group** *channel-group-number* is a number from 0 to 30 that you assign to identify each channel group you create.
- **timeslots** *list-of-timeslots* can be a value from 1 to 31, or a combination of timeslots from 1 to 31. You indicate a timeslot range using a hyphen, commas, or a combination of both. One timeslot defines a single E1 channel as shown by the following examples.
- **speed 64** specifies the digital data rate of a single timeslot as 64 kbps (default).

- **unframed** specifies a single digital interface whose bandwidth is 2048 kbps. If you do not specify this option, you invoke E1 framing and the channel-group bandwidth depends on the number of timeslots you assign to the interface.

Use the **no** form of the command to cancel a logical channel group previously created.

The following examples show how you use the **channel-group** command in E1 mode:

- In this example, you configure channel group 20 as nine timeslots, whose bandwidth is 576 kbps, on port 0:

```
Router(config)# controller E1 1/0/0
Router(config-controller)# channel-group 20 timeslots 1-9
Router(config-controller)#
```

To access the interface configuration mode for this channel group, you enter:

```
Router(config)# interface serial 1/0/0:20
Router (config-if)#
```

- In this example, an E1 interface includes channel group 18 and consists of all 31 timeslots, creating a full-rate framed E1 interface at port 0:

```
Router(config)# controller E1 1/0/0
Router(config-controller)# channel-group 18 timeslots 1-31
Router(config-controller)#
```

To access interface configuration mode for this channel group, enter:

```
Router(config)# interface serial 1/0/0:18
Router(config-if)#
```

- In this example, three channelized E1 interfaces are configured as three channel groups, which use 11 of the 31 available timeslots, at port 0:

```
Router(config)# controller E1 1/0/0
Router(config-controller)# channel-group 19 timeslots 1-6
Router(config-controller)# channel-group 20 timeslots 10
Router(config-controller)# channel-group 21 timeslots 7-9, 24
Router(config-controller)#
```

- In this example, channel groups 19, 20, and 21 are cancelled and timeslots 1 to 10, and 24 are restored to the available port 0 channel-group pool.

```
Router(config)# controller E1 1/0/0
Router(config-controller)# no channel-group 19
Router(config-controller)# no channel-group 20
Router(config-controller)# no channel-group 21
Router(config-controller)#
```

## Specifying T1 Channel Groups

A T1 port has 24 fixed timeslots available. Each T1 timeslot is a 56- or 64-kbps DS0 band depending on the configured line speed. To create T1 interfaces that support subscriber traffic rates from 56 kbps to 1344 kbps on any of the 24 line card ports operating at 56 kbps, you combine timeslots into framed channel groups.

To create T1 interfaces that support subscriber traffic rates from 64 kbps to 1536 kbps on any of the 24 line card ports operating at 64 kbps, you do the same.

You use the **channel-group** command to create one or more interfaces at any port operating in T1 mode. The T1 channel groups have these characteristics:

- A channel group is an interface.

- You partition the line card ports into channel groups. A port can have as many as 24 channel groups consisting of from 1 to 24 (DS0) timeslots. At any port:
  - A channel group that includes 24 timeslots (1 to 24) is a single *framed* (channelized) T1 interface whose bandwidth is 1536 kbps.
  - A channel group that consists of fewer than 24 timeslots is a single framed fractional T1 interface whose bandwidth you assign from the T1 port timeslot pool (see the “[Configuring a T1 Controller](#)” section on page 5-10).
- Each group of 24 framed timeslots can be grouped into multiple fractional T1 interfaces.
- A channel group cannot be part of more than one T1 interface.

After you configure a line card for T1 mode, you can create one or more logical T1 channel groups from the timeslots available at each port using the following controller command syntax:

```
[no] channel-group channel-group-number {timeslots list-of-timeslots [speed 56] | 64}
```

Where:

- **channel-group** *channel-group-number*, **timeslots** *list-of-timeslots*, and **speed 64** (default) have the same significance as the options described for the E1 channel-group command above in the “[Specifying E1 Channel Groups](#)” section.
- **speed 56** specifies the digital data rate of a single timeslot as 56 kbps.

The following examples show how you use the **channel-group** command in T1 mode:

- In this example, you configure channel group 20 as nine timeslots, whose bandwidth is 576 kbps (64 kbps default speed) on port 0:

```
Router(config)# controller t1 1/0/0
Router(config-controller)# channel-group 20 timeslots 1-9
Router(config-controller)#
```

To access the interface configuration mode for this channel group, you enter:

```
Router(config)# interface serial 1/0/0:20
Router (config-if)#
```

- In this example, a T1 interface includes channel group 18 and consists of all 24 timeslots, creating a full-rate framed T1 interface at port 0:

```
Router(config)# controller t1 1/0/0
Router(config-controller)# channel-group 18 timeslots 1-24
Router(config-controller)#
```

To access interface configuration mode for this channel group, enter:

```
Router(config)# interface serial 1/0/0:18
Router(config-if)#
```

- In this example, three channelized T1 interfaces are configured as three channel groups, which use 11 of the 24 available timeslots, at port 0:

```
Router(config)# controller t1 1/0/0
Router(config-controller)# channel-group 19 timeslots 1-6
Router(config-controller)# channel-group 20 timeslots 10
Router(config-controller)# channel-group 21 timeslots 7-9, 24
Router(config-controller)#
```

- In this example, channel groups 19, 20, and 21 are cancelled and timeslots 1 to 10, and 24 are restored to the available port 0 channel-group pool.

```
Router(config)# controller t1 1/0/0
Router(config-controller)# no channel-group 19
Router(config-controller)# no channel-group 20
Router(config-controller)# no channel-group 21
Router(config-controller)#
```

## Specifying a Clock Source

You use the **clock** command to choose whether the transmitted clock signal comes from the received clock or is generated by an internal clock source. You use the following controller command to specify the transmit timing source:

```
[no] clock source {line | internal}
```

Example:

```
Router(config-controller)# clock source line
```

The **no** form of this command sets the clock source to **line**, the default state.



### Caution

You should never configure both sides of an E1 or T1 link to **clock source line**.

## Adding a Controller Description

You can use the **description** command to identify particulars about a controller interface. You can enter up to 80 characters in your controller description string. To provide additional information about an interface you use to the following controller command:

```
[no] description text
```

Where: *text* is the description string.

Example:

```
Router(config-controller)# description Subscriber X
```

## Enabling T1 Facility Data Link Performance Monitoring

In T1 mode, you can specify the type of FDL (Facility Data Link) performance monitoring to use. You use FDL performance monitoring to verify the integrity of the data link and to transfer statistics between devices. FDL data is a diagnostic tool you use in remote testing of T1 network data links. You can specify either of 2 FDL performance monitoring versions for use in T1 networks:

- ANSI
- ATT

The version differences lie in the message protocols sent to or received from the remote device. To specify the FDL version, use the **fdl** command:

```
[no] fdl {ansi | att}
```

Where:

- **ansi**—Conforms with the requirements of the ANSI T1.403-1995 specification to communicate 16-bit data-link code words between the line card and the remote device.

- **att**—Conforms with the requirements of the AT&T TR 54016-1989 specification to receive 16-bit data-link code words between the line card and the remote device. Note that the 24-port 24-Port Channelized E1/T1 line card will not generate remote performance statistics requests. It only responds to received performance statistics requests.

## Specifying Framing

North American T1 facilities operate at a line speed of 1544 kbps. Framing conforms to either of 2 standards:

- D4 Superframe Format (SF)—The standard D4 SF consists of twelve 24-timeslot frames.
- Extended Superframe Format (ESF)—The ESF consists of twenty-four 24-timeslot frames.

European, Australian, and some Asian E1 facilities operate at a maximum line speed of 2048 kbps. Framing conforms to the CCITT G.704 or G.732 specification, which defines sixteen 32-timeslot multiframes. The initial timeslot (0) is used for framing.

## Specifying E1 Framing

To specify framing for an E1 interface, use the following **framing** command:

```
[no] framing {crc4 [australia] | no crc4 [australia]}
```

Example:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTRL/Z.
Router(config)# controller e1 1/0/0
Router(config-controller)# framing crc4
Router(config-controller)#
```

Where **crc4** is a checksum format used in framing timeslot 0 to provide error detection.

The default framing type is CRC4.

The **no** form of this command sets framing to the default value.

In Australia, you must also specify **australia** to obtain proper handling of the clock setting when AIS (alarm indication signal) detection occurs.

```
Router(config)# controller e1 1/0/0
Router(config-controller)# framing crc4 australia
Router(config-controller)#
```

## Specifying T1 Framing

To specify framing for a T1 interface, use the following **framing** command:

```
[no] framing {esf | sf }
```

Where:

- **esf**—Specifies the extended superframe format
- **sf**—Specifies the superframe format

Example:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTRL/Z.
Router(config)# controller t1 1/0/0
Router(config-controller)# framing sf hdlc-idle 0x7E
Router(config-controller)#
```

## Specifying Linecoding

You specify line coding to establish how physical data appears on the interface line using one of the following formats:

T1 formats:

- AMI (Alternate Mark Inversion)
- B8ZS (Binary 8 Zero Substitution)

E1 formats:

- HDB3 (High Density Bipolar 3)

These line coding formats ensure that line synchronization is maintained.

## Specifying E1 Linecoding

Linecode format HDB3 ensures that the E1 receiver remains synchronized in the presence of consecutive 0 bits in received data. In E1 mode, the line card supports HDB3 line encoding only:

```
[no] linecode hdb3
```

Where **hdb3** specifies the high-density bipolar 3 linecode in which every other 1 bit is of the opposite polarity and bipolar violations are used to automatically maintain proper 1s density.

The **no** form of this command sets the E1 default linecode to **hdb3**.

Example:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTRL/Z.
Router(config)# controller e1 1/0/0
Router(config-controller)# framing hdb3
Router(config-controller)#
```

## Specifying T1 Linecoding

You can specify either AMI or B8ZS line coding for T1 interfaces. In T1 mode, use the following linecode command:

```
[no] linecode {ami | b8zs}
```

- **ami**—specifies alternate mark inversion coding in which every other 1s bit is of the opposite polarity. If two consecutive bits have the same polarity, a bipolar violation occurs.
- **b8zs**—specifies binary 8 zero substitution in which each group of 8 consecutive zeros is replaced with a bipolar violation to maintain synchronization.

Example:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTRL/Z.
Router(config)# controller t1 1/0/0
Router(config-controller)# linecode ami
Router(config-controller)#
```



## Specifying Loopbacks

This line card supports local and network E1 and T1 loopback modes, and remote T1 loopback modes for testing, network fault isolation, and agency compliance. You can test E1 and T1 lines in local and network loopback modes. You can also test T1 lines in remote mode.

### Specifying E1 Loopbacks

If problems occur when you configure an E1 interface, you can troubleshoot the line card by using the following command in controller configuration mode:

```
[no] loopback {local | network {line | payload}}
```

Where:

- **local**—Configures the line card to loop transmitted traffic back to the line card as E1 received traffic and sends the local transmit signal to the remote receiver.



**Note** An E1 port in local loopback mode cannot send AIS due to hardware limitations. It only transmits to the line what it loops back to its receive. As a result, the remote end will keep receiving packets from a port in local loopback.

- **network line**—Configures the line card to loop received traffic back to the remote device without passing them through the framer.
- **network payload**—Configures the line card to loop received traffic back to the remote device after passing them through the framer.

Use the **no** form of the command to terminate a loopback.

For more information on this command, see the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Example 1:

- Configure an E1 controller port for local loopback.

```
Router(config)# controller e1 1/0/0
Router(config-controller)# loopback local
Router(config-controller)#
```

Example 2:

The following commands configure the E1 controller for local loopback at port 0, channel group 1

```
Router(config)# controller e1 1/0/0
Router(config-controller)# loopback local
Router(config-controller)#
```

### Specifying T1 Loopbacks

If problems occur when you configure an T1 interface, you can troubleshoot the line card by using the following command in controller configuration mode:

```
[no] loop {local | network {line | payload} | remote {line | payload | iboc}}
```

Where:

- **local**—Configures the line card to loop transmitted traffic back to the line card as T1 received traffic and sends the local transmit signal to the remote receiver.



**Note** A T1 port in local loopback mode cannot send AIS due to hardware limitations. It only transmits to the line what it loops back to its receive. As a result, the remote end will keep receiving packets from a port in local loopback.

- **network line**—Configures the T1 framer for the network line submode. In this mode, the line card transmitted packets are not reframed before they are sent to the remote device. The line card also receives all incoming packets.
- **network payload**—Configures the T1 framer for the network payload submode. In this mode, the line card received packets are reframed before they are sent back to the remote device.
- **remote line**—Configures the far end T1 in line loopback using the ESF ANSI protocol.
- **remote payload**—Configures the far end T1 in payload loopback using the ESF ANSI protocol.
- **remote iboc**—Configures the far end T1 in line loopback using the SF inband protocol.

## Specifying E1 National Reserve Bits

You use national reserve bits, which are embedded in-band control timeslot TS0 to codify a framing protocol for national variations:

```
[no] national reserve int sa4 sa5 sa6 sa7 sa8
```

Where:

- *int*—This is the national reserved bit.
- *Sa4* to *Sa8*—Specify the country-code bit values.

Example:

```
Router(config-controller)# controller 2/0/2
Router(config-controller)# national reserve 1 1 1 1 0 1
Router(config-controller)#
```

The default **[no]** value of this command is 000000.



**Note** National reserve bits are active only when the **framing no-crc4** command is invoked (see the “[Specifying E1 Framing](#)” section on page 5-25).

## Specifying a T1 Yellow Alarm

This line card supports the ability to control generation and detection of a T1 yellow Remote Alarm Indication (RAI). You enable or inhibit the RAI yellow alarm using the **yellow** command:

```
[no] yellow {generation | detection}
```

Where:

- **generation**—Enables or inhibits the near- and far-end RAI yellow alarms.
- **detection**—Inhibits or enables the near- end RAI yellow alarms.

**Example 1:**

This command inhibits far-end yellow alarms.

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTRL/Z.
Router(config)# controller t1 1/0/0
Router(config-controller)# no yellow generation
Router(config-controller)#
```

**Example 2:**

This command enables far-end yellow alarms.

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTRL/Z.
Router(config)# controller t1 1/0/0
Router(config-controller)# yellow generation
Router(config-controller)#
```

## Specifying Shutdown

You can shut down an interface. Doing so disables all interface functions and marks the interface as unavailable when you invoke monitoring commands such as **show**. You enable or shut down operation of an interface using the **shutdown** command:

**[no] shutdown****Example 1:**

```
Router(config-controller)# no shutdown
Router(config-controller)#
```

This command enables operation of the specified interface.

**Example 2:**

```
Router(config-controller)# shutdown
Router(config-controller)#
```

This command halts operation of the specified interface.





## CHAPTER 6

# 1-Port Channelized OC-12/STM-4 Line Card Configuration

---

This chapter describes the procedures for configuring the Cisco 10000 series 1-Port Channelized OC-12/STM-4 line card, hereafter known as the 1-Port Channelized OC-12/STM-4 line card.

The 1-Port Channelized OC-12/STM-4 line card uses fractional T1 (n x DS0), DS-1, E1, fractional E1 (n x DS0) and DS3 IP services to connect ISP customers to the network backbone. It provides full duplex operation at OC-12 bandwidth rates using a (single-mode) fiber optic port that provides the Cisco 10000 series router with a single interface that connects up to 768 individual channelized options.

This chapter contains the following sections:

- [Software Support, page 6-2](#)
- [SONET Channelization, page 6-2](#)
- [SDH Channelization, page 6-3](#)
- [Line Card Default Values, page 6-4](#)
- [Line Card Interface Syntax, page 6-8](#)
- [SONET-Framed Interface Configuration Sample, page 6-8](#)
- [SDH-Framed Interface Configuration Sample, page 6-10](#)
- [Configuring the SONET Controller for SONET or SDH Framing, page 6-14](#)
- [Creating a T3, VT, or AUG Controller, page 6-15](#)

## Software Support

Table 6-1 shows the minimum Cisco IOS release on each release train that supports the 1-Port Channelized OC-12/STM-4 line card.

**Table 6-1 1-Port Channelized OC-12/STM-4 Line Card Software Support**

Required PRE	Minimum Cisco IOS Releases
PRE1	Cisco IOS Release 12.0(9)SL and later releases of Cisco IOS Release 12.0SL Cisco IOS Release 12.0(17)ST and later releases of Cisco IOS Release 12.0ST Cisco IOS Release 12.0(22)S and later releases of Cisco IOS Release 12.0S Cisco IOS Release 12.2(8)BZ and later releases of Cisco IOS Release 12.2(8)BZ for SONET mode only. For both SONET and SDH mode, use Cisco IOS Release 12.0(23)S and later releases of Cisco IOS 12.0S.
PRE2	Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS 12.3XI For both SONET and SDH mode, use Cisco IOS Release 12.2(15)BX and later releases of Cisco IOS 12.2BX. Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB
PRE3	Cisco IOS Release 12.2(31)SB2 and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## SONET Channelization

The 1-Port Channelized OC-12/STM-4 line card supports the following SONET channelization modes:

- STS-1 > DS3/T3
- STS-1 > DS3/T3 > DS1
- STS-1 > DS3/T3 > DS3 subrate
- STS-1 > VT1.5 > DS1
- STS-1 > VT2 > E1

Table 6-2 shows serial interface examples for SONET channelizations on a previously-configured SONET-framed controller on the 1-Port Channelized OC-12/STM-4 line card.

**Table 6-2** SONET Interface Examples for a SONET-Framed Controller

Interface Type	Syntax
STS-1, over DS3/T3	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<T3#>
STS-1, over DS3/T3, channelized to DS1	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<T3#>/<ds1#>:[chan]
STS-1, over subrated DS3/T3	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<T3#>
STS-1, over VT1.5, channelized to DS1	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<VT#>/<ds1#>:[chan]
STS-1, over VT2, channelized to E1	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<VT#>/<E1#>:[chan]

## SDH Channelization

The 1-Port Channelized OC-12/STM-4 line card supports the following SDH channelization modes:

- STM-1 > AU-3 > DS3/T3
- STM-1 > AU-3 > DS3/T3 > DS3 subrate
- STM-1 > AU-3 > TUG-2 > C-11 > DS1/T1
- STM-1 > AU-3 > TUG-2 > C-12 > E1
- STM-1 > AU-4 > TUG-3 > TUG-2 > C-11 > DS1/T1
- STM-1 > AU-4 > TUG-3 > TUG-2 > C-12 > E1

Table 6-3 shows serial interface examples for SDH channelizations on a previously-configured SDH-framed controller on the 1-Port Channelized OC-12/STM-4 line card.

**Table 6-3** SDH Interface Examples for an SDH-Framed Controller

Interface Type	Syntax
STM-4, over STM-1, over AU-3, over DS3/T3	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<T3#>
STM-4, over STM-1, over AU-3, over a subrated DS3/T3	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<T3#>
STM-4, over STM-1 over AU-3, over TUG-2, over C-11 (DS1/T1)	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<AU-3#>/<TUG-2>/<C-11>:[chan]

**Table 6-3 SDH Interface Examples for an SDH-Framed Controller (continued)**

Interface Type	Syntax
STM-4, over STM-1 over AU-3, over TUG-2, over C-12 (E1)	Router (config) # <b>interface serial</b> <slot>/<subslot>/<port>.<AU-3#>/<TUG-2>/<C-12>: [chan]
STM-4, over STM-1 over AU-4, over TUG-3, over TUG-2, over C-11 (DS1/T1)	Router (config) # <b>interface serial</b> <slot>/<subslot>/<port>.<AU-4#>/<TUG-3>/<TUG-2>/<C-11>: [chan]
STM-4, over STM-1 over AU-4, over TUG-3, over TUG-2, over C-12 (E1)	Router (config) # <b>interface serial</b> <slot>/<subslot>/<port>.<AU-4#>/<TUG-3>/<TUG-2>/<C-12>: [chan]

## Line Card Default Values

The 1-Port Channelized OC-12/STM-4 line card has two sets of command default values. The set of default values in use is determined by the **framing** command—either SONET framing or SDH framing.

The following tables contains command default values, and indicate which configuration mode you need to be in to enter a command. Where applicable, the tables also indicate which commands apply to which line types. The tables include the commands used for modifying a default value and indicates whether a value needs to be the same (or opposite) on the remote end of the connection.

### Line Card Default Values for SONET Framing

This section contains tables of command default values that apply when the 1-Port Channelized OC-12/STM-4 line card is configured for SONET framing.

[Table 6-4](#) lists the default values for commands that are available in SONET controller configuration mode when the 1-Port Channelized OC-12/STM-4 line card is configured for SONET framing.

[Table 6-5](#) lists the default values for commands that are available in T3 controller configuration mode when the 1-Port Channelized OC-12/STM-4 line card is configured for SONET framing.

[Table 6-7](#) lists the default values for commands that are available in T1 controller configuration mode, under a T3 controller, when the 1-Port Channelized OC-12/STM-4 line card is configured for SONET framing.

[Table 6-6](#) lists the default values for commands that are available in VT controller configuration mode when the 1-Port Channelized OC-12/STM-4 line card is configured for SONET framing.



**Table 6-4** Default Values for SONET Controller Configuration Commands under SONET Framing

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>SONET Controller Configuration Mode</b>			
clock source	line	<code>clock source {internal   line}</code>	One side set to <b>internal</b>
framing	sonet	<code>framing {sonet   sdh}</code>	Same
loopback	no loopback	<code>[no] loopback {internal   line}</code>	—
overhead	1 for J0 0 for S1S0	<code>overhead {j0   s1s0}</code>	—

**Table 6-5** Default Values for T3 Controller Configuration Commands under SONET Framing

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>T3 Controller Configuration Mode</b>			
cablelength	0	<code>cablelength length</code>	—
channelized	channelized	<code>[no] channelized</code>	—
clock source <sup>1</sup>	internal	<code>clock source {line   internal}</code>	One side set to <b>internal</b>
framing	auto-detect	<code>framing {auto-detect   c-bit   m23}</code>	Same
idle pattern	0X7e (flags)	<code>idle pattern {0x0 to 0xFF}</code>	Same
overhead	4 for c2 64 for j1	<code>overhead {c2   j1}</code>	—

1. The default value for SONET clock source is **line**. At least one side of the connection must be set to **internal**.

**Table 6-6** Default Values for VT Controller Configuration Commands under SONET Framing

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>VT Controller Configuration Mode</b>			
overhead	2 for c2 64 for j1	<code>overhead {c2   j1}</code>	—

**Table 6-7** Default Values for T1 and E1 Configuration Commands under SONET Framing

Command Name	Default Setting	Command Syntax	Remote Side Setting
t1 clock source	internal	<b>t1</b> <i>ch_group_number</i> <b>clock source</b> { <b>line</b>   <b>internal</b> }	One side set to <b>internal</b>
t1 framing	esf	<b>t1</b> <i>t1-number</i> <b>framing</b> { <b>esf</b>   <b>sf</b> }	Same
e1 clock source	internal	<b>e1</b> <i>ch_group_number</i> <b>clock source</b> { <b>line</b>   <b>internal</b> }	One side set to <b>internal</b>
e1 framing	crc4	<b>e1</b> <i>e1-number</i> <b>framing</b> [ <b>crc4</b>   <b>no-crc4</b> ]	Same

## Line Card Default Values for SDH Framing

This section contains tables of command default values that apply when the 1-Port Channelized OC-12/STM-4 line card is configured for SDH framing.

[Table 6-8](#) lists the default values for commands that are available in SONET controller configuration mode when the 1-Port Channelized OC-12/STM-4 line card is configured for SDH framing.

[Table 6-9](#) lists the default values for commands that are available in AU-3 controller configuration mode for both AU-3 and AU-4-TUG-3 when the 1-Port Channelized OC-12/STM-4 line card is configured for SDH framing.

[Table 6-10](#) lists the default values for T3 commands when the 1-Port Channelized OC-12/STM-4 line card is configured for SDH framing.

[Table 6-11](#) lists default values for T1 and E1 commands when the 1-Port Channelized OC-12/STM-4 line card is configured for either SONET or SDH framing.

**Table 6-8** Default Values for SONET Controller Configuration Commands under SDH Framing

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>SONET Controller Configuration Mode under SDH</b>			
clock source <sup>1</sup>	line	[no] <b>clock source</b> { <b>internal</b>   <b>line</b> }	One side set to <b>internal</b>
framing	sonet	<b>framing</b> { <b>sonet</b>   <b>sdh</b> }	Same
loopback	no loopback	[no] <b>loopback</b> { <b>internal</b>   <b>line</b> }	—
overhead	1 for j0 2 for S1S0	<b>overhead</b> { <b>j0</b>   <b>s1s0</b> }	—
aug controller	no aug controller	[no] <b>aug controller</b> <au-3   au-4-tug-3>	—

1. The default value for SDH clock source is **line**. At least one side of the connection must be set to **internal**.

**Table 6-9** Default Values for AU-3/AU-4-TUG-3 Controller Configuration Commands for AU-3 and AU-4-TUG-3 under SDH Framing

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>AU-3/AU-4-TUG-3 Controller Configuration Mode under SDH</b>			
clock source	internal	<code>clock source {line   internal}</code>	One side set to <b>internal</b>
overhead	0 for c2 16 for j1	<code>overhead {c2   j1}</code>	—

**Table 6-10** Default Values for T3 Configuration Commands under SDH Framing

Command Name	Default Setting	Command Syntax	Remote Side Setting
bandwidth		<code>bandwidth bandwidth</code>	—
crc	16	<code>crc {16   32}</code>	—
encapsulation	HDLC	<code>encapsulation {frame-relay   hdlc   ppp}</code>	Same
idle-character	flags (0x7e)	<code>idle-character {flags   marks}</code>	
keepalive	10 seconds	<code>keepalive period</code>	—

**Table 6-11** Default Values for T1 and E1 Interface Configuration Commands

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>T1 Interface Configuration Mode</b>			
crc	16	<code>[no] crc [16   32]</code>	Same
DSU bandwidth	44210	<code>dsu bandwidth bandwidth</code>	Same
DSU mode	cisco	<code>dsu mode mode</code>	Same
encapsulation	HDLC	<code>encapsulation [hdlc   ppp]</code>	Same
framing	c-bit	<code>framing [c-bit   m13]</code>	Same
idle character	flags (0x7e)	<code>idle character [flags   marks]</code>	Same
keepalive	10 seconds	<code>keepalive seconds</code>	Same
mtu	4470	<code>mtu size</code>	Same
<b>E1 Interface Configuration Mode</b>			
crc	16	<code>[no] crc [16   32]</code>	Same
encapsulation	HDLC	<code>encapsulation [hdlc   ppp]</code>	Same
framing	c-bit	<code>framing [c-bit   m13]</code>	Same
idle character	flags (0x7e)	<code>idle character [flags   marks]</code>	Same
keepalive	10 seconds	<code>keepalive</code>	Same
mtu	4470	<code>mtu size</code>	Same

## Line Card Interface Syntax

To specify an unchannelized or 1-Port Channelized OC-12/STM-4 line card interface in a configuration command, use the syntax shown in [Table 6-12](#).

**Table 6-12 Interface Syntax for the 1-Port Channelized OC-12/STM-4 Line Card**

Type of Interface	Slot	Sub-slot	Port	STS-1 Path (T3)	T1 or E1 Number	Channel Group Number
Unchannelized	1 to 8/	0/	0.	1 to 12	—	—
Channelized	1 to 8/	0/	0.	1 to 12/	1 to 28: for T1 1 to 32: for E1	0 to 23 for T1 0 to 31 for E1

Examples:

- Modifying T1 interface 6 in controller configuration mode:
 

```
Router(config)# controller t3 2/0/0.1
Router(config-controller)# t1 6 command
```
- Modifying T1 interface 6, channel group number 8 in interface configuration mode:
 

```
Router(config)# interface serial 2/0/0.1/6:8
Router(config-if)
```

## SONET-Framed Interface Configuration Sample

You can configure up to 12 STS-1 connections on a 1-Port Channelized OC-12/STM-4 line card. Each STS-1 connection can be configured as a T3 controller or as a VT controller.

The following procedure walks you through the basic steps for creating full-rate and subrate T3 interfaces, as well as T1 and fractional T1 interfaces. Each T3 controller can be configured as a single T3 interface (full or subrate), as 28 T1 interfaces, or as an even larger number of fractional T1s.

**Step 1** Set the framing type to SONET using the framing command.

```
Router(config)# controller sonet 2/0/0
Router(config-controller)# framing sonet
```

**Step 2** Assign an STS-1 path to a T3 interface. In this example, the path command is used to set up four T3 interfaces:

```
Router(config-controller)# path 1 controller t3
Router(config-controller)# path 2 controller t3
Router(config-controller)# path 3 controller t3
Router(config-controller)# path 4 controller t3
Router(config-controller)# exit
```

**Step 3** Create an interface. In the following examples, each type of interface is created in a different T3 controller (4/0/0.1 through 4/0/0.4).

**Full-Rate T3 Interface**

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/0.1
Router(config-controller)#
```

- b. To create a full-rate T3 interface, you must eliminate the T1 interfaces by entering the **no channelized** command.

```
Router(config-controller)# no channelized
Router(config-controller)# exit
Router(config)#
```

- c. Enter interface configuration mode.

```
Router(config)# interface serial 2/0/0.1
```

- d. Go to Step 4.

**Subrate T3 Interface**

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/0.2
Router(config-controller)#
```

- b. To create a subrate T3 interface, first create a full-rate one.

```
Router(config-controller)# no channelized
Router(config-controller)# exit
Router(config)#
```

- c. Enter interface configuration mode, where you can use the **dsu bandwidth** command to create a subrate T3 interface. In this example, a subrate T3 interface is created that has a bandwidth of 16000 kbps.

```
Router(config)# interface serial 2/0/0.2
Router(config-if)# dsu bandwidth 16000
```

- d. Go to Step 4.

**Channelized T3 with a Full T1 Interface**

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/0.3
Router(config-controller)#
```

- b. Use the **t1 channel group** command to create a T1 interface. In the following example, T1 interface 1 (of 28) is defined as being made up of a single channel group, number 20 (any number between 0 and 23). This channel group consists of all 24 DS0 timeslots.

```
Router(config-controller)# t1 1 channel-group 20 timeslots 1-24
```

- c. Go to interface configuration mode for the channel group you just created.

```
Router(config)# interface serial 2/0/0.3/1:20
```

- d. Go to Step 4.

**Channelized T3 with a Fractional T1 Interface**

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/0.4
Router(config-controller)#
```

- b. Use the **t1 channel group** command to create fractional T1 interfaces. In the following example, T1 interface 3 (of 28) is defined as being made up of three channel groups, numbers 19, 20, and 21 (any numbers between 0 and 23). The channel groups consist of a total of 24 DS0 timeslots. Each channel group represents a separate interface.

```
Router(config-controller) t1 3 channel-group 19 timeslots 1-6, 10
Router(config-controller) t1 3 channel-group 20 timeslots 7,8,9
Router(config-controller) t1 3 channel-group 21 timeslots 11-24
```

- c. Go to interface configuration mode for one of the channel groups. For example:

```
Router(config)# interface serial 2/0/0.4/3:19
```

- d. Go to Step 4.

- Step 4** Enter the encapsulation method. This example shows the command for using Frame Relay encapsulation. You can also choose PPP or HDLC.

```
Router(config-if)# encapsulation frame-relay
```

- Step 5** If IP routing is enabled on the system, you can assign an IP address and subnet mask. For example:

```
Router(config-if)# ip address 172.16.32.49 255.255.0.0
```

- Step 6** Add any configuration subcommands required to enable routing protocols and set the interface line characteristics.

- Step 7** Change the shutdown state to up, which enables the interface.

```
Router(config-if)# no shutdown
```

- Step 8** When you have entered all of the configuration subcommands to complete the configuration, press **Ctrl-Z** to exit configuration mode.

- Step 9** Write the new configuration to NVRAM.

```
Router# copy running-config startup-config
```

---

After you create an interface configuration, you can modify it at any time by using the appropriate Cisco IOS configuration commands.

## SDH-Framed Interface Configuration Sample

If the 1-Port Channelized OC-12/STM-4 line card is configured for SDH framing, you can configure up to:

- 12 STM-0 controllers. Each STM-0 controller can be configured as one AU-3 controller, each of which can be configured a T3 interface or as 28 T1 interfaces or 21 E1 interfaces. These interfaces can be channelized into fractional T1s or E1s.
- 4 STM-1 controllers. Each STM-1 controller can be configured with three AU-4-TUG-3 controllers, each of which can be configured as 28 T1 interfaces or up to 21 E1 interfaces. These interfaces can be channelized into fractional T1s or E1s.

**Note**

AU-3 and AU-4-TUG-3s are based on the higher order path, and do not operate independently, but operate in groups of three. If you shutdown any AU-3 or AU-4-TUG-3 controller, the other two controllers on the same SONET port are also shut down.

The SONET **controller** command specifies the mode, and creates three [sub]controllers of that type, which you can configure like any other controller.

The format created adds a subport extension to the controller SONET name. The form of the subport extension is different for AU-3 and AU-4-TUG-3 controllers as the following examples show:

**AU-3 Controller Syntax**

```
controller au-3 <slot>/<subslot>/<port>.<AU-3#>
```

For example, the **controller** command for AU-3 #3 on port 0 of a 4 -port channelized STM-1 line card in slot 2 is:

```
controller au-3 2/0/0.3
```

**AU-4-TUG-3 Controller Syntax**

```
controller au-4-tug-3 <slot>/<subslot>/<port>.<AU-4#>/<TUG-3#>
```

For example, the command for a controller created for TUG-3 #3 on AU-4 of port 0 of a 1-Port Channelized OC-12/STM-4 line card in slot 2 is:

```
controller au-4-tug-3 2/0/0.1/3
```

## Show Controller Command Syntax

To display the settings for specific on AU-3 and AU-4-TUG-3 controllers, use the **show controller** command.

For AU-3:

```
show controller au-3 <slot>/<subslot>/<port>.<AU-3#>[/<tug-2>/<t1>]
```

For AU-4-TUG-3:

```
show controller au-4-tug-3  
<slot>/<subslot>/<port>.<AU-4#>/<TUG-3#>[/<tug-2>/<t1 or e1>]
```

Where:

- *slot* is 1 to 8
- *subslot* is 0
- *port* is always 0
- *AU-3#* is 1 to 12
- *AU-4#* is always 1
- *TUG-3#* is 1 to 12
- *tug-2* is 1 to 7
- *t1* is 1 to 4 or *e1* is 1 to 3

**Note**


---

The [/<tug-2>/<t1>] options are only available if a mode (C-11 or C-12) is configured on the controller.

---

For example, for T1 over AU-3, the command to display the settings for AU-3 #3 for a line card in slot 2 is:

```
show controller au-3 2/0/0.3
```

For AU-4-TUG-3, the command to display the settings for TUG-3 #3 on AU-4 of a 1-Port Channelized OC-12/STM-4 line card in slot 2 is:

```
show controller au-4-tug-3 2/0/0.1/3
```

To display a specific TUG-2 and E1 on the same AU-4-TUG-3, use the command:

```
show controller au-4-tug-3 2/0/0-1/3/1/3
```

## AU-3 Controller Interfaces

Use the following procedure to create T3 and T1 interfaces using AU-3 controllers.

---

**Step 1** Enter SONET controller configuration mode from global configuration mode.

In this example, the 1-Port Channelized OC-12/STM-4 line card is in slot 1.

```
Router(config)# controller sonet 2/0/0
Router(config-controller)#
```

**Step 2** Use the **aug controller** command to specify the mode of operation for an STM-4 port (for an AU-3, twelve controllers are created: 2/0/0.1 to 2/0/0.12).

```
Router(config-controller)# aug controller au-3
Router(config-controller)#
```

### Full-Rate T3 Interface




---

**Note** T3 lines can only operate over AU-3 controllers.

---

- a. Configure the controller on the port.

This example shows AU-3 controller #3 configured for a line card in slot 2.

```
Router(config-controller)# controller au-3 2/0/0.3
Router(config-controller)#
```

- b. Set the container mode to C-3 to establish a T3 interface.

```
Router(config-controller)# mode c-3
Router(config-controller)# exit
Router(config)#
```

C-3 mode creates a serial interface at the unchannelized T3 level.



**T1 Channel Group Interface**

- a. Configure the controller on the single OC-12 port.

This example shows AU-3 controller #2 configured on the OC-12 port for a line card in slot 2.

```
Router(config)# controller au-3 2/0/0.2
Router(config-controller)#
```

- b. Set the container mode to C-11 to establish a T1 interface.

```
Router(config-controller)# mode c-11
Router(config-controller)#
```

- c. Create a T1 interface.

In the following example, the TUG-2 interface is defined as 1 (any number between 1 and 7), the T1 interface is 2 (any number between 1 and 4), and is made up of a single channel group, 5 (any number between 0 and 23). This channel group consists of all 24 DS0 timeslots.

```
Router(config-controller)# tug-2 1 t1 2 channel-group 5 timeslots 1-24
Router(config-controller)#
```

## AU-4-TUG-3 Controller Interfaces

Use the following procedure to create T1 and E1 interfaces using AU-4-TUG-3 controllers.

**Caution**

The three AU-4-TUG-3 controllers created on a port are based on the same higher order path and do not operate independently from one another. In other words, when you “shutdown” any AU-4-TUG-3 controller, the other two controllers on the same SONET port are also shut down.

- Step 1** Enter SONET controller-configuration mode.

In this example, the line card is in slot 2.

```
Router(config)# controller sonet 2/0/0
Router(config-controller)#
```

- Step 2** Use the **aug controller** command to specify the mode of operation for the OC-12 port (for an AU-4, three controllers are created).

```
Router(config-controller)# aug controller au-4-tug-3
Router(config-controller)#
```

**T1 Channel Group Interface over AU-4-TUG-3/TUG-2**

- a. Configure the controller on an STM-4 port. This example shows AU-4-TUG-3 controller #2 configured on port 0 for a line card in slot 2.

```
Router(config-controller)# controller au-4-tug-3 2/0/0.1/2
Router(config-controller)#
```

- b. Set the container mode to C-11 to establish a T1 interface.

```
Router(config-controller)# mode c-11
Router(config-controller)#
```

- c. Create a T1 interface.

In the following example, the TUG-2 interface is 1 (any number between 1 and 7), the T1 interface is 2 (any number between 1 and 4,) and is defined as a single channel group, 5 (any number between 0 and 23). This channel group consists of all 24 DS0 timeslots.

```
Router(config-controller)# tug-2 1 t1 2 channel-group 5 timeslots 1-24
Router(config-controller)#
```

### E1 Channel Group Interface over AU-4-TUG-3/TUG-2

- a. Configure the controller on an STM-4 port.

This example shows AU-4-TUG-3 controller #2 configured on port 0 of a line card in slot 2.

```
Router(config-controller)# controller au-4-tug-3 2/0/0.1/2
Router(config-controller)#
```

- b. Set the container mode to C-12 to establish an E1 interface.

```
Router(config-controller)# mode c-12
Router(config-controller)#
```

- c. Create an E1 interface.

In the following example, the TUG-2 interface is 1 (any number between 1 and 7), the E1 interface is 2 (any number between 1 and 3), and is defined as a single channel group, 5 (any number between 0 and 31). This channel group consists of all 31 DS0 time slots.

```
Router(config-controller)# tug-2 1 e1 2 channel-group 5 timeslots 1-31
Router(config-controller)#
```

## Configuring the SONET Controller for SONET or SDH Framing

By default, the 1-Port Channelized OC-12/STM-4 line card consists of 12 STS-1 connections. To set up the 1-Port Channelized OC-12/STM-4 line card, you must configure each STS-1 as a T3 or VT interface. This section describes the commands used to create T3 and VT interfaces and test STS-1 connections. This section describes the following:

- [Entering Controller-Configuration Mode, page 6-14](#)
- [Selecting SONET or SDH Framing, page 6-15](#)
- [Configuring the SONET Controller Loopback Mode, page 6-15](#)

### Entering Controller-Configuration Mode

Use the **controller sonet** command to enter controller-configuration mode, where you can configure the controller:

```
controller sonet slot/subslot/port
```

Where *slot* is 1 to 8, and *subslot* and *port* are both 0.

The following example shows you how to enter SONET controller configuration mode for a card in slot 2:

```
Router(config)# controller sonet 2/0/0
Router(config-controller)#
```

## Selecting SONET or SDH Framing

To configure the 1-Port Channelized OC-12/STM-4 line card for SONET, you must first set the framing type to either SONET or SDH using the **framing** command.

If the 1-Port Channelized OC-12/STM-4 line card framing was previously configured for either SONET or SDH, and you wish to change the framing, you must enter the **no framing** command to return the line card to the default values. Then use the **framing** <framing type> command to set the new framing.



### Caution

If you enter the **no framing** command, the line card configuration is erased, and all default line card values are restored. Use the command with caution.

```
framing {sonet | sdh}
[no] framing
```

The default is SONET.

Use the **no** form of the command to remove framing and return the line card to the default values.

The following example shows you how to specify SONET framing for the 1-Port Channelized OC-12/STM-4 line card in slot 2:

```
Router(config)# controller sonet 2/0/0
Router(config-controller)# framing sonet
```

## Configuring the SONET Controller Loopback Mode

You can enable SONET controller loopbacks by using the **loopback** command.

```
loopback [internal | line]
[no] loopback [internal | line]
```

The default is no loopback.

Use the **no** form of the command to stop a loopback.

For more information on the **loopback** command, refer to the online *Cisco 10000 Series ESR Troubleshooting Guide*.

The commands in this example run an internal loopback on the 1-Port Channelized OC-12/STM-4 line card in slot 2:

```
Router(config)# controller sonet 2/0/0
Router(config-controller)# loopback internal
```

## Creating a T3, VT, or AUG Controller

This section show you how to create and configure T3, VT, or AUG controllers, and contains the following sections:

- [Designating an STS-1 Path as a T3 or VT under SONET Framing, page 6-16](#)
- [Designating an STM-4 Port as an AU-3 or AU-4-TUG-3 Controller under SDH Framing, page 6-16](#)
- [Configuring the SONET Controller Loopback Mode, page 6-15](#)
- [VT Commands under SONET Framing, page 6-17](#)

- [Unchannelized T3 Commands under SONET or SDH Framing, page 6-17](#)
- [Channelized T3 Commands under SONET or SDH Framing, page 6-21](#)
- [Creating T1 or E1 Channel Groups under SONET or SDH Framing, page 6-26](#)
- [Channelized T1 Commands under SONET or SDH Framing, page 6-29](#)

## Designating an STS-1 Path as a T3 or VT under SONET Framing

When the 1-Port Channelized OC-12/STM-4 line card is configured for SONET framing, you can use the **path** command to designate an STS-1 path as a T3 or VT controller. You can designate up to 12 STS-1 channels. (Figure 6-1 on page 6-22 shows the relationship between the OC-12, T3 interfaces, VT interfaces, and T1 interfaces.)

```
path STS_number controller {t3 | vt}
```

Where *STS\_number* is the virtual T3 or VT controller. Enter a value from 1 to 12.

Use the **no** form of the command to remove a T3 controller.

In the following example, STS-1 number 1 is defined as a T3 line and controller T3 number 2/0/0.1 is generated:

```
Router(config)# controller sonet 2/0/0
Router(config-controller)# path 1 controller t3
```

In the next example, STS-1 number 1 is defined as a VT line and a VT controller 2/0/0.1 is generated:

```
Router(config)# controller sonet 2/0/0
Router(config-controller)# path 1 controller vt
```

## Designating an STM-4 Port as an AU-3 or AU-4-TUG-3 Controller under SDH Framing

When the 1-Port Channelized OC-12/STM-4 line card is configured for SDH framing, you can use the **aug controller** command to specify the mode of operation for an STM-4 port as an AU-3 controller or an AU-4-TUG-3 controller. This command creates 12 subcontrollers of the designated type, which you can then configure like any other controller.

```
[no] aug controller <au-3/au-4-tug-3>
```

Where *au-3* and *au-4-tug-3* designate the type of controller. Enter a value from 1 to 12.

Use the **no** form of the command to remove an AU-3 or AU-4-TUG-3 controller.

The format of the name for these controllers requires you to add a subport extension to the SONET controller name. The subport extension is different for AU-3 and AU-4-TUG-3 controllers.

### AU-3 Controller

For an AU-3 controller, the syntax is:

```
controller au-3 <slot>/<subslot>/<port>.<AU-3#>
```

For example, the following command Uses AU-3 controller #3 on port 0 of a line card in slot 2.

```
Router(config-controller)# controller au-3 2/0/0.3
```

### AU-4-TUG-3 Controller

For an AU-4-TUG-3 controller, the syntax is:

```
Router(config-controller)# controller au-4-tug-3 <slot>/<subslot>/<port>.<AU-4#>/<TUG-3#>
```

**Note**

The twelve AU-4-TUG-3 controllers created on an SDH-framed SONET port are based on the same higher order path and do not operate independently from one another. In other words, when you “shutdown” any AU-4-TUG-3 controller, the other two controllers on the same SDH-framed SONET port are also shut down.

For example, the following command uses TUG-3 #3 on AU-4 of port 0 of an 1-Port Channelized OC-12/STM-4 line card in slot 2.

```
Router(config-controller)# controller au-4-tug-3 2/0/0.1/3
```

## VT Commands under SONET Framing

This section describes how to use the **controller vt** command to further channelize the SONET-framed STS-1 controller of the 1-Port Channelized OC-12/STM-4 line card.

### Entering Controller Configuration Mode for VT

A virtual tributary (VT) controller on a 1-Port Channelized OC-12/STM-4 line card can be channelized into 28 T1 (VT1.5) interfaces or 21 E1 (VT2) interfaces. You can use the **controller vt** command to shut down a VT link or to change the settings for a T1 or E1 interface.

For information about T1 configuration settings, see [“Creating T1 or E1 Channel Groups under SONET or SDH Framing” section on page 6-26](#), and the [“Channelized T1 Commands under SONET or SDH Framing” section on page 6-29](#).

You can configure a VT link by entering the **controller vt** command.

```
slot/sub-slot/port.path
```

Where *path* is a value from 1 to 12. Each number represents a VT that houses 28 T1 lines or 21 E1 lines.

For example:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# controller vt 1/0/0.1
Router(config-controller)#
```

## Unchannelized T3 Commands under SONET or SDH Framing

This section shows you how to configure an unchannelized T3 on a SONET-framed or SDH-framed controller.

If the 1-Port Channelized OC-12/STM-4 line card is configured for SONET framing, a T3 interface is channelized into 28 T1 interfaces by default. You must unchannelize the T3 interface to create a full-rate or subrate T3 interface.

If the 1-Port Channelized OC-12/STM-4 line card is configured for SDH framing, C-3 container mode automatically creates an unchannelized T3 serial interface.

This section describes the commands you use to create, customize, and test full-rate and subrate T3 interfaces. This section describes the following:

- [Entering Controller Configuration Mode for T3, page 6-18](#)
- [Configuring a T3 Interface on a SONET-Framed Controller as Unchannelized, page 6-18](#)
- [Implementing Subrate T3, page 6-19](#)
- [Setting a Framing Type, page 6-19](#)
- [Specifying a DSU Mode, page 6-19](#)
- [Enabling Scrambling, page 6-20](#)
- [Specifying the Idle Character, page 6-20](#)
- [Running a T3 BER Test under SONET or SDH Framing, page 6-20](#)

You can also use the following commands, described in the “[Channelized T3 Commands under SONET or SDH Framing](#)” section on page 6-21, when you configure unchannelized T3: **clock source**, **mdl**, **equipment**, and **loopback**.

## Entering Controller Configuration Mode for T3

To create an unchannelized T3 interface, you must first enter controller configuration mode for the T3 controller you want to configure.

```
controller T3 slot/sub-slot/port.path
```

Where *path* specifies the T3 interface number.

The following example shows how to enter controller configuration mode:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)#
```

## Configuring a T3 Interface on a SONET-Framed Controller as Unchannelized

If the 1-Port Channelized OC-12/STM-4 line card is configured for SONET framing, you must unchannelize the T3 interface to create a full-rate or subrate T3 interface.

You can configure the T3 interface as unchannelized (clear channel) by entering the **no channelized** command.

```
[no] channelized
```



### Caution

The **no channelized** command removes all channel groups from a channelized T3 interface. If you have already configured channel groups, use this command with caution.

Use the **channelized** command to return the interface to its default. The default value for a T3 interface is channelized.

In the following example, an unchannelized T3 interface is created:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# no channelized
```

## Implementing Subrate T3

You can implement subrate T3 by specifying the bandwidth for an unchannelized T3 interface. To do so, use the **dsu bandwidth** *bandwidth* command from interface configuration mode.

```
dsu bandwidth bandwidth  
[no] bandwidth bandwidth
```

Where *bandwidth* is a numeric value between 0 and 44,210 kbps.

The default bandwidth is 44,210 kbps.

To return to the default bandwidth, use the **no** form of this command.

When you specify a value, the software sets the bandwidth to the closest acceptable bandwidth based on the timeslot size for the current DSU mode.

For you to properly use this command, the remote side of the connection must have a Cisco 7200 router or Cisco 7500 router with a PA-T3 or PA-2T3 port adapter or a T3 DSU supported by the **dsu mode** command.

In the following example, a bandwidth of 16,000 kbps is specified:

```
Router(config)# interface serial 1/0/0.1  
Router(config-if)# dsu bandwidth 16000
```

## Setting a Framing Type

To specify a framing type for the unchannelized T3 controller, use the **framing** command.

```
framing [c-bit | m13]  
[no] framing [c-bit | m13]
```

The default framing type is c-bit.

Use the **no** form of this command to restore the default framing type.

In the following example, framing is set to m13:

```
Router(config)# interface serial 1/0/0.1  
Router(config-if)# framing m13
```

## Specifying a DSU Mode

To specify a DSU mode for a selected T3 interface, use the **dsu mode** command from interface configuration mode. This command configures the line card to emulate a manufacturer's proprietary multiplexing scheme.

```
dsu mode [Adtran | cisco | Digital-link | Kentrox | Larscom | verilink-highbit |  
verilink-lowbit]  
[no] dsu mode
```

The default DSU mode is cisco.

Use the **no** form of the command to return the DSU mode to its default.

In the following example, the DSU mode is set to **cisco**:

```
Router(config)# interface serial 1/0/0.1  
Router(config-if)# dsu mode cisco
```

## Enabling Scrambling

To enable scrambling on an unchannelized T3 interface, use the **scramble** command from interface configuration mode.

```
scramble
[no] scramble
```

The default setting for this command is no scramble (scrambling disabled).

Ensure that both sides of the link have the same scrambling setting.

In the following example, scrambling is enabled on the specified T3 interface:

```
Router(config)# interface serial 1/0/0.1
Router(config-if)# scramble
```

## Specifying the Idle Character

To set a specific character on the unchannelized T3 interface to be transmitted between HDLC packets, use the **idle character** command from interface configuration mode.

```
idle-character [flags | marks]
[no] idle-character [flags | marks]
```

Where:

- **flags** sets an idle character of 0x7e
- **marks** sets an idle character of all 0xff

The default idle character is 0x7e.

Use the **no** form of the command to return the idle character to its default.

In the following example, the idle character is set to flags:

```
Router(config)# interface serial 1/0/0.1
Router(config-if)# idle-character flags
```

**Note**

---

Some systems interpret marks, 0xff, as an abort signal. Therefore, flags, 0x7e, is preferred.

---

## Running a T3 BER Test under SONET or SDH Framing

You can configure an unchannelized T3 interface to run a bit error rate (BER) test. The test is used to check cables and solve signal problems in the field. To send a BER test pattern on an unchannelized T3 interface, use the following interface configuration command:

```
bert [errors number | pattern pattern] interval time
[no] bert
```

Where:

- **errors number** is 1 to 255
- **pattern pattern** is
  - 0s—repetitive test pattern of all zeros (00000..)
  - 1s—repetitive test pattern of all ones (11111..)
  - 2<sup>15</sup>—pseudorandom O.151 test pattern (32,768 bits in length)



- 2<sup>20</sup>-O153—pseudorandom O.153 test pattern (1,048,575 bits in length)
- QRSS-2<sup>20</sup>—pseudorandom QRSS O.151 test pattern (1,048,575 bits in length)
- 2<sup>23</sup>—pseudorandom O.151 test pattern (8,388,607 bits in length)
- **interval time** is 1 to 1440 minutes

You can terminate a BER test at any time using the **no bert** command.

For more information, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Examples:

- Send a BER test pseudorandom pattern of 2<sup>20</sup> through T3 line 1 for 5 minutes.

```
Router(config)# interface serial 1/0/0.1
Router(config-if)# bert pattern 2^20 interval 5
```

- Send a repetitive pattern of all 1s through T3 line 1 for 1440 minutes.

```
Router(config)# interface serial 1/0/0.1
Router(config-if)# bert pattern 1s interval 1440
```

## Channelized T3 Commands under SONET or SDH Framing

This section shows you how to configure a channelized T3 on a SONET-framed or SDH-framed controller.

By default, a T3 interface on a 1-Port Channelized OC-12/STM-4 line card is channelized into 28 T1 interfaces. This section describes the commands you use to customize and test a channelized T3 interface. This section describes procedures for

- [Entering Controller Configuration Mode for T3, page 6-21](#)
- [Configuring a T3 Interface as Channelized, page 6-22](#)
- [Setting the Framing Type, page 6-22](#)
- [Entering MDL Messages, page 6-23](#)
- [Specifying the Idle Pattern, page 6-24](#)
- [Setting the T3 Clock Source, page 6-24](#)
- [Configuring the Loopback Mode for a T3 Controller, page 6-25](#)
- [Configuring a T3 Controller to Respond to Remote Loopback Commands, page 6-25](#)

To use the interface for subscriber traffic, you must configure its T1 and DS0 components. For more information, see the “[Creating T1 or E1 Channel Groups under SONET or SDH Framing](#)” section on page 6-26.

[Figure 6-1](#) illustrates the levels of configurable interface bandwidth that channelization offers.

### Entering Controller Configuration Mode for T3

You may need to enter controller configuration mode for the T3 interface. For example, enter this mode to change an unchannelized T3 interface back to a channelized one or to set MDL messages.


```
controller T3 slot/sub-slot/port.path
```

*Path* specifies the T3 interface number.

The following example shows how to enter controller configuration mode:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)#
```

**Figure 6-1 Channelization of T3s**



## Configuring a T3 Interface as Channelized

A T3 interface is channelized by default. Use the **channelized** command if you had previously made the interface unchannelized.

```
[no] channelized
channelized
```



**Caution**

The **no channelized** command removes all channel groups from a channelized T3 interface. If you have already configured channel groups, use this command with caution.

The following example shows how to create a channelized T3 interface:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# channelized
```

## Setting the Framing Type

To specify a framing type for the channelized T3 controller, use the **framing** command.

```
framing [c-bit | m23 | auto-detect]
[no] framing [c-bit | m23 | auto-detect]
```

The default is auto-detect.

Use the **no** form of the command to return the framing type to its default.

You can instruct the 1-Port Channelized OC-12/STM-4 line card to detect the framing type from the far end and transmit that same framing type:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# framing auto-detect
```

## Entering MDL Messages

You can configure maintenance data link (MDL) messages (as defined in the ANSI T1.107a-1990 specification) on the channelized T3 interface.



### Note

MDL messages are supported only when the T3 framing is set for C-bit parity. (See the [“Setting the Framing Type”](#) section on page 6-22.)

To configure MDL messages, use the **mdl** command:

```
mdl {transmit {path | idle-signal | test-signal} | string {eic | lic | fic | unit | pfi | port
| generator} id_string}
[no] mdl {transmit {path | idle-signal | test-signal} | string {eic | lic | fic | unit | pfi |
port | generator} id_string}
```

Where:

- **transmit path** enables transmission of the MDL path message
- **transmit idle-signal** enables transmission of the MDL idle-signal message
- **eic** is the equipment identification code (up to 10 characters)
- **lic** is the location identification code (up to 11 characters)
- **fic** is the frame identification code (up to 10 characters)
- **unit** is the unit identification code (up to 6 characters)
- **pfi** is the facility identification code to include in the MDL path message (up to 38 characters)
- **port** is the equipment port (which initiates the idle signal) to include in the MDL idle signal message (up to 38 characters)
- **generator** is the generator number to include in the MDL test signal message (up to 38 characters)

The default is that no MDL message is configured.

Use the **no** form of the command to remove an MDL message.

Examples of configuring MDL messages follow:

- Enable the MDL path message transmission.

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# mdl transmit path
```

- Enable the MDL idle signal message transmission.

```
Router(config-controller)# mdl transmit idle-signal
```

- Enable the MDL test signal message transmission.

```
Router(config-controller)# mdl transmit test-signal
```

- Enter the equipment identification code.

```
Router(config-controller)# mdl string eic router A
```

- Enter the location identification code.  
Router(config-controller)# mdl string lic *test network*
- Enter the frame identification code.  
Router(config-controller)# mdl string fic *building b*
- Enter the unit identification code.  
Router(config-controller)# mdl string unit *abc*
- Enter the facility identification code.  
Router(config-controller)# mdl string pfi *string*
- Enter the port number to send in the MDL idle signal message.  
Router(config-controller)# mdl string port *string*
- Enter the generator number to send in the MDL test signal message.  
Router(config-controller)# mdl string generator *string*

## Specifying the Idle Pattern

You can set a specific pattern to be transmitted between HDLC packets on all unconfigured timeslot interfaces that belong to a channelized T3 interface. To do so, use the **idle pattern** command.

```
idle pattern patterns
[no] idle pattern patterns
```

Where *patterns* is a number in the range of 0x0 to 0xff (hexadecimal) or 0 to 255 (decimal). You can enter this value in either hexadecimal or decimal form. Values of 0 to 254 set the idle pattern to HDLC flags (0x7e); a value of 255 sets the pattern to 0xff (all ones).



### Note

---

Some systems interpret marks, 0xff, as an abort signal. Therefore, flags, 0x7e, is preferred.

---

The default idle pattern is 0x7e.

Use the **no** form of the command to return the idle pattern to its default value.

Examples:

- Set a hexadecimal idle pattern.  
Router(config)# controller T3 1/0/0.1  
Router(config-controller)# idle pattern 0x10
- Set a decimal idle pattern.  
Router(config)# controller T3 1/0/0.1  
Router(config-controller)# idle pattern 23

## Setting the T3 Clock Source

At the prompt, set the internal or line clock source for the selected T3 controller using the **clock source** command. This command is set in controller configuration mode.

```
clock source {internal | line}
```

Where:

- **internal** specifies that the internal clock source is used
- **line** specifies that the network clock source is used

The default is clock source internal.

In this example, a T3 controller is instructed to use a line clock source:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# clock source line
```

## Configuring the Loopback Mode for a T3 Controller

You can configure the loopback modes for a T3 controller by using the **loopback** command:

```
loopback {local | network | remote}
[no] loopback {local | network | remote}
```

The default is no loopback.

To disable loopback on the T3 controller, use the **no** form of the command.

Examples:

- Configure a T3 controller for local loopback.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# loopback local
```

Local loopback simultaneously loops all channels toward the router and transmits a T3 AIS to the network. You can use local loopback to diagnose problems with the port when the port is isolated from the network cables.

- Configure a T3 port for network loopback.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# loopback network
```

Network loopback loops the T3 line back towards the network and can be used to diagnose problems with cables from the central switching office to the port.

- Configure a T3 port for remote loopback.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# loopback remote
```

Remote loopback sends a command to loop the T3 line at the far end (central office). It can be used to diagnose problems with cables from the port adapter to the switching office.

## Configuring a T3 Controller to Respond to Remote Loopback Commands

Use the **equipment loopback** command to run loopbacks in conjunction with remote equipment.

```
equipment [customer | network] loopback
```

Where:

- **customer** allows a port to respond to loopback commands from remote T3 equipment.
- **network** causes a controller to ignore remote T3 loopback commands.

Example:

To enable the controller's ability to respond to remote loopback requests, type:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# equipment customer loopback
```

To prevent a controller from responding to remote loopback commands, type:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# equipment network loopback
```



**Note**

Remote loopbacks are only available when you use c-bit parity framing.

For more information on the **loopback** command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

## Creating T1 or E1 Channel Groups under SONET or SDH Framing

To create an interface that supports subscriber traffic, you must combine the timeslots into channel groups. To help you configure channel groups, consider the following T1 and E1 characteristics:

### For SONET-Framed T3 Controllers

- 1 channelized T3 is divided into 28 T1s
- 1 T1 is divided into 24 timeslots (or DS0s)

### For SONET-Framed VT Controllers

For T1:

- 1 VT controller is divided into 28 T1s (VT1.5)
- 1 T1 is divided into 24 timeslots (or DS0s)

For E1:

- 1 VT controller is divided into 21 E1s (VT2)
- 1 E1 can be divided into 31 timeslots (or DS0s)

### For SDH-Framed T3 Controllers

- 1 T3 is divided into 7 TUG-2s
- 1 TUG-2 is divided into either:
  - 4 T1s that can each be divided into 24 timeslots (or DS0s)
  - 3 E1s that can be divided into 31 timeslots (or DS0s)

## Creating Channel Groups for T1 SONET-Framed Interfaces

Use the **t1 channel-group** command to create a channel group for a SONET-framed interface.

[Figure 6-1](#) illustrates channelization possibilities on the 1-Port Channelized OC-12/STM-4 line card.

You create a logical channel group using the following command:

```
t1 t1-number channel-group channel-group-number timeslots list-of-timeslots [speed {56 | 64}]
[no] t1 t1-number channel-group channel-group-number
```

Where:

- *t1-number* is T1 interface number 1 to 28.
- **channel-group** *channel-group-number* identifies the channel group with any number from 0 to 23.
- **timeslots** *list-of-timeslots* can be 1 to 24 or a combination of subranges within the 1 to 24 interval. You can indicate a range using a hyphen, commas, or a combination of both. One timeslot equals one DS0. (See the examples below.)
- **speed**{56|64} is an optional argument that specifies the speed of a timeslot as either 56 or 64 kbps. The default is 64. (The 56 kbps timeslots are generally used with older T1 equipment that does not support B8ZS line coding and are associated with SF framing.)

Use the **no** form of the command to remove a logical channel group.

The following examples show how to use the **t1 channel-group** command:

- In this example, T1 interface 3 includes channel group 20 and consists of 9 channelized timeslots:

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 3 channel-group 20 timeslots 1-8, 10
```

To enter interface configuration mode for T1 interface 3 channel group 20, enter the following:

```
Router(config)# interface serial 1/0/0.1/3:20
```

- In this example, t1 interface 4 includes channel group 18 and consists of all 24 timeslots, creating a full T1 interface:

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 4 channel-group 18 timeslots 1-24
```

To enter interface configuration mode for T1 interface 4 channel group 18, enter the following:

```
Router(config)# interface serial 1/0/0.1/4:18
```

- In the following example, T1 interface number 5 is divided into three channel groups, which total 11 timeslots:

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 5 channel-group 19 timeslots 1-6
Router(config-controller)# t1 5 channel-group 20 timeslots 10
Router(config-controller)# t1 5 channel-group 21 timeslots 7-9, 24
```

- In the following example, channel group 20 on T1 1 is removed:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# no t1 1 channel-group 20
```

## Creating Channel-Groups for SDH-Framed Interfaces

### Channel Limitations

There is a limit of 128 channels per SDH controller, and a maximum of 192 channels for the single OC-12 port on the 1-Port Channelized OC-12/STM-4 line card. This limitation applies to both T1 and E1 interfaces when you create channel groups for controllers.

For example, if you created 128 channels on T1 controller #1 on port 2, and 64 channels on T1 controller #2 on port 2, then you could not create any additional channels on T1 controller #3 or T1 controller #4 because you have reached the maximum limit of 192 channels for a single port (port 2 in this example).

To create a logical channel group, use one of the following commands:

**For T1:**

```
[no] tug-2 <tug-2#> t1 <t1#> channel-group <channel#> timeslots <range> [speed 64|56]
```

**For E1 (framed):**

```
[no] tug-2 <tug-2#> e1 <e1#> channel-group <channel#> timeslots <range>
```

**For E1 (unframed):**

```
[no] tug-2 <tug-2#> e1 <e1#> unframed
```

Where:

- *tug-2* is 1 to 7
- *t1#* is 1 to 4
- *e1#* is 1 to 3
- **channel-group** *channel#* identifies the channel group with any number from 0 to 23.
- **timeslots** *range* can be 1 to 24 for T1, or 1 to 31 for E1, or a combination of subranges within those intervals. You can indicate a range using a hyphen, commas, or a combination of both. One timeslot equals one DS0. (See the examples below.)
- **speed** {56 | 64} is an optional T1 argument that specifies the speed of a timeslot as either 56 or 64 kbps. The default is 64. (The 56 kbps timeslots are generally used with older T1 equipment that does not support B8ZS and are associated with SF framing.)




---

**Note** The **speed** argument applies only to T1 channel groups and is not valid for E1.

---

- **unframed** creates an unframed E1 channel. This creates an interface with channel-group number 0.




---

**Note** The **unframed** argument applies only to E1 channel groups and is not valid for T1.

---

Use the **no** form of the command to remove a logical channel group.

The following examples show how to use the **channel-group** command:

- In this example, T1 interface 3 includes channel group 20 and consists of 9 channelized timeslots:

```
Router(config-controller)# controller au-3 2/0/0.2
Router(config-controller)# mode c-11
Router(config-controller)# tug-2 1 t1 3 channel-group 20 timeslots 1-9
```

To enter interface configuration mode for T1 interface 3 channel group 20, enter the following:

```
Router(config)# interface serial 2/0/0.2/3:20
```

- In this example, T1 interface 4 includes channel group 18 and consists of all 24 timeslots, creating a full T1 interface:

```
Router(config-controller)# controller au-3 2/0/0.2
Router(config-controller)# mode c-11
Router(config-controller)# tug-2 1 t1 4 channel-group 18 timeslots 1-24
```

To enter interface configuration mode for T1 interface 4 channel group 18, enter the following:

```
Router(config)# interface serial 2/0/0.2/4:18
```



- In the following example, T1 interface number 5 is divided into three channel groups, which total 11 timeslots:

```
Router(config-controller)# controller au3 2/0/0.2
Router(config-controller)# mode c-11
Router(config-controller)# tug-2 1 t1 5 channel-group 19 timeslots 1-6
Router(config-controller)# tug-2 1 t1 5 channel-group 20 timeslots 10
Router(config-controller)# tug-2 1 t1 5 channel-group 21 timeslots 7-9, 24
```

- In the following example, channel group 20 is removed:

```
Router(config-controller)# controller au3 2/0/0.2
Router(config-controller)# no tug-2 1 t1 5 channel-group 20
```

## Channelized T1 Commands under SONET or SDH Framing

You can enter commands to modify aspects of a T1 interface from controller configuration mode for a T3 interface. This section describes the commands for

- [Setting the Framing Format, page 6-29](#)
- [Controlling Yellow Alarms, page 6-30](#)
- [Setting the T1 Clock Source, page 6-30](#)
- [Configuring FDL, page 6-30](#)
- [Configuring a T1 BER Test, page 6-31](#)
- [Configuring Loopback Mode, page 6-31](#)

After you configure a T1 interface, you can add encapsulation, routing, and other instructions by entering interface configuration mode. For example:

```
Router(config)# interface serial 1/0/0.1/4:18
```

### Setting the Framing Format

You can specify the T1 interface framing format using the following command:

```
t1 t1-number framing {esf | sf [hdlc-idle {0x7E | 0xFF}]}
[no] t1 t1-number framing {esf | sf [hdlc-idle {0x7E | 0xFF}]}
```

Where:

- *t1-number* is T1 interface 1 to 28
- **framing** is either extended super frame (ESF) or super frame (SF). You can set SF hdlc-idle to 0x7E or 0xFF
- **hdlc-idle** options allow you to set the idle pattern for the T1 interface to either 0x7e (the default) or 0xFF

The default framing format is extended super frame (ESF).

Use the **no** form of the command to return framing to its default value.

Examples:

- Set SF framing format for T1 interface 6.

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# t1 6 framing sf
```

- Set ESF framing format for T1 interface 16:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# t1 16 framing esf
```

## Controlling Yellow Alarms

Use the **t1 yellow** command to turn the detection or generation of a yellow alarm on or off.

```
t1 t1-number yellow {detection | generation}
[no] t1 t1-number yellow {detection | generation}
```

Where:

- *t1-number* is T1 interface 1 to 28
- **detection** means that the interface is told that it is failing by the remote device, causing Cisco IOS software to send a message to the console
- **generation** means that the interface notifies the remote device if it is failing, causing Cisco IOS software to send a message to the console

When you select SF framing for a full T1 interface (24 timeslots) that uses the default speed of 64, consider using the **no t1-number yellow detection** command to turn off yellow alarm detection, because the yellow alarm can be incorrectly detected with SF framing.

In the following example, T1 interface 1 is set to yellow detection:

```
Router(config)# controller t3 2/0/0.1
Router(config-controller)# t1 1 yellow detection
```

## Setting the T1 Clock Source

You can set the internal or line (network) clock source for a T1 interface using the **controller** command.

```
t1 t1-number clock source {internal | line}
```

Where:

- *t1-number* is T1 interface 1 to 28
- **internal** specifies that the internal clock source is used
- **line** specifies that the network clock source is used

The default is clock source internal.

In the following example, the interface is instructed to get its clock source from the line:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# t1 1 clock source line
```

## Configuring FDL

You can use the **fdl ansi** command to enable 1-second transmissions of ANSI T1.403 performance reports through the facility data link (FDL), on both ends of the T1 connection.

```
t1 t1-number fdl ansi
[no] t1 t1-number fdl ansi
```

Where *t1-number* is T1 interface 1 to 28.

Use the **no** form of the command to disable this feature.

**Note**

You can use this command only when the T1 framing is ESF.

In the following example, FDL is enabled:

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 2 fdl ansi
```

## Configuring a T1 BER Test

You can configure an individual T1 interface to run an independent BER test. The test is used to check cables and solve signal problems in the field. To send a BER test pattern on a T1 interface, use the following command:

```
t1 t1-number bert pattern pattern interval time [unframed]
[no] t1 t1-number bert
```

Where:

- *t1-number* is T1 interface number 1 to 28
- *time* is 1 to 14,400 minutes
- *pattern* is
  - 2<sup>11</sup>—pseudorandom test pattern (2048 bits in length)
  - 2<sup>15</sup>—pseudorandom O.151 test pattern (32,768 bits in length)
  - 2<sup>20</sup>-O153—pseudorandom O.153 test pattern (1,048,575 bits in length)
- **unframed** causes the BER test pattern to use the entire T1 bandwidth, including the T1 framing and payload bits. If **unframed** is omitted, the T1 is either SF or ESF framed as configured by the T1 n framing command, and the BER test pattern occupies only the T1 payload bits.

**Note**

For each T3, you can run only one BER test at a time.

You can terminate a BER test at any time using the **no** form of the command.

For more information, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Example:

- Send a BER test pseudorandom pattern of 2<sup>15</sup> through T1 interface 10 for 5 minutes.

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# t1 10 bert pattern 2^15 interval 5 unframed
```

## Configuring Loopback Mode

If a problem occurs when you configure a T1 interface, you can troubleshoot the line card by using the following command from controller configuration mode:

```
t1 t1-number loopback [local | network {line | payload} | remote [line [fdl {ansi | bellcore}} | payload [fdl | ansi]]]
[no] t1 t1-number loopback [local | network {line | payload} | remote [line [fdl {ansi | bellcore}} | payload [fdl | ansi]]]
```

Where:

- *t1-number* is T1 interface 1 to 28.
- **local** loops the router output data back toward the router at the T1 framer and sends an alarm indication signal (AIS) out toward the network.
- **network {line | payload}** loops the data back toward the network and automatically sets a local loopback at the HDLC controllers (line) or loops the payload data back toward the network and automatically sets a local loopback at the HDLC controllers (payload).
- **remote line fdl {ansi | bellcore}** sends a repeating, 16-bit ESF data link keyword to the remote end, requesting that it enter into a network line loopback. You can specify an ANSI or Bellcore keyword.
- **remote payload [fdl] [ansi]** sends a repeating, 16-bit ESF data link code word to the remote end, requesting entry into a network payload loopback. Using **fdl** and **ansi** enables the remote payload facility data link (FDL) ANSI bit loopback on the T1 channel.

Use the **no** form of the command to terminate a loopback.

For more information on this command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Examples:

- Configure the T3 controller for local loopback on T1 interface 1.

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 1 loopback local
```

- Configure the T3 controller for remote FDL ANSI loopback on T1 interface 1.

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 1 loop remote line fdl ansi
```



## CHAPTER 7

# 4-Port Channelized OC-3/STM-1 Line Card Configuration

---

This chapter describes the procedures for configuring the Cisco 10000 series 4-Port Channelized OC-3/STM-1 line card, hereafter known as the 4-Port Channelized OC-3/STM-1 line card.

The 4-Port Channelized OC-3/STM-1 line card uses fractional T1 (n x DS0), DS-1, E1, fractional E1 (n x DS0) and DS3 IP services to connect ISP customers to the network backbone. It provides full duplex operation at OC-3 bandwidth rates using a (single-mode) fiber optic port that provides the Cisco 10000 series router with a single interface that connects up to 768 individual channelized options.

This chapter contains the following sections:

- [Software Support, page 7-2](#)
- [SONET Channelization, page 7-2](#)
- [SDH Channelization, page 7-3](#)
- [Default Values, page 7-4](#)
- [Interface Syntax, page 7-8](#)
- [SONET-Framed Interface Configuration Sample, page 7-8](#)
- [SDH-Framed Interface Configuration Sample, page 7-10](#)
- [Configuring the SONET Controller for SONET or SDH Framing, page 7-14](#)
- [Creating a T3, VT, or AUG Controller, page 7-15](#)

## Software Support

Table 7-1 shows the minimum Cisco IOS release on each release train that supports the 4-Port Channelized OC-3/STM-1 line card.

**Table 7-1 4-Port Channelized OC-3/STM-1 Line Card Software Support**

Required PRE	Minimum Cisco IOS Releases
PRE1	Cisco IOS Release 12.0(15)SL and later releases of Cisco IOS 12.0SL Cisco IOS Release 12.0(17)ST and later releases of Cisco IOS 12.0ST Cisco IOS Release 12.0(22)S and later releases of Cisco IOS 12.0S Cisco IOS Release 12.2(8)BZ and later releases of Cisco IOS 12.2BZ for SDH mode. For both SONET and SDH mode, use Cisco IOS Release 12.0(23)S and later releases of Cisco IOS 12.0S.
PRE2	Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS 12.3XI For both SONET and SDH mode, the use Cisco IOS Release 12.2(15)BX and later releases of Cisco IOS 12.2BX. Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## SONET Channelization

The 4-Port Channelized OC-3/STM-1 line card supports the following SONET channelization modes:

- STS-1 > DS3/T3
- STS-1 > DS3/T3 > DS1
- STS-1 > DS3/T3 > DS3 subrate
- STS-1 > VT1.5 > DS1
- STS-1 > VT2 > E1

Table 7-2 shows serial interface examples for SONET channelizations on a previously-configured SONET-framed controller on the 4-Port Channelized OC-3/STM-1 line card.

**Table 7-2 SONET Interface Examples for a SONET-Framed Controller**

Interface Type	Syntax
STS-1, over DS3/T3	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<T3#>
STS-1, over DS3/T3, channelized to DS1	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<T3#>:[chan]
STS-1, over subrated DS3/T3	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<T3#>
STS-1, over VT1.5, channelized to DS1	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<VT#>:[chan]
STS-1, over VT2, channelized to E1	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<VT#>:[chan]

## SDH Channelization

The 4-Port Channelized OC-3/STM-1 line card supports the following SDH channelization modes:

- STM-1 > AU-3 > DS3/T3
- STM-1 > AU-3 > DS3/T3 > DS3 subrate
- STM-1 > AU-3 > TUG-2 > C-11 > DS1/T1
- STM-1 > AU-3 > TUG-2 > C-12 > E1
- STM-1 > AU-4 > TUG-3 > TUG-2 > C-11 > DS1/T1
- STM-1 > AU-4 > TUG-3 > TUG-2 > C-12 > E1

Table 7-3 shows serial interface examples for SDH channelizations on a previously-configured SDH-framed controller on the 4-Port Channelized OC-3/STM-1 line card.

**Table 7-3 SDH Interface Examples for an SDH-Framed Controller**

Interface Type	Syntax
STM-4, over STM-1 over AU-3, over DS3/T3	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<AU-3#>/<T3#>
STM-4, over STM-1 over AU-3, over a subrated DS3/T3	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<AU-3#>/<T3#>

**Table 7-3 SDH Interface Examples for an SDH-Framed Controller (continued)**

Interface Type	Syntax
STM-4, over STM-1 over AU-3, over TUG-2, over C-11 (DS1/T1)	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<AU-3#>/<TUG-2>/<C-11>:[chan]
STM-4, over STM-1 over AU-3, over TUG-2, over C-12 (E1)	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<AU-3#>/<TUG-2>/<C-12>:[chan]
STM-4, over STM-1 over AU-4, over TUG-3, over TUG-2, over C-11 (DS1/T1)	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<AU-4#>/<TUG-3>/<TUG-2>/<C-11>:[chan]
STM-4, over STM-1 over AU-4, over TUG-3, over TUG-2, over C-12 (E1)	Router(config)# <b>interface serial</b> <slot>/<subslot>/<port>.<AU-4#>/<TUG-3>/<TUG-2>/<C-12>:[chan]

## Default Values

The 4-Port Channelized OC-3/STM-1 line card has two sets of command default values. The set of default values in use is determined by the **framing** command—either SONET framing or SDH framing.

The following tables contains command default values, and indicate which configuration mode you need to be in to enter a command. Where applicable, the tables also indicate which commands apply to which line types. The tables include the commands used for modifying a default value and indicates whether a value needs to be the same (or opposite) on the remote end of the connection.

### Default Values for SONET Framing

This section contains tables of command default values that apply when the 4-Port Channelized OC-3/STM-1 line card is configured for SONET framing.

[Table 7-4](#) lists the default values for commands that are available in SONET controller configuration mode when the 4-Port Channelized OC-3/STM-1 line card is configured for SONET framing.

[Table 7-5](#) lists the default values for commands that are available in T3 controller configuration mode when the 4-Port Channelized OC-3/STM-1 line card is configured for SONET framing.

[Table 7-6](#) lists the default values for commands that are available in T1 controller configuration mode, under a T3 controller, when the 4-port STM-4 line card is configured for SONET framing.



Table 7-7 lists the default values for commands that are available in VT controller configuration mode when the 4-Port Channelized OC-3/STM-1 line card is configured for SONET framing.

**Table 7-4** *Default Values for SONET Controller Configuration Commands under SONET Framing*

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>SONET Controller Configuration Mode</b>			
clock source <sup>1</sup>	line	<code>clock source {internal   line}</code>	One side set to <b>internal</b>
framing	sdh	<code>framing {sonet   sdh}</code>	Same
loopback	no loopback	<code>[no] loopback {internal   line}</code>	—
overhead	1 for J0 0 for S1S0	<code>overhead {j0   s1s0}</code>	—

1. The default value for SONET clock source is **line**. At least one side of the connection must be set to **internal**.

**Table 7-5** *Default Values for T3 Controller Configuration Commands under SONET Framing*

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>T3 Controller Configuration Mode</b>			
cablelength	0	<code>cablelength length</code>	—
channelized	channelized	<code>[no] channelized</code>	—
clock source	internal	<code>clock source {line   internal}</code>	One side set to <b>internal</b>
framing	auto-detect	<code>framing {auto-detect   c-bit   m23}</code>	Same
idle pattern	0X7e (flags)	<code>idle pattern {0x0 to 0xFF}</code>	Same
overhead	4 for c2 64 for j1	<code>overhead {c2   j1}</code>	—

**Table 7-6** *Default Values for VT Controller Configuration Commands under SONET Framing*

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>VT Controller Configuration Mode</b>			
overhead	2 for c2 64 for j1	<code>overhead {c2   j1}</code>	—

**Table 7-7** Default Values for T1 and E1 Configuration Commands under SONET Framing

Command Name	Default Setting	Command Syntax	Remote Side Setting
t1 clock source	internal	<b>t1</b> <i>ch_group_number</i> <b>clock source</b> { <b>line</b>   <b>internal</b> }	One side set to <b>internal</b>
t1 framing	esf	<b>t1</b> <i>t1-number</i> <b>framing</b> { <b>esf</b>   <b>sf</b> }	Same
e1 clock source	internal	<b>e1</b> <i>ch_group_number</i> <b>clock source</b> { <b>line</b>   <b>internal</b> }	One side set to <b>internal</b>
e1 framing	crc4	<b>e1</b> <i>e1-number</i> <b>framing</b> [ <b>crc4</b>   <b>no-crc4</b> ]	Same

## Default Values for SDH Framing

This section contains tables of command default values that apply when the 4-Port Channelized OC-3/STM-1 line card is configured for SDH framing.

[Table 7-8](#) lists the default values for commands that are available in SONET controller configuration mode when the 4-Port Channelized OC-3/STM-1 line card is configured for SDH framing.

[Table 7-9](#) lists the default values for commands that are available in AU-3 controller configuration mode for both AU-3 and AU-4-TUG-3 when the 4-Port Channelized OC-3/STM-1 line card is configured for SDH framing.

[Table 7-10](#) lists the default values for T3 commands when the 4-Port Channelized OC-3/STM-1 line card is configured for SDH framing.

[Table 7-11](#) lists default values for T1 and E1 commands when the 4-Port Channelized OC-3/STM-1 line card is configured for either SONET or SDH framing.

**Table 7-8** Default Values for SONET Controller Configuration Commands under SDH Framing

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>SONET Controller Configuration Mode under SDH</b>			
clock source <sup>1</sup>	line	[no] <b>clock source</b> { <b>internal</b>   <b>line</b> }	One side set to <b>internal</b>
framing	sdh	<b>framing</b> { <b>sonet</b>   <b>sdh</b> }	Same
loopback	no loopback	[no] <b>loopback</b> { <b>internal</b>   <b>line</b> }	—
overhead	1 for j0 2 for S1S0	<b>overhead</b> { <b>j0</b>   <b>s1s0</b> }	—
aug controller	no aug controller	[no] <b>aug controller</b> <au-3   au-4-tug-3>	—

1. The default value for SDH clock source is **line**. At least one side of the connection must be set to **internal**.

**Table 7-9** Default Values for AU-3/AU-4-TUG-3 Controller Configuration Commands for AU-3 and AU-4-TUG-3 under SDH Framing

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>AU-3/AU-4-TUG-3 Controller Configuration Mode under SDH</b>			
clock source	internal	<code>clock source {line   internal}</code>	One side set to <b>internal</b>
overhead	0 for c2 16 for j1	<code>overhead {c2   j1}</code>	—

**Table 7-10** Default Values for T3 Configuration Commands under SDH Framing

Command Name	Default Setting	Command Syntax	Remote Side Setting
crc	16	<code>crc {16   32}</code>	—
encapsulation	HDLC	<code>encapsulation {frame-relay   hdlc   ppp}</code>	Same
idle-character	flags (0x7e)	<code>idle-character {flags   marks}</code>	—
keepalive	10 seconds	<code>keepalive period</code>	—

**Table 7-11** Default Values for T1 and E1 Interface Configuration Commands

Command Name	Default Setting	Command Syntax	Remote Side Setting
<b>T1 Interface Configuration Mode</b>			
crc	16	<code>[no] crc [16   32]</code>	Same
DSU bandwidth	44210	<code>dsu bandwidth bandwidth</code>	Same
DSU mode	cisco	<code>dsu mode mode</code>	Same
encapsulation	HDLC	<code>encapsulation [hdlc   ppp]</code>	Same
framing	c-bit	<code>framing [c-bit   m13]</code>	Same
idle character	flags (0x7e)	<code>idle character [flags   marks]</code>	Same
keepalive	10 seconds	<code>keepalive seconds</code>	Same
mtu	4470	<code>mtu size</code>	Same
<b>E1 Interface Configuration Mode</b>			
crc	16	<code>[no] crc [16   32]</code>	Same
encapsulation	HDLC	<code>encapsulation [hdlc   ppp]</code>	Same
framing	c-bit	<code>framing [c-bit   m13]</code>	Same
idle character	flags (0x7e)	<code>idle character [flags   marks]</code>	Same
keepalive	10 seconds	<code>keepalive</code>	Same
mtu	4470	<code>mtu size</code>	Same

# Interface Syntax

To specify an unchannelized or channelized interface on the 4-port STM-1 line card in a configuration command, use the syntax shown in [Table 7-12](#).

**Table 7-12 Interface Syntax for the 4-Port Channelized OC-3/STM-1 Line Card**

Type of Interface	Slot	Sub-slot	Port	STS-1 Path (T3)	T1 or E1 Number	Channel Group Number
Unchannelized	1 to 8/	0/	0 to 3.	1 to 12	—	—
Channelized	1 to 8/	0/	0 to 3.	1 to 12/	1 to 28: for T1 1 to 32: for E1	0 to 23 for T1 0 to 31 for E1

Examples:

- Modifying T1 interface 6 in controller configuration mode:
 

```
Router(config)# controller t3 2/0/0.1
Router(config-controller)# t1 6 command
```
- Modifying T1 interface 6, channel group number 8 in interface configuration mode:
 

```
Router(config)# interface serial 2/0/0.1/6:8
Router(config-if)
```

## SONET-Framed Interface Configuration Sample

You can configure up to 12 STS-1 connections on a 4-Port Channelized OC-3/STM-1 line card. Each STS-1 connection can be configured as a T3 controller or as a VT controller.

The following procedure walks you through the basic steps for creating full-rate and subrate T3 interfaces, as well as T1 and fractional T1 interfaces. Each T3 controller can be configured as a single T3 interface (full or subrate), as 28 T1 interfaces, or as an even larger number of fractional T1s.

**Step 1** Set the framing type to SONET using the framing command.

```
Router(config)# controller sonet 2/0/0
Router(config-controller)# framing sonet
```

**Step 2** Assign an STS-1 path to a T3 interface. In this example, the path command is used to set up four T3 interfaces:

```
Router(config-controller)# path 1 controller t3
Router(config-controller)# path 2 controller t3
Router(config-controller)# path 3 controller t3
Router(config-controller)# exit
```

**Step 3** Create an interface. In the following examples, each type of interface is created in a different T3 controller (4/0/0.1 through 4/0/0.4).

### Full-Rate T3 Interface

- Enter controller configuration mode.

```
Router(config)# controller t3 2/0/0.1
Router(config-controller)#
```

- b. To create a full-rate T3 interface, you must eliminate the T1 interfaces by entering the **no channelized** command.

```
Router(config-controller)# no channelized
Router(config-controller)# exit
Router(config)#
```

- c. Enter interface configuration mode.

```
Router(config)# interface serial 2/0/0.1
```

- d. Go to Step 4.

#### Subrate T3 Interface

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/0.2
Router(config-controller)#
```

- b. To create a subrate T3 interface, first create a full-rate one.

```
Router(config-controller)# no channelized
Router(config-controller)# exit
Router(config)#
```

- c. Enter interface configuration mode, where you can use the **dsu bandwidth** command to create a subrate T3 interface. In this example, a subrate T3 interface is created that has a bandwidth of 16000 kbps.

```
Router(config)# interface serial 2/0/0.2
Router(config-if)# dsu bandwidth 16000
```

- d. Go to Step 4.

#### Channelized T3 with a Full T1 Interface

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/0.3
Router(config-controller)#
```

- b. Use the **t1 channel group** command to create a T1 interface. In the following example, T1 interface 1 (of 28) is defined as being made up of a single channel group, number 20 (any number between 0 and 23). This channel group consists of all 24 DS0 timeslots.

```
Router(config-controller)# t1 1 channel-group 20 timeslots 1-24
```

- c. Go to interface configuration mode for the channel group you just created.

```
Router(config)# interface serial 2/0/0.3/1:20
```

- d. Go to Step 4.

#### Channelized T3 with a Fractional T1 Interface

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/0.4
Router(config-controller)#
```

- b. Use the **t1 channel group** command to create fractional T1 interfaces. In the following example, T1 interface 3 (of 28) is defined as being made up of three channel groups, numbers 19, 20, and 21 (any numbers between 0 and 23). The channel groups consist of a total of 24 DS0 timeslots. Each channel group represents a separate interface.

```
Router(config-controller) t1 3 channel-group 19 timeslots 1-6, 10
Router(config-controller) t1 3 channel-group 20 timeslots 7,8,9
Router(config-controller) t1 3 channel-group 21 timeslots 11-24
```

- c. Go to interface configuration mode for one of the channel groups. For example:

```
Router(config)# interface serial 2/0/0.4/3:19
```

- d. Go to Step 4.

- Step 4** Enter the encapsulation method. This example shows the command for using Frame Relay encapsulation. You can also choose PPP or HDLC.

```
Router(config-if)# encapsulation frame-relay
```

- Step 5** If IP routing is enabled on the system, you can assign an IP address and subnet mask. For example:

```
Router(config-if)# ip address 172.16.32.49 255.255.0.0
```

- Step 6** Add any configuration subcommands required to enable routing protocols and set the interface line characteristics.

- Step 7** Change the shutdown state to up, which enables the interface.

```
Router(config-if)# no shutdown
```

- Step 8** When you have entered all of the configuration subcommands to complete the configuration, press **Ctrl-Z** to exit configuration mode.

- Step 9** Write the new configuration to NVRAM.

```
Router# copy running-config startup-config
```

---

After you create an interface configuration, you can modify it at any time by using the appropriate Cisco IOS configuration commands.

## SDH-Framed Interface Configuration Sample

If you configure the 4-port STM-1 line card for SDH framing, each OC-3/STM-1 port can be configured as:

- Three AU-3 controllers, each of which can be configured as a T3 interface or as 28 T1 interfaces or 21 E1 interfaces. These interfaces can be channelized into fractional T1s or E1s.
- Three AU-4-TUG-3 controllers, each of which can be configured as 28 T1 interfaces or up to 21 E1 interfaces. These interfaces can be channelized into fractional T1s or E1s.



**Note** AU-3 and AU-4-TUG-3s are based on the higher order path, and do not operate independently, but operate in groups of three. If you shutdown any AU-3 or AU-4-TUG-3 controller, the other two controllers on the same SONET port are also shut down.

The SONET **controller** command specifies the mode, and creates three [sub]controllers of that type, which you can configure like any other controller.

The format created adds a subport extension to the controller SONET name. The form of the subport extension is different for AU-3 and AU-4-TUG-3 controllers as the following examples show:

#### AU-3 Controller Syntax

```
controller au-3 <slot>/<subslot>/<port>.<AU-3#>
```

For example, the **controller** command for AU-3 #3 on port 0 of a 4-Port Channelized OC-3/STM-1 line card in slot 2 is:

```
controller au-3 2/0/0.3
```

#### AU-4-TUG-3 Controller Syntax

```
controller au-4-tug-3 <slot>/<subslot>/<port>.<AU-4#>/<TUG-3#>
```

For example, the command for a controller created for TUG-3 #3 on AU-4 of port 0 of a 4-Port Channelized OC-3/STM-1 line card in slot 2 is:

```
controller au-4-tug-3 2/0/0.1/3
```

## Show Controller Command Syntax

To display the settings for specific on AU-3 and AU-4-TUG-3 controllers, use the **show controller** command.

For AU-3:

```
show controller au-3 <slot>/<subslot>/<port>.<AU-3#>[/<tug-2>/<t1>]
```

For AU-4-TUG-3:

```
show controller au-4-tug-3  
<slot>/<subslot>/<port>.<AU-4#>/<TUG-3#>[/<tug-2>/<t1 or e1>]
```

Where:

- *slot* is 1 to 8
- *subslot* is 0
- *port* is always 0
- *AU-3#* is 1 to 12
- *AU-4#* is always 1
- *TUG-3#* is 1 to 12
- *tug-2* is 1 to 7
- *t1* is 1 to 4 or *e1* is 1 to 3



#### Note

The [/<tug-2>/<t1>] options are only available if a mode (C-11 or C-12) is configured on the controller.

For example, for T1 over AU-3, the command to display the settings for AU-3 #3 for a line card in slot 2 is:

```
show controller au-3 2/0/0.3
```

For AU-4-TUG-3, the command to display the settings for TUG-3 #3 on AU-4 of a 4-Port Channelized OC-3/STM-1 line card in slot 2 is:

```
show controller au-4-tug-3 2/0/0.1/3
```

To display a specific TUG-2 and E1 on the same AU-4-TUG-3, use the command:

```
show controller au-4-tug-3 2/0/0-1/3/1/3
```

## AU-3 Controller Interfaces

Use the following procedure to create T3 and T1 interfaces using AU-3 controllers.

---

**Step 1** Enter SONET controller configuration mode from global configuration mode.

In this example, the 4-port STM-1 line card is in slot 1.

```
Router(config)# controller sonet 2/0/0
Router(config-controller)#
```

**Step 2** Use the **aug controller** command to specify the mode of operation for an OC-3/STM-1 port (for an AU-3, twelve controllers are created: 2/0/0.1 to 2/0/0.12).

```
Router(config-controller)# aug controller au-3
Router(config-controller)#
```

### Full-Rate T3 Interface




---

**Note** T3 lines can only operate over AU-3 controllers.

---

**a.** Configure the controller on the port.

This example shows AU-3 controller #3 configured for a line card in slot 2.

```
Router(config-controller)# controller au-3 2/0/0.3
Router(config-controller)#
```

**b.** Set the container mode to C-3 to establish a T3 interface.

```
Router(config-controller)# mode c-3
Router(config-controller)# exit
Router(config)#
```

C-3 mode creates a serial interface at the unchannelized T3 level.

### T1 Channel Group Interface

**a.** Configure the controller on the STM-1 port.

This example shows AU-3 controller #2 configured on the STM-1 port for a line card in slot 2.

```
Router(config)# controller au-3 2/0/0.2
Router(config-controller)#
```

**b.** Set the container mode to C-11 to establish a T1 interface.

```
Router(config-controller)# mode c-11
Router(config-controller)#
```

**c.** Create a T1 interface.



In the following example, the TUG-2 interface is defined as 1 (any number between 1 and 7), the T1 interface is 2 (any number between 1 and 4), and is made up of a single channel group, 5 (any number between 0 and 23). This channel group consists of all 24 DS0 timeslots.

```
Router(config-controller)# tug-2 1 t1 2 channel-group 5 timeslots 1-24
Router(config-controller)#
```

## AU-4-TUG-3 Controller Interfaces

Use the following procedure to create T1 and E1 interfaces using AU-4-TUG-3 controllers.



### Caution

The three AU-4-TUG-3 controllers created on a port are based on the same higher order path and do not operate independently from one another. In other words, when you “shutdown” any AU-4-TUG-3 controller, the other two controllers on the same SONET port are also shut down.

**Step 1** Enter SONET controller-configuration mode.

In this example, the line card is in slot 2.

```
Router(config)# controller sonet 2/0/0
Router(config-controller)#
```

**Step 2** Use the **aug controller** command to specify the mode of operation for the STM-1 port (for an AU-4, three controllers are created).

```
Router(config-controller)# aug controller au-4-tug-3
Router(config-controller)#
```

### T1 Channel Group Interface over AU-4-TUG-3/TUG-2

- a. Configure the controller on an STM-4 port. This example shows AU-4-TUG-3 controller #2 configured on port 0 for a line card in slot 2.

```
Router(config-controller)# controller au-4-tug-3 2/0/0.1/2
Router(config-controller)#
```

- b. Set the container mode to C-11 to establish a T1 interface.

```
Router(config-controller)# mode c-11
Router(config-controller)#
```

- c. Create a T1 interface.

In the following example, the TUG-2 interface is 1 (any number between 1 and 7), the T1 interface is 2 (any number between 1 and 4,) and is defined as a single channel group, 5 (any number between 0 and 23). This channel group consists of all 24 DS0 timeslots.

```
Router(config-controller)# tug-2 1 t1 2 channel-group 5 timeslots 1-24
Router(config-controller)#
```

### E1 Channel Group Interface over AU-4-TUG-3/TUG-2

- a. Configure the controller on an STM-4 port.

This example shows AU-4-TUG-3 controller #2 configured on port 0 of a line card in slot 2.

```
Router(config-controller)# controller au-4-tug-3 2/0/0.1/2
Router(config-controller)#
```

- b. Set the container mode to C-12 to establish an E1 interface.

```
Router(config-controller)# mode c-12
Router(config-controller)#
```

- c. Create an E1 interface.

In the following example, the TUG-2 interface is 1 (any number between 1 and 7), the E1 interface is 2 (any number between 1 and 3), and is defined as a single channel group, 5 (any number between 0 and 31). This channel group consists of all 31 DS0 time slots.

```
Router(config-controller)# tug-2 1 e1 2 channel-group 5 timeslots 1-31
Router(config-controller)#
```

## Configuring the SONET Controller for SONET or SDH Framing

By default, the 4-port STM-1 line card consists of 12 STS-1 connections. To set up the 4-port STM-1 line card, you must configure each STS-1 as a T3 or VT interface. This section describes the commands used to create T3 and VT interfaces and test STS-1 connections. This section describes the following:

- [Entering Controller-Configuration Mode, page 7-14](#)
- [Selecting SONET or SDH Framing, page 7-14](#)
- [Configuring the SONET Controller Loopback Mode, page 7-15](#)

### Entering Controller-Configuration Mode

Use the **controller sonet** command to enter controller-configuration mode, where you can configure the controller:

```
controller sonet slot/subslot/port
```

Where *slot* is 1 to 8, and *subslot* and *port* are both 0.

The following example shows you how to enter SONET controller configuration mode for a card in slot 2:

```
Router(config)# controller sonet 2/0/0
ROuter(config-controller)#
```

### Selecting SONET or SDH Framing

To configure the 4-port STM-1 line card for SONET, you must first set the framing type to either SONET or SDH using the **framing** command.

If the 4-port STM-1 line card framing was previously configured for either SONET or SDH, and you wish to change the framing, you must enter the **no framing** command to return the line card to the default values. Then use the **framing <framing type>** command to set the new framing.



#### Caution

If you enter the **no framing** command, the line card configuration is erased, and all default line card values are restored. Use the command with caution.

```
framing {sonet | sdh}
[no] framing
```

The default is SONET.

Use the **no** form of the command to remove framing and return the line card to the default values.

The following example shows you how to specify SONET framing for the 4-port STM-1 line card in slot 2:

```
Router(config)# controller sonet 2/0/0
Router(config-controller)# framing sonet
```

## Configuring the SONET Controller Loopback Mode

You can enable SONET controller loopbacks by using the **loopback** command.

```
loopback [internal | line]
[no] loopback [internal | line]
```

The default is no loopback.

Use the **no** form of the command to stop a loopback.

For more information on the **loopback** command, refer to the online *Cisco 10000 Series ESR Troubleshooting Guide*.

The commands in this example run an internal loopback on the 4-Port Channelized OC-3/STM-1 line card in slot 2:

```
Router(config)# controller sonet 2/0/0
Router(config-controller)# loopback internal
```

## Creating a T3, VT, or AUG Controller

This section shows you how to create and configure T3, VT, or AUG controllers, and contains the following sections:

- [Designating an STS-1 Path as a T3 or VT under SONET Framing, page 7-15](#)
- [Designating an STM-4 Port as an AU-3 or AU-4-TUG-3 Controller under SDH Framing, page 7-16](#)
- [Configuring the SONET Controller Loopback Mode, page 7-15](#)
- [VT Commands under SONET Framing, page 7-17](#)
- [Unchannelized T3 Commands under SONET or SDH Framing, page 7-17](#)
- [Channelized T3 Commands under SONET or SDH Framing, page 7-21](#)
- [Creating T1 or E1 Channel Groups under SONET or SDH Framing, page 7-26](#)
- [Channelized T1 Commands under SONET or SDH Framing, page 7-29](#)

## Designating an STS-1 Path as a T3 or VT under SONET Framing

When the 4-port STM-1 line card is configured for SONET framing, you can use the **path** command to designate an STS-1 path as a T3 or VT controller. You can designate up to 12 STS-1 channels. (Figure 7-1 on page 7-22 shows the relationship between the STM-1, T3 interfaces, VT interfaces, and T1 interfaces.)

```
path STS_number controller {t3 | vt}
```

Where *STS\_number* is the virtual T3 or VT controller. Enter a value from 1 to 12.

Use the **no** form of the command to remove a T3 or VT controller.

In the following example, STS-1 number 1 is defined as a T3 line and controller T3 number 2/0/0.1 is generated:

```
Router(config)# controller sonet 2/0/0
Router(config-controller)# path 1 controller t3
```

In the next example, STS-1 number 1 is defined as a VT line and a VT controller 2/0/0.1 is generated:

```
Router(config)# controller sonet 2/0/0
Router(config-controller)# path 1 controller vt
```

## Designating an STM-4 Port as an AU-3 or AU-4-TUG-3 Controller under SDH Framing

When the 4-port STM-1 line card is configured for SDH framing, you can use the **aug controller** command to specify the mode of operation for an STM-4 port as an AU-3 controller or an AU-4-TUG-3 controller. This command creates 12 subcontrollers of the designated type, which you can then configure like any other controller.

```
[no] aug controller <au-3/au-4-tug-3>
```

Where *au-3* and *au-4-tug-3* designate the type of controller. Enter a value from 1 to 12.

Use the **no** form of the command to remove an AU-3 or AU-4-TUG-3 controller.

The format of the name for these controllers requires you to add a subport extension to the SONET controller name. The subport extension is different for AU-3 and AU-4-TUG-3 controllers.

### AU-3 Controller

For an AU-3 controller, the syntax is:

```
controller au-3 <slot>/<subslot>/<port>.<AU-3#>
```

For example, the following command Uses AU-3 controller #3 on port 0 of a line card in slot 2.

```
Router(config-controller)# controller au-3 2/0/0.3
```

### AU-4-TUG-3 Controller

For an AU-4-TUG-3 controller, the syntax is:

```
Router(config-controller)# controller au-4-tug-3 <slot>/<subslot>/<port>.<AU-4#>/<TUG-3#>
```



#### Note

The twelve AU-4-TUG-3 controllers created on an SDH-framed SONET port are based on the same higher order path and do not operate independently from one another. In other words, when you “shutdown” any AU-4-TUG-3 controller, the other two controllers on the same SDH-framed SONET port are also shut down.

For example, the following command uses TUG-3 #3 on AU-4 of port 0 of an 4-port STM-1 line card in slot 2.

```
Router(config-controller)# controller au-4-tug-3 2/0/0.1/3
```

## VT Commands under SONET Framing

This section describes how to use the **controller vt** command to further channelize the SONET-framed STS-1 controller of the 4-port STM-1 line card.

### Entering Controller Configuration Mode for VT

A virtual tributary (VT) controller on a 4-port STM-1 line card can be channelized into 28 T1 (VT1.5) interfaces or 21 E1 (VT2) interfaces. You can use the **controller vt** command to shut down a VT link or to change the settings for a T1 or E1 interface.

For information about T1 configuration settings, see [“Creating T1 or E1 Channel Groups under SONET or SDH Framing” section on page 7-26](#), and the [“Channelized T1 Commands under SONET or SDH Framing” section on page 7-29](#).

You can configure a VT link by entering the **controller vt** command.

```
slot/sub-slot/port.path
```

Where *path* is a value from 1 to 12. Each number represents a VT that houses 28 T1 lines or 21 E1 lines.

For example:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# controller vt 1/0/0.1
Router(config-controller)#
```

## Unchannelized T3 Commands under SONET or SDH Framing

This section shows you how to configure an unchannelized T3 on a SONET-framed or SDH-framed controller.

If the 4-port STM-1 line card is configured for SONET framing, a T3 interface is channelized into 28 T1 interfaces by default. You must unchannelize the T3 interface to create a full-rate or subrate T3 interface.

If the 4-Port Channelized OC-3/STM-1 line card is configured for SDH framing, C-3 container mode automatically creates an unchannelized T3 serial interface.

This section describes the commands you use to create, customize, and test full-rate and subrate T3 interfaces. This section describes the following:

- [Entering Controller Configuration Mode for T3, page 7-18](#)
- [Configuring a T3 Interface on a SONET-Framed Controller as Unchannelized, page 7-18](#)
- [Implementing Subrate T3, page 7-18](#)
- [Setting a Framing Type, page 7-19](#)
- [Specifying a DSU Mode, page 7-19](#)
- [Enabling Scrambling, page 7-19](#)
- [Specifying the Idle Character, page 7-19](#)
- [Running a T3 BER Test under SONET or SDH Framing, page 7-20](#)

You can also use the following commands, described in the [“Channelized T3 Commands under SONET or SDH Framing” section on page 7-21](#), when you configure unchannelized T3: **clock source**, **mdl**, **equipment**, and **loopback**.

## Entering Controller Configuration Mode for T3

To create an unchannelized T3 interface, you must first enter controller configuration mode for the T3 controller you want to configure.

```
controller T3 slot/sub-slot/port.path
```

Where *path* specifies the T3 interface number.

The following example shows how to enter controller configuration mode:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)#
```

## Configuring a T3 Interface on a SONET-Framed Controller as Unchannelized

If the 4-Port Channelized OC-3/STM-1 line card is configured for SONET framing, you must unchannelize the T3 interface to create a full-rate or subrate T3 interface.

You can configure the T3 interface as unchannelized (clear channel) by entering the **no channelized** command.

```
[no] channelized
```



### Caution

The **no channelized** command removes all channel groups from a channelized T3 interface. If you have already configured channel groups, use this command with caution.

Use the **channelized** command to return the interface to its default. The default value for a T3 interface is channelized.

In the following example, an unchannelized T3 interface is created:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# no channelized
```

## Implementing Subrate T3

You can implement subrate T3 by specifying the bandwidth for an unchannelized T3 interface. To do so, use the **dsu bandwidth bandwidth** command from interface configuration mode.

```
dsu bandwidth bandwidth
[no] bandwidth bandwidth
```

Where *bandwidth* is a numeric value between 0 and 44,210 kbps.

The default bandwidth is 44,210 kbps.

To return to the default bandwidth, use the **no** form of this command.

When you specify a value, the software sets the bandwidth to the closest acceptable bandwidth based on the timeslot size for the current DSU mode.

For you to properly use this command, the remote side of the connection must have a Cisco 7200 router or Cisco 7500 router with a PA-T3 or PA-2T3 port adapter or a T3 DSU supported by the **dsu mode** command.

In the following example, a bandwidth of 16,000 kbps is specified:

```
Router(config)# interface serial 1/0/0.1
Router(config-if)# dsu bandwidth 16000
```

## Setting a Framing Type

To specify a framing type for the unchannelized T3 controller, use the **framing** command.

```
framing [c-bit | m13]
[no] framing [c-bit | m13]
```

The default framing type is c-bit.

Use the **no** form of this command to restore the default framing type.

In the following example, framing is set to m13:

```
Router(config)# interface serial 1/0/0.1
Router(config-if)# framing m13
```

## Specifying a DSU Mode

To specify a DSU mode for a selected T3 interface, use the **dsu mode** command from interface configuration mode. This command configures the line card to emulate a manufacturer's proprietary multiplexing scheme.

```
dsu mode [Adtran | cisco | Digital-link | Kentrox | Larscom | verilink-highbit |
verilink-lowbit]
[no] dsu mode
```

The default DSU mode is cisco.

Use the **no** form of the command to return the DSU mode to its default.

In the following example, the DSU mode is set to **cisco**:

```
Router(config)# interface serial 1/0/0.1
Router(config-if)# dsu mode cisco
```

## Enabling Scrambling

To enable scrambling on an unchannelized T3 interface, use the **scramble** command from interface configuration mode.

```
scramble
[no] scramble
```

The default setting for this command is no scramble (scrambling disabled).

Ensure that both sides of the link have the same scrambling setting.

In the following example, scrambling is enabled on the specified T3 interface:

```
Router(config)# interface serial 1/0/0.1
Router(config-if)# scramble
```

## Specifying the Idle Character

To set a specific character on the unchannelized T3 interface to be transmitted between HDLC packets, use the **idle character** command from interface configuration mode.

```
idle-character [flags | marks]
[no] idle-character [flags | marks]
```

Where:

- **flags** sets an idle character of 0x7e
- **marks** sets an idle character of all 0xff

The default idle character is 0x7e.

Use the **no** form of the command to return the idle character to its default.

In the following example, the idle character is set to flags:

```
Router(config)# interface serial 1/0/0.1
Router(config-if)# idle-character flags
```



**Note**

---

Some systems interpret marks, 0xff, as an abort signal. Therefore, flags, 0x7e, is preferred.

---

## Running a T3 BER Test under SONET or SDH Framing

You can configure an unchannelized T3 interface to run a bit error rate (BER) test. The test is used to check cables and solve signal problems in the field. To send a BER test pattern on an unchannelized T3 interface, use the following interface configuration command:

```
bert [errors number | pattern pattern] interval time
[no] bert
```

Where:

- **errors** *number* is 1 to 255
- **pattern** *pattern* is
  - 0s—repetitive test pattern of all zeros (00000..)
  - 1s—repetitive test pattern of all ones (11111..)
  - 2<sup>15</sup>—pseudorandom O.151 test pattern (32,768 bits in length)
  - 2<sup>20</sup>-O153—pseudorandom O.153 test pattern (1,048,575 bits in length)
  - QRSS-2<sup>20</sup>—pseudorandom QRSS O.151 test pattern (1,048,575 bits in length)
  - 2<sup>23</sup>—pseudorandom O.151 test pattern (8,388,607 bits in length)
- **interval** *time* is 1 to 1440 minutes

You can terminate a BER test at any time using the **no bert** command.

For more information, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Examples:

- Send a BER test pseudorandom pattern of 2<sup>20</sup> through T3 line 1 for 5 minutes.

```
Router(config)# interface serial 1/0/0.1
Router(config-if)# bert pattern 2^20 interval 5
```

- Send a repetitive pattern of all 1s through T3 line 1 for 1440 minutes.

```
Router(config)# interface serial 1/0/0.1
Router(config-if)# bert pattern 1s interval 1440
```



## Channelized T3 Commands under SONET or SDH Framing

This section shows you how to configure a channelized T3 on a SONET-framed or SDH-framed controller.

By default, a T3 interface on a 4-Port Channelized OC-3/STM-1 line card is channelized into 28 T1 interfaces. This section describes the commands you use to customize and test a channelized T3 interface. This section describes procedures for

- [Entering Controller Configuration Mode for T3, page 7-21](#)
- [Configuring a T3 Interface as Channelized, page 7-22](#)
- [Setting the Framing Type, page 7-22](#)
- [Entering MDL Messages, page 7-23](#)
- [Specifying the Idle Pattern, page 7-24](#)
- [Setting the T3 Clock Source, page 7-24](#)
- [Configuring the Loopback Mode for a T3 Controller, page 7-25](#)
- [Configuring a T3 Controller to Respond to Remote Loopback Commands, page 7-25](#)

To use the interface for subscriber traffic, you must configure its T1 and DS0 components. For more information, see the “[Creating T1 or E1 Channel Groups under SONET or SDH Framing](#)” section on [page 7-26](#).

[Figure 7-1](#) illustrates the levels of configurable interface bandwidth that channelization offers.

### Entering Controller Configuration Mode for T3

You may need to enter controller configuration mode for the T3 interface. For example, enter this mode to change an unchannelized T3 interface back to a channelized one or to set MDL messages.


```
controller T3 slot/sub-slot/port.path
```

*Path* specifies the T3 interface number.

The following example shows how to enter controller configuration mode:

```
Router(config)# controller T3 1/0/0.1  
Router(config-controller)#
```

**Figure 7-1 Channelization of T3s**



## Configuring a T3 Interface as Channelized

A T3 interface is channelized by default. Use the **channelized** command if you had previously made the interface unchannelized.

```
[no] channelized
channelized
```



**Caution**

The **no channelized** command removes all channel groups from a 4-Port Channelized OC-3/STM-1 line card interface. If you have already configured channel groups, use this command with caution.

The following example shows how to create a 4-Port Channelized OC-3/STM-1 line card interface:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# channelized
```

## Setting the Framing Type

To specify a framing type for the channelized T3 controller, use the **framing** command.

```
framing [c-bit | m23 | auto-detect]
[no] framing [c-bit | m23 | auto-detect]
```

The default is auto-detect.

Use the **no** form of the command to return the framing type to its default.

You can instruct the 4-Port Channelized OC-3/STM-1 line card to detect the framing type from the far end and transmit that same framing type:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# framing auto-detect
```

## Entering MDL Messages

You can configure maintenance data link (MDL) messages (as defined in the ANSI T1.107a-1990 specification) on the channelized T3 interface.



### Note

MDL messages are supported only when the T3 framing is set for C-bit parity. (See the “[Setting the Framing Type](#)” section on page 7-22.)

To configure MDL messages, use the **mdl** command:

```
mdl {transmit {path | idle-signal | test-signal} | string {eic | lic | fic | unit | pfi | port
| generator} id_string}
[no] mdl {transmit {path | idle-signal | test-signal} | string {eic | lic | fic | unit | pfi |
port | generator} id_string}
```

Where:

- **transmit path** enables transmission of the MDL path message
- **transmit idle-signal** enables transmission of the MDL idle-signal message
- **eic** is the equipment identification code (up to 10 characters)
- **lic** is the location identification code (up to 11 characters)
- **fic** is the frame identification code (up to 10 characters)
- **unit** is the unit identification code (up to 6 characters)
- **pfi** is the facility identification code to include in the MDL path message (up to 38 characters)
- **port** is the equipment port (which initiates the idle signal) to include in the MDL idle signal message (up to 38 characters)
- **generator** is the generator number to include in the MDL test signal message (up to 38 characters)

The default is that no MDL message is configured.

Use the **no** form of the command to remove an MDL message.

Examples of configuring MDL messages follow:

- Enable the MDL path message transmission.

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# mdl transmit path
```

- Enable the MDL idle signal message transmission.

```
Router(config-controller)# mdl transmit idle-signal
```

- Enable the MDL test signal message transmission.

```
Router(config-controller)# mdl transmit test-signal
```

- Enter the equipment identification code.

```
Router(config-controller)# mdl string eic router A
```

- Enter the location identification code.

```
Router(config-controller)# mdl string lic test network
```

- Enter the frame identification code.

```
Router(config-controller)# mdl string fic building b
```

- Enter the unit identification code.  
Router(config-controller)# mdl string unit *abc*
- Enter the facility identification code.  
Router(config-controller)# mdl string pfi *string*
- Enter the port number to send in the MDL idle signal message.  
Router(config-controller)# mdl string port *string*
- Enter the generator number to send in the MDL test signal message.  
Router(config-controller)# mdl string generator *string*

## Specifying the Idle Pattern

You can set a specific pattern to be transmitted between HDLC packets on all unconfigured timeslot interfaces that belong to a channelized T3 interface. To do so, use the **idle pattern** command.

```
idle pattern patterns
[no] idle pattern patterns
```

Where *patterns* is a number in the range of 0x0 to 0xff (hexadecimal) or 0 to 255 (decimal). You can enter this value in either hexadecimal or decimal form. Values of 0 to 254 set the idle pattern to HDLC flags (0x7e); a value of 255 sets the pattern to 0xff (all ones).



### Note

---

Some systems interpret marks, 0xff, as an abort signal. Therefore, flags, 0x7e, is preferred.

---

The default idle pattern is 0x7e.

Use the **no** form of the command to return the idle pattern to its default value.

Examples:

- Set a hexadecimal idle pattern.  
Router(config)# controller T3 1/0/0.1  
Router(config-controller)# idle pattern 0x10
- Set a decimal idle pattern.  
Router(config)# controller T3 1/0/0.1  
Router(config-controller)# idle pattern 23

## Setting the T3 Clock Source

At the prompt, set the internal or line clock source for the selected T3 controller using the **clock source** command. This command is set in controller configuration mode.

```
clock source {internal | line}
```

Where:

- **internal** specifies that the internal clock source is used
- **line** specifies that the network clock source is used

The default is clock source internal.

In this example, a T3 controller is instructed to use a line clock source:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# clock source line
```

## Configuring the Loopback Mode for a T3 Controller

You can configure the loopback modes for a T3 controller by using the **loopback** command:

```
loopback {local | network | remote}
[no] loopback {local | network | remote}
```

The default is no loopback.

To disable loopback on the T3 controller, use the **no** form of the command.

Examples:

- Configure a T3 controller for local loopback.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# loopback local
```

Local loopback simultaneously loops all channels toward the router and transmits a T3 AIS to the network. You can use local loopback to diagnose problems with the port when the port is isolated from the network cables.

- Configure a T3 port for network loopback.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# loopback network
```

Network loopback loops the T3 line back towards the network and can be used to diagnose problems with cables from the central switching office to the port.

- Configure a T3 port for remote loopback.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# loopback remote
```

Remote loopback sends a command to loop the T3 line at the far end (central office). It can be used to diagnose problems with cables from the port adapter to the switching office.

## Configuring a T3 Controller to Respond to Remote Loopback Commands

Use the **equipment loopback** command to run loopbacks in conjunction with remote equipment.

```
equipment [customer | network] loopback
```

Where:

- **customer** allows a port to respond to loopback commands from remote T3 equipment.
- **network** causes a controller to ignore remote T3 loopback commands.

Example:

To enable the controller's ability to respond to remote loopback requests, type:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# equipment customer loopback
```

To prevent a controller from responding to remote loopback commands, type:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# equipment network loopback
```

**Note**

Remote loopbacks are only available when you use c-bit parity framing.

For more information on the **loopback** command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

## Creating T1 or E1 Channel Groups under SONET or SDH Framing

To create an interface that supports subscriber traffic, you must combine the timeslots into channel groups. To help you configure channel groups, consider the following T1 and E1 characteristics:

### For SONET-Framed T3 Controllers

- 1 channelized T3 is divided into 28 T1s
- 1 T1 is divided into 24 timeslots (or DS0s)

### For SONET-Framed VT Controllers

For T1:

- 1 VT controller is divided into 28 T1s (VT1.5)
- 1 T1 is divided into 24 timeslots (or DS0s)

For E1:

- 1 VT controller is divided into 21 E1s (VT2)
- 1 E1 can be divided into 31 timeslots (or DS0s)

### For SDH-Framed T3 Controllers

- 1 T3 is divided into 7 TUG-2s
- 1 TUG-2 is divided into either:
  - 4 T1s that can each be divided into 24 timeslots (or DS0s)
  - 3 E1s that can be divided into 31 timeslots (or DS0s)

## Creating Channel Groups for T1 SONET-Framed Interfaces

Use the **t1 channel-group** command to create a channel group for a SONET-framed interface.

[Figure 7-1](#) illustrates channelization possibilities on the 4-Port Channelized OC-3/STM-1 line card.

You create a logical channel group using the following command:

```
t1 t1-number channel-group channel-group-number timeslots list-of-timeslots [speed {56 | 64}]
[no] t1 t1-number channel-group channel-group-number
```

Where:

- *t1-number* is T1 interface number 1 to 28.
- **channel-group** *channel-group-number* identifies the channel group with any number from 0 to 23.

- **timeslots** *list-of-timeslots* can be 1 to 24 or a combination of subranges within the 1 to 24 interval. You can indicate a range using a hyphen, commas, or a combination of both. One timeslot equals one DS0. (See the examples below.)
- **speed**{ 56 | 64 } is an optional argument that specifies the speed of a timeslot as either 56 or 64 kbps. The default is 64. (The 56 kbps timeslots are generally used with older T1 equipment that does not support B8ZS line coding and are associated with SF framing.)

Use the **no** form of the command to remove a logical channel group.

The following examples show how to use the **t1 channel-group** command:

- In this example, T1 interface 3 includes channel group 20 and consists of 9 channelized timeslots:

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 3 channel-group 20 timeslots 1-8, 10
```

To enter interface configuration mode for T1 interface 3 channel group 20, enter the following:

```
Router(config)# interface serial 1/0/0.1/3:20
```

- In this example, t1 interface 4 includes channel group 18 and consists of all 24 timeslots, creating a full T1 interface:

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 4 channel-group 18 timeslots 1-24
```

To enter interface configuration mode for T1 interface 4 channel group 18, enter the following:

```
Router(config)# interface serial 1/0/0.1/4:18
```

- In the following example, T1 interface number 5 is divided into three channel groups, which total 11 timeslots:

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 5 channel-group 19 timeslots 1-6
Router(config-controller)# t1 5 channel-group 20 timeslots 10
Router(config-controller)# t1 5 channel-group 21 timeslots 7-9, 24
```

- In the following example, channel group 20 on T1 1 is removed:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# no t1 1 channel-group 20
```

## Creating Channel-Groups for SDH-Framed Interfaces

### Channel Limitations

There is a limit of 128 channels per SDH controller, and a maximum of 192 channels for the 4-Port Channelized OC-3/STM-1 line card. This limitation applies to both T1 and E1 interfaces when you create channel groups for controllers.

For example, if you created 128 channels on T1 controller #1 on port 2, and 64 channels on T1 controller #2 on port 2, then you could not create any additional channels on T1 controller #3 or T1 controller #4 because you have reached the maximum limit of 192 channels for a single port (port 2 in this example).

To create a logical channel group, use one of the following commands:

### For T1:

```
[no] tug-2 <tug-2#> t1 <t1#> channel-group <channel#> timeslots <range> [speed 64|56]
```

**For E1 (framed):**

```
[no] tug-2 <tug-2#> e1 <e1#> channel-group <channel#> timeslots <range>
```

**For E1 (unframed):**

```
[no] tug-2 <tug-2#> e1 <e1#> unframed
```

Where:

- *tug-2* is 1 to 7
- *t1#* is 1 to 4
- *e1#* is 1 to 3
- **channel-group** *channel#* identifies the channel group with any number from 0 to 23.
- **timeslots** *range* can be 1 to 24 for T1, or 1 to 31 for E1, or a combination of subranges within those intervals. You can indicate a range using a hyphen, commas, or a combination of both. One timeslot equals one DS0. (See the examples below.)
- **speed**{56 | 64} is an optional T1 argument that specifies the speed of a timeslot as either 56 or 64 kbps. The default is 64. (The 56 kbps timeslots are generally used with older T1 equipment that does not support B8ZS and are associated with SF framing.)




---

**Note** The **speed** argument applies only to T1 channel groups and is not valid for E1.

---

- **unframed** creates an unframed E1 channel. This creates an interface with channel-group number 0.




---

**Note** The **unframed** argument applies only to E1 channel groups and is not valid for T1.

---

Use the **no** form of the command to remove a logical channel group.

The following examples show how to use the **channel-group** command:

- In this example, T1 interface 3 includes channel group 20 and consists of 9 channelized timeslots:

```
Router(config-controller)# controller au-3 2/0/0.2
Router(config-controller)# mode c-11
Router(config-controller)# tug-2 1 t1 3 channel-group 20 timeslots 1-9
```

To enter interface configuration mode for T1 interface 3 channel group 20, enter the following:

```
Router(config)# interface serial 2/0/0.2/3:20
```

- In this example, T1 interface 4 includes channel group 18 and consists of all 24 timeslots, creating a full T1 interface:

```
Router(config-controller)# controller au-3 2/0/0.2
Router(config-controller)# mode c-11
Router(config-controller)# tug-2 1 t1 4 channel-group 18 timeslots 1-24
```

To enter interface configuration mode for T1 interface 4 channel group 18, enter the following:

```
Router(config)# interface serial 2/0/0.2/4:18
```

- In the following example, T1 interface number 5 is divided into three channel groups, which total 11 timeslots:

```
Router(config-controller)# controller au3 2/0/0.2
Router(config-controller)# mode c-11
Router(config-controller)# tug-2 1 t1 5 channel-group 19 timeslots 1-6
```



```
Router(config-controller)# tug-2 1 t1 5 channel-group 20 timeslots 10
Router(config-controller)# tug-2 1 t1 5 channel-group 21 timeslots 7-9, 24
```

- In the following example, channel group 20 is removed:

```
Router(config-controller)# controller au3 2/0/0.2
Router(config-controller)# no tug-2 1 t1 5 channel-group 20
```

## Channelized T1 Commands under SONET or SDH Framing

You can enter commands to modify aspects of a T1 interface from controller configuration mode for a T3 interface. This section describes the commands for:

- [Setting the Framing Format, page 7-29](#)
- [Controlling Yellow Alarms, page 7-30](#)
- [Setting the T1 Clock Source, page 7-30](#)
- [Configuring FDL, page 7-30](#)
- [Configuring a T1 BER Test, page 7-31](#)
- [Configuring Loopback Mode, page 7-31](#)

After you configure a T1 interface, you can add encapsulation, routing, and other instructions by entering interface configuration mode. For example:

```
Router(config)# interface serial 1/0/0.1/4:18
```

### Setting the Framing Format

You can specify the T1 interface framing format using the following command:

```
t1 t1-number framing {esf | sf [hdlc-idle {0x7E | 0xFF}]}
[no] t1 t1-number framing {esf | sf [hdlc-idle {0x7E | 0xFF}]}
```

Where:

- *t1-number* is T1 interface 1 to 28
- **framing** is either extended super frame (ESF) or super frame (SF). You can set SF hdlc-idle to 0x7E or 0xFF
- **hdlc-idle** options allow you to set the idle pattern for the T1 interface to either 0x7e (the default) or 0xFF

The default framing format is extended super frame (ESF).

Use the **no** form of the command to return framing to its default value.

Examples:

- Set SF framing format for T1 interface 6.

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# t1 6 framing sf
```

- Set ESF framing format for T1 interface 16:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# t1 16 framing esf
```

## Controlling Yellow Alarms

Use the **t1 yellow** command to turn the detection or generation of a yellow alarm on or off.

```
t1 t1-number yellow {detection | generation}
[no] t1 t1-number yellow {detection | generation}
```

Where:

- *t1-number* is T1 interface 1 to 28
- **detection** means that the interface is told that it is failing by the remote device, causing Cisco IOS software to send a message to the console
- **generation** means that the interface notifies the remote device if it is failing, causing Cisco IOS software to send a message to the console

When you select SF framing for a full T1 interface (24 timeslots) that uses the default speed of 64, consider using the **no t1-number yellow detection** command to turn off yellow alarm detection, because the yellow alarm can be incorrectly detected with SF framing.

In the following example, T1 interface 1 is set to yellow detection:

```
Router(config)# controller t3 2/0/0.1
Router(config-controller)# t1 1 yellow detection
```

## Setting the T1 Clock Source

You can set the internal or line (network) clock source for a T1 interface using the **controller** command.

```
t1 t1-number clock source {internal | line}
```

Where:

- *t1-number* is T1 interface 1 to 28
- **internal** specifies that the internal clock source is used
- **line** specifies that the network clock source is used

The default is clock source internal.

In the following example, the interface is instructed to get its clock source from the line:

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# t1 1 clock source line
```

## Configuring FDL

You can use the **fdl ansi** command to enable 1-second transmissions of ANSI T1.403 performance reports through the facility data link (FDL), on both ends of the T1 connection.

```
t1 t1-number fdl ansi
[no] t1 t1-number fdl ansi
```

Where *t1-number* is T1 interface 1 to 28.

Use the **no** form of the command to disable this feature.



### Note

You can use this command only when the T1 framing is ESF.

In the following example, FDL is enabled:

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 2 fdl ansi
```

## Configuring a T1 BER Test

You can configure an individual T1 interface to run an independent BER test. The test is used to check cables and solve signal problems in the field. To send a BER test pattern on a T1 interface, use the following command:

```
t1 t1-number bert pattern pattern interval time [unframed]
[no] t1 t1-number bert
```

Where:

- *t1-number* is T1 interface number 1 to 28
- *time* is 1 to 14,400 minutes
- *pattern* is
  - 2<sup>11</sup>—pseudorandom test pattern (2048 bits in length)
  - 2<sup>15</sup>—pseudorandom O.151 test pattern (32,768 bits in length)
  - 2<sup>20</sup>-O153—pseudorandom O.153 test pattern (1,048,575 bits in length)
- **unframed** causes the BER test pattern to use the entire T1 bandwidth, including the T1 framing and payload bits. If **unframed** is omitted, the T1 is either SF or ESF framed as configured by the T1 n framing command, and the BER test pattern occupies only the T1 payload bits.



### Note

For each T3, you can run only one BER test at a time.

You can terminate a BER test at any time using the **no** form of the command.

For more information, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Example:

- Send a BER test pseudorandom pattern of 2<sup>15</sup> through T1 interface 10 for 5 minutes.

```
Router(config)# controller T3 1/0/0.1
Router(config-controller)# t1 10 bert pattern 2^15 interval 5 unframed
```

## Configuring Loopback Mode

If a problem occurs when you configure a T1 interface, you can troubleshoot the line card by using the following command from controller configuration mode:

```
t1 t1-number loopback [local | network {line | payload} | remote [line [fdl {ansi | bellcore}} | payload [fdl | ansi]]]
[no] t1 t1-number loopback [local | network {line | payload} | remote [line [fdl {ansi | bellcore}} | payload [fdl | ansi]]]
```

Where:

- *t1-number* is T1 interface 1 to 28.
- **local** loops the router output data back toward the router at the T1 framer and sends an alarm indication signal (AIS) out toward the network.

- **network {line | payload}** loops the data back toward the network and automatically sets a local loopback at the HDLC controllers (line) or loops the payload data back toward the network and automatically sets a local loopback at the HDLC controllers (payload).
- **remote line fdl {ansi | bellcore}** sends a repeating, 16-bit ESF data link keyword to the remote end, requesting that it enter into a network line loopback. You can specify an ANSI or Bellcore keyword.
- **remote payload [fdl] [ansi]** sends a repeating, 16-bit ESF data link code word to the remote end, requesting entry into a network payload loopback. Using **fdl** and **ansi** enables the remote payload facility data link (FDL) ANSI bit loopback on the T1 channel.

Use the **no** form of the command to terminate a loopback.

For more information on this command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Examples:

- Configure the T3 controller for local loopback on T1 interface 1.

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 1 loopback local
```

- Configure the T3 controller for remote FDL ANSI loopback on T1 interface 1.

```
Router(config)# controller t3 1/0/0.1
Router(config-controller)# t1 1 loop remote line fdl ansi
```



## CHAPTER 8

# 6-Port Channelized T3 Line Card Configuration

This chapter describes procedures for configuring the Cisco 10000 series 6-Port Channelized T3 line card, hereafter known as the 6-Port Channelized T3 line card.

The 6-Port Channelized T3 line card provides the Cisco 10000 series routers with six DS3 ports of high-density T3 service.

This chapter contains the following sections:

- [Software Support, page 8-1](#)
- [Default Values, page 8-2](#)
- [Interface Syntax, page 8-3](#)
- [Interface Configuration Sample, page 8-3](#)
- [Unchannelized T3 Commands, page 8-5](#)
- [Channelized T3 Commands, page 8-9](#)
- [Channel-Group Command for DS0 Timeslots and T1s, page 8-14](#)
- [Channelized T1 Commands, page 8-15](#)

## Software Support

[Table 8-1](#) shows the minimum Cisco IOS release on each release train that supports the 6-Port Channelized T3 line card.

**Table 8-1** 6-Port Channelized T3 Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE1	Cisco IOS Release 12.0(9)SL and later releases of Cisco IOS 12.0SL Cisco IOS Release 12.0(17)ST and later releases of Cisco IOS 12.0ST Cisco IOS Release 12.0(22)S and later releases of Cisco IOS 12.0S Cisco IOS Release 12.2(8)BZ and later releases of Cisco IOS 12.2BZ
PRE2	Cisco IOS Release 12.2(15)BX and later releases of Cisco IOS 12.2BX Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS 12. XI Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Default Values

Table 8-2 lists default values for the 6-Port Channelized T3 line card and indicates which values apply to which line speeds. This table also includes the command used for modifying a default value and indicates whether a value needs to be the same (or opposite) on the remote end of the connection.

**Table 8-2 6-Port Channelized T3 Line Card Default Values**

Command Name	Default Setting	Command Syntax	Remote Side Setting	DS0	T1	Ch T3	Unch T3
<b>Controller Configuration Mode</b>							
cable length	249	<b>cablelength</b> <i>feet</i>	—			x	x
channelized	channelized	[no] <b>channelized</b>	—			x	x
clock source	internal	<b>clock source</b> [ <i>line</i>   <b>internal</b> ]	At least one side set to <b>internal</b>			x	x
T1 clock source	internal	<b>t1</b> <i>t1-number</i> <b>clock source</b> [ <i>line</i>   <b>internal</b> ]	At least one side set to <b>internal</b>		x		
framing	auto-detect	<b>framing</b> [ <i>c-bit</i>   <b>m23</b>   <b>auto-detect</b> ]	Same			x	
T1 framing	esf	<b>t1</b> <i>t1-number</i> <b>framing</b> [ <b>esf</b>   <b>sf</b> [ <b>hdlc-idle</b> { <b>0x7E</b>   <b>0xFF</b> }]]	Same		x		
idle pattern	0X7e (flags)	<b>idle pattern</b> [ <b>0x0</b> to <b>0xFF</b> ]	Same			x	
<b>Interface Configuration Mode</b>							
crc (cyclical redundancy check)	16	[no] <b>crc</b> [ <b>16</b>   <b>32</b> ]	Same	x			x
DSU bandwidth	44,210	<b>dsu bandwidth</b> <i>bandwidth</i>	Same				x
DSU mode	cisco	<b>dsu mode</b> <i>mode</i>	Same				x
encapsulation	HDLC	<b>encapsulation</b> [ <b>hdlc</b>   <b>ppp</b>   <b>frame-relay</b> ]	Same	x			x

**Table 8-2** 6-Port Channelized T3 Line Card Default Values (continued)

Command Name	Default Setting	Command Syntax	Remote Side Setting	DS0	T1	Ch T3	Unch T3
framing	c-bit	<b>framing</b> [c-bit   m13]	Same				x
idle character	flags (0x7e)	<b>idle character</b> [flags   marks]	Same				x
keepalive	keepalive (10 sec)	<b>keepalive</b>	Same	x			x
mtu (maximum transmission unit)	4470	<b>mtu size</b>	Same	x			x
scramble	No scrambling	[no] <b>scramble</b>	Same				x

## Interface Syntax

To specify an interface number in a configuration command, use the syntax in [Table 8-3](#) to identify interfaces on the 6-Port Channelized T3 line card.

**Table 8-3** 6-Port Channelized T3 Line Card Interface Syntax

Type of Interface	Slot	Subslot	Port (T3 Number)	T1 Number	Channel Group Number
Unchannelized	1 to 8/	0/	0 to 5	—	—
Channelized	1 to 8/	0/	0 to 5/	1 to 28	0 to 23

Examples:

- Modifying T1 interface 6 in controller configuration mode:

```
Router(config)# controller t3 2/0/0
Router(config-controller)# t1 6 command
```

- Modifying T1 interface 6, channel group number 8 in interface configuration mode:

```
Router(config)# interface serial 2/0/0/6:8
Router(config-if)
```

## Interface Configuration Sample

Each T3 controller can be configured as a single T3 interface (full or subrate), as 28 T1 interfaces, or as an even larger number of fractional T1s. The following procedure walks you through the basic steps for creating full-rate and subrate T3 interfaces, as well as T1 and fractional T1 interfaces:

- 
- Step 1** Create an interface. In the following examples, each type of interface is created in a different T3 controller (2/0/0 through 2/0/3).

**Full-Rate T3 Interface**

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/0
Router(config-controller)#
```

- b. To create a full-rate T3 interface, you must eliminate the T1 interfaces by entering the **no channelized** command.

```
Router(config-controller)# no channelized
Router(config-controller)# exit
Router(config)#
```

- c. Go to interface configuration mode:

```
Router(config)# interface serial 2/0/0
```

- d. You can now continue to Step 2.

**Subrate T3 Interface**

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/1
Router(config-controller)#
```

- b. To create a subrate T3 interface, first create a full-rate one.

```
Router(config-controller)# no channelized
Router(config-controller)# exit
Router(config)#
```

- c. Then go into interface configuration mode, where you can use the **dsu bandwidth** command to create a subrate T3 interface. In this example, a subrate T3 interface is created that has a bandwidth of 16,000 kbps.

```
Router(config)# interface serial 2/0/1
Router(config-if)# dsu bandwidth 16000
```

- d. You can now continue to Step 2.

**Full T1 Interface**

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/2
Router(config-controller)#
```

- b. Use the **t1 channel group** command to create a T1 interface. In the following example, T1 interface 1 (of 28) is defined as being made up of a single channel group, number 20 (any number between 0 and 23). This channel group consists of all 24 DS0 timeslots.

```
Router(config-controller)# t1 1 channel-group 20 timeslots 1-24
```

- c. Go to interface configuration mode for the channel group you just created.

```
Router(config)# interface serial 2/0/2/1:20
```

- d. You can now continue to Step 2.



**Fractional T1 Interface**

- a. Enter controller configuration mode.

```
Router(config)# controller t3 2/0/3
Router(config-controller)#
```

- b. Use the **t1 channel group** command to create fractional T1 interfaces. In the following example, T1 interface 3 (of 28) is defined as being made up of three channel groups, numbers 19, 20, and 21. (numbers between 0 and 23 are allowed.) The channel groups consist of a total of 24 DS0 timeslots. Each channel group represents a separate interface.

```
Router(config-controller) t1 3 channel-group 19 timeslots 1-6, 10
Router(config-controller) t1 3 channel-group 20 timeslots 7,8,9
Router(config-controller) t1 3 channel-group 21 timeslots 11-24
```

- c. Go to interface configuration mode for one of the channel groups. For example:

```
Router(config)# interface serial 2/0/3/3:19
```

- d. You can now continue to Step 2.

- Step 2** Enter the encapsulation method. This example shows the command for using Frame Relay encapsulation. You can also choose PPP or HDLC.

```
Router(config-if)# encapsulation frame relay
```

- Step 3** If IP routing is enabled on the system, assign an IP address and subnet mask. For example:

```
Router(config-if)# ip address 172.16.32.49 255.255.0.0
```

- Step 4** Add any configuration subcommands required to enable routing protocols and set the interface line characteristics.

- Step 5** Change the shutdown state to up, which enables the interface.

```
Router(config-if)# no shutdown
```

- Step 6** When you have entered all of the configuration subcommands to complete the configuration, press **Ctrl-Z** to exit configuration mode.

- Step 7** To write the new configuration to NVRAM, type

```
Router# copy running-config startup-config
```

---

After you create an interface configuration, you can modify it at any time by using the appropriate Cisco IOS configuration commands.

## Unchannelized T3 Commands

By default, a T3 interface on a 6-Port Channelized T3 line card is channelized into 28 T1 interfaces. You must unchannelize the T3 interface in order to create a full-rate or subrate T3 interface. This section describes the commands you use to create, customize, and test full-rate and subrate T3 interfaces. This section describes the following:

- [Entering Controller Configuration Mode for T3, page 8-6](#)
- [Configuring a T3 Interface as Unchannelized, page 8-6](#)
- [Implementing Subrate T3, page 8-6](#)

- [Setting the Framing Type, page 8-7](#)
- [Specifying the DSU Mode, page 8-7](#)
- [Enabling Scrambling, page 8-7](#)
- [Specifying an Idle Character, page 8-8](#)
- [Running a BER Test, page 8-8](#)

You can also use the following commands, described in the “[Channelized T3 Commands](#)” section on [page 8-9](#), when you are configuring an unchannelized T3: **cablelength**, **clock source**, **mdl**, **equipment**, and **loopback**.

## Entering Controller Configuration Mode for T3

To create an unchannelized T3 interface, you must first enter controller configuration mode for the T3 controller you want to configure.

```
controller T3 slot/sub-slot/port
```

The following example shows how to enter controller configuration mode:

```
Router(config)# controller T3 1/0/0
Router(config-controller)#
```

## Configuring a T3 Interface as Unchannelized

You can configure the T3 interface as unchannelized (clear channel) by entering the **no channelized** command.

```
[no] channelized
channelized
```



### Caution

The **no channelized** command removes all channel groups from a channelized T3 interface. If you have already configured channel groups, use this command with caution.

Use the **channelized** command to return the interface to its default. The default value for a T3 interface is channelized.

In the following example, an unchannelized T3 interface is created:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# no channelized
```

## Implementing Subrate T3

You can implement subrate T3 by specifying the bandwidth for an unchannelized T3 interface. To do so, use the command **dsu bandwidth bandwidth** from interface configuration mode.

```
dsu bandwidth bandwidth
[no] bandwidth bandwidth
```

Where *bandwidth* is a numeric value between 0 and 44210 kbps.

The default bandwidth is 44210 kbps.

To return to the default bandwidth, use the **no** form of this command.

When you specify a value, the software sets the bandwidth to the closest acceptable bandwidth, based on the timeslot size for the current DSU mode.

In order for you to use this command, the remote side of the connection must have a Cisco 7200 or Cisco 7500 with a PA-T3 or PA-2T3 port adapter or a T3 DSU supported by the **dsu mode** command.

In the following example, a bandwidth of 16000 kbps is specified:

```
Router(config)# interface serial 1/0/0
Router(config-if)# dsu bandwidth 16000
```

## Setting the Framing Type

To specify a framing type for the unchannelized T3 controller, use the **framing** command.

```
framing [c-bit | m13]
[no] framing [c-bit | m13]
```

The default framing type is C-bit.

Use the **no** form of this command to restore the default framing type.

In the following example, framing is set to m13:

```
Router(config)# interface serial 1/0/0
Router(config-if)# framing m13
```

## Specifying the DSU Mode

To specify a DSU mode for a selected T3 interface, use the **dsu mode** command from interface configuration mode. This command configures the line card to emulate a manufacturer's proprietary multiplexing scheme.

```
dsu mode [Adtran | cisco | Digital-link | Kentrox | Larscom | verilink-highbit |
verilink-lowbit]
[no] dsu mode
```

The default DSU mode is **cisco**.

Use the **no** form of the command to return the DSU mode to its default.

In the following example, the DSU mode is set to **cisco**:

```
Router(config)# interface serial 1/0/0
Router(config-if)# dsu mode cisco
```

## Enabling Scrambling

To enable scrambling on an unchannelized T3 interface, use the **scramble** command from interface configuration mode.

```
scramble
[no] scramble
```

The default setting for this command is no scramble (scrambling disabled).

Both sides of the link should have the same scrambling setting.

In the following example, scrambling is enabled on the specified T3 interface:

```
Router(config)# interface serial 1/0/0
Router(config-if)# scramble
```

## Specifying an Idle Character

To set a specific character on the unchannelized T3 interface to be transmitted between HDLC packets, use the **idle character** command from interface configuration mode.

```
idle-character [flags | marks]
[no] idle-character [flags | marks]
```

Where:

- **flags** sets an idle character of 0x7e.
- **marks** sets an idle character of all 0xff.

The default idle character is 0x7e.

Use the **no** form of the command to return the idle character to its default.

In the following example, the idle character is set to flags:

```
Router(config)# interface serial 1/0/0
Router(config-if)# idle-character flags
```



### Note

Some systems interpret marks, 0xff, as an abort signal. Therefore, flags, 0x7e, is preferred.

## Running a BER Test

You can configure an unchannelized T3 interface to run a bit error rate (BER) test. The test can be used in checking cables and solving signal problems in the field. To send a BER test pattern on an unchannelized T3 interface, use the following interface configuration command:

```
bert [errors number | pattern pattern] interval time
[no] bert
```

Where:

- **errors number** is 1 to 255.
- **pattern pattern** is
  - 0s—repetitive test pattern of all zeros (00000..)
  - 1s—repetitive test pattern of all ones (11111..)
  - 2<sup>15</sup>—pseudorandom O.151 test pattern (32,768 bits long)
  - 2<sup>20</sup>-O153—pseudorandom O.153 test pattern (1,048,575 bits long)
  - QRSS-2<sup>20</sup>—pseudorandom QRSS O.151 test pattern (1,048,575 bits long)
  - 2<sup>23</sup>—pseudorandom O.151 test pattern (8,388,607 bits long)
- **interval time** is 1 to 1440 minutes.

You can terminate a BER test at any time using the **no bert** command.

For more information, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Examples:

- Send a BER test pseudorandom pattern of 2<sup>20</sup> through T3 interface 1/0/0 for 5 minutes.

```
Router(config)# interface serial 1/0/0
Router(config-if)# bert pattern 2^20 interval 5
```

- Send a repetitive pattern of all 1s through T3 interface 1/0/0 for 1440 minutes.

```
Router(config)# interface serial 1/0/0
Router(config-if)# bert pattern 1s interval 1440
```

## Channelized T3 Commands

By default, a T3 interface on a 6-Port Channelized T3 line card is channelized into 28 T1 interfaces. This section describes the commands you use to customize and test a channelized T3 interface. This section discusses

- [Entering Controller Configuration Mode for T3, page 8-9](#)
- [Configuring a T3 Interface as Channelized, page 8-10](#)
- [Specifying the Cable Length, page 8-10](#)
- [Setting the Framing Type, page 8-11](#)
- [Entering MDL Messages, page 8-11](#)
- [Specifying the Idle Pattern, page 8-12](#)
- [Setting the Clock Source, page 8-13](#)
- [Configuring Loopback Mode, page 8-13](#)
- [Running Equipment Loopbacks, page 8-14](#)

To use the channels for subscriber traffic, you must configure the T1 and DS0 components. For more information, see the “[Channel-Group Command for DS0 Timeslots and T1s](#)” section on page 8-14.

[Figure 8-1](#) shows the levels of configurable interface bandwidth that channelization offers.

## Entering Controller Configuration Mode for T3

You may need to enter controller configuration mode for actions involving the T3 interface. For example, enter this mode to change an unchannelized T3 interface back to a channelized one or to set MDL messages.

```
controller T3 slot/sub-slot/port
```


The following example shows how to enter controller configuration mode:

```
Router(config)# controller T3 1/0/0
Router(config-controller)#
```

**Figure 8-1 Channelization of T3s**

A fully channelized T3  
can be broken into 28 T1s...

...each of which contains 24 56-KB  
(or 64-KB) timeslots (numbered 0 to 23).



38544

## Configuring a T3 Interface as Channelized

A T3 interface is channelized by default. Use the **channelized** command if you had previously made the interface unchannelized and want to change the setting.

```
[no] channelized
channelized
```

**Caution**

The **no channelized** command removes all channel groups from a channelized T3 interface. If you have already configured channel groups, use this command with caution.

The following example shows the creation of a channelized T3 interface:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# channelized
```

## Specifying the Cable Length

To specify the cable length for the T3 controller, use the **cablelength** command.

```
cablelength feet
[no] cablelength feet
```

Where *feet* is a number from 0 to 450.

The default value is 249 feet.

Use the **no** form of this command to restore the default cable length.

In the following example, the cablelength value is set to 40 feet.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# cablelength 40
```

**Note**

This command causes the system to use one of two settings for impedance matching and pulse shaping, one setting for any cable length between 0 and 249 feet and another setting for any cable length greater than 250 feet. The exact value you enter is stored in the configuration file.

## Setting the Framing Type

To specify a framing type for the channelized T3 controller, use the **framing** command.

```
framing [c-bit | m23 | auto-detect]
[no] framing [c-bit | m23 | auto-detect]
```

The default is auto-detect.

Use the **no** form of the command to return the framing type to its default.

You can instruct the 6-Port Channelized T3 line card to detect the framing type from the far end and transmit that same framing type as follows:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# framing auto-detect
```

## Entering MDL Messages

You can configure maintenance data link (MDL) messages (as defined in the ANSI T1.107a-1990 specification) on the channelized T3 interface.

**Note**

MDL messages are supported only when the T3 framing is set for C-bit parity. (See the [“Setting the Framing Type”](#) section on page 8-11.)

To configure MDL messages, use the **mdl** command.

```
mdl {transmit {path | idle-signal | test-signal} | string {eic | lic | fic | unit | pfi | port
| generator} id_string}
[no] mdl {transmit {path | idle-signal | test-signal} | string {eic | lic | fic | unit | pfi |
port | generator} id_string}
```

Where:

- **transmit path** enables transmission of the MDL path message.
- **transmit idle-signal** enables transmission of the MDL idle-signal message.
- **eic** is the equipment identification code (up to 10 characters).
- **lic** is the location identification code (up to 11 characters).
- **fic** is the frame identification code (up to 10 characters).
- **unit** is the unit identification code (up to 6 characters).
- **pfi** is the facility identification code to include in the MDL path message (up to 38 characters).
- **port** is the equipment port (which initiates the idle signal) to include in the MDL idle signal message (up to 38 characters).
- **generator** is the generator number to include in the MDL test signal message (up to 38 characters).

The default is that no MDL message is configured.

Use the **no** form of the command to remove an MDL message.

Examples of configuring MDL messages follow:

- Enable the MDL path message transmission.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# mdl transmit path
```

- Enable the MDL idle signal message transmission.

```
Router(config-controller)# mdl transmit idle-signal
```

- Enable the MDL test signal message transmission.

```
Router(config-controller)# mdl transmit test-signal
```

- Enter the equipment identification code.

```
Router(config-controller)# mdl string eic router A
```

- Enter the location identification code.

```
Router(config-controller)# mdl string lic test network
```

- Enter the frame identification code.

```
Router(config-controller)# mdl string fic building b
```

- Enter the unit identification code.

```
Router(config-controller)# mdl string unit abc
```

- Enter the facility identification code.

```
Router(config-controller)# mdl string pfi string
```

- Enter the port number to send in the MDL idle signal message.

```
Router(config-controller)# mdl string port string
```

- Enter the generator number to send in the MDL test signal message.

```
Router(config-controller)# mdl string generator string
```

## Specifying the Idle Pattern

You can set a specific pattern to be transmitted between HDLC packets on all unconfigured timeslots that belong to a channelized T3 interface. To do so, use the **idle pattern** command.

```
idle pattern patterns
[no] idle pattern patterns
```

Where *patterns* is a number in the range of 0x0 to 0xff (hexadecimal) or 0 to 255 (decimal). You can enter this value in either hexadecimal or decimal form. Values of 0 to 254 set the idle pattern to HDLC flags (0x7e); a value of 255 sets the pattern to 0xff (all ones).



### Note

Some systems interpret marks, 0xff, as an abort signal. Therefore, flags, 0x7e, is preferred.

The default idle pattern is 0x7e.



Use the **no** form of the command to return the idle pattern to its default value.

Examples:

- Set a hexadecimal idle pattern.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# idle pattern 0x10
```

- Set a decimal idle pattern.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# idle pattern 23
```

## Setting the Clock Source

At the prompt, set the internal or line clock source for the selected T3 controller using the **clock source** command. This command is set in controller configuration mode.

```
clock source {internal | line}
```

Where:

- **internal** specifies that the internal clock source is used
- **line** specifies that the network clock source is used

The default is clock source internal.

In this example, a T3 controller is instructed to use a line clock source.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# clock source line
```

## Configuring Loopback Mode

You can configure the T3 controller for a loopback mode using the **loopback** command.

```
loopback [local | network | remote]
[no] loopback [local | network | remote]
```

Local and network loopbacks are the same.

To cancel a loopback, use the **no** form of the command.

For more information on the **loopback** command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Examples:

- Configure the T3 controller for local loopback.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# loopback local
```

- Configure the T3 controller for remote loopback.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# loopback remote
```

## Running Equipment Loopbacks

Use the **equipment loopback** command to run loopbacks in conjunction with remote equipment.

```
equipment [customer | network] loopback
[no] equipment [customer | network] loopback
```

Where:

- **customer** enables the line card to respond to remote T3 loopback commands from the remote T3 equipment.
- **network** causes the line card to ignore remote T3 loopback commands.

Use the **no** form of the command to terminate the loopback.

For more information on the **loopback** command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

In the following example, an equipment network loopback is configured:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# equipment network loopback
```

## Channel-Group Command for DS0 Timeslots and T1s

Each channelized T3 consists of 28 T1s, each of which is divided into 24 timeslots (or DS0s). To create an interface that supports subscriber traffic, you must combine the timeslots into channel groups. Use the **t1 channel-group** command to create a channel group.

Channel groups have these characteristics:

- A channel group is an interface.
- A channel group can be one timeslot to 24 timeslots in size.
  - A channel group that consists of 24 timeslots is a T1 interface.
  - A channel group that consists of fewer than 24 timeslots can be described as a fractional T1 interface.
- Each group of 24 timeslots can be divided into multiple fractional T1 interfaces.
- A channel group cannot be part of more than one T1.

[Figure 8-1](#) illustrates channelization possibilities on the 6-Port Channelized T3 line card.

You create a logical channel group using the following command:

```
t1 t1-number channel-group channel-group-number timeslots list-of-timeslots [speed {56 | 64}]
[no] t1 t1-number channel-group channel-group-number
```

Where:

- *t1-number* is T1 interface number 1 to 28.
- **channel-group** *channel-group-number* identifies the channel group with any number from 0 to 23.

- **timeslots** *list-of-timeslots* can be 1 to 24 or a combination of subranges within 1 to 24. You can indicate a range using a hyphen, commas, or a combination of both. One timeslot equals one DS0. Refer to the examples below.
- **speed** {56|64} is an optional argument that specifies the speed of a timeslot as either 56 or 64 kbps. The default is 64. (The 56-kbps timeslots are generally used with older T1 equipment that does not support B8ZS and are associated with SF framing.)

Use the **no** form of the command to remove a logical channel group.

The following examples show how to use the **t1 channel-group** command:

- In this example, T1 interface 3 includes channel group 20 and consists of nine channelized timeslots:

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 3 channel-group 20 timeslots 1-8, 10
```

To enter interface configuration mode for this channel group, enter the following:

```
Router(config)# interface serial 1/0/0/3:20
```

- In the following example, T1 interface 4 includes channel group 18 and consists of all 24 timeslots, creating a full T1 interface:

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 4 channel-group 18 timeslots 1-24
```

To enter interface configuration mode for this channel group, you enter the following:

```
Router(config)# interface serial 1/0/0/4:18
```

- In the following example, T1 interface number 5 is divided into three channel groups, which total 11 timeslots:

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 5 channel-group 19 timeslots 1-6
Router(config-controller)# t1 5 channel-group 20 timeslots 10
Router(config-controller)# t1 5 channel-group 21 timeslots 7-9, 24
```

- In the following example, channel group 20 is removed:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# no t1 1 channel-group 20
```

## Channelized T1 Commands

From controller configuration mode for a T3 interface, you can enter commands to modify aspects of a T1 interface. This section describes the commands for

- [Setting the Framing Format, page 8-16](#)
- [Controlling Yellow Alarms, page 8-16](#)
- [Setting the Clock Source, page 8-17](#)
- [Configuring FDL, page 8-17](#)
- [Configuring a BER Test, page 8-17](#)
- [Configuring Loopback Mode, page 8-18](#)

After you configure a T1 interface, you can add encapsulation, routing, and other instructions by entering interface configuration mode. For example:

```
Router(config)# interface serial 1/0/0/4:18
```

## Setting the Framing Format

You can specify the T1 interface framing format using the following command:

```
t1 t1-number framing {esf | sf [hdlc-idle {0x7E | 0xFF}]}
[no] t1 t1-number framing {esf | sf [hdlc-idle {0x7E | 0xFF}]}
```

Where:

- *t1-number* is T1 interface number 1 to 28.
- **framing** is either extended super frame (ESF) or super frame (SF). You can set SF hdlc-idle to 0x7E or 0xFF.
- **hdlc-idle** options allow you to set the idle pattern for the T1 interface to either 0x7e (the default) or 0xff.

The default framing format is extended super frame (ESF).

Use the **no** form of the command to return framing to its default value.

Examples:

- Set SF framing format for T1 interface 6.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# t1 6 framing sf
```

- Set ESF framing format for T1 interface 16.

```
Router(config)# controller T3 1/0/0
Router(config-controller)# t1 16 framing esf
```

## Controlling Yellow Alarms

Use the **t1 yellow** command to turn the detection or generation of a yellow alarm on or off.

```
t1 t1-number yellow {detection | generation}
[no] t1 t1-number yellow {detection | generation}
```

Where:

- *t1-number* is T1 interface 1 to 28
- **detection** means that the interface is told it is failing by the remote device, causing IOS to send a message to the console
- **generation** means that the interface notifies the remote device if it is failing, causing IOS to send a message to the console

When you select SF framing for a full T1 interface (24 timeslots) that uses the default speed of 64, consider using the **no t1-number yellow detection** command to turn off yellow alarm detection, because the yellow alarm can be incorrectly detected with SF framing.

In the following example, T1 interface 1 is set to yellow detection:

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 1 yellow detection
```

## Setting the Clock Source

You can set the internal or line (network) clock source for a T1 interface using the **controller** command.

```
t1 t1-number clock source {internal | line}
```

Where:

- *t1-number* is T1 interface 1 to 28
- **internal** specifies that the internal clock source is used
- **line** specifies that the network clock source is used

The default is clock source internal.

In the following example, the interface is instructed to get its clock source from the line:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# t1 1 clock source line
```

## Configuring FDL

You can enable 1-second transmissions of performance reports through the facility data link (FDL) according to the specification ANSI T1.403, on both ends of the T1 connection. To do so, use the following command:

```
t1 t1-number fdl ansi
[no] t1 t1-number fdl ansi
```

Where *t1-number* is T1 interface 1 to 28.

Use the **no** form of the command to disable this feature.



### Note

---

You can use this command only when the T1 framing is ESF.

---

In the following example, FDL is enabled:

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 2 fdl ansi
```

## Configuring a BER Test

You can configure an individual T1 interface to run an independent BER test. The test is used to check cables and solve signal problems in the field. To send a BER test pattern on a T1 interface, use the following command:

```
t1 t1-number bert pattern pattern interval time [unframed]
[no] t1 t1-number bert
```

Where:

- *t1-number* is T1 interface number 1 to 28.
- *time* is 1 to 14,400 minutes.

- *pattern* is
  - 0s—repetitive test pattern of all zeros (00000..)
  - 1s—repetitive test pattern of all ones (11111..)
  - 2<sup>11</sup>—pseudorandom test pattern (2048 bits long)
  - 2<sup>15</sup>—pseudorandom O.151 test pattern (32,768 bits long)
  - 2<sup>20</sup>-O153—pseudorandom O.153 test pattern (1,048,575 bits long)
  - 2<sup>20</sup>-QRSS—pseudorandom QRSS O.151 test pattern (1,048,575 bits long)
  - 2<sup>23</sup>—pseudorandom O.151 test pattern (8,388,607 bits long)
  - alt-0-1—repetitive alternating test pattern of zeros (0s) and ones (1s), for example 01010101
- **unframed** causes the BER test pattern to use the entire T1 bandwidth, including the T1 framing and payload bits. If **unframed** is omitted, the T1 is either SF or ESF framed as configured by the T1 n framing command, and the BER test pattern occupies only the T1 payload bits.




---

**Note** For each T3, you can run only one BER test at a time.

---

You can terminate a BER test at any time using the **no** form of the command.

For more information, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Examples:

- Send a BER test pseudorandom pattern of 2<sup>20</sup> through T1 interface 10 for 5 minutes.
 

```
Router(config)# controller T3 1/0/0
Router(config-controller)# t1 10 bert pattern 2^20 interval 5 unframed
```
- Send a repetitive pattern of all 1s through T1 interface 10 for 14,400 minutes (240 hours).
 

```
Router(config)# controller T3 1/0/0
Router(config-controller)# t1 10 bert pattern 1s interval 14400 unframed
```

## Configuring Loopback Mode

If problems occur when you configure a T1 interface, you can troubleshoot the line card by using the following command from controller configuration mode:

```
t1 t1-number loopback [local | network {line | payload} | remote [line [fdl {ansi | bellcore} | inband] | payload [fdl | ansi]]]
[no] t1 t1-number loopback
```

Where:

- *t1-number* is T1 interface 1 to 28.
- **local** loops the router output data back toward the router at the T1 framer and sends an alarm indication signal (AIS) out toward the network.
- **network {line | payload}** loops the data back toward the network and automatically sets a local loopback at the HDLC controllers (line) or loops the payload data back toward the network and automatically sets a local loopback at the HDLC controller (payload).
- **remote line fdl {ansi | bellcore}** sends a repeating, 16-bit ESF data link keyword to the remote end, requesting that it enter into a network line loopback. You can specify an ANSI or Bellcore keyword.




---

**Note** Loopback codes are defined in ANSI T1.404-1989 Table 3 (Assigned Bit-Oriented ESF Data-Link Messages)

---

The 6-Port Channelized T3 line card sends the following code for remote line fdl ANSI loopback:

- Line Loopback Active Code: 0 000111 01111111
- Line Loopback Deactivate Code: 0 010010 01111111

The 6-Port Channelized T3 line card sends the following code for remote line FDL Bellcore (SmartJack) loopback:

- Network Use (loopback active) Code: 0 001001 01111111
- Network Use (loopback deactivate) Code: 0 010010 01111111
- **remote line inband** sends a repeating inband pattern to the remote end, requesting entry into a network line loopback. The inband loopback request overwrites all data in the T1 with the loop request pattern. The remote end responds to this code only after it receives the pattern continuously for at least five seconds.
  - Repeating Inband Loopback Activate Code: 00001
  - Repeating Inband Loopback Deactivate Code: 001
- **remote payload [fdl] [ansi]** sends a repeating, 16-bit ESF data link code word to the remote end, requesting entry into a network payload loopback. Using **fdl** and **ansi** enables the remote payload facility data link (FDL) ANSI bit loopback on the T1 channel.




---

**Note** Loopback codes are defined in ANSI T1.404-1989 Table 3 (Assigned Bit-Oriented ESF Data-Link Messages)

---

The 6-Port Channelized T3 line card sends the following code for remote payload fdl ANSI loopback:

- Payload Loopback Active Code: 0 001010 01111111
- Payload Loopback Deactivate Code: 0 011001 01111111

Use the **no** form of the command to terminate a loopback.

For more information on this command, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

Examples:

- Configure the T3 controller for local loopback on T1 interface 1.

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 1 loopback local
```

- Configure the T3 controller for remote FDL ANSI loopback on T1 interface 1.

```
Router(config)# controller t3 1/0/0
Router(config-controller)# t1 1 loopback remote line fdl ansi
```







## **PART 3**

### **Fast Ethernet and Gigabit Ethernet Line Cards**





# CHAPTER 9

## 8-Port Fast Ethernet Half-Height Line Card Configuration

This chapter describes procedures for configuring the Cisco 10000 series 8-Port Fast Ethernet Half-Height line card, hereafter known as the 8-Port Fast Ethernet Half-Height line card.

The 8-Port Fast Ethernet Half-Height line card contains eight 100BASE-TX ports. Each port autonegotiates between half and full duplex mode. Each port supports 100BASE-T, but does not support 10BASE-T.

This chapter contains the following sections:

- [Software Support, page 9-1](#)
- [Default Values, page 9-2](#)
- [Management Port, page 9-2](#)
- [Configuring the Interface, page 9-3](#)



### Note

For information about installing half-height line cards in subslot locations, see the [Cisco 10000 Series Router Line Card Hardware Installation Guide](#).

## Software Support

[Table 9-1](#) shows the minimum Cisco IOS release on each release train that supports the 8-Port Fast Ethernet Half-Height line card.

**Table 9-1** 8-Port Fast Ethernet Half-Height Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE1	Cisco IOS Release 12.0(23)S and later releases of Cisco IOS 12.0S
PRE2	Cisco IOS Release 12.2(15)BX and later releases of Cisco IOS 12.2BX Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS 12.3 XI Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Default Values

Table 9-2 lists default values for the 8-Port Fast Ethernet Half-Height line card.

**Table 9-2 8-Port Fast Ethernet Half-Height Line Card Defaults**

Parameter	Default Setting	Description
Speed	100 Mbps	You cannot use the <b>speed</b> command. The speed is advertised as 100 Mbps to the remote device.
Duplex	Autonegotiated	See the “ <a href="#">Specifying Full or Half Duplex Mode</a> ” section on page 9-4 to manually set the duplex value.  <b>Note</b> The Fast Ethernet line card only responds to 802.3x pause frames from another device when it autonegotiates the duplex mode (the default). The line card does not support 802.3x flow control when you manually set half-duplex or full-duplex mode.

## Management Port

The Fast Ethernet interface 0/0/0 is reserved for management purposes only and cannot be used for such things as customer traffic or L2TP establishment. This interface also does not allow you to configure subinterfaces. However, the interface does allow **radius**, **snmp**, or **telnet** commands.

# Configuring the Interface

To configure the 8-Port Fast Ethernet Half-Height line card interface, perform the following tasks:

- [Specifying the Interface for Configuration](#)
- [Configuring the IP Address](#)
- [Specifying Full or Half Duplex Mode](#) (optional)
- [Configuring 802.1Q VLAN Encapsulation](#) (optional)
- [Configuring Routing](#)
- [Saving the Configuration](#)
- [Viewing the Configuration](#) (optional)
- [Disabling the Interface](#) (optional)

For quick reference, refer to the configuration task commands below:

```
Router# configure terminal
Router(config)# interface FastEthernet slot/subslot/port
Router(config-if)# ip address ip-address mask
Router(config-if)# [no] {full-duplex | half-duplex} (optional)
Router(config-if)# [no] encapsulation dot1q vlan-id [native] (optional)
Router(config-if)# exit
Router(config)# router rip (For instance, use to configure RIP)
Router(config-router)# network ip-address
Router(config-router)# end
Router# copy running-config startup-config
```

## Specifying the Interface for Configuration

Follow these steps to specify the interface that you want to configure:

---

**Step 1** Enter global configuration mode by entering:

```
Router# configure terminal
```

**Step 2** Specify the interface you want to configure by entering:

```
Router(config)# interface FastEthernet slot/subslot/port
```

- *slot*—1 to 8 on the Cisco 10008 series router; 1 to 5 on the Cisco 10005 series router (slots 0A and 0B are used for the PREs).
- *subslot*—0 or 1. 0 is the top subslot.
- *port*—0 to 7.

**Note** Fast Ethernet 0/0/0 is reserved for management purposes only. Do not use this interface for such things as customer traffic or L2TP establishment. This interface does not allow you to configure subinterfaces.

---

## Configuring the IP Address

To set the IP address of the interface, enter the following command:

```
Router(config-if)# ip address ip-address mask
```

## Specifying Full or Half Duplex Mode

If the negotiation of the duplex mode fails, and a duplex mode mismatch occurs, manually set the duplex mode.



### Note

The 8-Port Fast Ethernet Half-Height line card only responds to 802.3x pause frames from another device when it autonegotiates the duplex mode (the default). The line card does not support 802.3x flow control when you manually set half-duplex or full-duplex mode.

Set the duplex mode using the following command:

```
Router(config-if)# [no] {half-duplex | full-duplex}
```

The **no** option disables the duplex setting. If no duplex mode is set, the mode reverts to autonegotiation.

## Configuring 802.1Q VLAN Encapsulation

The 8-Port Fast Ethernet Half-Height line card supports 802.1Q VLAN encapsulation. The card does not support Inter-Switch Link (ISL) encapsulation. To set 802.1Q encapsulation, enter:

```
Router(config-if)# [no] encapsulation dot1q vlan-id [native]
```

- *vlan-id*—The VLAN identifier, between 1 and 1000.
- **native**—Sets the Port VLAN ID (PVID) value of the port to the *vlan-id* value.
- **no**—Disables encapsulation.

## Configuring Routing

See the [Cisco IOS Command References](#) for information about configuring routing protocols, such as RIP or OSPF.

## Saving the Configuration

After completing your configuration changes, save the configuration by following these steps:

---

**Step 1** To exit configuration mode, either enter **Ctrl-Z** or enter the following command:

```
Router(config-if)# end
```

**Step 2** Write the new configuration to memory by entering:

```
Router# copy running-config startup-config
```

When the configuration is stored, an OK message appears.

---

## Viewing the Configuration

You can check the configuration using the following command:

```
Router# show interface FastEthernet slot/subslot/port
```

## Disabling the Interface

The interface is enabled by default. To disable it, enter:

```
Router(config-if)# shutdown
```

To enable the interface, enter:

```
Router(config-if)# no shutdown
```







# CHAPTER 10

## 1-Port Gigabit Ethernet Half-Height Line Card Configuration

This chapter describes procedures for configuring the Cisco 10000 series 1-Port Gigabit Ethernet Half-Height line card, hereafter known as the 1-Port Gigabit Ethernet Half-Height line card.

The 1-Port Gigabit Ethernet Half-Height line card contains a single Gigabit Ethernet port that provides a trunk uplink to switches and core routers.

This chapter contains the following sections:

- [Software Support, page 10-1](#)
- [Default Values, page 10-2](#)
- [Interface Syntax, page 10-2](#)
- [Configuring an Interface, page 10-3](#)
- [Configuration Commands, page 10-3](#)



**Note**

For information about installing half-height line cards in subslot locations, see the [Cisco 10000 Series Router Line Card Hardware Installation Guide](#).

## Software Support

[Table 10-1](#) shows the minimum Cisco IOS release on each release train that supports the 1-Port Gigabit Ethernet Half-Height line card.

**Table 10-1** 1-Port Gigabit Ethernet Half-Height Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE1	Cisco IOS Release 12.0(23)S and later releases of Cisco IOS 12.0S
PRE2	Cisco IOS Release 12.2(15)BX and later releases of Cisco IOS 12.2BX Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS 12.3 XI Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB
PRE3	Cisco IOS Release 12.2(31)SB2 and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Default Values

Table 10-2 lists default values for the 1-Port Gigabit Ethernet Half-Height line card. This table also includes the command used for modifying a default value and indicates if a value needs to be the same (or opposite) on the remote end of the connection.

**Table 10-2 1-Port Gigabit Ethernet Half-Height Line Card Defaults**

Command Name	Default Setting	Command Syntax	Remote Side Setting
auto-negotiation	Enabled	<code>[no] negotiation auto</code>	Same
mtu (maximum transmission unit)	<ul style="list-style-type: none"> <li>1500 to 4470 (full-height)</li> <li>1500 to 9180 (half-height)</li> </ul>	<code>mtu size</code>	Same

## Interface Syntax

To specify an interface number in a configuration command, use the syntax in Table 10-3 to identify interfaces on the 1-Port Gigabit Ethernet Half-Height line card.

**Table 10-3 1-Port Gigabit Ethernet Half-Height Interface Syntax**

Slot	Subslot	Port
1 to 8/	0 or 1/	0

The following example shows the syntax for configuring a 1-Port Gigabit Ethernet Half-Height line card in slot 1:

```
Router(config)# interface GigabitEthernet 1/0/0
Router(config-if)#
```

## Configuring an Interface

Use the following procedure to create a basic configuration (enabling an interface and specifying IP routing) for a 1-Port Gigabit Ethernet Half-Height line card interface. Be prepared with the information you need, such as the interface IP address.

- 
- Step 1** At the global configuration prompt, specify the new interface to configure by entering the **interface** command.
- ```
Router(config)# interface GigabitEthernet 1/0/0
```
- Step 2** Assign an IP address and subnet mask to the interface using the **ip address** configuration subcommand, as in the following example:
- ```
Router(config-if)# ip address 192.168.172.12 255.255.255.0
```
- Step 3** If necessary, modify the 1-Port Gigabit Ethernet Half-Height line card configuration or that of the remote device to ensure that, where appropriate, they use the same settings. For more information, refer to the Remote Side Setting column in [Table 10-2](#).
- Step 4** Add any other configuration subcommands required for the enabling of routing protocols and adjust the interface characteristics.
- Step 5** Enter the **no shutdown** command to enable the interface.
- ```
Router(config-if)# no shutdown
```
- Step 6** When you have included all of the configuration subcommands to complete the configuration, enter **Ctrl-Z** to exit configuration mode.
- Step 7** Write the new configuration to memory.
- ```
Router# copy running-config startup-config
```

When the configuration is stored, the system displays an OK message.

---

After you complete the configuration, you can check the configuration using the **show interface GigabitEthernet slot/subslot/port** command.

## Configuration Commands

This section lists some of the commands that you can use to further customize your 1-Port Gigabit Ethernet Half-Height line card configuration. The commands described in this section are for:

- [Specifying Auto-Negotiation, page 10-3](#)
- [Assigning a MAC Address, page 10-4](#)
- [Setting and Changing Loopback Mode, page 10-4](#)

## Specifying Auto-Negotiation

To enable auto-negotiation, enter the **negotiation auto** command.

```
negotiation auto  
[no] negotiation auto
```

The default configuration is auto-negotiation enabled.

Use the **no** form of the command to disable negotiation.

**Note**


---

Both sides must be enabled for auto-negotiation, or the link does not come up.

---

In the following example, negotiation is disabled:

```
Router(config)# interface GigabitEthernet 1/0/0
Router(config-if)# no negotiation auto
```

## Assigning a MAC Address

To assign a specific MAC address to a 1-Port Gigabit Ethernet Half-Height line card interface, use the **mac-address** command:

```
mac-address address
[no] mac-address address
```

Where *address* assigns a user-defined MAC address to a Gigabit Ethernet interface. The MAC address takes the form *xxxx.xxxx.xxxx*, where *xxxx* represents a 2-byte hexadecimal value.

**Tip**


---

Use the **mac-address** command to preserve a MAC address when you move a card to a new slot or chassis. You may want to preserve the MAC address if you have an access list that refers to it. If you use this command, you should change the address on the original slot so that you do not have two slots with the same address.

---

Use **no mac-address** to restore the default MAC address.

Use the **show interfaces GigabitEthernet slot/subslot/port** command to see the MAC address.

In the following example, a new MAC address is assigned:

```
Router(config)# interface GigabitEthernet 1/0/0
router(config-if)# mac-address 6000.0001.0003
```

## Setting and Changing Loopback Mode

To set the loopback mode on a 1-Port Gigabit Ethernet Half-Height line card interface, use the **loopback** command in interface configuration mode.

```
loopback [internal | external]
[no] loopback [internal | external]
```

Where:

- **external** runs a loopback that requires a loopback connector.
- **internal** runs a loopback at the MAC controller.

Use the **no** form of the command to stop the loopback.

For more information about this command, refer to the [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

In the following example, an internal loopback mode is defined for a 1-Port Gigabit Ethernet Half-Height line card interface:

```
router(config)# interface GigabitEthernet 1/0/0
router(config-if)# loopback internal
```





# CHAPTER 11

## 1-Port Gigabit Ethernet Line Card Configuration

This chapter describes procedures for configuring the Cisco 10000 series 1-Port Gigabit Ethernet line card, hereafter known as the 1-Port Gigabit Ethernet line card.

The 1-Port Gigabit Ethernet line card provides:

- A trunk uplink to the core for Gigabit Ethernet aggregation
- The Cisco 10000 system with an IEEE 802.3z-compliant Ethernet interface running at 1 Gbps in full-duplex mode

This chapter contains the following sections:

- [Software Support, page 11-1](#)
- [Default Values, page 11-2](#)
- [Interface Syntax, page 11-2](#)
- [Configuring an Interface, page 11-3](#)
- [Configuration Commands, page 11-3](#)

## Software Support

[Table 11-1](#) shows the minimum Cisco IOS release on each release train that supports the 1-Port Gigabit Ethernet line card.

**Table 11-1** 1-Port Gigabit Ethernet Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE1	Cisco IOS Release 12.0(22)S and later releases of Cisco IOS 12.0S
PRE2	Cisco IOS Release 12.0(22)S and later releases of Cisco IOS 12.0S Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS Release 12.3XI Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB
PRE3	Cisco IOS Release 12.2(31)SB2 and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Default Values

Table 11-2 lists default values for the 1-Port Gigabit Ethernet line card. This table also includes the command used for modifying a default value and indicates if a value needs to be the same (or opposite) on the remote end of the connection.

**Table 11-2 1-Port Gigabit Ethernet Line Card Defaults**

Command Name	Default Setting	Command Syntax	Remote Side Setting
auto-negotiation	Enabled	<code>[no] negotiation auto</code>	Same
mtu (maximum transmission unit)	<ul style="list-style-type: none"> <li>1500 to 4470 (full-height)</li> <li>1500 to 9180 (half-height)</li> </ul>	<code>mtu size</code>	Same

## Interface Syntax

To specify an interface number in a configuration command, use the syntax in Table 11-3 to identify interfaces on the 1-Port Gigabit Ethernet line card.

**Table 11-3 1-Port Gigabit Ethernet Interface Syntax**

Slot	Subslot	Port
1 to 8/	0 or 1/	0

The following example shows the syntax for configuring a 1-Port Gigabit Ethernet line card in slot 1:

```
Router(config)# interface GigabitEthernet 1/0/0
Router(config-if)#
```



# Configuring an Interface

Use the following procedure to create a basic configuration (enabling an interface and specifying IP routing) for a 1-Port Gigabit Ethernet line card interface. Be prepared with the information you need, such as the interface IP address.

- 
- Step 1** At the global configuration prompt, specify the new interface to configure by entering the **interface** command.
- ```
Router(config)# interface GigabitEthernet 1/0/0
```
- Step 2** Assign an IP address and subnet mask to the interface using the **ip address** configuration subcommand, as in the following example:
- ```
Router(config-if)# ip address 192.168.172.12 255.255.255.0
```
- Step 3** If necessary, modify the 1-Port Gigabit Ethernet line card line card configuration or that of the remote device to ensure that, where appropriate, they use the same settings. For more information, refer to the Remote Side Setting column in [Table 11-2](#).
- Step 4** Add any other configuration subcommands required for the enabling of routing protocols and adjust the interface characteristics.
- Step 5** Enter the **no shutdown** command to enable the interface.
- ```
Router(config-if)# no shutdown
```
- Step 6** When you have included all of the configuration subcommands to complete the configuration, enter **Ctrl-Z** to exit configuration mode.
- Step 7** Write the new configuration to memory.
- ```
Router# copy running-config startup-config
```

When the configuration is stored, the system displays an OK message.

---

After you complete the configuration, you can check the configuration using the **show interface GigabitEthernet slot/subslot/port** command.

## Configuration Commands

This section lists some of the commands that you can use to further customize your 1-Port Gigabit Ethernet line card configuration. The commands described in this section are for:

- [Specifying Auto-Negotiation, page 11-4](#)
- [Assigning a MAC Address, page 11-4](#)
- [Setting and Changing Loopback Mode, page 11-5](#)

## Specifying Auto-Negotiation

To enable auto-negotiation, enter the **negotiation auto** command.

```
negotiation auto
[no] negotiation auto
```

The default configuration is auto-negotiation enabled.

Use the **no** form of the command to disable negotiation.



### Note

---

Both sides must be enabled for auto-negotiation, or the link does not come up.

---

In the following example, negotiation is disabled:

```
Router(config)# interface GigabitEthernet 1/0/0
Router(config-if)# no negotiation auto
```

## Assigning a MAC Address

To assign a specific MAC address to a 1-Port Gigabit Ethernet line card interface, use the **mac-address** command:

```
mac-address address
[no] mac-address address
```

Where *address* assigns a user-defined MAC address to a Gigabit Ethernet interface. The MAC address takes the form *xxxx.xxxx.xxxx*, where *xxxx* represents a 2-byte hexadecimal value.



### Tip

---

Use the **mac-address** command to preserve a MAC address when you move a card to a new slot or chassis. You may want to preserve the MAC address if you have an access list that refers to it. If you use this command, you should change the address on the original slot so that you do not have two slots with the same address.

---

Use **no mac-address** to restore the default MAC address.

Use the **show interfaces GigabitEthernet slot/subslot/port** command to see the MAC address.

In the following example, a new MAC address is assigned:

```
Router(config)# interface GigabitEthernet 1/0/0
router(config-if)# mac-address 6000.0001.0003
```

## Setting and Changing Loopback Mode

To set the loopback mode on a 1-Port Gigabit Ethernet line card interface, use the **loopback** command in interface configuration mode.

```
loopback [internal | external]
[no] loopback [internal | external]
```

Where:

- **external** runs a loopback that requires a loopback connector.
- **internal** runs a loopback at the MAC controller.

Use the **no** form of the command to stop the loopback.

For more information about this command, refer to the [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

In the following example, an internal loopback mode is defined for a 1-Port Gigabit Ethernet line card interface:

```
router(config)# interface GigabitEthernet 1/0/0
router(config-if)# loopback internal
```





## **PART 4**

### **Packet over SONET Line Cards**





# CHAPTER 12

## 6-Port OC-3/STM-1 Packet over SONET Line Card Configuration

This chapter describes the procedures for configuring the Cisco 10000 series 6-Port OC-3/STM-1 Packet over SONET line card, hereafter known as the 6-Port OC-3/STM-1 Packet over SONET line card.

The 6-Port OC-3/STM-1 Packet over SONET line card provides 6 STS-3/STM-1 Packet over SONET trunk uplinks that support throughput of up to 155.52 Mbps each over a SONET/ITU-T Synchronous Digital Hierarchy (SDH) interface. Each port (0 to 5) has a single-mode optical fiber intermediate-reach LC connector.

This chapter contains the following sections:

- [Software Support, page 12-1](#)
- [Default Values, page 12-2](#)
- [Interface Syntax, page 12-3](#)
- [Configuring the Interface, page 12-3](#)
- [Configuration Commands, page 12-4](#)

### Software Support

[Table 12-1](#) shows the minimum Cisco IOS release on each release train that supports the 6-Port OC-3/STM-1 Packet over SONET line card.

**Table 12-1** 6-Port OC-3/STM-1 Packet over SONET Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE1	Cisco IOS Release 12.0(22)S and later releases of Cisco IOS Release 12.0S
PRE2	Cisco IOS Release 12.0(20)ST and later releases of Cisco IOS 12.0ST Cisco IOS Release 12.0(22)S and later releases of Cisco IOS Release 12.0S Cisco IOS Release 12.2(8)BZ and later releases of Cisco IOS Release 12.2BZ Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS 12.3XI Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Default Values

Table 12-2 lists default values and command syntax for the 6-Port OC-3/STM-1 Packet over SONET line card. Table 12-2 includes the command to modify a default value, and indicates if a value needs to be the same (or opposite) on the remote end of the connection.

**Table 12-2 6-Port OC-3/STM-1 Packet over SONET Line Card Defaults**

Command Name	Default Setting	Command Syntax	Remote Side Setting
bandwidth	155,000	<b>bandwidth</b> <i>kilobits</i>	Same.
clock source	line	<b>clock source</b> [ <b>line</b>   <b>internal</b> ]	At least one side must be set to <i>internal</i> .
crc	16	<b>crc</b> [ <b>16</b>   <b>32</b> ]	Same.
encapsulation	HDLC	<b>encapsulation</b> [ <b>hdlc</b>   <b>ppp</b> ]	Same.
keepalive	no keepalive	[ <b>no</b> ] <b>keepalive</b> <i>period</i>	Same.
loopback	no loopback	[ <b>no</b> ] <b>loopback</b> [ <b>line</b>   <b>internal</b> ]	Same
mtu (maximum transmission unit)	4470	<b>mtu</b> <i>size</i>	Same.
pos framing	SONET	<b>pos framing</b> [ <b>sonet</b>   <b>sdh</b> ]	Same.
pos scramble-atm	No scrambling	[ <b>no</b> ] <b>pos scramble-atm</b>	Same.
pos flag (SONET overhead)	c2—0xcf j0—0x01 s1s0—0	<b>pos flag</b> [ <b>c2</b>   <b>j0</b>   <b>s1s0</b> ] <i>value</i>	Same.



# Interface Syntax

To specify an interface number in a configuration command, use the syntax in [Table 12-3](#) to identify interfaces on the 6-Port OC-3/STM-1 Packet over SONET line card.

**Table 12-3** 6-Port OC-3/STM-1 Packet over SONET Line Card Interface Syntax

Type of Interface	Slot	Subslot	Port
Packet over SONET interface	1 to 8	0	0 to 5

The following example shows the syntax for configuring a 6-Port OC-3/STM-1 Packet over SONET line card in slot 1:

```
Router(config)# interface pos 1/0/0
```

## Configuring the Interface

After you verify that the 6-Port OC-3/STM-1 Packet over SONET line card is installed correctly, use the following procedure to configure the new interface. Be prepared with the information you will need, such as the interface IP address.

Use the following procedure to create a basic configuration—enable an interface and specify IP routing.

- 
- Step 1** At the global configuration prompt, specify the new interface to configure by entering the **interface pos** command and interface address. For example:
- ```
Router(config)# interface pos 1/0/1
```
- Step 2** Assign an IP address and a subnet mask to the interface using the **ip address** configuration subcommand, as in the following example:
- ```
Router(config-if)# ip address 192.168.255.255 255.255.255.0
```
- Step 3** Specify either HDLC or PPP encapsulation. For example:
- ```
Router(config-if)# encapsulation hdlc
```
- Step 4** If necessary, modify the 6-Port OC-3/STM-1 Packet over SONET line card configuration or that of the remote device to ensure that, where appropriate, they use the same settings. For more information, refer to the Remote Side Setting column in [Table 12-2](#).
- Step 5** Add any other configuration subcommands required for the enabling of routing protocols and adjust the interface characteristics.
- Step 6** Enter the **no shutdown** command to enable the interface.
- ```
Router(config-if)# no shutdown
```
- Step 7** When you have included all of the configuration subcommands to complete the configuration, enter **Ctrl-Z** to exit configuration mode.
- Step 8** Write the new configuration to memory.
- ```
Router# copy running-config startup-config
```

When the configuration has been stored, the system displays an OK message.

After you have completed your configuration, you can check it using the **show interface pos slot/subslot/port** command.

## Configuration Commands

The following sections present some of the commands that you can use to customize your 6-Port OC-3/STM-1 Packet over SONET line card configuration.



### Note

These configuration commands are specific to each port on the 6-Port OC-3/STM-1 Packet over SONET line card.

## Setting the Clock Source

You can set the internal or line clock source by using the **clock source** command.

```
clock source {internal | line}
```

Where:

- **internal** specifies that the internal clock source is used
- **line** specifies that the network clock source is used

The default is clock source line.

In this example, the line card is instructed to use a line clock source.

```
Router(config)# interface pos 3/0/2
Router(config-if)# clock source line
```

## Configuring Framing

You can use the **pos framing** command to set framing to SONET STS-3c or SDH STM-1 framing.

```
pos framing [sdh | sonet]
[no] pos framing
```

The default is SONET.



### Note

Your system must support SDH to use this option.

Use the **no** form of the command to restore the default framing mode.

In the following example, the framing type is set to SONET:

```
Router(config)# interface pos 5/0/1
Router(config-if)# no pos framing
```

## Specifying SONET Overhead

You can use the **pos flag** command to assign values for specific elements of the frame header. This command is typically used to meet a standards requirement or to ensure interoperability with another vendor's equipment.

```
pos flag [c2 value] [j0 value] [s1s0 value]
[no] pos flag [c2 value] [j0 value] [s1s0 value]
```

Where:

- **c2** is a path signal identifier, and *value* is one of the following:
  - 0xCF for PPP or HDLC without scrambling
  - 0x16 for PPP or HDLC with scrambling
- **j0** is the section trace byte, and *value* is 0x01 for interoperability with some SDH devices in Japan
- **s1s0** is part of the payload pointer byte, and *value* is 0 for OC-3c and 2 for AU-4

Use the **no** form of the command to restore the default values.

In the following example, the **c2** bit is set to 0xCF.

```
Router(config)# interface pos 4/0/02
Router(config-if)# pos flag c2 0xCF
```

## Controlling the S1 SONET Overhead Byte

In most situations, the default value for the S1 SONET overhead byte (0x0) does not need to be changed. Refer to the SONET standards for information about the possible values for the S1 SONET overhead byte and the definition of each value.

### Controlling a Transmitted S1 Overhead Byte

In Cisco IOS Release 12.2(28)SB, use the **pos flag s1-byte tx** command in interface configuration mode to control the transmission of the S1 SONET overhead byte.

```
pos flag s1-byte tx value
```

Where:

- *value* is in the range of 0x0 to 0xF
- 0x0 is the default value

In the following example the S1 SONET overhead byte is set to 0xF:

```
pos flag s1-byte tx 0xF
```

### Reacting to a Received S1 Overhead Byte

In Cisco IOS Release 12.2(28)SB, use the **pos flag s1-byte rx-communicate** command to direct the router to switch the clock source to internal when it receives an S1 SONET overhead byte with a value of 0xF. When the S1 SONET overhead byte changes from 0xF to any other value, the clock source reverts back to the clock source specified in the user configuration.

The S1 overhead byte is ignored by the receiving router unless the **pos flag s1-byte rx-communicate** command is issued.

```
pos flag s1-byte rx-communicate
no pos flag s1-byte rx-communicate
```

The following example directs the router to switch to internal clocking when it receives an S1 SONET overhead byte with a value of 0xF:

```
pos flag s1-byte rx-communicate
```

The default for the **pos flag s1-byte rx-communicate** command is disabled or off.

## Configuring Packet over SONET SPE Scrambling

You can use the **pos scramble-atm** command to scramble the Packet over SONET synchronous payload envelope (SPE). SONET payload scrambling applies a self-synchronous scrambler to the SPE of the interface to ensure sufficient bit transition density.

```
pos scramble-atm
[no] pos scramble-atm
```

The default is no Packet over SONET SPE scrambling.

Use the **no** form of the command to disable scrambling.

In the following example, scrambling is enabled:

```
Router(config)# interface pos 3/0/3
Router(config-if)# pos scramble-atm
```

## Configuring Loopback Testing

To enable loopback testing of data transmitted from the PRE line card to the 6-Port OC-3/STM-1 Packet over SONET line card and back, use the **loopback** command in interface configuration mode.

```
loopback [line | internal]
[no] loopback [line | internal]
```

Where:

- **loopback line** loops any data received at the 6-Port OC-3/STM-1 Packet over SONET line card network interface back into the network
- **loopback internal** loops any data sent out the 6-Port OC-3/STM-1 Packet over SONET line card back into the 6-Port OC-3/STM-1 Packet over SONET line card

Use the **no** form of the command to stop the loopback test.

For more information on loopbacks, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

In the following example, a loopback is set for the 6-Port OC-3/STM-1 Packet over SONET line card in slot 5:

```
Router(config)# interface pos 5/0/0
Router(config-if)# loopback line
```

## Configuring APS

The 6-Port OC-3/STM-1 Packet over SONET line card supports port-level automatic protection switching (APS). For information about APS redundancy commands, see the [Cisco 10000 Series Router Software Configuration Guide](#).





# CHAPTER 13

## 1-Port OC-12 Packet over SONET Line Card Configuration

---

This chapter describes procedures for configuring the Cisco 10000 series 1-Port OC-12 Packet over SONET line card, hereafter known as the 1-Port OC-12 Packet over SONET line card.

The 1-Port OC-12 Packet over SONET line card provides a trunk uplink that supports up to 622 Mbps throughput over a standard SONET/ITU-T Synchronous Digital Hierarchy (SDH) interface using a single-mode fiber intermediate-reach SC connector.

This chapter contains the following sections:

- [Software Support, page 13-1](#)
- [Default Values, page 13-2](#)
- [Interface Syntax, page 13-3](#)
- [Configuring the Interface, page 13-3](#)
- [Other Configuration Commands, page 13-4](#)

### Software Support

[Table 13-1](#) shows the minimum Cisco IOS release on each release train that supports the 1-Port OC-12 Packet over SONET line card.

**Table 13-1** 1-Port OC-12 Packet over SONET Line Card Software Support

| Required PRE | Minimum Cisco IOS Releases                                                                                                                                                                                     |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PRE1         | Cisco IOS Release 12.0(22)S and later releases of Cisco IOS 12.0S                                                                                                                                              |
| PRE2         | Cisco IOS Release 12.0(22)S and later releases of Cisco IOS 12.0S<br>Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS 12.3XI<br>Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB |

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Default Values

Table 13-2 lists default values for the 1-Port OC-12 Packet over SONET line card. This table includes the command used for modifying a default value and indicates whether a value needs to be the same (or opposite) on the remote end of the connection.

**Table 13-2 1-Port OC-12 Packet over SONET Line Card Defaults**

| Command Name                    | Default Setting              | Command Syntax                                                       | Remote Side Setting                                |
|---------------------------------|------------------------------|----------------------------------------------------------------------|----------------------------------------------------|
| bandwidth                       | 622000                       | <b>bandwidth</b> <i>kilobits</i>                                     | Same.                                              |
| clock source                    | line                         | <b>clock source</b> [ <b>line</b>   <b>internal</b> ]                | At least one side must be set to <i>internal</i> . |
| crc                             | 32                           | <b>crc</b> [ <b>16</b>   <b>32</b> ]                                 | Same.                                              |
| encapsulation                   | HDLC                         | <b>encapsulation</b> [ <b>hdlc</b>   <b>ppp</b> ]                    | Same.                                              |
| keepalive                       | no keepalive                 | [ <b>no</b> ] <b>keepalive</b> <i>period</i>                         | Same.                                              |
| mtu (maximum transmission unit) | 4470                         | <b>mtu</b> <i>size</i>                                               | Same.                                              |
| pos framing                     | SONET                        | <b>pos framing</b> [ <b>sonet</b>   <b>sdh</b> ]                     | Same.                                              |
| pos scramble-atm                | No scrambling                | [ <b>no</b> ] <b>pos scramble-atm</b>                                | Same.                                              |
| pos flag (SONET overhead)       | c2—0xcf<br>j0—0x01<br>s1s0—0 | <b>pos flag</b> [ <b>c2</b>   <b>j0</b>   <b>s1s0</b> ] <i>value</i> | Same.                                              |



# Interface Syntax

To specify an interface number in a configuration command, use the syntax in [Table 13-3](#) to identify interfaces on the 1-Port OC-12 Packet over SONET line card.

**Table 13-3 1-Port OC-12 Packet over SONET Interface Syntax**

| Type of Interface           | Slot    | Subslot | Port |
|-----------------------------|---------|---------|------|
| Packet over SONET interface | 1 to 8/ | 0/      | 0    |

The following example shows the syntax for configuring an 1-Port OC-12 Packet over SONET line card in slot 1:

```
Router(config)# interface pos 1/0/0
```

## Configuring the Interface

After you verify that the 1-Port OC-12 Packet over SONET line card is installed correctly, use the following procedure to configure the new interface. Be prepared with necessary information, such as the interface IP address.

Use the following procedure to create a basic configuration—enabling an interface and specifying IP routing.

- 
- Step 1** At the global configuration prompt, specify the new interface to configure by entering the **interface pos** command and interface address. For example:
- ```
Router(config)# interface pos 1/0/0
```
- Step 2** Assign an IP address and a subnet mask to the interface with the **ip address** configuration subcommand, as in the following example:
- ```
Router(config-if)# ip address 192.168.255.255 255.255.255.0
```
- Step 3** Specify either HDLC or PPP encapsulation. For example:
- ```
Router(config-if)# encapsulation hdlc
```
- Step 4** If necessary, modify the 1-Port OC-12 Packet over SONET line card configuration or that of the remote device to ensure that, where appropriate, they use the same settings. For more information, refer to the Remote Side Setting column in [Table 13-2](#).
- Step 5** Add any other configuration subcommands required for the enabling of routing protocols and adjust the interface characteristics.
- Step 6** Enter the **no shutdown** command to enable the interface.
- ```
Router(config-if)# no shutdown
```
- Step 7** When you have included all of the configuration subcommands to complete the configuration, enter **Ctrl-Z** to exit configuration mode.
- Step 8** Write the new configuration to memory.
- ```
Router# copy running-config startup-config
```

The system displays an OK message when the configuration has been stored.

---

After you have completed your configuration, you can check it using the **show interface pos slot/subslot/port**.

## Other Configuration Commands

The following sections present some of the commands that you can use to customize your Cisco 10000 1-Port OC-12 Packet over SONET line card configuration.

### Setting the Clock Source

At the prompt, set the internal or line clock source by using the **clock source** command.

```
clock source {internal | line}
```

Where:

- **internal** specifies that the internal clock source is used
- **line** specifies that the network clock source is used

The default is clock source internal.

In this example, the line card is instructed to use a line clock source.

```
Router(config)# interface pos 1/0/0
Router(config-if)# clock source line
```

### Configuring Framing

You can use the **pos framing** command to set framing to SONET STS-12c or SDH STM-4 framing.

```
pos framing [sdh | sonet]
[no] pos framing
```

The default is SONET.

Make sure your system supports SDH before using this option.

Use the **no** form of the command to restore the default framing mode.

In the following example, the framing type is set to SONET:

```
Router(config)# interface pos 5/0/0
Router(config-if)# no pos framing
```

### Specifying SONET Overhead

You can use the **pos flag** command to assign values for specific elements of the frame header. This command is typically used to meet a standards requirement or to ensure interoperability with another vendor's equipment.

```
pos flag [c2 value] [j0 value] [s1s0 value]
[no] pos flag [c2 value] [j0 value] [s1s0 value]
```

Where:

- **c2** is a path signal identifier, and *value* is one of the following:
  - 0xCF for PPP or HDLC without scrambling
  - 0x16 for PPP or HDLC with scrambling
- **j0** is the section trace byte, and *value* is 0x1 for interoperability with some SDH devices in Japan
- **s1s0** is part of the payload pointer byte, and *value* is 0 for OC-12c and 2 for AU-4

The default values are c2—0xCF, j0—0x01, and s1s0—0.

Use the **no** form of the command to restore the default values.

In the following example, the c2 bit is set to 0xCF.

```
Router(config)# interface pos 5/0/0
Router(config-if)# pos flag c2 0xCF
```

## Controlling the S1 SONET Overhead Byte

In most situations, the default value for the S1 SONET overhead byte (0x0) does not need to be changed. Refer to the SONET standards for information about the possible values for the S1 SONET overhead byte and the definition of each value.

### Controlling a Transmitted S1 Overhead Byte

In Cisco IOS Release 12.2(28)SB, use the **pos flag s1-byte tx** command in interface configuration mode to control the transmission of the S1 SONET overhead byte.

**pos flag s1-byte tx value**

Where:

- *value* is in the range of 0x0 to 0xF
- 0x0 is the default value

In the following example the S1 SONET overhead byte is set to 0xF:

```
pos flag s1-byte tx 0xF
```

### Reacting to a Received S1 Overhead Byte

In Cisco IOS Release 12.2(28)SB, use the **pos flag s1-byte rx-communicate** command to direct the router to switch the clock source to internal when it receives an S1 SONET overhead byte with a value of 0xF. When the S1 SONET overhead byte changes from 0xF to any other value, the clock source reverts back to the clock source specified in the user configuration.

The S1 overhead byte is ignored by the receiving router unless the **pos flag s1-byte rx-communicate** command is issued.

**pos flag s1-byte rx-communicate**

**no pos flag s1-byte rx-communicate**

The following example directs the router to switch to internal clocking when it receives an S1 SONET overhead byte with a value of 0xF:

```
pos flag s1-byte rx-communicate
```

The default for the **pos flag s1-byte rx-communicate** command is disabled or off.

## Configuring Packet over SONET SPE Scrambling

The **pos scramble-atm** command allows you to scramble the Packet over SONET synchronous payload envelope (SPE). SONET payload scrambling applies a self-synchronous scrambler to the SPE of the interface to ensure sufficient bit transition density.

```
pos scramble-atm
[no] pos scramble-atm
```

The default is no Packet over SONET SPE scrambling.

Use the **no** form of the command to disable scrambling.

In the following example, scrambling is enabled:

```
Router(config)# interface pos 5/0/0
Router(config-if)# pos scramble-atm
```

## Configuring Loopback Testing

To enable loopback testing of data transmitted from the PRE line card to the 1-Port OC-12 Packet over SONET line card and back, use the **loopback** command in interface configuration mode.

```
loopback [line | internal]
[no] loopback [line | internal]
```

Where:

Both **line** and **internal** do the following:

- Loop any data received at the 1-Port OC-12 Packet over SONET line card network interface back into the network
- Loop any data received at the 1-Port OC-12 Packet over SONET line card network interface back into the PRE card

Use the **no** form of the command to stop the loopback test.

For more information on loopbacks, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

In the following example, a loopback is set for the 1-Port OC-12 Packet over SONET line card in slot 5:

```
Router(config)# interface pos 5/0/0
Router(config-if)# loopback line
```



# CHAPTER 14

## 1-Port OC-48/STM-16 Packet over SONET Line Card Configuration

This chapter describes procedures for configuring the Cisco 10000 series 1-Port OC-48/STM-16 Packet over SONET line card, hereafter known as the 1-Port OC-48/STM-16 Packet over SONET line card.

The 1-Port OC-48/STM-16 Packet over SONET line card provides a trunk uplink capable of supporting up to 2.4 Gbps full duplex throughput over a standard SONET/ITU-T Synchronous Digital Hierarchy (SDH) interface, using a single-mode fiber with SC connectors.

This chapter contains the following sections:

- [Software Support, page 14-1](#)
- [Default Values, page 14-2](#)
- [SDCC Default Values, page 14-2](#)
- [Interface Syntax, page 14-3](#)
- [Configuring the Interface, page 14-3](#)
- [MAC Protocol Selection Command, page 14-4](#)
- [Interface Configuration Mode Command, page 14-4](#)
- [SDCC Interface Configuration Commands, page 14-5](#)
- [Other Configuration Commands, page 14-7](#)

### Software Support

[Table 14-1](#) shows the minimum Cisco IOS release on each release train that supports the 1-Port OC-48/STM-16 Packet over SONET line card.

**Table 14-1** 1-Port OC-48/STM-16 Packet over SONET Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE2	Cisco IOS Release 12.2(15)BX and later releases of Cisco IOS 12.2BX Cisco Release IOS 12.3(7)XI and later releases of Cisco IOS 12.3XI Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Default Values

Table 14-2 lists default values for the 1-Port OC-48/STM-16 Packet over SONET line card. This table also includes the command used for modifying a default value and indicates whether a value needs to be the same (or opposite) on the remote end of the connection.

**Table 14-2 1-Port OC-48/STM-16 Packet over SONET Line Card SONET Defaults**

Command Name	Default Setting	Command Syntax	Remote Side Setting
bandwidth	2488	<b>bandwidth</b> <i>kilobits</i>	Same
clock source	line	<b>clock source</b> [ <i>line</i>   <i>internal</i> ]	At least one side must be set to <i>internal</i> .
crc	32	<b>crc</b> [ <i>16</i>   <i>32</i> ]	Same
encapsulation	HDLC	<b>encapsulation</b> [ <i>hdlc</i>   <i>ppp</i>   <i>frame-relay</i> ]	Same
keepalive	10	[ <i>no</i> ] <b>keepalive</b> <i>period</i>	Same
mtu (maximum transmission unit)	4470	<b>mtu</b> <i>size</i>	Same
MAC Protocol	pos	<b>hw-module slot</b> [ <i>pos</i> ]	Same
pos framing	SONET	<b>pos framing</b> [ <i>sonet</i>   <i>sdh</i> ]	Same
pos scramble-atm	No scrambling	[ <i>no</i> ] <b>pos scramble-atm</b>	Same
pos flag (SONET overhead)	c2 to 0xcf j0 to 0x01 s1s0 to 0	<b>pos flag</b> [ <i>c2</i>   <i>j0</i>   <i>s1s0</i> ] <i>value</i>	Same

## SDCC Default Values

Table 14-3 lists default values for the 1-Port OC-48/STM-16 Packet over SONET line card if you configure a SONET Section Data Communications Channel (SDCC) interface.

The table includes the command used for modifying a default value and indicates whether a value needs to be the same (or opposite) on the remote end of the connection.

**Table 14-3** 1-Port OC-48/STM-16 Packet over SONET Line Card SONET SDCC Defaults

Command Name	Default Setting	Command Syntax	Remote Side Setting
bandwidth	192	<b>bandwidth</b> <i>kilobits</i>	Same
crc	32	<b>crc</b> [16   32]	Same
keepalive	10	[no] <b>keepalive</b> <i>period</i>	Same
mtu (maximum transmission unit)	1500	<b>mtu</b> <i>size</i>	Same
loopback (internal)	off	[no] <b>loopback</b>	N/A

## Interface Syntax

Use the syntax in Table 14-4 to specify an 1-Port OC-48/STM-16 Packet over SONET line card interface number in a configuration command.

**Table 14-4** OC-48 Interface Syntax

Type of Interface	Slot	Subslot	Port
Packet over SONET interface	1 to 8/	0/	0

The following example shows the syntax for an OC-48 card in slot 1:

```
Router(config)# interface pos 1/0/0
Router(config-if)#
```

## Configuring the Interface

After verifying that the 1-Port OC-48/STM-16 Packet over SONET line card is installed correctly, use the following procedure to configure the interface and specify an IP address. Be prepared with the information you will need, such as the IP address.

- 
- Step 1** Specify the MAC protocol using the **hw-module slot** command. In this example, the controller is configured for Packet over SONET:
- ```
Router(config)# hw-module slot 2 pos
```
- Step 2** At the global configuration prompt, enter interface configuration mode. In this example, the interface configuration mode is Packet Over SONET (POS):
- ```
Router(config)# interface pos 2/0/0
```
- Step 3** Assign an IP address and a subnet mask to the interface using the **ip address** command. For example:
- ```
Router(config-if)# ip address 192.168.21.1 255.255.255.0
```
- Step 4** Specify either HDLC or PPP encapsulation. The following example specifies HDLC encapsulation:
- ```
Router(config-if)# encapsulation hdlc
```

- Step 5** If necessary, modify the 1-Port OC-48/STM-16 Packet over SONET line card configuration or the configuration of the remote device to ensure that they use the same settings, where appropriate. For more information, refer to the Remote Side Setting column in [Table 14-2](#).
- Step 6** Add any other configuration commands required to enable routing protocols and adjust the interface characteristics.
- Step 7** Enter the **no shutdown** command to enable the interface. For example:
- ```
Router(config-if)# no shutdown
```
- Step 8** When you have included all of the configuration commands to complete the configuration, enter **Ctrl-Z** to exit configuration mode.
- Step 9** Write the new configuration to memory.
- ```
Router# copy running-config startup-config
```
- The system displays an OK message when the configuration has been stored.
- 

After you have completed the configuration, you can verify that it is correct using the **show interface pos slot/subslot/port** command.

## MAC Protocol Selection Command

You must specify the MAC protocol that the 1-Port OC-48/STM-16 Packet over SONET line card will use before you configure the interface, by using the following command:

```
hw-module slot slot [pos]
```

Where *slot* is 1 to 8.

The following example shows how you specify the Packet over SONET MAC protocol for a card in slot 2:

```
Router(config)# hw-module slot 2 pos
```

## Interface Configuration Mode Command

To configure an interface, you must specify an interface configuration mode by using the following command:

```
interface [pos | sdcc] slot/subslot/port
```

Where *slot* is 1 to 8, *subslot* is 0, and *port* is 0.

The following example shows how you specify Packet over SONET interface configuration mode for a card in slot 2:

```
Router(config)# interface pos 2/0/0
Router(config-if)#
```



# SDCC Interface Configuration Commands

This section lists the commands that are available when you configure a SONET Section Data Communications Channel (SDCC) interface on the router.

**Note**

The SDCC interface is available only after the MAC protocol has been set to Packet over SONET. For more information about setting the MAC protocol, see the [MAC Protocol Selection Command](#), page 14-4

## Enabling the SDCC Interface Configuration Mode

You must first enable the SDCC interface configuration mode before attempting to configure any SDCC commands. You can enable the SDCC interface mode from global configuration mode by using the **sdcc enable** command.

```
sdcc enable
[no] sdcc enable
```

The default setting is disabled.

In the following example, SDCC is enabled:

```
Router(config)# sdcc enable
```

**Caution**

If you enter the **no sdcc enable** command after configuring an SDCC interface, the interface is removed from the interface list in the configuration.

## Enabling an SDCC Interface

You can administratively enable an SDCC interface using the **no shutdown** command.

```
shutdown
[no] shutdown
```

The default state of an SDCC interface is administratively up.

In the following example, an SDCC interface is enabled:

```
Router(config)# no shutdown
```

## Interface Selection Command

To configure an SDCC interface, you must select an interface using the **interface** command:

```
interface sdcc slot/subslot/port
```

Where *slot* is 1 to 8, *subslot* is 0, and *port* is 0.

The following example shows how you specify an SDCC interface for a card in slot 2:

```
Router(config)# interface sdcc 2/0/0
Router(config-if)#
```

## Enabling Loopback Tests

You can configure an SDCC interface for an internal loopback test by using the **loopback** command. With an internal loopback, packets that are received by the line card from the route processor are looped back to the route processor without being sent to the line.

```
loopback
[no] loopback
```

Use the **no** form of the command to stop the loopback test.

The default is none.

In the following example, the loopback is set to line:

```
Router(config-if)# loopback
```

## Configuring CRC Size

You can configure the CRC size for HDLC encapsulation on an SDCC interface to 16- and 32-bit CRCs using the **crc** command.

```
crc {16 | 32}
```

Where:

**16** sets the CRC to 16 bits.

**32** sets the CRC to 32 bits.

The default is 32.

In the following example, the CRC size is set to 16:

```
Router(config-if)# crc 16
```

## Configuring MTU Size

You can configure the Maximum Transmission Unit (MTU) size for up to 1500 bytes, using the **mtu** command.



### Note

---

The MTU size does not include the 4 bytes for the HDLC header, or the 2 or 4 bytes of the CRC.

---

```
mtu mtu bytes
```

Where *mtu bytes* is the MTU size from zero to 1500.

The default is 1500.

In the following example, the MTU size is set to 1000:

```
Router(config-if)# mtu 1000
```

## Configuring Hold Queue Size

You can configure a hold queue on an SDCC interface for packets received from the line using the **hold-queue** command.

```
hold-queue number in
```

Where *number* is the maximum number of packets that the line card will hold in the hold queue, from zero to 4096.

The default hold queue size is 75 packets.

In the following example, the hold queue size is set to 60 packets:

```
Router(config-if)# hold-queue 60 in
```

## Other Configuration Commands

The following sections present some of the commands that you can use to customize the 1-Port OC-48/STM-16 Packet over SONET line card configuration.

### Setting the Clock Source

You can set the clock source to internal or line by using the **clock source** command.

```
clock source {internal | line}
```

Where:

- **internal** specifies that the internal clock source is used
- **line** specifies that the network clock source is used

The default is clock source internal.

In this example, the clock source is set to line:

```
Router(config)# interface pos 1/0/0  
Router(config-if)# clock source line
```

### Configuring Framing

You can use the **pos framing** command to set framing to SONET STS-3c or SDH STM-1 framing.

```
pos framing [sdh | sonet]  
[no] pos framing
```

The default is SONET.

Make sure your system supports SDH before using this option.

Use the **no** form of the command to restore the default framing mode.

In the following example, the framing type is set to SONET:

```
Router(config)# interface pos 5/0/0  
Router(config-if)# no pos framing
```

## Configuring SONET Overhead

You can use the **pos flag** command to assign values for specific elements of the frame header. This command is typically used to meet a standards requirement or to ensure interoperability with another vendor's equipment.

```
pos flag [c2 value] [j0 value] [s1s0 value]
[no] pos flag [c2 value] [j0 value] [s1s0 value]
```

Where:

- **c2** is a path signal identifier, and *value* is one of the following:
  - 0xCF for PPP or HDLC without scrambling
  - 0x16 for PPP or HDLC with scrambling
- **j0** is the section trace byte, and *value* is 0x1 for interoperability with SDH devices.
- **s1s0** is part of the payload pointer byte, *value* is 0 for OC-48c and 2 for AU-4.

The default values are c2—0xCF, j0—0x01, and s1s0—0.

Use the **no** form of the command to restore the default values.

In the following example, the c2 bit is set to 0xCF:

```
Router(config)# interface pos 5/0/0
Router(config-if)# pos flag c2 0xCF
```

## Configuring Packet over SONET SPE Scrambling

You can set the 1-Port OC-48/STM-16 Packet over SONET line card to scramble the Packet over SONET synchronous payload envelope (SPE) using the **pos scramble-atm** command. SONET payload scrambling applies a self-synchronous scrambler to the SPE of the interface to ensure sufficient bit transition density.

```
pos scramble-atm
[no] pos scramble-atm
```

The default is no Packet over SONET SPE scrambling.

Use the **no** form of the command to disable scrambling.

In the following example, scrambling is enabled:

```
Router(config)# interface pos 5/0/0
Router(config-if)# pos scramble-atm
```

## Configuring Loopback Testing

You can enable loopback testing of data transmitted from the PRE to the OC-48 line card and back, by using the **loopback** command in interface configuration mode.

```
loopback [line | internal]
[no] loopback [line | internal]
```

Where:

**internal** loops packets received from the route processor back into the line card to the route processor without being sent to the line.

**line** loops packets received from the line back onto the line at the line card level without being processed in the Route Processor.

Use the **no** form of the command to stop the loopback test.

For more information on loopbacks, refer to the online [Cisco 10000 Series Internet Router Troubleshooting Guide](#).

In the following example, a loopback is set for the 1-Port OC-48/STM-16 Packet over SONET line card in slot 5:

```
Router(config)# interface pos 5/0/0
Router(config-if)# loopback line
```





## **PART 5**

### **Unchannelized Line Card**







# CHAPTER 15

## 8-Port Unchannelized E3/T3 Line Card Configuration

---

This chapter describes procedures for configuring the Cisco 10000 series 8-Port Unchannelized E3/T3 line card, hereafter known as the 8-Port Unchannelized E3/T3 line card.

The 8-Port Unchannelized E3/T3 line card provides Cisco 10000 series routers with eight E3 or T3 high-density unchannelized interface ports.

This chapter contains the following sections:

- [Software Support, page 15-1](#)
- [Default Values, page 15-2](#)
- [Configuration Task Overview, page 15-4](#)
- [Controller Configuration Commands, page 15-6](#)
- [Interface Configuration Commands, page 15-8](#)

### Software Support

[Table 15-1](#) shows the minimum Cisco IOS release on each release train that supports the 8-Port Unchannelized E3/T3 line card.

**Table 15-1** 8-Port Unchannelized E3/T3 Line Card Software Support

Required PRE	Minimum Cisco IOS Releases
PRE1	Cisco IOS Release 12.0(22)S and later releases of Cisco IOS 12.0S
PRE2	Cisco IOS Release 12.0(22)S and later releases of Cisco IOS 12.0S Cisco IOS Release 12.0(20)ST and later releases of Cisco IOS Release 12.0ST Cisco IOS Release 12.3(7)XI and later releases of Cisco IOS 12.3XI Cisco IOS Release 12.2(28)SB and later releases of Cisco IOS 12.2SB

## Checking Hardware and Software Compatibility

The PRE installed in the Cisco 10000 series router chassis must support the Cisco IOS software running on the router. Use the **show version** command to check the PRE version installed.

To see if a feature is supported by a Cisco IOS release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS software with the hardware installed on your router, Cisco maintains the Software Advisor tool on Cisco.com at <http://www.cisco.com/cgi-bin/Support/CompNav/Index.pl>

This tool does not verify whether line cards within a system are compatible, but does provide the minimum Cisco IOS requirements for individual hardware line cards, modules, or options.

You must be a registered user on Cisco.com to access this tool.

## Default Values

Table 15-2 lists default configuration values for the 8-Port Unchannelized E3/T3 line card. This table also includes default values and indicates whether or not you must invoke a corresponding value at the remote side Channel Service Unit/Data Service Unit (CSU/DSU).

**Table 15-2 8-Port Unchannelized E3/T3 Line Card Parameters**

Command Name	Default Value	Command Syntax	Remote CSU/DSU Setting
<b>Common Controller Configuration Mode</b>			
cable length	450	<code>cablelength <i>feet</i></code>	—
clock source	internal	<code>clock source [line   internal]</code>	At least one side set to <b>internal</b>
description	—	<code>description <i>string</i></code>	—
dsx3mode	t3	<code>[no] dsx3mode [e3   t3]</code>	Same
shutdown	no shutdown	<code>[no] shutdown</code>	—
<b>T3 Interface Configuration Mode</b>			
bert	no bert	<code>[no] bert pattern <i>pattern</i> interval <i>time</i> [unframed]</code>	No
description	—	<code>description <i>string</i></code>	—
dsu bandwidth	44,210	<code>dsu bandwidth <i>bandwidth</i> [no] bandwidth</code>	Same
dsu mode	cisco	<code>dsu mode [adtran   cisco   digilink   kentrox   larscom   verilink low-bit   verilink high-bit]</code>	Same
encapsulation	hdlc	<code>encapsulation [hdlc   ppp   frame-relay]</code>	Same
equipment	customer	<code>equipment [customer   network]loopback</code>	Same
framing	auto-detect	<code>framing [auto-detect   c-bit   m13]</code>	Same
idle character	flags (0x7e)	<code>idle character [flags   marks]</code>	Same

Table 15-2 8-Port Unchannelized E3/T3 Line Card Parameters (continued)

Command Name	Default Value	Command Syntax	Remote CSU/DSU Setting
loopback	no loopback	[no] loopback network [line   payload] [no] loopback [local   remote]	No
mdl	no mdl	[no] mdl {transmit {idle-signal   path   test-signal}   string {eic   fic   generator   lic   pfi   port   unit} <string>}	Same
scramble	no scramble	[no] scramble	Same
shutdown	no shutdown	shutdown	—
<b>E3 Interface Configuration Mode</b>			
bert	no bert	[no] bert pattern pattern interval time [unframed]	Same
description	—	description string	—
encapsulation	hdlc	encapsulation [hdlc   ppp   frame-relay]	Same
dsu bandwidth	34,368 kbps	[no] dsu bandwidth bandwidth	Same
dsu mode	cisco	[no] dsu mode [cisco   kentrox]	Same
fallback-clocking	off	fallback-clocking on   off	Same
idle character	flags (0x7e)	idle character [flags   marks]	Same
loopback	no loopback local network line	[no] loopback network [line   payload] [no] loopback [local   remote]	No
scramble	no scrambling	[no] scramble	Same
shutdown	no shutdown	shutdown	—

## Naming Convention

The Cisco 10000 series router line cards use the extended slot naming convention to identify the line card slot, subslot, and port in commands. This convention uses the following format:

slot/subslot/port

Where:

- **slot** is the slot number of the installed the line card
- **subslot** is the subslot number of the line card (the subslot number for all full-height line cards is always 0)
- **port** is the number of the line card port

## Interface Syntax

The following tables contain the line card syntax to configure 8-Port Unchannelized E3/T3 line card interfaces for the Cisco 10008 router and Cisco 10005 router chassis.

**Note**

The dsx3 controller designation is a generic term that refers to both E3 and T3 type interfaces. A dsx3 interface controls the configuration and management of DS3 channels and characteristics.

Table 15-3 specifies the 8-Port Unchannelized E3/T3 line card interface syntax for the Cisco 10008 router 8-slot chassis.

**Table 15-3 8-Port Unchannelized E3/T3 Line Card Interface Syntax for the Cisco 10008 Chassis**

Configuration	Command	Slot	Subslot	Port Number
Controller	controller dsx3 slot/0/port	1 to 8/	0/	0 to 7
Interface T3 (DS3)	serialslot/0/port	1 to 8/	0/	0 to 7
Interface E3	serialslot/0/port	1 to 8/	0/	0 to 7

Table 15-4 specifies the 8-Port Unchannelized E3/T3 line card interface syntax for the Cisco 10005 router 5-slot chassis.

**Table 15-4 8-Port Unchannelized E3/T3 Line Card Interface Syntax for the Cisco 10005 Chassis**

Configuration	Command	Slot	Subslot	Port Number
Controller	controller dsx3 slot/0/port	1 to 5/	0/	0 to 7
Interface T3 (DS3)	serialslot/0/port	1 to 5/	0/	0 to 7
Interface E3	serialslot/0/port	1 to 5/	0/	0 to 7

## Configuration Task Overview

You can configure each port of the 8-Port Unchannelized E3/T3 line card as a full-rate or subrate unchannelized E3 or T3 interface.

**Note**

Subrate unchannelized interfaces use specific vendor DSU proprietary formats that limit interface bit rates to less than full-rate on an E3 or T3 serial interface line.

To configure an 8-Port Unchannelized E3/T3 line card interface:

1. Designate a port as a controller.
2. Configure the controller parameters and save the configuration to NVRAM.
3. Create a serial interface.
4. Specify the interface parameters for the interface and save the configuration to NVRAM.

**Note**

Each time you change a port mode (from T3 to E3, or E3 to T3), the running configuration of the controller and interface of the changed port mode is erased. If you want to keep a configuration, you must save it before you change its mode.

## Configuration Examples

This section contains examples to configure both full-rate and subrate E3 or T3 interfaces on the line card. You must be in privileged EXEC mode to designate, create, and configure an E3 or T3 controller and interface.

**Tip**

---

To view available command parameters, type ? at the command line.

---

### Configuring an E3 Interface

The following sample procedure describes how to create and configure an E3 interface on port 6 of the line card in slot 4.

---

**Step 1** Enter global configuration mode and designate the port as a controller.

```
Router# configure terminal
Router(config)# controller dsx3 4/0/6
```

**Step 2** Configure the port as a **dsx3 e3** controller and save the configuration to NVRAM.

```
Router(config-controller)# dsx3mode e3
Router(config-controller)# end
Router# write
```

**Step 3** Enter configuration interface mode and designate port 6 as the serial interface.

```
Router# configure terminal
Router(config)# interface serial 4/0/6
```

**Step 4** Configure the E3 interface DSU parameters for the port as a full-rate or subrate interface:

**a.** Full-rate (default 34,368):

```
Router (config-if)# dsu mode cisco
Router (config-if)#
```

**b.** Subrate (any value below 34,368):

```
Router (config-if)# dsu mode cisco
Router (config-if)# dsu bandwidth 16000
```

**Step 5** Save the configuration to NVRAM.

```
Router(config-if)# end
Router# write
```

---

### Configuring a T3 Interface

The following sample procedure describes how to create and configure a T3 interface on port 6 of the line card in slot 4.

---

**Step 1** Enter global configuration mode and designate the port as a controller.

```
Router# configure terminal
Router(config)# controller dsx3 4/0/6
```

**Step 2** Configure the port as a **dsx3 t3** controller and save the configuration to NVRAM.

```
Router(config-controller)# dsx3mode t3
Router(config-controller)# end
Router# write
```

**Step 3** Enter configuration interface mode and designate port 6 as the serial interface.

```
Router# configure terminal
Router(config)# interface serial 4/0/6
```

**Step 4** Configure the T3 interface DSU parameters for the port as a full-rate or subrate interface:

**a.** Full-rate (default of 44,210):

```
Router (config-if)# dsu mode cisco
```

**b.** Subrate (any value below 44,210):

```
Router (config-if)# dsu mode cisco
Router (config-if)# dsu bandwidth 16000
```

**Step 5** Save the configuration to NVRAM.

```
Router(config-if)# end
Router# write
```

## Controller Configuration Commands

This section describes the 8-Port Unchannelized E3/T3 line card commands to modify and test an E3 or T3 controller. You must be in configuration-controller mode to modify an E3 or T3 controller.



### Note

Each time you change a port (from T3 to E3, or E3 to T3), the running configuration of the controller and interface of the changed port is erased. If you want to keep a configuration, you must save it before you change its port mode.

- [Cablelength Command, page 15-6](#)
- [Clock Source Command, page 15-7](#)
- [Controller Description Command, page 15-7](#)
- [Controller dsx3mode Command, page 15-8](#)
- [Shutdown Command, page 15-8](#)

## Cablelength Command

The **cablelength** command improves signal strength for losses associated with lengthy cables. To specify the physical length of the interface cable between the near and far-end CSU/DSU devices, use the **cablelength** command in the following format:

```
[no] cablelength feet
```

Where *feet* is a number from 0 to 450.

The default value is 450 feet.

Use the **no** form of this command to restore the default cable length.

In the following example, the cable length is set to 120 feet:

```
Router(config)# controller dsx3 4/0/6
Router(config-controller)# cablelength 120
```

The following cable length distances take into consideration line buildout for E3 and T3 controllers:

Interface	Cable Length (feet)	Buildout
E3	0 to 224	no line buildout
E3	225 to 450	line buildout
T3	0 to 299	no line buildout
T3	300 to 450	line buildout

## Clock Source Command

Use the **clock source** command to choose whether or not the transmitted clock is derived from the received clock or is generated by an internal clock source. In some cases a network configuration may require you to derive network synchronization from a remote master clock.

The **clock source** command is set in controller configuration mode using the following format:

```
clock source [internal | line]
```

Where:

- **internal** specifies that the internal clock source is used
- **line** specifies that the network clock source is used

The default is clock source internal.

In this example, the controller is instructed to use a line clock source.

```
Router(config)# controller dsx3 4/0/6
Router(config-controller)# clock source line
```



**Caution**

Never configure both sides of an E3 or T3 link to the clock source line.

## Controller Description Command

Use the **description** command to identify particulars about the controller. You can enter up 80 characters in your controller description string using the following format:

```
description string
```

In the following example, port 6 is labeled with a description to help identify it:

```
Router(config)# controller dsx3 4/0/6
Router(config-controller)# description "Company ABC; IP = 240.21.3.8"
```

**Note**

The **description** command can also be used in interface mode (see [“Interface Description Command” section on page 15-10](#)).

## Controller dsx3mode Command

Use the **dsx3mode** command to define the controller type as an E3 or T3 controller using the following format:

```
[no] dsx3mode [e3 | t3]
```

The default controller type is **t3**.

Use the **no** form of this command to remove the controller.

The following example shows how to define a T3 type controller:

```
Router(config)# controller dsx3 2/0/0
Router(config-controller)# dsx3mode t3
```

## Shutdown Command

Use the **shutdown** command to shut down the controller and interface using the following format:

```
[no] shutdown
```

Use the **no** form of this command to restore the previously configured controller and interface.

- It takes 10 seconds for alarms to clear after issuing a **no shut** command on a T3 port. Shutting down a controller causes a T3 port to transmit:
  - AIS (alarm indication signal, for **m13** framing)
  - An idle signal (for **c-bit** framing)
- There is no delay for alarms to clear after issuing a **no shut** command on an E3 port.
  - Shutting down a controller causes an E3 port to transmit AIS.

**Note**

The AIS (alarm indication signal), also called a blue alarm, is sent downstream to notify the downstream device that an upstream line failure has occurred.

In the following example, the controller on port 0 is shut down:

```
Router(config)# controller dsx3 1/0/0
Router(config-controller)# shutdown
```

## Interface Configuration Commands

This section describes the following command procedures to modify and test E3 and T3 interfaces on the line card:

- [Running a BER Test, page 15-9](#)
- [Interface Description Command, page 15-10](#)



- [Specifying DSU Mode, page 15-10](#)
- [Specifying DSU Bandwidth, page 15-11](#)
- [Encapsulation Command, page 15-11](#)
- [Equipment Loopback Command, page 15-12](#)
- [Fallback-Clocking Command, page 15-12](#)
- [Setting the Framing Type, page 15-13](#)
- [Specifying the Idle-Character, page 15-13](#)
- [Performing Loopback Tests, page 15-14](#)
- [Entering MDL Messages, page 15-14](#)
- [Setting the National Bit, page 15-16](#)
- [Enabling Scrambling, page 15-16](#)

You must be in configuration interface mode to modify an E3 or T3 configuration, for example:

```
Router# configure terminal
Router(config)# interface serial 1/0/0
Router(config-if)#
```

## Running a BER Test

You can configure an interface to run a BER test (bit error-rate test). The BER test checks network cables and isolates apparent signal problems in the field.

Before you begin a BER test, you need to set up a remote loopback from the far-end (remote) DSU/CSU. See “[Performing Loopback Tests](#)” section on [page 15-14](#) for additional information about configuring the loopbacks.

The following loopback commands cause the remote CSU/DSU to perform a full-bandwidth loopback through its CSU:

- **loopback network line** causes a loopback toward the network *before* going through the CSU/DSU framer.
- **loopback network payload** causes a loopback toward the network *after* going through the CSU/DSU framer.

To run a BER test pattern on an interface, use the following interface configuration command:

```
bert [errors number | pattern pattern] interval time
[no] bert
```

Where:

- **errors** *number* is 1 to 255
- **pattern** *pattern* is:
  - 0s—repetitive test pattern of all zeros (00000..)
  - 1s—repetitive test pattern of all ones (11111..)
  - 2^15—pseudo-random O.151 test pattern (32,768 bits in length)
  - 2^20-O153—pseudorandom O.153 test pattern (1,048,575 bits in length)
  - 2^23—test pattern
  - alt-0-1—alternating 0s and 1s test pattern

- QRSS-2<sup>20</sup>—pseudorandom QRSS O.151 test pattern (1,048,575 bits in length)

The default is no bert pattern test. Use the **no** form of this command to terminate a BER test.

For more information about BER testing, refer to the *Cisco IOS Interface and Hardware Component Configuration Guide* and the online *Cisco 10000 Series Internet Router Troubleshooting Guide*.

Example:

- Send a BERT pseudorandom pattern of 2<sup>20</sup> through T3 interface 1/0/0 for 5 minutes.

```
Router(config)# interface serial 1/0/0
Router(config-if)# bert pattern 2^20 interval 5
```

## Interface Description Command

Use the **description** command to identify particulars about the interface. You can enter up to 80 characters in your controller description string using the following format:

**description** *string*

In the following example, port 6 is labeled with a description to help identify it:

```
Router(config)# interface 4/0/6
Router(config-if)# description "Company ABC; IP = 240.21.3.8"
```



### Note

The **description** command can also be used in controller mode (see the “[Controller Description Command](#)” section on page 15-7).

## Specifying DSU Mode

The **dsu mode** command configures the line card to emulate a manufacturer’s proprietary multiplexing scheme. Be sure that the remote DSU connection at the far end is connected and set up as an identical E3 or T3 interface.



### Note

Only Cisco, Digital-Link, and Kentrox are supported on E3 interfaces.

Use the **dsu mode** command to specify a Data Service Unit (DSU) mode for a selected interface using the following format:

```
dsu mode [adtran | cisco | digital-link | kentrox | larscom | verilink-highbit |
verilink-lowbit]
[no] dsu mode
```

The default DSU mode is **cisco**. Use the **no** form of the command to return the DSU mode to the default mode.

In the following example, the DSU mode is set to **cisco**:

```
Router(config)# interface serial 1/0/0
Router(config-if)# dsu mode cisco
```

## Specifying DSU Bandwidth

Use the **dsu bandwidth** command to specify the full-rate or subrate bandwidth for an E3 or T3 interface using the following format:

```
dsu bandwidth bandwidth  
[no] bandwidth
```

Where:

- bandwidth = 0 to 44210 kbps for a T3 interface
  - The default value for a T3 interface is 44210 (full-rate)
- bandwidth = 0 to 34368 kbps for an E3 interface
  - The default value for an E3 interface is 34368 (full-rate)

Use the **no** form of this command to return to the full-rate default values.

In the following example, the full-rate bandwidth for an E3 interface is set to 34368:

```
Router(config)# interface serial 2/0/0  
Router(config-if)# dsu bandwidth 34368
```

## Creating a Subrate E3 or T3 Interface

You can create a subrate E3 or T3 controller interface by specifying a bandwidth value that is less than full-rate for the near end DSU.

In the following example, the subrate **dsu bandwidth** for a T3 interface is set to 16000:

```
Router(config)# interface serial 4/0/6  
Router(config-if)# dsu mode cisco  
Router(config-if)# dsu bandwidth 16000
```



### Note

When you specify a bandwidth, the software sets that bandwidth to the closest acceptable bandwidth value based on the time-slot size for the current DSU mode. See the [Chapter 17, “Provisioning a Subrate E3 or T3 Interface”](#) for information about bandwidth.

## Encapsulation Command

Use the **encapsulation** command to specify the type of encapsulation for the interface using the following format:

```
encapsulation encapsulation-type
```

Where *encapsulation-type* is:

- **frame-relay**
- **hdlc** (serial HDLC synchronous)
- **ppp** (Point-to-Point Protocol)

The default encapsulation is **hdlc**.

The following example sets the encapsulation type as **ppp**:

```
Router(config)# interface serial 4/0/6  
Router(config-if)# encapsulation ppp
```

## Equipment Loopback Command

Use the **equipment loopback** command to specify whether or not a T3 port for the near-end device will accept remote loopback requests from the far-end device.



### Note

Because remote loopback requests are available only when **c-bit** framing is invoked, the **equipment loopback** command is useful only when framing is set to **c-bit** or **auto-frame-detect**.

```
[no] equipment [customer | network] loopback
```

The default mode is **customer**.

Use the **no** form of this command to disable the equipment selection and revert back to **auto-detect** as the framing value (see [Setting the Framing Type, page 15-13](#)).

The following examples show how to the **equipment loopback** command:

### Equipment Customer Loopback Command

When you invoke the **equipment customer loopback** command, the near-end T3 port accepts far-end loopback requests.

```
Router(config)# interface dsx3 1/0/0
Router(config-if)# equipment customer loopback
```



### Note

Specify **equipment customer loopback** as the equipment type, unless you want to block the far end from setting near-end loopbacks.

### Equipment Network Loopback Command

When you invoke the **equipment network loopback** command, the near-end T3 port ignores far-end loopback requests.

```
Router(controller)# interface dsx3 1/0/0
Router(config-if)# equipment network loopback
```

## Fallback-Clocking Command

Use the **fallback-clocking** command to force the setting on the master clock to *internal* on receipt of an AIS message. This command is used only for E3 serial interfaces.



### Note

We recommend that you use the **fallback clock** command only in countries in which regulations require it.

Use the **fallback-clocking** command using the following format:

```
[no] fallback-clocking [on | off]
```

The default is off.

Use the **no** form of this command to restore the E3 interface default, which causes the controller to revert back to programmed E3 clocking.

In the following example, the fallback-clocking is set to **on**.

```
Router(config-if)# interface dsx3 1/0/0
Router(config-if)# fallback-clocking on
```

## Setting the Framing Type

Use the **framing** command to specify the framing type for the T3 interface using the following format:

```
[no] framing [auto-detect | c-bit | m13]
```

Where:

- **auto-detect** detects whether or not the far-end T3 line is currently using m13 or c-bit framing and automatically configures itself to match.



---

**Note** If the port detects that framing rapidly toggles between m13 and c-bit framing, the port forces m13 framing.

---

- **c-bit** specifies c-bit framing.
- **m13** specifies m13 framing. m13 is a Cisco framing method that functions the same as m23 framing.

The default is no framing.

Use the **no** form of this command to restore the default **auto-detect** framing type.

In the following example, framing is set to **m13**:

```
Router(config)# interface serial 1/0/0
Router(config-if)# framing m13
```

## Specifying the Idle-Character

Use the **idle-character command** to set a specific character on the interface for transmission between HDLC packets using the following format:

```
[no] idle-character [flags | marks]
```

Where:

- **flags** sets an idle character of **0x7e**
- **marks** sets an idle character of all **0xff**

The default idle character is 0x7e.

Use the **no** form of this command to return the idle character to its default value.

In the following example, the idle character is set to flags (**0x7e**):

```
Router(config)# interface serial 1/0/0
Router(config-if)# idle-character flags
```



**Note**

---

Some systems interpret marks (0xff), as an abort signal. Therefore, the flags (0x7e) setting is preferred.

---

## Performing Loopback Tests

Use the **loopback** command to assign an E3 or T3 interface into loopback test using the following format:

```
[no] loopback network [line | payload]
[no] loopback [local | remote]
```

Where:

- **network line** loops the data back to the network
- **network payload** loops the payload portion back to the network
- **local** loops the line card output data back toward the line card and sends an AIS message
- **remote** sends a far end alarm control (FEAC) request to the far-end (remote) device, requesting that it enter a network line loopback




---

**Note** A remote loopback test is possible only when the line is configured for c-bit framing.

---

The default is no loopback.

To cancel a loopback test, use the **no** form of the command.

In the following example, the loopback network is set to line:

```
Router(config)# dsx3 1/0/0
Router(config-if)# network loopback line
```

See the *Cisco IOS Interface and Hardware Component Configuration Guide*, and the *Cisco 10000 Series Internet Router Troubleshooting Guide* for details about loopback testing.

## Entering MDL Messages

Use the maintenance data link (MDL) message strings and codes to send messages in response to far-end inquiries.



**Note**

---

MDL messages are supported only when the T3 framing is set to c-bit (see the “[Setting the Framing Type](#)” section on page 15-13.)

---

You can configure MDL messages (as defined in the ANSI T1.107a-1990 specification) on a T3 interface using the **mdl** command in the following format:

```
[no] mdl {transmit {path | idle-signal | test-signal} | string {eic | lic | fic | unit | pfi | port | generator} id_string}
```

Where:

- **transmit** enables one of the following transmissions:
  - **path** enables transmission of the MDL path message
  - **idle-signal** enables transmission of the MDL idle-signal message
  - **test-signal** enables transmission of the MDL test-signal message
- **string** enables one of the following identification codes:

- **eic** is the equipment identification code (up to 10 characters).
- **lic** is the location identification code (up to 11 characters).
- **fic** is the frame identification code (up to 10 characters).
- **unit** is the unit identification code (up to 6 characters).
- **pfi** is the facility identification code to include in the MDL path message (up to 38 characters).
- **port** is the equipment port (which initiates the idle signal) to include in the MDL idle signal message (up to 38 characters).
- **generator** is the generator number to include in the MDL test signal message (up to 38 characters).

The default is no mdl message.

Use the **no** form of the command to remove an MDL message.

Examples of configuring MDL messages are:

- Enable the MDL path message transmission.

```
Router(config-controller)# mdl transmit path
```

- Enable the MDL idle signal message transmission.

```
Router(config-controller)# mdl transmit idle-signal
```

- Enable the MDL test signal message transmission.

```
Router(config-controller)# mdl transmit test-signal
```

- Enter the equipment identification code.

```
Router(config-controller)# mdl string eic router A
```

- Enter the location identification code.

```
Router(config-controller)# mdl string lic test network
```

- Enter the frame identification code.

```
Router(config-controller)# mdl string fic building b
```

- Enter the unit identification code.

```
Router(config-controller)# mdl string unit abc
```

- Enter the facility identification code.

```
Router(config-controller)# mdl string pfi string
```

- Enter the port number to send in the MDL idle signal message.

```
Router(config-controller)# mdl string port string
```

- Enter the generator number to send in the MDL test signal message.

```
Router(config-controller)# mdl string generator string
```

## Setting the National Bit

Use the **national bit** command to set bit 12 in the E3 frame, using the following format:

```
[no] national bit [0 | 1]
```

The default is 0.

Use the **no** form of this command to return to the default bit.

In the following example, the national bit is set to **1** on an E3 interface:

```
Router(config)# interface serial 1/0/0
Router(config-if)# national bit 1
```

## Enabling Scrambling

Scrambling can prevent some bit patterns from being mistakenly interpreted as alarms by switches placed between the DSUs. Use the **scramble** command to assist clock recovery on the receiving end using the following format:

```
[no] scramble
```

The default is no scramble.

In the following example, scrambling is enabled:

```
Router(config)# interface serial 1/0/0
Router(config-if)# scramble
```





## **PART 6**

### **Configuration Notes and Examples**





# CHAPTER 16

## Preparing for Line Card Installation and Configuration

---

This chapter provides general information about configuring line cards on the Cisco 10000 series router. This chapter contains the following sections:

- [Treatment of Newly Inserted Line Cards, page 16-1](#)
- [Preprovisioning Line Card Slots, page 16-2](#)
- [Resetting Line Cards, page 16-5](#)

### Treatment of Newly Inserted Line Cards

After you insert a line card into the router, the software identifies the card and executes one of three actions, depending on the contents of the running configuration file:

- If the card is not described in the running configuration file, the system enters a basic configuration into the running configuration file. For example, if you insert a Gigabit Ethernet line card into slot 4, the system adds the following lines to the running configuration:

```
card 4/0 1gigetherenet-1
.
.
.
interface GigabitEthernet4/0/0
no ip address
no ip directed-broadcast
no cdp enable
```

- If the card and slot are described in the running configuration file, the system applies that configuration to the card.
- If the card is of a type different from the one listed in the running configuration file, the software replaces the configuration with a basic configuration for the newly inserted card.

To find out the type of card that a slot is configured to use, enter the **show running-config** command.



**Tip**

Most **show** commands support the pipe character and **begin** argument. For example, you can use the command **show running-config | begin card** to start the display of the running configuration file at the point where it lists the cards that are configured on your Cisco 10000 series router.

---

## Preprovisioning Line Card Slots

The line card slot preprovisioning feature allows you to preprovision a Cisco 10000 series router line card slot to accept a particular line card. Using the **card** command, you can configure interfaces for a line card that is not yet inserted into the router chassis.

The line card slot preprovisioning feature allows you to plan for future configurations. Preprovisioning a line card slot downloads software to the line card slot for the line card you are planning to install. Preprovisioning allows you to prepare in advance a complete configuration for the line card, including items you normally need to configure after initially configuring the line card, such as PVCs under an ATM line card or VLANs under an Ethernet line card.

Personnel responsible for provisioning and setup operations can preprovision line card slots in the Cisco 10000 series router to accept a particular line card. When the functionality is needed, installers can then insert the card into the router chassis.

The following example preprovisions line card slot 2 to accept a 24-port E1/T1 line card operating in E1 mode:

```
Router(config)# card 2/0 24chelt1-1 mode e1
```

## Changing the Provisioning of a Line Card Slot

Use the **card** command to change the provisioning of a line card slot. You can remove the old line card before or after using the **card** command to change the line card provisioning. The following example shows how to change the provisioning for line card slot 5 from the 1-Port Gigabit Ethernet Half-Height line card to the 4-Port OC3/STM-1 line card.

```
Router(config)# card 5/0 4oc3atm-1
```

## Feature History for Line Card Slot Preprovisioning

Cisco IOS Release	Description	Required PRE
Release 12.0(17)ST	The line card slot preprovisioning feature was introduced on the Cisco 10000 series router for the following line cards: <ul style="list-style-type: none"> <li>1-Port Gigabit Ethernet line card</li> <li>1-Port OC-12 Packet Over SONET line card</li> <li>6-Port OC-3/STM-1 Packet Over SONET line card</li> <li>6-Port Channelized T3 line card</li> <li>1-Port Channelized OC-12/STM-4 line card</li> <li>4-Port Channelized OC-3/STM-1 line card</li> <li>8-Port Unchannelized E3/T3 line card</li> <li>1-Port OC-12 ATM line card</li> </ul>	PRE1
Release 12.0(21)SX	This feature was modified to support the 4-Port OC3/STM-1 line card with intermediate-reach optics.	PRE1
Release 12.0(22)S	This feature was modified to support the 24-port E1/T1 line card and the 8-Port Unchannelized E3/T3 line card.	PRE1

Cisco IOS Release	Description	Required PRE
Release 12.0(23)S	This feature was modified to support the 1-Port Gigabit Ethernet Half-Height line card and the 8-Port Fast Ethernet Half-Height line card.	PRE1
Release 12.2(15)BX	This feature was modified to support the 1-Port OC-48/STM-16 Packet Over SONET line card.	PRE2
Release 12.3XI	This feature was integrated into Cisco IOS Release 12.3XI.	PRE2
Release 12.2(28)SB	This feature was modified to support the 4-Port Channelized T3 Half-Height line card and the 4-Port OC3/STM-1 line card with long-reach optics.	PRE2

## card Command

To preprovision a line card slot in the Cisco 10000 series router, use the **card** command in global configuration mode. To remove preprovisioning from a line card slot, use the **no** form of this command.

```
card {slot/subslot} {lchoc12-1 | lgigetherne-1 | 1gigetherne-hh-1 | loc12atm-1 | loc12pos-1 |
1oc48dpt-pos-1 | 24che1t1-1 | 4chstm-1 | 4cht3-hh-1 | 4oc3atm-1 | 4oc3atm_lr-1 | 6cht3-1 |
6oc3pos-1 | 8e3ds3-1 | 8e3ds3atm-1 | 8fastetherne-1 [mode {e1 | t1}]}
```

```
no card {slot/subslot}
```

### Syntax Description

<i>slot</i>	Number of the line card slot in the Cisco 10000 series router to be preprovisioned.
<i>subslot</i>	Number of the line card subslot in the Cisco 10000 series router to be preprovisioned.
<b>lchoc12-1</b>	Preprovisions a line card slot for a 1-Port Channelized OC-12/STM-4 line card.
<b>lgigetherne-1</b>	Preprovisions a line card slot for a 1-Port Gigabit Ethernet line card.
<b>1gigetherne-hh-1</b>	Preprovisions a line card slot for a 1-Port Gigabit Ethernet Half-Height line card.
<b>loc12atm-1</b>	Preprovisions a line card slot for a 1-Port OC-12 ATM line card.
<b>loc12pos-1</b>	Preprovisions a line card slot for a 1-Port OC-12 Packet Over SONET line card.
<b>1oc48dpt-pos-1</b>	Preprovisions a line card slot for a 1-Port OC-48/STM-16 Packet Over SONET line card.
<b>24che1t1-1</b>	Preprovisions a line card slot for a 24-Port Channelized E1/T1 line card.
<b>4chstm-1</b>	Preprovisions a line card slot for a 4-Port Channelized OC-3/STM-1 line card.
<b>4cht3-hh-1</b>	Preprovisions a line card slot for a 4-Port Channelized T3 Half-Height line card.
<b>4oc3atm-1</b>	Preprovisions a line card slot for a 4-Port OC3/STM-1 line card with intermediate-reach optics.
<b>4oc3atm_lr-1</b>	Preprovisions a line card slot for a 4-Port OC3/STM-1 line card with long-reach optics.

<b>6cht3-1</b>	Preprovisions a line card slot for a 6-Port Channelized T3 line card.
<b>6oc3pos-1</b>	Preprovisions a line card slot for a 6-Port OC-3/STM-1 Packet Over SONET line card.
<b>8e3ds3-1</b>	Preprovisions a line card slot for an 8-Port Unchannelized E3/T3 line card.
<b>8e3ds3atm-1</b>	Preprovisions a line card slot for an 8-Port E3/DS3 ATM line card.
<b>8fastethernet-1</b>	Preprovisions a line card slot for an 8-Port Fast Ethernet Half-Height line card.
<b>mode</b>	Indicates the mode of operation of the line card. Available options are E1 and T1.

**Defaults**

The default mode of operation for the 24-port E1/T1 line card is E1.

**Command Modes**

Global configuration

**Command History**

<b>Release</b>	<b>Modification</b>
Release 12.0(17)ST	This command was introduced on the Cisco 10000 series router for the following line cards: <ul style="list-style-type: none"> <li>• 1-Port Gigabit Ethernet line card</li> <li>• 1-Port OC-12 Packet Over SONET line card</li> <li>• 6-Port OC-3/STM-1 Packet Over SONET line card</li> <li>• 6-Port Channelized T3 line card</li> <li>• 1-Port Channelized OC-12/STM-4 line card</li> <li>• 4-Port Channelized OC-3/STM-1 line card</li> <li>• 8-Port Unchannelized E3/T3 line card</li> <li>• 1-Port OC-12 ATM line card</li> </ul>
Release 12.0(21)SX	This command was modified to support the 4-Port OC3/STM-1 line card with intermediate-reach optics.
Release 12.0(22)S	This command was modified to support the 24-port E1/T1 line card and the 8-Port Unchannelized E3/T3 line card.
Release 12.0(23)S	This command was modified to support the 1-Port Gigabit Ethernet Half-Height line card and the 8-Port Fast Ethernet Half-Height line card.
Release 12.2(15)BX	This command was modified to support the 1-Port OC-48/STM-16 Packet Over SONET line card.
Release 12.3XI	This command was integrated into Cisco IOS Release 12.3XI.
Release 12.2(28)SB	This command was modified to support the 4-Port Channelized T3 Half-Height line card.

**Usage Guidelines**

You must specify a line card slot and subslot, and the line card for which you want to preprovision the line card slot.

If you insert a line card into a line card slot that has been preprovisioned for a different line card, the line card reports a boot failure in an error message to the console. Output from the **show ip interface brief** command indicates that the line card remains in an initialized state.

You can specify a mode of operation for the 24-port E1/T1 line card. If you do not, the line card operates in the E1 mode.

---

**Example**

The following example preprovisions line card slot 2 to accept a 24-port E1/T1 line card operating in E1 mode:

```
Router(config)# card 2/0 24che1t1-1 mode e1
```

## Resetting Line Cards

You can use the privileged EXEC mode **hw-module** command to reset a line card. For example:

```
Router# hw-module slot 2 reset  
Router#
```

Resetting a line card effectively reloads the line card software onto the line card.







## CHAPTER 17

# Provisioning a Subrate E3 or T3 Interface

---

Subrating a T3 or E3 interface reduces the peak access rate by limiting the data transfer rate. Subrate modes configure the line card to connect with Cisco port adapters and with customer premise Data Service Units (DSUs). Bandwidth provisioning tables are provided in this guide to help you connect the Cisco 10000 series router T3 or E3 interface with several manufacturer's DSUs.

You can provision a subrate E3 or T3 interface on the following Cisco 10000 series router line cards:

- 4-Port Channelized T3 Half-Height line card
- 6-Port Channelized T3 line card
- 8-Port Unchannelized E3/T3 line card
- 1-Port Channelized OC-12/STM4 line card
- 4-Port Channelized OC-3/STM-1 line card

The chapter contains the following sections:

- [Implementing a Subrate T3 or E3 Interface, page 17-1](#)
- [Subrate T3 Bandwidth Tables, page 17-2](#)
- [Subrate E3 Bandwidth Tables, page 17-26](#)

## Implementing a Subrate T3 or E3 Interface

DSU manufacturers supporting a subrate T3 or E3 interface use proprietary methods of multiplexing. The Cisco IOS software command line interface (CLI) supports the **dsu mode** and **dsu bandwidth** commands, which configure the line card to emulate a DSU manufacturer's proprietary multiplexing scheme.

The default DSU mode is *cisco*. If the remote end is not a Cisco DS3 subrate interface, use the **dsu mode** command to specify the DSU.

For T3 interfaces, the Cisco 10000 series router supports the following DSUs:

- Digital Link DL3100 T3 Access Multiplexer
- Larscom Access-T45 DS3 Network Service Unit
- Verilink HDM 2 182 DS3 Module
- Kentrox DataSMART T3/E3 IDSU
- Adtran T3SU 300 T3 DSU/CSU

For E3 interfaces, the Cisco 10000 series router supports the following DSUs:

- Digital Link DL3100E E3 Access Multiplexer
- Kentrox DataSMART T3/E3 IDSU

The following sample procedure shows how to use the **dsu mode** and **dsu bandwidth** commands for connecting to a Digital Link DL3100 T3 Access Multiplexer.

- 
- Step 1** Specify a DSU mode for a selected interface using the **dsu mode mode** command from interface configuration mode, where *mode* is the name of the DSU manufacturer.

For example:

```
Router(config)# interface serial 1/0/0
Router(config-if)# dsu mode Digital-link
```

- Step 2** Specify the bandwidth for the T3 or E3 interface by using the **dsu bandwidth bandwidth** command, where *bandwidth* is a value in Kbits/sec. This value indicates the bandwidth needed to match the T3 or E3 interface to the nearest number of timeslots for the configured DSU mode.

For example:

```
Router(config)# interface serial 1/0/0
Router(config-if)# dsu bandwidth 3600
```

See the [Subrate T3 Bandwidth Tables](#) section or the [Subrate E3 Bandwidth Tables](#) section for more information.

- Step 3** After you specify the mode and bandwidth on the line card, you must specify the timeslots on the DSU. For more information, refer to the technical documentation provided with the DSU.
- 

## Subrate T3 Bandwidth Tables

The following tables contain the **dsu bandwidth** command values, based on the dsu mode setting and the number of DSU timeslots. If you specify a dsu bandwidth value as shown in the table, the DS3 subrate interface uses the actual bandwidth and the number of DSU timeslots indicated.

The tables below provide the DSU manufacturer-specific T3 bandwidth settings for the following DSU products:

- [Digital Link DL3100 T3 Access Multiplexer](#)—Table 17-1 on page 17-2
- [Larscom Access-T45 DS3 Network Service Unit](#)—Table 17-2 on page 17-7
- [Verilink HDM 2182 DS3 DSU Module](#)—Table 17-3 on page 17-7
- [Kentrox DataSMART T3/E3 IDSU](#)—Table 17-4 on page 17-8
- [Adtran T3SU 300 T3 DSU/CSU](#)—Table 17-5 on page 17-10

**Table 17-1** Digital Link DL3100 T3 Access Multiplexer

DSU Timeslots	Actual Bandwidth	dsu bandwidth Value
1	300,746	300
2	601,492	600
3	902,239	900

**Table 17-1** *Digital Link DL3100 T3 Access Multiplexer (continued)*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
4	1,202,985	1200
5	1,503,731	1500
6	1,804,477	1800
7	2,105,224	2100
8	2,405,970	2400
9	2,706,716	2700
10	3,007,462	3000
11	3,308,208	3300
12	3,608,955	3600
13	3,909,701	3900
14	4,210,447	4200
15	4,511,193	4500
16	4,811,939	4800
17	5,112,686	5100
18	5,413,432	5400
19	5,714,178	5700
20	6,014,924	6000
21	6,315,671	6300
22	6,616,417	6600
23	6,917,163	6900
24	7,217,909	7200
25	7,518,655	7500
26	7,819,402	7800
27	8,120,148	8100
28	8,420,894	8400
29	8,721,640	8700
30	9,022,387	9000
31	9,323,133	9300
32	9,623,879	9600
33	9,924,625	9900
34	10,225,371	10200
35	10,526,118	10500
36	10,826,864	10800
37	11,127,610	11100
38	11,428,356	11400
39	11,729,103	11700

**Table 17-1** *Digital Link DL3100 T3 Access Multiplexer (continued)*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
40	12,029,849	12000
41	12,330,595	12300
42	12,631,341	12600
43	12,932,087	12900
44	13,232,834	13200
45	13,533,580	13500
46	13,834,326	13800
47	14,135,072	14100
48	14,435,818	14400
49	14,736,565	14700
50	15,037,311	15000
51	15,338,057	15300
52	15,638,803	15600
53	15,939,550	15900
54	16,240,296	16200
55	16,541,042	16500
56	16,841,788	16800
57	17,142,534	17100
58	17,443,281	17400
59	17,744,027	17700
60	18,044,773	18000
61	18,345,519	18300
62	18,646,266	18600
63	18,947,012	18900
64	19,247,758	19200
65	19,548,504	19500
66	19,849,250	19800
67	20,149,997	20100
68	20,450,743	20500
69	20,751,489	20800
70	21,052,235	21100
71	21,352,982	21400
72	21,653,728	21700
73	21,954,474	22000
74	22,255,220	22300
75	22,555,966	22600

**Table 17-1** *Digital Link DL3100 T3 Access Multiplexer (continued)*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
76	22,856,713	22900
77	23,157,459	23200
78	23,458,205	23500
79	23,758,951	23800
80	24,059,697	24100
81	24,360,444	24400
82	24,661,190	24700
83	24,961,936	25000
84	25,262,682	25300
85	25,563,429	25600
86	25,864,175	25900
87	26,164,921	26200
88	26,465,667	26500
89	26,766,413	26800
90	27,067,160	27100
91	27,367,906	27400
92	27,668,652	27700
93	27,969,398	28000
94	28,270,145	28300
95	28,570,891	28600
96	28,871,637	28900
97	29,172,383	29200
98	29,473,129	29500
99	29,773,876	29800
100	30,074,622	30100
101	30,375,368	30400
102	30,676,114	30700
103	30,976,861	31000
104	31,277,607	31300
105	31,578,353	31600
106	31,879,099	31900
107	32,179,845	32200
108	32,480,592	32500
109	32,781,338	32800
110	33,082,084	33100
111	33,382,830	33400

**Table 17-1** *Digital Link DL3100 T3 Access Multiplexer (continued)*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
112	33,683,576	33700
113	33,984,323	34000
114	34,285,069	34300
115	34,585,815	34600
116	34,886,561	34900
117	35,187,308	35200
118	35,488,054	35500
119	35,788,800	35800
120	36,089,546	36100
121	36,390,292	36400
122	36,691,039	36700
123	36,991,785	37000
124	37,292,531	37300
125	37,593,277	37600
126	37,894,024	37900
127	38,194,770	38200
128	38,495,516	38500
129	38,796,262	38800
130	39,097,008	39100
131	39,397,755	39400
132	39,698,501	39700
133	39,999,247	40000
134	40,299,993	40300
135	40,600,739	40600
136	40,901,486	40900
137	41,202,232	41200
138	41,502,978	41500
139	41,803,724	41800
140	42,104,471	42100
141	42,405,217	42400
142	42,705,963	42700
143	43,006,709	43000
144	43,307,455	43300
145	43,608,202	43600
146	43,908,948	43900
147	44,209,694	44210

**Table 17-2** *Larscom Access-T45 DS3 Network Service Unit*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
1	3,157,835	3200
2	6,315,671	6300
3	9,473,506	9500
4	12,631,341	12600
5	15,789,176	15800
6	18,947,012	18900
7	22,104,847	22100
8	25,262,682	25300
9	28,420,518	28400
10	31,578,353	31600
11	34,736,188	34700
12	37,894,024	37900
13	41,051,859	41100
14	44,209,694	44210

**Table 17-3** *Verilink HDM 2182 DS3 DSU Module*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
1	1,578,918	1600
2	3,157,835	3200
3	4,736,753	4700
4	6,315,671	6300
5	7,894,588	7900
6	9,473,506	9500
7	11,052,424	11100
8	12,631,341	12600
9	14,210,259	14200
10	15,789,176	15800
11	17,368,094	17400
12	18,947,012	18900
13	20,525,929	20500
14	22,104,847	22100
15	23,683,765	23700
16	25,262,682	25300
17	26,841,600	26800
18	28,420,518	28400

**Table 17-3 Verilink HDM 2182 DS3 DSU Module (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
19	29,999,435	30000
20	31,578,353	31600

**Table 17-4 Kentrox DataSMART T3/E3 IDSU**

<b>DSU Bandwidth</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
1.5	1,500,000	1500
2.0	2,000,000	2000
2.5	2,500,000	2500
3.0	3,000,000	3000
3.5	3,500,000	3500
4.0	4,000,000	4000
4.5	4,500,000	4500
5.0	5,000,000	5000
5.5	5,500,000	5500
6.0	6,000,000	6000
6.5	6,500,000	6500
7.0	7,000,000	7000
7.5	7,500,000	7500
8.0	8,000,000	8000
8.5	8,500,000	8500
9.0	9,000,000	9000
9.5	9,500,000	9500
10.0	10,000,000	10000
10.5	10,500,000	10500
11.0	11,000,000	11000
11.5	11,500,000	11500
12.0	12,000,000	12000
12.5	12,500,000	12500
13.0	13,000,000	13000
13.5	13,500,000	13500
14.0	14,000,000	14000
14.5	14,500,000	14500
15.0	15,000,000	15000
15.5	15,500,000	15500
16.0	16,000,000	16000



**Table 17-4** *Kentrox DataSMART T3/E3 IDSU (continued)*

<b>DSU Bandwidth</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
16.5	16,500,000	16500
17.0	17,000,000	17000
17.5	17,500,000	17500
18.0	18,000,000	18000
18.5	18,500,000	18500
19.0	19,000,000	19000
19.5	19,500,000	19500
20.0	20,000,000	20000
20.5	20,500,000	20500
21.0	21,000,000	21000
21.5	21,500,000	21500
22.0	22,000,000	22000
22.5	22,500,000	22500
23.0	23,000,000	23000
23.5	23,500,000	23500
24.0	24,000,000	24000
24.5	24,500,000	24500
25.0	25,000,000	25000
25.5	25,500,000	25500
26.0	26,000,000	26000
26.5	26,500,000	26500
27.0	27,000,000	27000
27.5	27,500,000	27500
28.0	28,000,000	28000
28.5	28,500,000	28500
29.0	29,000,000	29000
29.5	29,500,000	29500
30.0	30,000,000	30000
30.5	30,500,000	30500
31.0	31,000,000	31000
31.5	31,500,000	31500
32.0	32,000,000	32000
32.5	32,500,000	32500
33.0	33,000,000	33000
33.5	33,500,000	33500
34.0	34,000,000	34000

**Table 17-4** *Kentrox DataSMART T3/E3 IDSU (continued)*

<b>DSU Bandwidth</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
34.5	34,500,000	34500
35.0	35,000,000	35000
45.0	44,209,694	44210

**Table 17-5** *Adtran T3SU 300 T3 DSU/CSU*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
1	75,187	80
2	150,373	150
3	225,560	230
4	300,746	300
5	375,933	380
6	451,119	450
7	526,306	530
8	601,492	600
9	676,679	680
10	751,866	750
11	827,052	830
12	902,239	900
13	977,425	980
14	1,052,612	1050
15	1,127,798	1130
16	1,202,985	1200
17	1,278,171	1280
18	1,353,358	1350
19	1,428,545	1430
20	1,503,731	1500
21	1,578,918	1580
22	1,654,104	1650
23	1,729,291	1730
24	1,804,477	1800
25	1,879,664	1880
26	1,954,850	1950
27	2,030,037	2030
28	2,105,224	2110
29	2,180,410	2180

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
30	2,255,597	2260
31	2,330,783	2330
32	2,405,970	2410
33	2,481,156	2480
34	2,556,343	2560
35	2,631,529	2630
36	2,706,716	2710
37	2,781,903	2780
38	2,857,089	2860
39	2,932,276	2930
40	3,007,462	3010
41	3,082,649	3080
42	3,157,835	3160
43	3,233,022	3230
44	3,308,208	3310
45	3,383,395	3380
46	3,458,582	3460
47	3,533,768	3530
48	3,608,955	3610
49	3,684,141	3680
50	3,759,328	3760
51	3,834,514	3830
52	3,909,701	3910
53	3,984,887	3980
54	4,060,074	4060
55	4,135,261	4140
56	4,210,447	4210
57	4,285,634	4290
58	4,360,820	4360
59	4,436,007	4440
60	4,511,193	4510
61	4,586,380	4590
62	4,661,566	4660
63	4,736,753	4740
64	4,811,939	4810
65	4,887,126	4890

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
66	4,962,313	4960
67	5,037,499	5040
68	5,112,686	5110
69	5,187,872	5190
70	5,263,059	5260
71	5,338,245	5340
72	5,413,432	5410
73	5,488,618	5490
74	5,563,805	5560
75	5,638,992	5640
76	5,714,178	5710
77	5,789,365	5790
78	5,864,551	5860
79	5,939,738	5940
80	6,014,924	6010
81	6,090,111	6090
82	6,165,297	6170
83	6,240,484	6240
84	6,315,671	6320
85	6,390,857	6390
86	6,466,044	6470
87	6,541,230	6540
88	6,616,417	6620
89	6,691,603	6690
90	6,766,790	6770
91	6,841,976	6840
92	6,917,163	6920
93	6,992,350	6990
94	7,067,536	7070
95	7,142,723	7140
96	7,217,909	7220
97	7,293,096	7290
98	7,368,282	7370
99	7,443,469	7440
100	7,518,655	7520
101	7,593,842	7590

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
102	7,669,029	7670
103	7,744,215	7740
104	7,819,402	7820
105	7,894,588	7890
106	7,969,775	7970
107	8,044,961	8040
108	8,120,148	8120
109	8,195,334	8200
110	8,270,521	8270
111	8,345,708	8350
112	8,420,894	8420
113	8,496,081	8500
114	8,571,267	8570
115	8,646,454	8650
116	8,721,640	8720
117	8,796,827	8800
118	8,872,013	8870
119	8,947,200	8950
120	9,022,387	9020
121	9,097,573	9100
122	9,172,760	9170
123	9,247,946	9250
124	9,323,133	9320
125	9,398,319	9400
126	9,473,506	9470
127	9,548,692	9550
128	9,623,879	9620
129	9,699,066	9700
130	9,774,252	9770
131	9,849,439	9850
132	9,924,625	9920
133	9,999,812	10000
134	10,074,998	10070
135	10,150,185	10150
136	10,225,371	10230
137	10,300,558	10300

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
138	10,375,745	10380
139	10,450,931	10450
140	10,526,118	10530
141	10,601,304	10600
142	10,676,491	10680
143	10,751,677	10750
144	10,826,864	10830
145	10,902,050	10900
146	10,977,237	10980
147	11,052,424	11050
148	11,127,610	11130
149	11,202,797	11200
150	11,277,983	11280
151	11,353,170	11350
152	11,428,356	11430
153	11,503,543	11500
154	11,578,729	11580
155	11,653,916	11650
156	11,729,103	11730
157	11,804,289	11800
158	11,879,476	11880
159	11,954,662	11950
160	12,029,849	12030
161	12,105,035	12110
162	12,180,222	12180
163	12,255,408	12260
164	12,330,595	12330
165	12,405,782	12410
166	12,480,968	12480
167	12,556,155	12560
168	12,631,341	12630
169	12,706,528	12710
170	12,781,714	12780
171	12,856,901	12860
172	12,932,087	12930
173	13,007,274	13010

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
174	13,082,461	13080
175	13,157,647	13160
176	13,232,834	13230
177	13,308,020	13310
178	13,383,207	13380
179	13,458,393	13460
180	13,533,580	13530
181	13,608,766	13610
182	13,683,953	13680
183	13,759,139	13760
184	13,834,326	13830
185	13,909,513	13910
186	13,984,699	13980
187	14,059,886	14060
188	14,135,072	14140
189	14,210,259	14210
190	14,285,445	14290
191	14,360,632	14360
192	14,435,818	14440
193	14,511,005	14510
194	14,586,192	14590
195	14,661,378	14660
196	14,736,565	14740
197	14,811,751	14810
198	14,886,938	14890
199	14,962,124	14960
200	15,037,311	15040
201	15,112,497	15110
202	15,187,684	15190
203	15,262,871	15260
204	15,338,057	15340
205	15,413,244	15410
206	15,488,430	15490
207	15,563,617	15560
208	15,638,803	15640
209	15,713,990	15710

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
210	15,789,176	15790
211	15,864,363	15860
212	15,939,550	15940
213	16,014,736	16010
214	16,089,923	16090
215	16,165,109	16170
216	16,240,296	16240
217	16,315,482	16320
218	16,390,669	16390
219	16,465,855	16470
220	16,541,042	16540
221	16,616,229	16620
222	16,691,415	16690
223	16,766,602	16770
224	16,841,788	16840
225	16,916,975	16920
226	16,992,161	16990
227	17,067,348	17070
228	17,142,534	17140
229	17,217,721	17220
230	17,292,908	17290
231	17,368,094	17370
232	17,443,281	17440
233	17,518,467	17520
234	17,593,654	17590
235	17,668,840	17670
236	17,744,027	17740
237	17,819,213	17820
238	17,894,400	17890
239	17,969,587	17970
240	18,044,773	18040
241	18,119,960	18120
242	18,195,146	18200
243	18,270,333	18270
244	18,345,519	18350
245	18,420,706	18420



**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
246	18,495,892	18500
247	18,571,079	18570
248	18,646,266	18650
249	18,721,452	18720
250	18,796,639	18800
251	18,871,825	18870
252	18,947,012	18950
253	19,022,198	19020
254	19,097,385	19100
255	19,172,571	19170
256	19,247,758	19250
257	19,322,945	19320
258	19,398,131	19400
259	19,473,318	19470
260	19,548,504	19550
261	19,623,691	19620
262	19,698,877	19700
263	19,774,064	19770
264	19,849,250	19850
265	19,924,437	19920
266	19,999,624	20000
267	20,074,810	20070
268	20,149,997	20150
269	20,225,183	20230
270	20,300,370	20300
271	20,375,556	20380
272	20,450,743	20450
273	20,525,929	20530
274	20,601,116	20600
275	20,676,303	20680
276	20,751,489	20750
277	20,826,676	20830
278	20,901,862	20900
279	20,977,049	20980
280	21,052,235	21050
281	21,127,422	21130

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
282	21,202,608	21200
283	21,277,795	21280
284	21,352,982	21350
285	21,428,168	21430
286	21,503,355	21500
287	21,578,541	21580
288	21,653,728	21650
289	21,728,914	21730
290	21,804,101	21800
291	21,879,287	21880
292	21,954,474	21950
293	22,029,661	22030
294	22,104,847	22100
295	22,180,034	22180
296	22,255,220	22260
297	22,330,407	22330
298	22,405,593	22410
299	22,480,780	22480
300	22,555,966	22560
301	22,631,153	22630
302	22,706,339	22710
303	22,781,526	22780
304	22,856,713	22860
305	22,931,899	22930
306	23,007,086	23010
307	23,082,272	23080
308	23,157,459	23160
309	23,232,645	23230
310	23,307,832	23310
311	23,383,018	23380
312	23,458,205	23460
313	23,533,392	23530
314	23,608,578	23610
315	23,683,765	23680
316	23,758,951	23760
317	23,834,138	23830

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
318	23,909,324	23910
319	23,984,511	23980
320	24,059,697	24060
321	24,134,884	24130
322	24,210,071	24210
323	24,285,257	24290
324	24,360,444	24360
325	24,435,630	24440
326	24,510,817	24510
327	24,586,003	24590
328	24,661,190	24660
329	24,736,376	24740
330	24,811,563	24810
331	24,886,750	24890
332	24,961,936	24960
333	25,037,123	25040
334	25,112,309	25110
335	25,187,496	25190
336	25,262,682	25260
337	25,337,869	25340
338	25,413,055	25410
339	25,488,242	25490
340	25,563,429	25560
341	25,638,615	25640
342	25,713,802	25710
343	25,788,988	25790
344	25,864,175	25860
345	25,939,361	25940
346	26,014,548	26010
347	26,089,734	26090
348	26,164,921	26160
349	26,240,108	26240
350	26,315,294	26320
351	26,390,481	26390
352	26,465,667	26470
353	26,540,854	26540

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
354	26,616,040	26620
355	26,691,227	26690
356	26,766,413	26770
357	26,841,600	26840
358	26,916,787	26920
359	26,991,973	26990
360	27,067,160	27070
361	27,142,346	27140
362	27,217,533	27220
363	27,292,719	27290
364	27,367,906	27370
365	27,443,092	27440
366	27,518,279	27520
367	27,593,466	27590
368	27,668,652	27670
369	27,743,839	27740
370	27,819,025	27820
371	27,894,212	27890
372	27,969,398	27970
373	28,044,585	28040
374	28,119,771	28120
375	28,194,958	28190
376	28,270,145	28270
377	28,345,331	28350
378	28,420,518	28420
379	28,495,704	28500
380	28,570,891	28570
381	28,646,077	28650
382	28,721,264	28720
383	28,796,450	28800
384	28,871,637	28870
385	28,946,824	28950
386	29,022,010	29020
387	29,097,197	29100
388	29,172,383	29170
389	29,247,570	29250

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
390	29,322,756	29320
391	29,397,943	29400
392	29,473,129	29470
393	29,548,316	29550
394	29,623,503	29620
395	29,698,689	29700
396	29,773,876	29770
397	29,849,062	29850
398	29,924,249	29920
399	29,999,435	30000
400	30,074,622	30070
401	30,149,808	30150
402	30,224,995	30220
403	30,300,182	30300
404	30,375,368	30380
405	30,450,555	30450
406	30,525,741	30530
407	30,600,928	30600
408	30,676,114	30680
409	30,751,301	30750
410	30,826,487	30830
411	30,901,674	30900
412	30,976,861	30980
413	31,052,047	31050
414	31,127,234	31130
415	31,202,420	31200
416	31,277,607	31280
417	31,352,793	31350
418	31,427,980	31430
419	31,503,166	31500
420	31,578,353	31580
421	31,653,539	31650
422	31,728,726	31730
423	31,803,913	31800
424	31,879,099	31880
425	31,954,286	31950

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
426	32,029,472	32030
427	32,104,659	32100
428	32,179,845	32180
429	32,255,032	32260
430	32,330,218	32330
431	32,405,405	32410
432	32,480,592	32480
433	32,555,778	32560
434	32,630,965	32630
435	32,706,151	32710
436	32,781,338	32780
437	32,856,524	32860
438	32,931,711	32930
439	33,006,897	33010
440	33,082,084	33080
441	33,157,271	33160
442	33,232,457	33230
443	33,307,644	33310
444	33,382,830	33380
445	33,458,017	33460
446	33,533,203	33530
447	33,608,390	33610
448	33,683,576	33680
449	33,758,763	33760
450	33,833,950	33830
451	33,909,136	33910
452	33,984,323	33980
453	34,059,509	34060
454	34,134,696	34130
455	34,209,882	34210
456	34,285,069	34290
457	34,360,255	34360
458	34,435,442	34440
459	34,510,629	34510
460	34,585,815	34590
461	34,661,002	34660

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
462	34,736,188	34740
463	34,811,375	34810
464	34,886,561	34890
465	34,961,748	34960
466	35,036,934	35040
467	35,112,121	35110
468	35,187,308	35190
469	35,262,494	35260
470	35,337,681	35340
471	35,412,867	35410
472	35,488,054	35490
473	35,563,240	35560
474	35,638,427	35640
475	35,713,613	35710
476	35,788,800	35790
477	35,863,987	35860
478	35,939,173	35940
479	36,014,360	36010
480	36,089,546	36090
481	36,164,733	36160
482	36,239,919	36240
483	36,315,106	36320
484	36,390,292	36390
485	36,465,479	36470
486	36,540,666	36540
487	36,615,852	36620
488	36,691,039	36690
489	36,766,225	36770
490	36,841,412	36840
491	36,916,598	36920
492	36,991,785	36990
493	37,066,971	37070
494	37,142,158	37140
495	37,217,345	37220
496	37,292,531	37290
497	37,367,718	37370

**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
498	37,442,904	37440
499	37,518,091	37520
500	37,593,277	37590
501	37,668,464	37670
502	37,743,650	37740
503	37,818,837	37820
504	37,894,024	37890
505	37,969,210	37970
506	38,044,397	38040
507	38,119,583	38120
508	38,194,770	38190
509	38,269,956	38270
510	38,345,143	38350
511	38,420,329	38420
512	38,495,516	38500
513	38,570,703	38570
514	38,645,889	38650
515	38,721,076	38720
516	38,796,262	38800
517	38,871,449	38870
518	38,946,635	38950
519	39,021,822	39020
520	39,097,008	39100
521	39,172,195	39170
522	39,247,382	39250
523	39,322,568	39320
524	39,397,755	39400
525	39,472,941	39470
526	39,548,128	39550
527	39,623,314	39620
528	39,698,501	39700
529	39,773,687	39770
530	39,848,874	39850
531	39,924,061	39920
532	39,999,247	40000
533	40,074,434	40070



**Table 17-5 Adtran T3SU 300 T3 DSU/CSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
534	40,149,620	40150
535	40,224,807	40220
536	40,299,993	40300
537	40,375,180	40380
538	40,450,366	40450
539	40,525,553	40530
540	40,600,739	40600
541	40,675,926	40680
542	40,751,113	40750
543	40,826,299	40830
544	40,901,486	40900
545	40,976,672	40980
546	41,051,859	41050
547	41,127,045	41130
548	41,202,232	41200
549	41,277,418	41280
550	41,352,605	41350
551	41,427,792	41430
552	41,502,978	41500
553	41,578,165	41580
554	41,653,351	41650
555	41,728,538	41730
556	41,803,724	41800
557	41,878,911	41880
558	41,954,097	41950
559	42,029,284	42030
560	42,104,471	42100
561	42,179,657	42180
562	42,254,844	42250
563	42,330,030	42330
564	42,405,217	42410
565	42,480,403	42480
566	42,555,590	42560
567	42,630,776	42630
568	42,705,963	42710
569	42,781,150	42780

**Table 17-5** *Adtran T3SU 300 T3 DSU/CSU (continued)*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
570	42,856,336	42860
571	42,931,523	42930
572	43,006,709	43010
573	43,081,896	43080
574	43,157,082	43160
575	43,232,269	43230
576	43,307,455	43310
577	43,382,642	43380
578	43,457,829	43460
579	43,533,015	43530
580	43,608,202	43610
581	43,683,388	43680
582	43,758,575	43760
583	43,833,761	43830
584	43,908,948	43910
585	43,984,134	43980
586	44,059,321	44060
587	44,134,508	44130
588	44,209,694	44210

## Subrate E3 Bandwidth Tables

The following tables contain the **dsu bandwidth** command values, based on the dsu mode setting and the number of DSU timeslots. If you specify a dsu bandwidth value as shown in the table, the E3 subrate interface uses the actual bandwidth and the number of DSU timeslots indicated.

The tables below provide the DSU manufacturer-specific E3 bandwidth settings for the following DSU products:

- [Digital Link DL3100E E3 Access Multiplexer—Table 17-6 on page 17-26](#)
- [Kentrox DataSMART T3/E3 IDSU—Table 17-7 on page 17-29](#)

**Table 17-6** *Digital Link DL3100E E3 Access Multiplexer*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
1	358,000	358
2	716,000	716
3	1,074,000	1074
4	1,432,000	1432
5	1,790,000	1790

**Table 17-6** *Digital Link DL3100E E3 Access Multiplexer (continued)*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
6	2,148,000	2148
7	2,506,000	2506
8	2,864,000	2864
9	3,222,000	3222
10	3,580,000	3580
11	3,938,000	3938
12	4,296,000	4296
13	4,654,000	4654
14	5,012,000	5012
15	5,370,000	5370
16	5,728,000	5728
17	6,086,000	6086
18	6,444,000	6444
19	6,802,000	6802
20	7,160,000	7160
21	7,518,000	7518
22	7,876,000	7876
23	8,234,000	8234
24	8,592,000	8592
25	8,950,000	8950
26	9,308,000	9308
27	9,666,000	9666
28	10,024,000	10024
29	10,382,000	10382
30	10,740,000	10740
31	11,098,000	11098
32	11,456,000	11456
33	11,814,000	11814
34	12,172,000	12172
35	12,530,000	12530
36	12,888,000	12888
37	13,246,000	13246
38	13,604,000	13604
39	13,962,000	13962
40	14,320,000	14320
41	14,678,000	14678

**Table 17-6** *Digital Link DL3100E E3 Access Multiplexer (continued)*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
42	15,036,000	15036
43	15,394,000	15394
44	15,752,000	15752
45	16,110,000	16110
46	16,468,000	16468
47	16,826,000	16826
48	17,184,000	17184
49	17,542,000	17542
50	17,900,000	17900
51	18,258,000	18258
52	18,616,000	18616
53	18,974,000	18974
54	19,332,000	19332
55	19,690,000	19690
56	20,048,000	20048
57	20,406,000	20406
58	20,764,000	20764
59	21,122,000	21122
60	21,480,000	21480
61	21,838,000	21838
62	22,196,000	22196
63	22,554,000	22554
64	22,912,000	22912
65	23,270,000	23270
66	23,628,000	23628
67	23,986,000	23986
68	24,344,000	24344
69	24,702,000	24702
70	25,060,000	25060
71	25,418,000	25418
72	25,776,000	25776
73	26,134,000	26134
74	26,492,000	26492
75	26,850,000	26850
76	27,208,000	27208
77	27,566,000	27566

**Table 17-6** *Digital Link DL3100E E3 Access Multiplexer (continued)*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
78	27,924,000	27924
79	28,282,000	28282
80	28,640,000	28640
81	28,998,000	28998
82	29,356,000	29356
83	29,714,000	29714
84	30,072,000	30072
85	30,430,000	30430
86	30,788,000	30788
87	31,146,000	31146
88	31,504,000	31504
89	31,862,000	31862
90	32,220,000	32220
91	32,578,000	32578
92	32,936,000	32936
93	33,294,000	33294
94	33,652,000	33652
95	34,010,000	34010

**Table 17-7** *Kentrox DataSMART T3/E3 IDSU*

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
1	1,000,000	1000
1.5	1,500,000	1500
2	2,000,000	2000
2.5	2,500,000	2500
3	3,000,000	3000
3.5	3,500,000	3500
4	4,000,000	4000
4.5	4,500,000	4500
5	5,000,000	5000
5.5	5,500,000	5500
6	6,000,000	6000
6.5	6,500,000	6500
7	7,000,000	7000
7.5	7,500,000	7500

**Table 17-7 Kentrox DataSMART T3/E3 IDSU (continued)**

<b>DSU Timeslots</b>	<b>Actual Bandwidth</b>	<b>dsu bandwidth Value</b>
8	8,000,000	8000
8.5	8,500,000	8500
9	9,000,000	9000
9.5	9,500,000	9500
10	10,000,000	10000
10.5	10,500,000	10500
11	11,000,000	11000
11.5	11,500,000	11500
12	12,000,000	12000
12.5	12,500,000	12500
13	13,000,000	13000
13.5	13,500,000	13500
14	14,000,000	14000
14.5	14,500,000	14500
15	15,000,000	15000
15.5	15,500,000	15500
16	16,000,000	16000
16.5	16,500,000	16500
17	17,000,000	17000
17.5	17,500,000	17500
18	18,000,000	18000
18.5	18,500,000	18500
19	19,000,000	19000
19.5	19,500,000	19500
20	20,000,000	20000
20.5	20,500,000	20500
21	21,000,000	21000
21.5	21,500,000	21500
22	22,000,000	22000
22.5	22,500,000	22500
23	23,000,000	23000
23.5	23,500,000	23500
24	24,000,000	24000
24.5	24,500,000	24500
34	34,000,000	34000









# CHAPTER 18

## Configuration Examples

---

This chapter provides Cisco IOS CLI configuration examples for the Cisco 10000 series router. Each example uses the commands you enter at the IOS command line interface (CLI).

This chapter contains the following examples:

- [Example 1: Configuring an Unchannelized Subrate T3 Port, Point to Multipoint Frame Relay, and OSPF, page 18-1](#)
- [Example 2: OSPF, BGP, Channelized Full Rate T1, page 18-3](#)
- [Example 3: Quality of Service Policy Propagation Using Border Gateway Protocol, page 18-5](#)
- [Example 4: MPLS Virtual Private Networks, page 18-8](#)

### Example 1: Configuring an Unchannelized Subrate T3 Port, Point to Multipoint Frame Relay, and OSPF

This example provides the sequence of commands necessary to accomplish the following:

- [Configure an Unchannelized T3 Controller, page 18-2](#)
- [Configure Subrate T3, page 18-2](#)
- [Configure Frame Relay Encapsulation, page 18-2](#)
- [Configure Point to Multipoint Frame Relay, page 18-2](#)
- [Create an OSPF Routing Process, page 18-2](#)

The CLI command sequence is based on the assumption that we begin at a privileged EXEC prompt. Descriptive headings inserted in the CLI text announce that the hardware or features are being enabled.

```
Router# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# ip routing
Router(config)# !
```

### Configure an Unchannelized T3 Controller

Configure an unchannelized T3 controller and specify clock source:

```
Router(config)# controller T3 1/0/0
Router(config)# no channelized
Router(config-controller)# clock source line
Router(config-controller)# end
```

### Configure Subrate T3

Configure a subrate of 25,000 kbps on the T3 port:

```
Router(config)# interface Serial1/0/0/1:0
Router(config-if)# no ip address
Router(config-if)# no ip directed broadcast
Router(config-if)# dsu bandwidth 25000
Router(config-if)# dsu mode <dsu type>
```

### Configure Frame Relay Encapsulation

Configure Frame Relay encapsulation on interface Serial1/0/0/1:0:

```
Router(config-if)# encapsulation frame-relay
Router(config-if)# frame-relay lmi-n391dte 6
Router(config-if)# keepalive 10
Router(config-if)# frame-relay lmi-n392dte 3
Router(config-if)# frame-relay lmi-n393dte 4
Router(config-if)# no shutdown
Router(config-if)# ip address 20.0.0.1 255.255.255.0
```

### Configure Point to Multipoint Frame Relay

Configure the Cisco 10000 series router to use DLCI 101 to communicate with Router 1 and DLCI 102 to communicate with Router 2:

```
Router(config-if)# ip ospf network point-to-multipoint
Router(config-if)# frame-relay map ip 20.0.0.2 101 broadcast
Router(config-if)# frame-relay map ip 20.0.0.3 102 broadcast
Router(config-if)# no shutdown
```

### Create an OSPF Routing Process

Enable OSPF routing process 100. Define an interface on which OSPF runs and the area ID for that interface.

```
Router(config-if)# router ospf 100
Router(config-router)# network 20.0.0.0 0.255.255.255 area 0
Router(config-router)# end
```

## Example 2: OSPF, BGP, Channelized Full Rate T1

This example provides the sequence of commands necessary to accomplish the following:

- [Create a Gigabit Ethernet Uplink Port, page 18-3](#)
- [Create a T3 Controller, page 18-3](#)
- [Create a Full-Rate Channelized T1 Interface, page 18-3](#)
- [Configure Frame Relay Encapsulation, page 18-3](#)
- [Enable an OSPF Routing Process, page 18-4](#)
- [Enable OSPF Route Redistribution, page 18-4](#)
- [Configure BGP to Redistribute Routes Between Autonomous Systems, page 18-4](#)

The CLI command sequence below starts with the assumption that you begin at a privileged EXEC prompt. Descriptive headings inserted in the CLI text announce that the hardware or features are being enabled.

```
Router# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
```

### Create a Gigabit Ethernet Uplink Port

Provision an operational gigabit Ethernet card:

```
Router(config)# interface GigabitEthernet8/0/0
Router(config-if)# ip address 125.1.1.2 255.255.255.0
Router(config-if)# keepalive
Router(config-if)# no shutdown
Router(config-if)# end
Router# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# ip routing
```

### Create a T3 Controller

Enable a functional T3 controller on the CT3 line card:

```
Router(config)# controller T3 1/0/0
Router(config-controller)# clock source line
```

### Create a Full-Rate Channelized T1 Interface

Configure a channelized, full-rate T1:

```
Router(config-controller)# t1 1 channel-group 0 timeslots 1-24
Router(config-controller)# t1 1 clock source Line
Router(config-controller)# interface Serial1/0/0/1:0
Router(config-if)# no ip address
```

### Configure Frame Relay Encapsulation

Enable Frame Relay encapsulation, create a Frame Relay subinterface, and specify the default LMI type:

```
Router(config-if)# encapsulation frame-relay
Router(config-if)# frame-relay lmi-n391dte 6
Router(config-if)# keepalive 10
```

```

Router(config-if)# frame-relay lmi-n392dte 3
Router(config-if)# frame-relay lmi-n393dte 4
Router(config-if)# no shutdown
Router(config-if)# interface Serial1/0/0/1:0.100 point-to-point
Router(config-subif)# ip address 128.1.1.2 255.255.255.0
Router(config-subif)# frame-relay interface-dlci 100
Router(config-fr-dlci)# no shutdown
Router(config-if)# end
Router# config terminal
Enter configuration commands, one per line. End with CNTL/Z.

```

### Enable an OSPF Routing Process

Create OSPF routing process 200, specify a range of IP addresses to be associated with the routing process, and assign an area ID to be associated with that range of IP addresses:

```

Router(config)# router ospf 200
Router(config-router)# network 125.1.1.0 0.0.0.255 area 0

```

### Enable OSPF Route Redistribution

Enable route redistribution through BGP:

```

Router(config-router)# redistribute bgp 200 subnets

```

### Configure BGP to Redistribute Routes Between Autonomous Systems

Enable BGP (starting at the first arrow), define a neighbor for autonomous system 300 (the second arrow). The **network** commands define the networks from which OSPF routes are injected into the BGP table.

```

Router(config-router)# router bgp 200
Router(config-router)# neighbor 128.1.1.1 remote-as 300
Router(config-router)# network 125.0.0.0
Router(config-router)# end
Router# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# router bgp 200
Router(config-router)# network 130.1.0.0
Router(config-router)# end
Router# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# router bgp 200
Router(config-router)# network 130.2.0.0
Router(config-router)# end
Router# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# router bgp 200
Router(config-router)# network 130.3.0.0
Router(config-router)# end
Router# config terminal
Enter configuration commands, one per line. End with CNTL/Z.

```

```

Router(config)# router bgp 200
Router(config-router)# network 130.4.0.0
Router(config-router)# end
Router# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# router bgp 200
Router(config-router)# network 130.5.0.0
Router(config-router)# end
Router#

```

## Example 3: Quality of Service Policy Propagation Using Border Gateway Protocol


QoS Policy Propagation using Border Gateway Protocol (QPPB) allows you to classify packets by IP precedence based on BGP community lists, BGP autonomous system paths, and access lists. After a packet has been classified, you can use other QoS features such as committed access rate (CAR) and weighted random early detection (WRED) to specify and enforce policies to fit your business model.

The following example shows how to

1. Create route maps to match BGP community lists, access lists, and BGP AS paths
2. Apply IP precedence to routes learned from neighbors

In this example, the Cisco 10000 series router learns routes from autonomous system (AS) 10 and AS 60. QoS policy is applied to all packets that match the defined route maps. Any packets from the Cisco 10000 series router to AS 10 or AS 60 are sent to the appropriate QoS policy (Figure 18-1).

**Figure 18-1 Cisco 10000 Series Router Routes and QoS Policy Application**



### Cisco 10000 Series Router Configuration

```

Router(config)# router bgp 30
Router(config)# table-map precedence-map
Router(config-router)# neighbor 20.20.20.1 remote-as 10
Router(config-router)# neighbor 20.20.20.1 send-community
Router(config-router)# neigh 20.20.20.1 route-map precedence-map out
!
Router(config)# ip bgp-community new-format

```

Match community 1, set the IP precedence to priority, and set the QoS group to 1.

```

Router(config)# route-map precedence-map permit 10
Router(config-route-ma)# match community 1

```

```
Router(config-route-ma)# set ip precedence priority
Router(config-route-ma)# set ip qos-group 1
```

Match community 2 and set the IP precedence to immediate.

```
Router(config)# route-map precedence-map permit 20
Router(config-route-ma)# match community 2
Router(config-route-ma)# set ip precedence immediate
```

Match community 3 and set the IP precedence to Flash.

```
Router(config)# route-map precedence-map permit 30
Router(config-route-ma)# match community 3
Router(config-route-ma)# set ip precedence flash
```

Match community 4 and set the IP precedence to Flash-override.

```
Router(config)# route-map precedence-map permit 40
Router(config-route-ma)# match community 4
Router(config-route-ma)# set ip precedence flash-override
```

Match community 5 and set the IP precedence to critical.

```
Router(config)# route-map precedence-map permit 50
Router(config-route-ma)# match community 5
Router(config-route-ma)# set ip precedence critical
```

Match community 6 and set the IP precedence to internet.

```
Router(config)# route-map precedence-map permit 60
Router(config-route-ma)# match community 6
Router(config-route-ma)# set ip precedence internet
```

Match community 7 and set the IP precedence to network.

```
Router(config)# route-map precedence-map permit 70
Router(config-route-ma)# match community 7
Router(config-route-ma)# set ip precedence network
```

Match ip address access list 69 or match AS path 1, set the IP precedence to critical, and set the QoS group to 9.

```
Router(config)# route-map precedence-map permit 75
Router(config-route-ma)# match ip address 69
Router(config-route-ma)# match as-path 1
Router(config-route-ma)# set ip precedence critical
Router(config-route-ma)# set ip qos-group 9
```

For everything else, set the IP precedence to routine.

```
Router(config)# route-map precedence-map permit 80
Router(config-route-ma)# set ip precedence routine
```

Define the community lists.

```
Router(config)# ip community-list 1 permit 60:1
Router(config)# ip community-list 2 permit 60:2
Router(config)# ip community-list 3 permit 60:3
Router(config)# ip community-list 4 permit 60:4
Router(config)# ip community-list 5 permit 60:5
Router(config)# ip community-list 6 permit 60:6
Router(config)# ip community-list 7 permit 60:7
```

Define the AS path.

```
Router(config)# ip as-path access-list 1 permit ^10_60
```

Define the access list.

```
Router(config)# access-list 69 permit 69.0.0.0
```

### Router B Running Configuration

```
RouterB(config)# router bgp 10
RouterB(config-router)# neighbor 30.30.30.1 remote-as 30
RouterB(config-router)# neighbor 30.30.30.1 send-community
RouterB(config-router)# neigh 30.30.30.1 route-map send_community out
!
RouterB(config)# ip bgp-community new-format
```

Match prefix 10 and set community to 60:1.

```
RouterB(config)# route-map send_community permit 10
RouterB(config-route-ma)# match ip address 10
RouterB(config-route-ma)# set community 60:1
```

Match prefix 20 and set community to 60:2.

```
RouterB(config)# route-map send_community permit 20
RouterB(config-route-ma)# match ip address 20
RouterB(config-route-ma)# set community 60:2
```

Match prefix 30 and set community to 60:3.

```
RouterB(config)# route-map send_community permit 30
RouterB(config-route-ma)# match ip address 30
RouterB(config-route-ma)# set community 60:3
```

Match prefix 40 and set community to 60:4.

```
RouterB(config)# route-map send_community permit 40
RouterB(config-route-ma)# match ip address 40
RouterB(config-route-ma)# set community 60:4
```

Match prefix 50 and set community to 60:5.

```
RouterB(config)# route-map send_community permit 50
RouterB(config-route-ma)# match ip address 50
RouterB(config-route-ma)# set community 60:5
```

Match prefix 60 and set community to 60:6.

```
RouterB(config)# route-map send_community permit 60
RouterB(config-route-ma)# match ip address 60
RouterB(config-route-ma)# set community 60:6
```

Match prefix 70 and set community to 60:7.

```
RouterB(config)# route-map send_community permit 70
RouterB(config-route-ma)# match ip address 70
RouterB(config-route-ma)# set community 60:7
```

For all others, set community to 60:8.

```
RouterB(config)# route-map send_community permit 80
RouterB(config-route-ma)# set community 60:8
```

Define the access lists.

```
RouterB(config)# access-list 10 permit 61.0.0.0
RouterB(config)# access-list 20 permit 62.0.0.0
RouterB(config)# access-list 30 permit 63.0.0.0
RouterB(config)# access-list 40 permit 64.0.0.0
```

```
RouterB(config)# access-list 50 permit 65.0.0.0
RouterB(config)# access-list 60 permit 66.0.0.0
RouterB(config)# access-list 70 permit 67.0.0.0
```

The following example shows how to configure several interfaces to classify packets based on the IP precedence and QoS group ID:

```
interface serial5/0/0/1:0
ip address 200.28.38.2 255.255.255.0
bgp-policy source ip-prec-map
no ip mroute-cache
no cdp enable
frame-relay interface-dlci 20 IETF

interface serial6/0/0/1:0
ip address 200.28.28.2 255.255.255.0
bgp-policy source qos-group
no ip mroute-cache
no cdp enable
frame-relay interface-dlci 20 IETF
```

## Example 4: MPLS Virtual Private Networks

MPLS can be used to create IP-based VPNs. MPLS VPNs offer all of the value of traditional VPNs, including reduced costs and enhanced security. In addition, because MPLS VPNs are created in Layer 3, they are more scalable, easier to configure, and easier to manage than Layer 2 VPNs.

Perform the tasks in the following sections to configure MPLS Virtual Private Networks (VPNs):

The following sections show examples of:

- [Defining a VPN](#)
- [Configuring BGP Routing Sessions](#)
- [Configuring PE to PE Routing Sessions](#)
- [Configuring BGP PE to CE Routing Sessions](#)
- [Configuring RIP PE to CE Routing Sessions](#)
- [Configuring Static Route PE to CE Routing Sessions](#)

### Defining a VPN

Enter VRF configuration mode, define the VPN routing instance by assigning a VRF name, and create routing and forwarding tables.

```
Router(config)# ip vrf go_fast_internet_company
Router(config-vrf)# rd 200.28.28.40:42
```

Create a list of import or export route target communities for the specified VRF.

```
Router(config-vrf)# route-target import 200.28.28.40:43
```

Associate the specified route map with the VRF and with an interface or subinterface.

```
Router(config-vrf)# import map go_fast
Router(config-if)# ip vrf forwarding go_fast_internet_company
```



### Configuring BGP Routing Sessions

To configure BGP routing sessions in a provider network, use the following commands in router configuration mode on the PE router:

Configure the BGP routing process with the autonomous system number.

```
Router(config)# router bgp 42
```

Specify a neighbor's IP address or BGP peer group, identifying it to the local autonomous system.

```
Router(config-router)# neighbor 200.28.28.40
```

Activate the advertisement of the IPv4 address family.

```
Router(config-router)# neighbor 200.28.28.40 activate
```

### Configuring PE to PE Routing Sessions

To configure PE to PE routing sessions in a provider network, use the following commands in router configuration mode on the PE router:

Define IBGP parameters for VPNv4 network-layer reachability information (NLRI) exchange.

```
Router(config-router)# address-family vpnv4 unicast
```

Define an IBGP session to exchange VPNv4 NLRIs.

```
Router(config-router-af)# neighbor 200.28.28.45 remote-as 48  
Router(config-router-af)# exit
```

Activate the advertisement of the IPv4 address family.

```
Router(config-router)# neighbor 200.28.28.45 activate
```

### Configuring BGP PE to CE Routing Sessions

To configure BGP PE to CE routing sessions, use the following commands in router configuration mode on the PE router:

Define EBGP parameters for PE to CE routing sessions.

```
Router(config-router)# address-family ipv4 unicast vrf go_fast_internet_company
```

Define an EBGP session between PE and CE routers and activate the advertisement of the IPv4 address family.

```
Router(config-router-af)# neighbor 200.28.28.46 remote-as 49  
Router(config-router-af)# neighbor 200.28.28.46 activate
```

### Configuring RIP PE to CE Routing Sessions

To configure RIP PE to CE routing sessions, use the following commands in router configuration mode on the PE router:

Enable RIP, define RIP parameters for PE to CE routing sessions, and enable RIP on the PE to CE link.

```
Router(config)# router rip  
Router(config-router)# address-family ipv4 unicast vrf go_fast_internet_company  
Router(config-router-af)# network 200.28.28.47
```

**Configuring Static Route PE to CE Routing Sessions**

To configure static route PE to CE routing sessions, use the following commands in router configuration mode on the PE router:

Define static route parameters for each PE to CE session and for each BGP PE to CE routing session.

```
Router(config)# ip route vrf go_fast_internet_company 200.28.28.46 255.255.255.0  
200.28.28.50
```

```
Router(config-router)# address-family ipv4 unicast vrf go_fast_internet_company
```

Redistribute VRF static routes and directly connected networks into the VRF BGP table.

```
Router(config-router-af)# redistribute static  
Router(config-router-af)# redistribute static connected
```



## GLOSSARY

---

### A

- AAA** Authentication, authorization, and accounting.
- Access list** List kept by a router to control access to or from the router for a number of services. For example, access lists can be used to prevent packets with a certain IP address from leaving a particular interface on the router.
- Alarm** A status condition that shows that a module or port is experiencing an abnormal operating condition. See also [Critical alarm](#), [Major alarm](#), and [Minor alarm](#).
- APS** Automatic protection switching. A SONET switching mechanism that achieves network resiliency by automatically switching from a primary circuit to a secondary circuit. This switching process occurs if the primary circuit fails or if the error rate on the primary line exceeds a set threshold. The Cisco 10000 series ESR supports 1+1 APS, which provides permanent electrical bridging to the service and protection equipment, placed at both ends of the circuit.

---

### B

- Bellcore** Bell Communications Research. An organization that performs research and development on behalf of the Regional Bell Operating Companies (RBOCs).
- BER** Bit error rate. The ratio of received bits that contain errors to all received bits.
- BGP** Border Gateway Protocol. An interdomain routing protocol that replaces EGP. BGP exchanges connection information with other BGP systems. It is defined by RFC 1163.
- Bit error rate** See [BER](#).
- Border Gateway Protocol** See [BGP](#).

---

### C

- CAR** Committed Access Rate. A QoS feature that classifies packets based on such things as access lists, a MAC address, and IP precedence. It measures traffic rates and can be configured to take actions such as dropping packets or changing the ToS value.
- C-bit parity** A modification of the M23 framing method for DS3 which frees the C bits for additional uses. See also [M23](#).

<b>CB-WRED</b>	Class-based weighted random early detection. Class-based WRED applies WRED to packets in different traffic classes. See also <a href="#">WRED</a> .
<b>Channel</b>	Communication path. Multiple channels can be multiplexed over a single cable in certain environments.
<b>Channel service unit</b>	See <a href="#">CSU</a> .
<b>Cisco IOS</b>	Cisco system software that provides common functionality, scalability, and security for Cisco products. Cisco IOS allows centralized, integrated, and automated installation and management of internetworks, while ensuring support for a wide variety of protocols, media, services, and platforms.
<b>Clear channel DS3</b>	A framed DS3 signal that is not multiplexed from 28 DS1 signals. Sometimes referred to as unchannelized DS3.
<b>CLI</b>	Command line interface. Interface that allows the user to interact with the operating system by entering commands and optional arguments at the command prompt.
<b>Command Line Interface</b>	See <a href="#">CLI</a> .
<b>Committed access rate</b>	See <a href="#">CAR</a> .
<b>CRC</b>	Cyclic redundancy check. Error-checking technique in which the frame recipient calculates a remainder by dividing frame contents by a prime binary divisor and then compares the calculated remainder to a value stored in the frame by the sending node.
<b>Critical alarm</b>	An alarm condition that might affect most or all subscribers that connect to the reporting node. To obtain more information about a problem, use the <b>show facility-alarm status</b> command. See also <a href="#">Major alarm</a> and <a href="#">Minor alarm</a> .
<b>CSU</b>	Channel service unit. Digital interface device that connects end-user equipment to the local digital telephone loop. Often referred to, together with DSU, as CSU/DSU. See also <a href="#">DSU</a> .
<b>Cyclic redundancy check</b>	See <a href="#">CRC</a> .
<hr/>	
<b>D</b>	
<b>Data service unit</b>	See <a href="#">DSU</a> .
<b>Differentiated service code point</b>	See <a href="#">DSCP</a> .
<b>DS0</b>	Digital signal level 0. Framing specification used in transmitting digital signals over a single channel at 64 kbps on a T1 facility. Compare with <a href="#">DS1</a> and <a href="#">DS3</a> .
<b>DS1</b>	Digital signal level 1. Framing specification used in transmitting digital signals at 1.544 Mbps on a T1 facility (in the United States) or at 2.108 Mbps on an E1 facility (in Europe). Compare with <a href="#">DS0</a> and <a href="#">DS3</a> .
<b>DS3</b>	Digital signal level 3. Framing specification used for transmitting digital signals at 44.736 Mbps on a T3 facility. Compare with <a href="#">DS0</a> and <a href="#">DS1</a> .

- DSCP** Differentiated service code point. Specifies a precedence value for handling packets belonging to the specified class.
- DSU** Data service unit. Device used in digital transmission that adapts the physical interface on a DTE device to a transmission facility such as T1 or E1. The DSU is also responsible for such functions as signal timing. Often used with CSU, as in CSU/DSU. See also [CSU](#).

---

**E**

- Edge Services Router** See [ESR](#).
- ESF** Extended superframe. Framing type used on T1 circuits that consists of 24 frames of 192 bits each, with the 193rd bit providing timing and other functions. ESF is an enhanced version of SF. See also [SF](#).
- ESR** Edge Services Router. A router that aggregates traffic from thousands of low- and medium-bandwidth subscriber connections and routes it on a few high-bandwidth connections to the Internet core.
- Ethernet** Baseband LAN specification. Ethernet networks use CSMA/CD and run over a variety of cable types at 10 Mbps, 100 Mbps, or 1000 Mbps. Ethernet is similar to the IEEE 802.3 series of standards. See also [Fast Ethernet](#), [Gigabit Ethernet](#).
- Extended Superframe Format** See [ESF](#).

---

**F**

- Facility data link** See [FDL](#).
- Fast Ethernet** Any of a number of 100 Mbps Ethernet specifications. Fast Ethernet offers a speed increase 10 times that of the 10BaseT Ethernet specification, while preserving qualities such as frame format, MAC mechanisms, and MTU. Existing 10BaseT applications and network management tools can be used on Fast Ethernet networks. The Fast Ethernet specification is based on an extension to the IEEE 802.3 specification. Compare with [Ethernet](#) and [Gigabit Ethernet](#).
- FDL** Facility data link. Embedded communications channel in ESF DS1 framing. Used to convey both bit-oriented and message-oriented signals.
- Flash memory** Nonvolatile storage that can be electrically erased and reprogrammed so that software images can be stored, booted, and rewritten as necessary. Flash memory was developed by Intel and is licensed to other semiconductor companies.
- Frame Relay** Industry-standard, switched data link layer protocol that handles multiple virtual circuits using HDLC encapsulation between connected devices. Frame Relay is more efficient than X.25, the protocol for which it is generally considered a replacement.

---

**G**

**Gigabit Ethernet** Gigabit Ethernet. Ethernet running at a transmission speed of 1 billion bits per second.

---

**H**

**HDLC** High Level Data Link Control. Bit-oriented synchronous data link layer protocol developed by ISO. Derived from SDLC, HDLC specifies a data encapsulation method on synchronous serial links using frame characters and checksums.

**High Level Data Link Control** See [HDLC](#).

---

**I**

**IOS** Internet Operating System. See [Cisco IOS](#).

**IP** Internet Protocol. Network layer protocol in the TCP/IP stack offering a connectionless internetwork service. IP provides features for addressing, type-of-service specification, fragmentation and reassembly, and security. Defined in RFC 791.

---

**K**

**Keepalive message** Message sent by one network device to inform another network device that the virtual circuit between the two is still active.

---

**L**

**LAIS** Line Alarm Indication Signal. A SONET port status indicator that activates when an LAIS defect occurs and does not clear throughout the alarm integration period, which is typically 2.5 seconds. An LAIS defect occurs when bits 6, 7, and 8 of the K2 byte are 111 for three consecutive frames. This occurrence begins the alarm integration period. If this period elapses without the detection of three consecutive frames in which K2 bits 6, 7, and 8 show any pattern other than 111, the LAIS indicator activates. The LAIS indicator clears when an LAIS defect does not occur for a time interval equal to the alarm deactivation period (typically 10 seconds).

**Line card** Any I/O card that can be inserted in a modular chassis.

<b>LOF</b>	Loss of Frame. A SONET port status indicator that activates when an LOF defect occurs and does not clear for an interval of time equal to the alarm integration period, which is typically 2.5 seconds. An LOF defect occurs when an out-of-frame (OOF) condition occurs and does not clear for more than 3 microseconds (ms). This occurrence begins the alarm integration period. (OOF occurs when four consecutive frames do not contain a valid frame word. OOF clears when two valid consecutive frames are detected.) The LOF indicator clears when an LOF defect is not detected for a time interval that is equal to the alarm deactivation period (typically 10 seconds).
<b>Loopback test</b>	A test in which signals are sent and then directed back toward their source from some point along the communications path. Loopback tests are often used to check network interface usability.
<b>LOS</b>	Loss of signal. A SONET port status indicator that activates when an LOS defect occurs and does not clear throughout the alarm integration period, which is typically 2.5 seconds. An LOS defect occurs when the OC-3 port receives all zeros for 20 microseconds (+.3 ms). This occurrence begins the alarm integration period. If this period elapses without the detection of two consecutive frames in which there are no 20-ms periods of signal loss, the LOS indicator activates. The LOS indicator clears when an LOS defect is not detected for an interval equal to the alarm deactivation period (typically 10 seconds).
<hr/>	
<b>M</b>	
<b>M13</b>	Generic term for equipment that multiplexes DS1s into DS3s. Sometimes used to describe a specific DS3 multiplex format. Some standards use this term to describe a synchronous multiplexing format also known as SYNTRAN. In many cases, however, M13 does not refer to the SYNTRAN format; it refers instead to the format also known as M23.
<b>M23</b>	A method of multiplexing four DS1 signals into a DS2 signal, then multiplexing seven DS2 signals into a DS3 signal.
<b>MAC</b>	Media Access Control. The lower of the two sublayers of the data link layer defined by the IEEE. The MAC sublayer handles access to shared media.
<b>MAC address</b>	Standardized data link layer address that is required for each port or device that connects to a LAN. Other devices in the network use these addresses to locate specific ports in the network, and to create and update routing tables and data structures. MAC addresses are 6 bytes long and are controlled by the IEEE. Also known as a hardware address, MAC-layer address, or physical address.
<b>Maintenance data link</b>	See <a href="#">MDL</a> .
<b>Major alarm</b>	One of a group of alarm conditions that are considered the second most severe of all reportable alarms. Major alarms affect several subscribers who connect to the reporting node. You can use the <code>show facility-alarm status</code> IOS command to obtain more information about the problem. See also <a href="#">Critical alarm</a> and <a href="#">Minor alarm</a> .
<b>Maximum transmission unit</b>	See <a href="#">MTU</a> .
<b>MDL</b>	Maintenance data link. Embedded communications channel in C-bit parity DS3 framing. Used to convey message-oriented signals.

<b>Minor alarm</b>	One of a group of alarm conditions that are considered the third most severe of all reportable alarms. Minor alarms affect a single or small number of subscribers who connect to the reporting node. You can use the <code>show facility-alarm status</code> IOS command to obtain more information about the problem. See also <a href="#">Critical alarm</a> and <a href="#">Major alarm</a> .
<b>MLP</b>	Multilink Point-to-Point Protocol. A method of splitting, recombining, and sequencing datagrams across multiple logical data links.
<b>MTU</b>	Maximum transmission unit. Maximum packet size, in bytes, that a particular interface can handle.
<b>Multilink Point-to-Point</b>	See <a href="#">MLP</a> .

---

## N

<b>NEBS</b>	Network Equipment Building Systems. The Bellcore requirement for equipment deployed in a central office environment. Covers spatial and thermal requirements as well as requirements for hardware, crafts person interface, fire resistance, handling and transportation, earthquake and vibration, airborne contaminants, grounding, acoustical noise, illumination, EMC, and ESD.
<b>Network Equipment Building Systems</b>	See <a href="#">NEBS</a> .
<b>Nonvolatile RAM</b>	See <a href="#">NVRAM</a> .
<b>NVRAM</b>	Nonvolatile RAM. RAM that retains its contents when a unit is powered off.

---

## P

<b>Packet</b>	Logical grouping of information that includes a header containing control information and (usually) user data. Packets are most often used to refer to network layer units of data. The terms datagram, frame, message, and segment are also used to describe logical information groupings at various layers of the OSI reference model and in various technology circles.
<b>Packet over SONET</b>	See <a href="#">POS</a> .
<b>PCMCIA Flash disk card</b>	A portable (credit-card size), nonvolatile storage device. PCMCIA Flash disk cards use Flash technology to store data. PCMCIA stands for Personal Computer Memory Card International Association, which sets the standard for this technology. Also called PC card.
<b>Performance Routing Engine</b>	See <a href="#">PRE</a> .
<b>Point-to-Point Protocol</b>	See <a href="#">PPP</a> .



<b>POS</b>	Packet Over SONET. A high-speed means of transmitting data over a SONET fiber-optic transmission system through a direct fiber connection to a data switch or router. POS is a point-to-point dedicated leased-line approach intended purely for high-speed data applications. POS allows a user organization to pass data in its native format, without the addition of any significant level of overhead in the form of signaling and control information.
<b>PPP</b>	Point-to-Point Protocol. Provides router-to-router and host-to-network connections over synchronous and asynchronous circuits.
<b>PRE</b>	Performance routing engine. The central routing unit for the Cisco 10000 series ESR. The PRE performs all Layer 2 and Layer 3 packet manipulation related to routing and forwarding through the Cisco 10000 ESR. Dual PREs can be configured in a single chassis for redundancy.

---

## Q

<b>QoS</b>	Quality of service. A measure of performance for a transmission system that reflects its transmission quality and service availability.
<b>QoS Policy Propagation on BGP</b>	See <a href="#">QPPB</a> .
<b>QPPB</b>	QoS Policy Propagation on BGP. A feature involving the classification of packets by IP precedence based on BGP community lists, BGP autonomous system paths, and access lists. After a packet is classified, other quality of service features such as committed access rate (CAR) and weighted random early detection (WRED) can specify and enforce policies to fit a business model.
<b>Quality of Service</b>	See <a href="#">QoS</a> .

---

## R

<b>RAM</b>	Random-access memory. Volatile memory that can be read and written by a microprocessor.
<b>Random Access Memory</b>	See <a href="#">RAM</a> .
<b>Redundancy</b>	In internetworking, the duplication of devices, services, or connections so that, in the event of a failure, the redundant devices, services, or connections can perform the work of those that failed.
<b>RMON</b>	Remote Monitoring. MIB agent specification described in RFC 1271 that defines functions for the remote monitoring of networked devices. The RMON specification provides numerous monitoring, problem detection, and reporting capabilities.
<b>ROM</b>	Read only memory. Nonvolatile memory that can be read, but not written, by the microprocessor.

---

**S**

- SDH** Synchronous Digital Hierarchy. European standard that defines a set of rate and format standards that are transmitted using optical signals over fiber. SDH is similar to SONET, with a basic rate of 155.52 Mbps, designated as STM-1. See also [SONET](#) and [STM-1](#).
- SF** Super frame. Common framing type used on T1 circuits. SF consists of 12 frames of 192 bits each, with the 193rd bit providing error checking and other functions. SF has been superseded by ESF, but is still widely used. Also called D4 framing. See also [ESF](#).
- Simple Network Management Protocol** See [SNMP](#).
- SNMP** Simple Network Management Protocol. Network management protocol used almost exclusively in TCP/IP networks. SNMP provides a means to monitor and control network devices, and to manage configurations, statistics collection, performance, and security. See also [SNMP2](#).
- SNMP2** SNMP Version 2. Version 2 of the network management protocol. SNMP2 supports centralized as well as distributed network management strategies, and includes improvements in the SMI, protocol operations, management architecture, and security. See also [SNMP](#).
- SONET** Synchronous Optical Network. High-speed synchronous network specification developed by Bellcore and designed to run on optical fiber. STS-1 is the basic building block of SONET. It was approved as an international standard in 1988. See also [SDH](#) and [STS-1](#).
- SPE** Synchronous Payload Envelope. The major portion of the SONET frame format used to carry the STS-1 signal; it is divided into an information payload section and a transport overhead system. SPE is used to address three payload structures: direct to STS-1 line rate multiplexing; asynchronous DS3 multiplexing; and synchronous DS3 multiplexing.
- STM-1** Synchronous Transport Module level 1. Basic building block signal of SDH, operating at 155.52 Mbps. Faster SDH rates are defined as STS-*n*, where *n* is a multiple of 155.52 Mbps. See also [SDH](#).
- STS-1** Synchronous Transport Signal level 1. Basic building block signal of SONET, operating at 51.84 Mbps. Faster SONET rates are defined as STS-*n*, where *n* is a multiple of 51.84 Mbps. See also [SONET](#).
- Subrate DS3** A generic term to describe a process in which the bandwidth of a clear channel DS3 is limited to a lower rate. Many proprietary formats exist.
- Super Frame** See [SF](#).
- SDH** Synchronous Digital Hierarchy. European standard that defines a set of rate and format standards that are transmitted using optical signals over fiber. SDH is similar to SONET, with a basic rate of 155.52 Mbps, designated as STM-1. See also [SONET](#) and [STM-1](#).
- SF** Super frame. Common framing type used on T1 circuits. SF consists of 12 frames of 192 bits each, with the 193rd bit providing error checking and other functions. SF has been superseded by ESF, but is still widely used. Also called D4 framing. See also [ESF](#).

---

**T**

- T1** Digital WAN carrier facility. T1 transmits DS1-formatted data at 1.544 Mbps through the telephone switching network.
- T3** Digital WAN carrier facility. T3 transmits DS3-formatted data at 44.736 Mbps through the telephone switching network.
- TAC** A Cisco Technical Assistance Center. There are four TACs worldwide.
- Telnet** Standard terminal emulation protocol in the TCP/IP protocol stack. Telnet is used for remote terminal connection, enabling users to log in to remote systems and use resources as if they were connected to a local system. Telnet is defined in RFC 854.
- TFTP** Trivial File Transfer Protocol. A simplified version of FTP that allows files to be transferred from one computer to another over a network.

---

**U**

- Unchannelized DS3** See [Clear channel DS3](#).

---

**V**

- VT-*n*** Virtual tributary level *n*. The SONET format for mapping a lower-rate signal into a SONET payload. For example, VT-1.5 is used to transport a DS1 signal. See also [DS1](#) and [SONET](#).

---

**W**

- Weighted Random Early Detection** See [WRED](#).
- WRED** Weighted random early detection. RED uses an algorithm to randomly discard packets. The result of the drop is that the source detects the dropped traffic and slows its transmission. WRED combines the capabilities of the RED algorithm with IP precedence. This combination provides for preferential traffic handling for higher-priority packets. It can selectively discard lower-priority traffic when the interface starts to get congested and provide differentiated performance characteristics for different classes of service.





## INDEX

---

### Numerics

#### 1-Port Channelized OC-12/STM-4 line card

- default values [6-4](#)
- software support [6-2](#)
- syntax [6-8](#)

#### 1-Port Gigabit Ethernet Half-Height line card

- commands [10-3](#)
- default values [10-2](#)
- MAC address [10-4](#)
- software support [10-1](#)
- syntax [10-2](#)

#### 1-Port Gigabit Ethernet line card

- commands [11-3](#)
- default values [11-2](#)
- MAC address [11-4](#)
- software support [11-1](#)
- syntax [11-2](#)

#### 1-Port OC-12 ATM line card

- applying VC class [3-6](#)
- creating subinterfaces [3-4](#)
- default configuration values [3-2](#)
- enabling ILMI PVC discovery [3-6](#)
- software support [3-1](#)
- syntax [3-4](#)

#### 1-Port OC-12 Packet over SONET line card

- command syntax [13-3](#)
- default values [13-2](#)
- software support [13-1](#)

#### 1-Port OC-48/STM-16 Packet over SONET line card

- command syntax [14-3](#)
- configuring [14-3](#)
- default values [14-2](#)

SDCC default values [14-2](#)

software support [14-1](#)

#### 24-Port Channelized E1/T1 line card

- default value [5-2](#)
- E1 default values [5-2](#)
- E1 syntax [5-3](#)
- software support [5-1](#)
- T1 default values [5-4](#)
- T1 syntax [5-5](#)

#### 4-Port Channelized OC-3/STM-1 line card

- default values [7-4](#)
- software support [7-2](#)
- syntax [7-8](#)

#### 4-Port Channelized T3 Half-Height line card

- cable length [4-14](#)
- controller [4-4](#)
- controller configuration mode [4-13](#)
- default value [4-3](#)
- enable scrambling [4-8](#)
- features [4-2](#)
- framing type [4-8, 4-14](#)
- HDLC packets [4-15](#)
- idle pattern [4-15](#)
- interface syntax [4-4](#)
- line clock source [4-16](#)
- loopback mode [4-16](#)
- redundancy [4-24](#)
- substrate DS3 [4-7](#)
- unchannelized configuration [4-7](#)

#### 4-Port OC-3/STM-1 ATM line card

- default configuration values [1-2](#)
- software support [1-1, 4-1](#)
- syntax [1-3](#)

## 6-Port Channelized T3 line card

- configurable interface bandwidth [8-9](#)

- default value [8-2](#)

- interface number syntax [8-3](#)

- software support [8-1](#)

## 6-Port OC-3/STM-1 Packet over SONET line card

- command syntax [12-3](#)

- configuring [12-3](#)

- default values [12-2](#)

- software support [12-1](#)

## 8-Port E3/DS3 ATM line card

- default configuration values [2-2](#)

- software support [2-1](#)

- syntax [2-3](#)

## 8-port E3/T3 line card

- default values [15-2](#)

## 8-Port Fast Ethernet Half-Height line card

- default values [9-2](#)

- software support [9-1](#)

## 8-Port Unchannelized E3/T3 line card

- default values [15-2](#)

- software support [15-1](#)

- syntax [15-3](#)

**A**

- abort signal [4-9, 8-8, 15-13](#)

## AIS

- blue alarm [15-8](#)

- Alarm Indication Signal (AIS) [15-8](#)

- alarm reporting, atm [3-12](#)

- alarm threshold

- atm [3-13](#)

- ANSI T1.403 specification [4-20, 6-30, 7-30, 8-17](#)

- atm alarm reporting command [3-12](#)

- atm alarm threshold command [3-13](#)

- atm clock internal command [3-2, 3-12](#)

- atm encapsulation command [3-18](#)

- atm flag command [3-12](#)

- atm ilmi-enable command [3-11](#)

- atm ilmi-keepalive command [3-12](#)

- atm ilmi-pvc discovery command [3-11](#)

- atm pvp command [3-9](#)

## AU-3 controller

- configuration [6-10, 7-10](#)

- interfaces [6-12, 7-12](#)

- specifying [6-16, 7-16](#)

- syntax [6-11, 6-16, 7-11, 7-16](#)

## AU-4-TUG-3/TUG-2

- E1 channel group [6-14, 7-13](#)

- T1 channel group [6-13, 7-13](#)

## AU-4-TUG-3 controller

- configuration [6-10, 7-10](#)

- specifying [6-16, 7-16](#)

- syntax [6-11, 6-17, 7-11, 7-16](#)

- aug controller command [6-6, 7-6](#)

- auto-detect setting [6-5, 7-5](#)

- auto negotiation command [9-2, 10-2, 11-2](#)

**B**

## bandwidth

- available e1 [5-7](#)

- configurable levels [4-13, 8-9](#)

- bandwidth command [12-2, 13-2, 14-2, 14-3](#)

- Bellcore keyword [4-22, 6-32, 7-32, 8-18](#)

- BER test [15-9](#)

- BER test command [15-2, 15-3](#)

## BER tests

- patterns [6-31, 7-31](#)

- terminating [4-9, 5-19, 6-31, 7-31, 8-8](#)

## BGP routing sessions

- configuring [18-9](#)

- BGP table [18-4](#)

## bit error rate

- See BER tests

- blue alarm [15-8](#)

- broadcast command [3-16](#)

## C

cable length command [4-3](#), [4-10](#), [4-14](#), [8-2](#), [8-10](#), [15-2](#)

cablelength command [15-6](#)

card [5-2](#)

C-bit framing type [4-8](#), [5-25](#), [6-7](#), [6-19](#), [6-23](#), [7-7](#), [7-19](#), [7-23](#), [8-7](#)

CE

routing sessions [18-9](#), [18-10](#)

channel group number syntax [5-4](#), [5-5](#)

channel groups

creating [4-17](#), [5-21](#), [5-22](#), [8-14](#)

removing from channelized T3 [4-13](#), [8-10](#)

channelized command [4-3](#), [4-7](#), [4-13](#), [6-5](#), [6-18](#), [6-22](#), [7-5](#), [7-18](#), [7-22](#), [8-2](#), [8-6](#), [8-10](#)

channelized OC-12 line card

default configuration values [6-4](#), [6-6](#), [7-4](#), [7-5](#), [7-6](#)

Frame Relay encapsulation [4-6](#), [5-7](#), [5-9](#), [5-11](#), [8-5](#)

STS-1 channels [6-16](#), [7-15](#)

channelized STM-1 line card

channelization examples [6-3](#), [7-3](#)

channelized T3 line card

cable length [8-10](#)

configurable interface bandwidth [4-13](#)

controller [8-3](#)

controller configuration mode [4-7](#), [8-6](#), [8-9](#)

DSU mode [4-7](#), [8-7](#)

enable scrambling [8-7](#)

framing format [4-19](#), [8-16](#)

framing type [5-25](#), [8-7](#), [8-11](#)

HDLC packets [8-12](#)

idle pattern [8-12](#)

line clock source [8-13](#), [13-4](#), [14-7](#)

loopback mode [8-13](#)

maintenance data link messages [4-14](#), [8-11](#)

MDL messages [4-14](#), [8-11](#)

responding to remote T3 loopback commands [4-17](#), [8-14](#)

subrate DS3 [8-6](#)

supporting subscriber traffic [4-17](#), [5-21](#), [6-26](#), [7-26](#), [8-14](#)

unchannelized configuration [8-6](#)

yellow alarm [4-19](#), [8-16](#)

channel limitations [6-27](#), [7-27](#)

channels [5-4](#), [5-5](#)

Cisco 10000 Series edge services router (ESR)

configuration examples [18-1](#)

class-int command [3-9](#)

class-vc command [3-17](#)

clear channel configuration [4-7](#), [8-6](#)

CLI

IOS configuration [18-1](#)

clock command [3-12](#)

clock source command [4-3](#), [4-11](#), [4-16](#), [6-5](#), [6-6](#), [6-7](#), [6-24](#), [7-5](#), [7-6](#), [7-7](#), [7-24](#), [8-2](#), [8-13](#), [12-2](#), [12-4](#), [13-2](#), [13-4](#), [14-2](#), [14-7](#), [15-2](#), [15-7](#)

command

E1 line card [5-4](#)

commands

aug controller [6-6](#), [7-6](#)

auto negotiation [10-2](#), [11-2](#)

bandwidth [12-2](#), [13-2](#), [14-2](#), [14-3](#)

BER test [15-2](#), [15-3](#)

cable length [2-15](#), [4-3](#), [4-10](#), [4-14](#), [8-2](#), [8-10](#), [15-2](#), [15-6](#)

cablelength [15-6](#)

channelized [4-3](#), [4-13](#), [8-2](#), [8-6](#), [8-10](#)

clock source [4-3](#), [6-5](#), [6-6](#), [6-7](#), [7-5](#), [7-6](#), [7-7](#), [8-2](#), [12-2](#), [13-2](#), [14-2](#), [15-2](#), [15-7](#)

crc [4-3](#), [8-2](#), [15-2](#)

description [15-2](#), [15-3](#), [15-7](#), [15-10](#)

dsu bandwidth [4-3](#), [4-7](#), [6-7](#), [6-19](#), [7-7](#), [7-18](#), [8-2](#), [8-6](#), [15-2](#), [15-3](#), [15-11](#), [17-2](#), [17-7](#), [17-8](#), [17-10](#), [17-26](#), [17-29](#)

dsu mode [4-3](#), [8-2](#), [15-2](#), [15-3](#), [15-10](#)

dsx3mode [15-2](#), [15-8](#)

encapsulation [4-3](#), [6-7](#), [7-7](#), [8-2](#), [12-2](#), [13-2](#), [14-2](#), [15-2](#), [15-3](#), [15-11](#)

equipment [15-2](#)

equipment customer loopback [15-12](#)

equipment loopback [15-12](#)

equipment network loopback [15-12](#)

fallback-clocking [15-3](#), [15-12](#)

framing [4-3, 6-5, 6-7, 7-5, 7-7, 8-2, 8-3, 12-2, 13-2, 14-2, 15-2, 15-13](#)  
 idle character [4-3, 4-8, 6-7, 6-20, 7-7, 7-19, 8-3, 8-8, 15-2, 15-3](#)  
 idle-character [15-13](#)  
 idle pattern [4-3, 6-5, 7-5, 8-2](#)  
 interface [10-3, 11-3](#)  
 keepalive [4-3, 6-7, 7-7, 8-3, 12-2, 13-2, 14-2, 14-3](#)  
 loopback [4-12, 4-16, 6-5, 6-6, 7-5, 7-6, 8-13, 10-4, 11-5, 12-2, 15-3, 15-14](#)  
 mac-address [10-4, 11-4](#)  
 mdl [15-3](#)  
 mtu [4-3, 6-7, 7-7, 8-3, 12-2, 13-2, 14-2, 14-3](#)  
 national bit [15-16](#)  
 negotiation auto [10-3, 11-4](#)  
 pos framing [12-4, 13-4, 14-7](#)  
 privileged EXEC mode hw-module [16-5](#)  
 scramble [4-3, 4-8, 8-3, 8-7, 12-2, 13-2, 14-2, 15-3, 15-16](#)  
 show  
     version [1-2, 2-1, 3-2, 4-2, 5-2, 6-2, 7-2, 8-2, 9-2, 10-2, 11-2, 12-2, 13-2, 14-2, 15-2](#)  
 show interface slot/subslot/port [9-5, 10-3, 11-3](#)  
 shutdown [15-2, 15-3, 15-8](#)  
 T1 clock source [4-3, 5-3, 5-5, 6-6, 7-6, 8-2](#)  
 T1 framing [4-3, 6-6, 7-6, 8-2](#)  
 t1 yellow [4-19, 8-16](#)  
 committed access rate (CAR) [18-5](#)  
 community list [18-6](#)  
 configuration  
     controller mode [5-6, 5-10, 5-16](#)  
     IOS global [5-6, 5-10](#)  
     values [1-2, 2-2, 3-2, 6-4, 6-6, 7-4, 7-5, 7-6, 15-2](#)  
 configure  
     serial interface [5-9, 5-11](#)  
 configuring an E3 interface [15-5](#)  
 configuring a T3 interface [15-5](#)  
 connections  
     STS-1 [6-8, 6-14, 7-8, 7-14](#)  
 controller  
     e1 [5-2](#)

parameters [5-18](#)

t1 [5-4](#)

controller command [4-20, 8-17](#)

controller configuration mode [8-9](#)

controller sonet command [14-4](#)

crc command [4-3, 6-7, 7-7, 8-2, 12-2, 13-2, 14-2, 14-3](#)

cyclical redundancy check command

See crc command

## D

default

1-Port Gigabit Ethernet Half-Height line card values [10-2](#)

1-Port Gigabit Ethernet line card values [11-2](#)

1-Port OC-12 Packet over SONET line card values [13-2](#)

1-Port OC-48/STM-16 Packet over SONET line card SDCC values [14-2](#)

1-Port OC-48/STM-16 Packet over SONET line card values [14-2](#)

24-Port Channelized E1/T1 line card values [5-2, 5-4](#)

4-Port Channelized T3 Half-Height line card [4-3](#)

6-Port Channelized T3 line card values [8-2](#)

6-Port OC-3/STM-1 Packet over SONET line card values [12-2](#)

8-Port Fast Ethernet Half-Height line card values [9-2](#)

channelized OC-12 line card values [6-4, 6-6, 7-4, 7-5, 7-6](#)

gigabit Ethernet (GE) line card values [9-2, 10-2, 11-2](#)

modifying [12-2, 13-2, 14-2](#)

OC-12 ATM line card values [3-2](#)

description command [15-2, 15-3, 15-7, 15-10](#)

DS0

    components, configuring [6-21, 7-21](#)

DS3

    interface configuration [15-4](#)

dsu bandwidth command [4-3, 4-5, 4-7, 6-7, 6-9, 6-19, 7-7, 7-9, 7-18, 8-2, 8-4, 8-6, 15-2, 15-3, 15-11](#)

dsu mode command [4-3, 4-7, 6-7, 6-19, 7-7, 7-18, 7-19, 8-2, 8-7, 15-2, 15-3, 15-10](#)



dsx3 designation [15-4](#)

dsx3 interface [15-4](#)

dsx3mode command [15-2, 15-8](#)

## E

E1 [5-9](#)

available bandwidth [5-7](#)

controller and interface syntax [5-4](#)

line card port [5-10](#)

ports [5-6, 5-10](#)

e1

controller configuration mode [5-9, 5-11](#)

full bandwidth [5-8, 5-10](#)

full framed bandwidth [5-8, 5-10](#)

full-rate bandwidth [5-10](#)

global configuration mode [5-14](#)

interface [5-2](#)

interface configuration mode [5-9, 5-11](#)

serial interface [5-9, 5-11](#)

unchannelized full bandwidth [5-6](#)

E3

configuring an interface [15-5](#)

interface configuration [15-4](#)

E3/T3

BER test [15-9](#)

cable length buildout [15-7](#)

configuration examples [15-5](#)

configuration overview [15-4](#)

controller configuration commands [15-6](#)

dsu bandwidth [15-11](#)

dsu mode [15-10](#)

dsx3mode command [15-8](#)

interface configuration commands [15-8](#)

subrate interface [15-11](#)

E3/T3 port mode

changing [15-4, 15-6](#)

encapsulation command [3-18, 4-3, 6-7, 7-7, 8-2, 12-2, 13-2, 14-2, 15-2, 15-3, 15-11, 18-2](#)

equipment command [15-2](#)

equipment customer loopback command [15-12](#)

equipment identification code [6-23, 7-23](#)

equipment loopback command [4-12, 4-17, 15-12](#)

equipment network loopback command [15-12](#)

extended super frame (ESF) format [4-19, 6-29, 7-29, 8-16](#)

## F

facility data link (FDL) [4-20, 8-17](#)

facility identification code [6-23, 7-23](#)

fallback-clocking command [15-3, 15-12](#)

formats

DSU proprietary [15-4](#)

frame header, customizing [12-5, 13-4, 14-8](#)

frame identification code [6-23, 7-23](#)

frame-relay command [18-2](#)

framing

SDH STM-1 [12-4, 13-4, 14-7](#)

SONET STS-12c [13-4](#)

SONET STS-3c [12-4, 14-7](#)

framing command [4-3, 4-8, 4-14, 5-3, 5-25, 6-5, 6-7, 6-19, 6-22, 7-5, 7-7, 7-19, 7-22, 8-2, 8-3, 8-7, 8-11, 15-2, 15-13](#)

framing type, specifying [4-14, 8-11](#)

full-rate line [15-4](#)

## G

generator number [6-23, 7-23](#)

gigabit Ethernet (GE) line card

auto-negotiation [10-3, 11-4](#)

basic configuration [10-3, 11-3](#)

IP address [10-3, 11-3](#)

loopback mode [10-4, 11-5](#)

provisioning [18-3](#)

syntax [10-2](#)

**H**

- HDLC controller [4-22, 8-18](#)
- high availability
  - 4-Port Channelized T3 Half-Height line card [4-24](#)
- hw-module [5-2, 5-4](#)
  - shutdown [5-2, 5-4](#)

**I**

- idle character command [4-3, 4-8, 6-7, 6-20, 7-7, 7-19, 8-3, 8-8, 15-2, 15-3](#)
- idle-character command [15-13](#)
- idle pattern command [4-3, 4-15, 6-5, 6-24, 7-5, 7-24, 8-2, 8-12](#)
- ilmi [3-10, 3-11, 3-12](#)
- ilmi manage command [3-18](#)
- impedance matching [4-10, 4-14, 8-11](#)
- inarp command [3-16](#)
- inband pattern [4-23, 8-19](#)
- interface
  - bit-rates [15-4](#)
- interface command [3-8, 10-3, 11-3](#)
- interval time [4-9, 5-19, 8-8](#)
- IP
  - routing [10-3, 11-3](#)
- ip address configuration subcommand [10-3, 11-3, 12-3, 13-3, 14-3](#)

**K**

- keepalive command [4-3, 6-7, 7-7, 8-3, 12-2, 13-2, 14-2, 14-3](#)

**L**

- line card
  - 1-Port Gigabit Ethernet Half-Height line card [10-2](#)
  - 1-Port Gigabit Ethernet line card [11-2](#)
  - 1-port OC-12 ATM [3-7](#)
  - 4-Port Channelized T3 Half-Height line card [4-4](#)

- 4-Port Channelized T3 Half-Height line card, framing type [4-14](#)
- 6-Port Channelized T3 [8-3](#)
- 6-Port OC-3/STM-1 Packet over SONET line card [12-3](#)
- 8-Port Fast Ethernet Half-Height line card [9-2](#)
  - channelized T3, framing type [8-11](#)
  - clock source [12-4, 13-4](#)
  - configuring [8-7](#)
  - functionality [5-17](#)
  - OC-12 POS [13-3, 14-3](#)
  - resetting [16-5](#)
  - troubleshooting [5-27, 8-18](#)
- line speed [4-3, 6-4, 7-4, 8-2](#)
- location identification code [6-23, 7-23](#)
- logical channel group [4-18, 5-21, 5-23, 8-14](#)
  - creating [6-28, 7-27](#)
- loopback
  - command [4-12, 4-16, 6-15, 7-15, 8-13, 10-4, 11-5, 12-6, 13-6, 14-8](#)
  - connector [10-4, 11-5](#)
  - mode [10-4, 11-5](#)
- loopback command [3-2, 3-14, 6-5, 6-6, 7-5, 7-6, 12-2, 15-3, 15-14](#)

**M**

- mac-address command [10-4, 11-4](#)
- maintenance data link (MDL) messages [4-10, 4-14, 6-23, 7-23, 8-11, 15-14](#)
- maximum transmission unit command
  - See mtu command
- mdl [15-14](#)
- mdl command [4-10, 4-14, 6-23, 7-23, 8-11, 15-3, 15-14](#)
- mdl messages [4-10, 4-14, 6-23, 7-23, 8-11, 15-14](#)
- modes
  - controller configuration [4-5, 6-24, 7-24, 8-4](#)
  - dsu [6-19, 7-19, 15-10](#)
- monitor
  - serial interface [5-9, 5-11](#)
- mtu command [3-2, 4-3, 6-7, 7-7, 8-3, 12-2, 13-2, 14-2, 14-3](#)

mtu size command [10-2, 11-2](#)  
multipoint subinterface [3-8](#)

## N

national bit command [15-16](#)  
negotiation auto command [10-3, 11-4](#)  
network command [18-4](#)  
network loopbacks [4-12, 4-16, 8-13](#)  
no bert command [6-21, 7-20](#)  
no channelized command [4-13, 8-10](#)  
no shutdown command [12-3, 13-3, 14-4](#)  
no t3 port bert command [4-9, 5-19, 8-8](#)  
NVRAM [5-18](#)

## O

oam-pvc command [3-19](#)  
oam retry command [3-18](#)  
OC-12 ATM line card  
    creating PVCs [3-5](#)  
    creating VC class [3-5](#)  
OC-12 POS line card  
    configuring [13-3](#)  
    framing mode [13-4, 14-7](#)  
    interoperability [13-4, 14-8](#)  
    loopback testing [13-6, 14-8](#)  
    scrambling POS synchronous payload envelope (SPE) [13-6, 14-8](#)  
OC-3 POS line card  
    framing mode [12-4](#)  
    interoperability [12-5](#)  
    line clock source [12-4](#)  
    loopback testing [12-6](#)  
    scrambling POS synchronous payload envelope (SPE) [12-6](#)  
OSPF routing [18-4](#)

## P

PA-2T3 port adapter [6-19, 7-18, 8-7](#)  
packet  
    classifying [18-5](#)  
    HDLC [4-15, 6-20, 6-24, 7-19, 7-24, 8-12](#)  
path command [6-16, 7-15](#)  
performance reports, enabling [4-20, 8-17](#)  
PE to CE routing sessions  
    configuring [18-9](#)  
point-to-multipoint Frame Relay [18-2](#)  
port adapters, PA-T3 and PA-2T3 [6-19, 7-18, 8-7](#)  
port number  
    syntax [5-4, 5-5](#)  
ports [5-4, 5-5](#)  
    T3 [18-2](#)  
    uplink [18-3](#)  
pos flag command [12-2, 12-5, 13-2, 13-4, 14-2, 14-8](#)  
pos framing command [12-2, 12-4, 13-2, 13-4, 14-2, 14-7](#)  
pos scramble-atm command [12-2, 12-6, 13-2, 13-6, 14-2, 14-8](#)  
POS synchronous payload envelope (SPE) [12-6, 13-6, 14-8](#)  
PRE card [13-6](#)  
privileged EXEC mode hw-module command [16-5](#)  
protocol ip command [3-15](#)  
protocols  
    policy propagation border gateway [18-5](#)  
pulse shaping [4-10, 4-14, 8-11](#)  
pvc command [3-10](#)  
pvc encapsulation command [3-2](#)  
pvc ilmi [3-10](#)  
pvp command [3-9](#)

## Q

QPPB  
    configuration example [18-5](#)

**R**

## redundancy

4-Port Channelized T3 Half-Height line card [4-24](#)

remote end [10-2, 11-2](#)

remote FDL ANSI loopback [6-32, 7-32](#)

## reset

e1 hw-module [5-2](#)

t1 hw-module [5-4](#)

reset line card [16-5](#)

## RIP

parameters [18-9](#)

routing, OSPF [18-4](#)

**S**

s1 SONET overhead byte [1-14, 3-14, 12-5, 13-5](#)

scramble command [4-3, 4-8, 6-20, 7-19, 8-3, 8-7, 15-3, 15-16](#)

## show

version command [1-2, 2-1, 3-2, 4-2, 5-2, 6-2, 7-2, 8-2, 9-2, 10-2, 11-2, 12-2, 13-2, 14-2, 15-2](#)

show atm pvc command [3-20](#)

show atm vc command [3-19](#)

show atm vp command [3-19](#)

show controllers [5-2, 5-4](#)

show interfaces [5-2, 5-4](#)

show interface slot/subslot/port command [9-5, 10-3, 11-3](#)

show running-config command [16-1](#)

shutdown [5-5](#)

e1 hardware module [5-2](#)

t1 hardware module [5-4](#)

shutdown command [15-2, 15-3, 15-8](#)

simulated line card installation [5-13](#)

simulated line card removal [5-13](#)

slot [15-4](#)

slot naming convention [15-3](#)

## slot number

ESR line card [15-3](#)

slot syntax [5-4, 5-5](#)

static route PE to CE routing sessions

configuring [18-10](#)

## STS-1

channels [6-16, 7-15](#)

connection [6-8, 6-14, 7-8, 7-14](#)

subinterface command [3-8](#)

subrate interface [15-11](#)

subrate T3 interface [4-6, 8-5, 18-2](#)

subslot [15-4](#)

super frame (SF) [4-19, 8-16](#)

synchronous payload envelope (SPE) [12-6, 13-6, 14-8](#)

**T**T1 [5-11](#)

clock source command [4-3, 6-6, 7-6, 8-2](#)

controller and interface syntax [5-5](#)

facility data link (FDL) [4-20, 8-17](#)

framing command [4-3, 6-6, 7-6, 8-2](#)

interface framing format [4-19, 8-16](#)

loopback mode [4-22, 8-18](#)

setting clock source [4-20, 8-17](#)

## t1

clock source [5-5](#)

default value [5-4](#)

fdl [5-5](#)

framing [5-5](#)

linecode [5-5](#)

loopback [5-5](#)

yellow [5-5](#)

t1 card command [5-4](#)

t1 yellow command [4-19, 8-16](#)

## T3

configuring an interface [15-5](#)

controller, configuring [4-12, 4-17, 8-13](#)

DSU mode [4-7, 8-7](#)

full-rate interface [6-12, 7-12, 15-5](#)

interface, configuring [4-7, 8-6](#)

interface configuration [15-4](#)

- serial interface [15-4](#)
- subrate [4-7, 8-6](#)
- time slot group [5-4, 5-5](#)
- time slots [4-5](#)
- timeslots [8-4](#)
- traffic
  - subscriber [6-26, 7-26](#)
- troubleshooting
  - serial interface [5-9, 5-11](#)
- turning off yellow alarm detection [4-20, 8-16](#)

---

## U

- unchannelized interface [15-4](#)
- unchannelized T3 line card
  - BER testing [4-9, 8-8](#)
  - cable length [4-10](#)
  - changing to channelized [8-9](#)
  - idle character settings [4-8, 8-8](#)
  - line clock source [4-11](#)
  - loopback mode [4-12](#)
  - maintenance data link messages [4-10](#)
  - MDL messages [4-10](#)
  - responding to remote T3 loopback commands [4-12](#)
- unit identification code [6-23, 7-23](#)
- uplink port [18-3](#)

---

## V

- vbr-nrt command [3-17](#)
- VC class [3-5, 3-6](#)
- vc-class command [3-7](#)
- VPN
  - defining [18-8](#)

---

## W

- WRED [18-5](#)

---

## Y

- yellow detection command [4-20, 8-16](#)

